


P1GCxAS Quick Start Guide

This document describes the front panel, LED indications, interfaces, rear panel, rear switch and installation procedure for the P1GCCAS and the P1GCSAS. This portable network TAP series is ideal for 10/100/1000MB copper network monitoring. The innovative design allows these TAPs to be easily installed into any copper 10/100/1000MB network segment.

Front Panel



LED Indications

Port A LFP	Green indicates LFP on	Off indicates LFP off
Port A LNK	Link/Activity LED	
Port B LFP	Green indicates LFP on	Off indicates LFP off
Port B LNK	Link/Activity LED	
Port C BP	LED N/A	
Port C LNK	Link/Activity LED	
Port D BP	LED N/A	
Port D LNK	Link/Activity LED	

* In SYNC mode the LFP LEDs on both Network port A and B are green when there are no ethernet cables connected.

* The P1GCSAS does not have LEDs for the Monitoring Ports C and D.

Rear Panel



Rear Panel Switch Settings

Speed Mode	Switch 1 Speed 1	Switch 2 Speed 2	Switch 3 Speed 3	Tap Mode	Switch 4 Tap Mode	Switch 5 Tap Mode	Switch 6 Monitor Port Speed	Switch 7 LFP Mode	Switch 8
1G Auto Neg	Off	Off	Off						N/A
1G Full Duplex	On	Off	Off	BRE	Off	Off	100M ON	Enabled ON	N/A
100M Auto Neg	Off	On	Off	AGG	On	OFF	1G OFF	Disabled OFF	N/A
100M Full Duplex	On	On	Off	Span	Off	Off			N/A
10M Auto Neg	Off	Off	On	Span	On	On			N/A
10M Full Duplex	On	Off	On						N/A
Sync Mode	Off	On	On						N/A
Sync Mode	On	On	On						N/A

* Link Failure Propagation (LFP) allows the link state to be mirrored to adjacent live network interfaces.

When the tap is in SYNC mode then LFP is set to be enabled and DIP Switch 7's position is ignored.

* The unit must be power cycled if the switch settings are modified.

* The unit supports fail mode open on ports 1 and 2.

Mode Interface Assignment

Breakout

Port A	Network Interface
Port B	Network Interface
Port C	Monitor port (A)
Port D	Monitor port (B)

Aggregate

Port A	Network Interface
Port B	Network Interface
Port C	Monitor port (A/B)
Port D	Monitor port (A/B)

Span

Port A	Traffic input port (B/C/D)
Port B	Span port (A)
Port C	Span port (A)
Port D	Span port (A)

Installation Procedure

1. Unpack the device and attach it to an optional rack mount bracket (sold separately)
2. Install the P1GCxAS assembly into any available 1U slot of a network rack and secure it with rack mount screws.
3. Utilizing the DIP switches (located on the reverse side of the unit, next to the power input) configure the P1GCxAS for the operating mode of your choice (see next page) Install network TAP into the live network. **THIS STEP NEEDS TO BE DONE WITH NO POWER CONNECTED TO THE TAP**
4. Using standard Ethernet cables, connect ports [A] and [B] (Auto MDIX) of the P1GCxAS between the two live network devices where monitoring is desired. Verify network traffic is flowing, confirming that network cabling is correct.
5. Connect ports [C] and [D] (Auto MDIX) to the monitoring tools for traditional traffic monitoring (SPAN mode may also be used for regenerating outputs).
6. Connect the power supply to the P1GCxAS and plug it in to an available power source.
7. Anytime the configuration switches are changed the user must remove and then re-apply power for the changes to take effect.

Note: Other operating modes are available for monitoring and may be configured using the provided DIP switches. Using SPAN or regeneration mode on fiber models may require both [A] and [B] ports to be connected to obtain link on port [A] or [B].

Optional Rack Mount



For questions, please contact Garland Technology Support at:
8AM-9PM (CST) Monday - Friday (Except for observed US Holidays)
Tel: 716.242.8500 Online: www.garlandtechnology.com/support