



CLI Guide

AF1G52AC/DC

03/2024

Release Version: 3.0.18.r3

Copyright © 2024 Garland Technology, LLC. All rights reserved.

No part of this document may be reproduced in any form or by any means without prior written permission of Garland Technology, LLC. The Garland Technology trademarks, service marks ("Marks") and other Garland Technology trademarks are the property of Garland Technology, LLC. PacketMAX Series products of marks are trademarks or registered trademarks of Garland Technology, LLC. You are not permitted to use these Marks without the prior written consent of Garland Technology. All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between Garland Technology and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied. The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

Table of Contents

1 Preface	16
1.1 Declaration.....	16
1.2 Suggestion feedback.....	16
1.3 Audience.....	16
1.4 Conventions.....	16
2 INTERFACE Commands	18
2.1 interface range	18
2.2 interface.....	19
2.3 no interface.....	20
2.4 shutdown	21
2.5 description	22
2.6 speed.....	23
2.7 duplex.....	25
2.8 unidirectional.....	26
2.9 fec	27
2.10 static-channel-group	29
2.11 distribute-weight	30
2.12 media-type	31
2.13 show management interface.....	32
2.14 show interface	33
2.15 show interface summary	34
2.16 show interface status	36
2.17 show interface description.....	37
2.18 show interface bandwidth-in-use	39
2.19 clear counters	40
2.20 crc-check.....	41
2.21 crc-recalculation.....	42
2.22 log-threshold	43
2.23 log-threshold output-discard	44
2.24 show this	45
3 ErrDisable Commands	47
3.1 errdisable detect.....	47
3.2 errdisable recovery interval.....	48

3.3 errdisable recovery reason	49
3.4 errdisable flap	50
3.5 show errdisable detect.....	51
3.6 show errdisable recovery	52
3.7 show errdisable flap	53
4 FLOW Commands.....	55
4.1 show interface flow statistics.....	55
4.2 clear interface flow statistics.....	56
4.3 show flow.....	58
4.4 flow	59
4.5 remark	60
4.6 no sequence-num	61
4.7 sequence-num	62
4.8 flow statistics rate interval	81
5 UDF Commands.....	83
5.1 show udf.....	83
5.2 udf.....	84
5.3 match	85
5.4 offset.....	87
6 PORT-GROUP Commands.....	89
6.1 port-group.....	89
6.2 member interface.....	90
6.3 show port-group.....	91
6.4 show port-group flow statistics.....	92
7 INNER-MATCH Commands.....	94
7.1 show inner-match	94
7.2 inner-match.....	95
7.3 remark	97
7.4 no sequence-num	98
7.5 sequence-num	99
8 ACL Commands	110
8.1 show interface egress ip access-list.....	110
8.2 clear interface egress ip access-list.....	111
8.3 show ip access-list	112
8.4 ip access-list	113
8.5 remark	114
8.6 no sequence-num	115

8.7 sequence-num	116
8.8 egress	129
9 TAP Commands	131
9.1 tap-group	131
9.2 description	132
9.3 ingress	133
9.4 egress	137
9.5 show tap-group	139
10 TIMESTAMP Commands	141
10.1 timestamp-over-ether	141
10.2 show timestamp sync	142
10.3 timestamp sync	143
11 TRUNCATION Commands	145
11.1 truncation.....	145
12 SSH Commands.....	147
12.1 ssh.....	147
12.2 ip ssh server enable	148
12.3 ip ssh server disable.....	149
12.4 ip ssh server version.....	150
12.5 ip ssh server authentication-retries	151
12.6 ip ssh server authentication-timeout.....	152
12.7 ip ssh server authentication-type.....	153
12.8 ip ssh server rekey-interval	154
12.9 ip ssh server host-key	155
12.10 ip ssh server port.....	157
12.11 ip ssh server acl	158
12.12 show ip ssh server status.....	159
13 LACP Commands	161
13.1 port-channel load-balance-mode	161
13.2 port-channel self-healing.....	162
13.3 show channel-group	163
13.4 show channel-group interface	165
14 NTP Commands	167
14.1 ntp minimum-distance	167
14.2 ntp server	168
14.3 ntp authentication	169

14.4 ntp key	170
14.5 ntp trustedkey	171
14.6 show ntp	173
14.7 show ntp status	174
14.8 show ntp statistics.....	175
14.9 show ntp associations.....	176
14.10 show ntp key	177
14.11 clear ntp statistics	178
15 NETWORK DIAGNOSIS Commands.....	179
15.1 ping	179
15.2 traceroute	180
16 MONITOR CAPTURE Commands	182
16.1 monitor-capture global	182
16.2 monitor-capture packet	183
16.3 monitor-capture input	184
16.4 monitor-capture output	185
16.5 monitor-capture packet start.....	186
16.6 monitor-capture packet stop	187
16.7 monitor-capture packet restart	188
16.8 show monitor-capture packet	189
16.9 clear monitor-capture packet all	191
16.10 show monitor-capture global.....	191
17 SYSLOG Commands.....	193
17.1 logging sync.....	193
17.2 logging buffer	194
17.3 logging file.....	195
17.4 logging level file	196
17.5 logging level module	197
17.6 logging timestamp.....	199
17.7 logging server	200
17.8 logging server severity.....	201
17.9 logging server facility.....	203
17.10 logging server address.....	204
17.11 logging merge.....	205
17.12 show logging	207
17.13 show logging buffer	208
17.14 show logging buffer statistics	210

17.15 show logging levels	211
17.16 show logging facilities	212
17.17 clear logging buffer	213
18 SNMP Commands.....	214
18.1 show snmp	214
18.2 show snmp-server version	215
18.3 show snmp-server community	215
18.4 show snmp-server engineID	216
18.5 show snmp-server sys-info	217
18.6 show snmp-server trap-receiver	218
18.7 show snmp-server inform-receiver	219
18.8 show snmp-server view	220
18.9 snmp-server enable	221
18.10 snmp-server engineID.....	222
18.11 snmp-server system-contact	224
18.12 snmp-server system-location.....	225
18.13 snmp-server version	226
18.14 snmp-server view	227
18.15 snmp-server community.....	229
18.16 snmp-server trap enable	230
18.17 snmp-server trap target-address	232
18.18 snmp-server trap delay linkup	233
18.19 snmp-server trap delay linkdown.....	234
18.20 snmp-server inform target-address	235
18.21 snmp-server access-group	237
19 AUTH Commands	239
19.1 show usernames	239
19.2 show users	240
19.3 show web users	241
19.4 show privilege	241
19.5 clear line console 0.....	242
19.6 clear line vty	243
19.7 clear web session	244
19.8 show console	245
19.9 show vty.....	246
19.10 show rsa keys	247
19.11 show rsa key	248

19.12 show key config	250
19.13 show key string	251
19.14 show tacacs	252
19.15 show aaa status.....	253
19.16 show aaa privilege mapping	254
19.17 show aaa method-lists.....	255
19.18 line console	257
19.19 line vty	257
19.20 line vty maximum	258
19.21 rsa key generate.....	259
19.22 rsa key import	261
19.23 rsa key export	262
19.24 rsa key	264
19.25 reset.....	265
19.26 key type	266
19.27 key format.....	267
19.28 key string end.....	268
19.29 validate	268
19.30 KEYLINE	269
19.31 re-activate radius-server.....	270
19.32 show radius-server	271
19.33 radius-server host	272
19.34 radius-server deadtime.....	274
19.35 radius-server retransmit	275
19.36 radius-server timeout	276
19.37 radius-server key	277
19.38 re-activate tacacs-server	278
19.39 tacacs-server host.....	280
19.40 username	281
19.41 username password	282
19.42 username assign	284
19.43 username privilege.....	285
19.44 username secret.....	286
19.45 re-username.....	287
19.46 enable password.....	288
19.47 enable password privilege	289
19.48 service password-encryption	291
19.49 aaa new-model	292

19.50 aaa authentication login	293
19.51 aaa authorization exec	294
19.52 aaa accounting exec	296
19.53 aaa accounting commands	297
19.54 aaa privilege mapping	299
19.55 debug aaa	300
19.56 exec-timeout	301
19.57 login	303
19.58 privilege level	304
19.59 line-password	305
19.60 stopbits	306
19.61 databits	307
19.62 parity	309
19.63 speed	310
19.64 authorization exec	311
19.65 accounting exec	312
19.66 accounting commands	313
19.67 end	315
19.68 ip access-class	316
19.69 cipher detect	317
19.70 login-security enable	318
19.71 login-security max-fail-num	319
19.72 login-security lock-duration	321
20 SFLOW Commands	323
20.1 sflow enable	323
20.2 sflow agent	324
20.3 sflow collector	325
20.4 sflow counter interval	326
20.5 sflow counter-sampling enable	327
20.6 sflow flow-sampling rate	328
20.7 sflow flow-sampling enable	330
20.8 debug sflow	331
20.9 show sflow	332
21 GLOBAL Commands	334
21.1 show debugging	334
21.2 no debug all	335
21.3 show history	336

21.4 show running-config	337
21.5 md5sum	340
22 MANAGEMENT Commands	342
22.1 show diagnostic-information.....	342
22.2 show services.....	343
22.3 show services rpc-api	344
22.4 hostname.....	345
22.5 format	346
22.6 umount udisk:	347
22.7 reset factory-config	348
22.8 management ip address dhcp.....	348
22.9 management ip address	349
22.10 management ipv6 address	351
22.11 management route gateway.....	352
22.12 management ipv6 route gateway.....	353
22.13 service telnet enable	354
22.14 service telnet acl.....	355
22.15 service http	356
22.16 service http port	357
22.17 service http acl	358
22.18 service https	360
22.19 service http load	361
22.20 service https port	362
22.21 service https acl.....	363
22.22 service rpc-api enable.....	364
22.23 service rpc-api auth-mode.....	366
22.24 service rpc-api acl	367
22.25 certificate load pem-cert.....	368
22.26 statistics unit	369
23 SYSTEM CONFIGURATION Commands	371
23.1 disable.....	371
23.2 enable	372
23.3 logout.....	373
23.4 reboot	374
23.5 show file system	375
23.6 show management ip address	376
23.7 show startup-config	377

23.8 write	381
23.9 boot system flash	381
23.10 boot system tftp:.....	383
23.11 show boot	384
23.12 show memory	385
23.13 show memory summary	387
23.14 show cpu utilization	388
23.15 terminal length	389
23.16 terminal monitor	390
23.17 cd	391
23.18 mkdir	392
23.19 rmdir	393
23.20 pwd	394
23.21 ls	395
23.22 copy running-config.....	397
23.23 copy startup-config	398
23.24 copy mgmt-if.....	399
23.25 copy	400
23.26 more	401
23.27 delete	402
23.28 rename	403
23.29 source	404
23.30 system min-frame check	405
23.31 banner	406
23.32 do	407
24 DEVICE Commands	410
24.1 show version.....	410
24.2 show stm prefer	411
24.3 show transceiver.....	412
24.4 show system summary	414
24.5 show reboot-info.....	416
24.6 clear reboot-info.....	417
24.7 set device id-led	418
24.8 show device id-led	419
24.9 show schedule reboot.....	420
24.10 stm prefer	421
24.11 temperature	422
24.12 clock set datetime	423

24.13 clock set timezone	424
24.14 update bootrom	426
24.15 schedule reboot at	427
24.16 schedule reboot delay	428
24.17 telnet	429
25 Hash load-balance Commands	431
25.1 hash field	431
25.2 l2	432
25.3 ip	433
25.4 ipv6	435
25.5 vxlan	436
25.6 nvgre	438
25.7 mpls	440
25.8 udf	441
25.9 disable control	442
25.10 ipv6 adress compress mode	444
25.11 hash arithmetic	445
25.12 hash symmetry	446
25.13 description	447
25.14 show hash-field	448
25.15 hash value	450
25.16 port-channel select	451
25.17 description	452
25.18 show hash-value	453
25.19 hash-value global	454
25.20 port-channel select	455
25.21 show hash-value global	456
25.22 hash value applied to interface	457
25.23 show hash-value interface-applied	458
26 IPFIX Commands	460
26.1 ipfix enable	460
26.2 ipfix recorder	461
26.3 description	462
26.4 match ipv4	463
26.5 match ipv6	465
26.6 match mac	466
26.7 match transport	467

26.8 match vlan	468
26.9 match cos	469
26.10 match interface (input output)	470
26.11 match interface input	471
26.12 match vxlan-vni	472
26.13 match nvgre-key	473
26.14 match transport tcp flags	474
26.15 match packet (drop non-drop)	476
26.16 collect counter	477
26.17 collect flow	478
26.18 collect ttl	479
26.19 collect timestamp	480
26.20 ipfix exporter	481
26.21 description	483
26.22 destination	484
26.23 dscp	485
26.24 domain-id	486
26.25 template data timeout	487
26.26 flow data timeout	488
26.27 transport protocol	489
26.28 ttl	490
26.29 event flow	491
26.30 flow data flush threshold length	492
26.31 flow data flush threshold timer	493
26.32 flow data flush threshold count	494
26.33 ipfix sampler	495
26.34 description	496
26.35 1 out-of	497
26.36 mode	498
26.37 mode flow	499
26.38 ipfix monitor	500
26.39 description	502
26.40 recorder	503
26.41 exporter	504
26.42 ipfix monitor	505
26.43 ipfix global	506
26.44 flow aging	507
26.45 flow export	508

26.46 show ipfix global	509
26.47 show ipfix recorder	510
26.48 show ipfix exporter	511
26.49 show ipfix cache.....	512
26.50 show ipfix monitor	513
26.51 show ipfix sampler	514
26.52 clear ipfix cache monitor	515
26.53 clear ipfix cache observe-point interface	516
27 DIAG Commands	518
27.1 show interface queue discard	518
27.2 diagnostic-information discard	519
27.3 show diagnostic-information.....	521
28 De-duplicate Commands	523
28.1 de-duplicate global.....	523
28.2 de-duplicate enable	524
28.3 de-duplicate mode	525
28.4 de-duplicate times	528
28.5 de-duplicate aging-time	529
28.6 de-duplicate ignore	530
28.7 show de-duplicate global.....	531
28.8 show de-duplicate stats	532
29 DDOS Prevent Commands	534
29.1 ip intercept	534
29.2 show ip-intercept config	536
29.3 clear ip-intercept statistics	537
29.4 show ip-intercept statistics	537
30 LLDP Commands	539
30.1 lldp enable.....	539
30.2 lldp timer tx-interval	540
30.3 lldp timer tx-hold.....	541
30.4 lldp timer tx-delay	542
30.5 lldp timer reinit-delay	543
30.6 lldp management ip	544
30.7 lldp system-name	545
30.8 lldp system-description	546
30.9 lldp enable.....	548
30.10 lldp tlv basic	549

30.11 lldp tlv med	550
30.12 lldp tlv 8023-org-specific	551
30.13 show lldp local config	553
30.14 show lldp local tlv-info	554
30.15 show lldp neighbor	556
30.16 show lldp statistics.....	558
30.17 clear lldp statistics.....	559
31 ECMP-GROUP Commands	561
31.1 ecmp-group.....	561
31.2 member interface	562
31.3 show ecmp-group.....	563

1 Preface

1.1 Declaration

This document updates at irregular intervals because of product upgrades or other reasons. This document is for your reference only.

1.2 Suggestion feedback

If you have any questions when using our product and reading this document, please contact us:

Email:

1.3 Audience

This document is for the following audiences:

- System maintenance engineers
- Debugging and testing engineers
- Network monitoring engineers
- Field maintenance engineers

1.4 Conventions

Table 1-1 Command syntax convention table

Syntax	Description
Italic type with capital letters	Use <i>italic type</i> with capital letters for the parameters of the commands. Parameters are the parts which need to replace with the actual value.
(x y ...)	Select one among the choices.
(x y ...)	Select one or none among the choices.

[x y ...]	Select one or more among the choices. The choices can be selected repeatedly.
[x y ...]	Select one or more or none among the choices. The choices can be selected repeatedly.
{x y ...}	Select one or more among the choices. The choices can be selected only once.
{x y ... }	Select one or more or none among the choices. The choices can be selected only once.
<x-y>	Select a number between x and y.

2 INTERFACE Commands

2.1 interface range

Command Purpose

Use this command to enter interface range mode, include physical port, linkagg interface.

Command Syntax

interface range *KLINE*

Parameter	Parameter Description	Parameter Value
KLINE	Interface range, with “,” or “-” to distinguish the interface range set.	-

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example shows how to enter interface range eth-0-1 to eth-0-24 and shutdown these 24 interfaces:

```
Switch(config)# interface range eth-0-1 - 24
Switch(config-if-range)# shutdown
```

The following example shows how to enter interface eth-0-8 and eth-0-10, and shutdown these 2 interfaces:

```
Switch(config)# interface range eth-0-8,eth-0-10
Switch(config-if-range)# shutdown
```

Related Commands

interface

2.2 interface

Command Purpose

Use this command to enter interface mode or create iloop interface.

Command Syntax

interface *IF_NAME*

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name. e.g.eth-0-1, agg1,iloop1.	-

Command Mode

Global Configuration

Default

None

Usage

The interface name can be a physical port name (i.e. eth-0-1), link-agg name (i.e. agg1) or iloop port name(i.e. iloop1).

Examples

This example shows how to enter physical port eth-0-1:

```
Switch(config)# interface eth-0-1
```

This example shows how to enter aggregation interface agg10:

```
Switch(config)# interface agg10
```

This example shows how to create iloop interface iloop1:

```
Switch(config)# interface iloop1
```

Related Commands

interface range

2.3 no interface

Command Purpose

Use this command to delete iloop interface.

Command Syntax

no interface *IF_ILOOP_NAME*

Parameter	Parameter Description	Parameter Value
IF_ILOOP_NAME	Specify the iloop interface name. e.g.iloop1.	-

Command Mode

Global Configuration

Default

None

Usage

The interface name can only be an iloop port name (i.e. iloop1).

Examples

This example shows how to delete iloop interface iloop1:

```
Switch(config)# no interface iloop1
```

Related Commands

interface

2.4 shutdown

Command Purpose

Use this command to disable the interface manually.

Use the no form of this command to enable the interface.

Command Syntax

shutdown

no shutdown

Command Mode

Interface Configuration

Default

No shutdown

Usage

None

Examples

The following example shows how to enter physical port eth-0-1 and disable the interface:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# shutdown
```

The following example shows how to enter physical port eth-0-1 and enable the interface:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no shutdown
```

Related Commands

show interface status

2.5 description

Command Purpose

Use this command to set the description on the interface.

Use the no form of this command to delete the description.

Command Syntax

description *LINE*

no description

Parameter	Parameter Description	Parameter Value
LINE	Interface description	-

Command Mode

Interface Configuration

Default

None

Usage

None

Examples

The following example shows how to set the description on the interface eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# description TenGigabitEthernet
```

The following example shows how to remove the description on the interface eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no description
```

Related Commands

show interface description

2.6 speed

Command Purpose

Use this command to set the interface speed.

Use the no form of this command to restore the interface to its default speed value.

Command Syntax

speed (auto | 10 | 100 | 1000 | 2.5G | 5G | 10G | 25G | 40G | 100G)

no speed

Parameter	Parameter Description	Parameter Value
auto	Auto negotiation the speed of a port	-

10	Force the port speed to be 10Mb/s	-
100	Force the port speed to be 100Mb/s	-
1000	Force the port speed to be 1000Mb/s	-
2.5G	Force the port speed to be 2.5Gb/s	-
5G	Force the port speed to be 5Gb/s	-
10G	Force the port speed to be 10Gb/s	-
25G	Force the port speed to be 25Gb/s	-
40G	Force the port speed to be 40Gb/s	-
100G	Force the port speed to be 100Gb/s	-

Command Mode

Interface Configuration

Default

Auto

Usage

For different interfaces, some speed value can't be set.

Examples

The following example shows how to set the port speed to 1000Mb/s:


```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# speed 1000
```

The following example shows how to restore the port speed to default value:

```
Switch(config-if-eth-0-1)# no speed
```

Related Commands

show interface status

show interface

2.7 duplex

Command Purpose

Use this command to set the mode of operation for a port. And use the no form of this command set the mode of operation to default value.

Command Syntax

duplex (auto | full | half)

no duplex

Parameter	Parameter Description	Parameter Value
auto	Auto negotiation mode, the port should be automatically detected in full duplex or half duplex state according to the device it is connected to	-
full	Full duplex mode	-
half	Half duplex mode, can only be configured on ports of 10M or 100M	-

Command Mode

Interface Configuration

Default

Auto

Usage

Half mode is only supported on 10M/100M link.

Examples

The following example shows how to set interface eth-0-1 duplex mode to auto:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# duplex auto
```

The following example shows how to set interface eth-0-1 duplex mode to full:

```
Switch(config-if-eth-0-1)# duplex full
```

The following example shows how to set interface eth-0-1 duplex mode to default:

```
Switch(config-if-eth-0-1)# no duplex
```

Related Commands

show interface status

show interface

2.8 unidirectional

Command Purpose

Use this command to set unidirectional function for a port.

Command Syntax

unidirectional (enable | disable | rx-only)

Parameter	Parameter Description	Parameter Value
enable	Enable unidirectional	-
disable	Disable unidirectional	-
rx-only	Receive only	-

Command Mode

Interface Configuration

Default

Disable

Usage

None

Examples

The following example shows how enable unidirectional on interface eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# unidirectional enable
```

The following example shows how disable unidirectional on interface eth-0-1:

```
Switch(config-if-eth-0-1)# unidirectional disable
```

Related Commands

show interface status

show interface

2.9 fec

Command Purpose

Use the command to set fec function for a port.

Use the no form of this command set fec function to default value.

Command Syntax

fec (enable | disable | none | baser | rs)

no fec

Parameter	Parameter Description	Parameter Value
enable	Enable fec	-
disable	Disable fec	-
none	Set fec none	-
baser	Set fec baser	-
rs	Set fec rs	-

Command Mode

Interface Configuration

Default

None

Usage

None

Examples

The following example shows how to set fec none for a port:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# fec none
```

Related Commands

show interface status

2.10 static-channel-group

Command Purpose

Use this command to add a port to a static channel group.

Use the no form of this command to remove this port from this static channel group.

Command Syntax

static-channel-group *AGG_GID*

no static-channel-group

Parameter	Parameter Description	Parameter Value
AGG_GID	Channel group ID	range is <1-55>

Command Mode

Interface Configuration

Default

None

Usage

The valid range of channel group id is limited by hardware and is different for each model.

Examples

The following example shows how to add interface eth-0-1 to static channel group 2:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# static-channel-group 2
```

The following example shows how to remove interface eth-0-1 from static channel group 2:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no static-channel-group
```

Related Commands

show interface

2.11 distribute-weight

Command Purpose

Use this command to set port weight of static channel group member.

Command Syntax

distribute-weight *VALUE*

no distribute-weight

Parameter	Parameter Description	Parameter Value
VALUE	The weight value of port	range is <1-63>

Command Mode

Interface Configuration

Default

None

Usage

The total weight of static channel group member should be under the max member number.

Examples

The following example shows how to set interface eth-0-1 weight as 2:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# static-channel-group 1
```

```
Switch(config-if-eth-0-1)# distribute-weight 2
```

The following example shows how to set interface eth-0-1 weight to default:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no distribute-weight
```

Related Commands

static-channel-group

2.12 media-type

Command Purpose

Use this command to set media type of combo port.

Use the no form of this command to set media type to default.

Command Syntax

media-type (auto | rj45 | sfp)

no media-type

Parameter	Parameter Description	Parameter Value
auto	Automatically select media type of combo port	-
rj45	Set media type as rj45	-
sfp	Set media type as sfp	-

Command Mode

Interface Configuration

Default

Auto

Usage

Different media types of the combo port cannot be active at the same time.

Examples

The following example shows how to set media type of combo port:

```
Switch(config-if-eth-0-1) media-type auto
```

The following example shows how to set media type of combo port to default:

```
Switch(config-if-eth-0-1)# no media-type
```

Related Commands

show interface

2.13 show management interface

Command Purpose

Use this command to display the status and configurations of management interface.

Command Syntax

show management interface

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to displays the states, configurations, and statistics on management interface:

```
Switch# show management interface

Management Interface current state: UP
Description:
Link encap: Ethernet           HWaddr: 00:1E:08:0B:E6:C1
net addr: 10.10.39.104        Mask: 255.255.254.0
Bcast: 10.10.39.255          MTU: 1500
Speed: 1000Mb/s              Duplex: Full
Auto-negotiation: Enable
Received:                    1030834 Packets,      79596824 Bytes (75.9 MiB)
Transmitted:                  110758 Packets,      16209745 Bytes (15.4 MiB)
```

Related Commands

show interface status

2.14 show interface

Command Purpose

Use this command to display the configurations and statistics on all interfaces or one interface.

Command Syntax

show interface (*IF_NAME* |)

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name to show	-

Command Mode

Privileged EXEC

Default

None

Usage

If the parameter “IF_NAME” is not specified, the command indicates that all interfaces on this device should be displayed; otherwise only the specified interface should be displayed.

Examples

The following example shows how to display the configurations and statistics of interface eth-0-1:

```
Switch# show interface eth-0-1

Interface eth-0-1
  Interface current state: DOWN
  Hardware is Port, address is 001e.080b.e6c2
  Bandwidth 1000000 kbits
  Index 1 , Metric 1
  Speed - auto , Duplex - auto , Metadata - Disable , Media type is UNKNOWN
  Link type is autonegotiation
  Admin input flow-control is off, output flow-control is off
  Oper input flow-control is off, output flow-control is off
  The Maximum Frame Size is 12800 bytes
    5 minute input rate 0 bits/sec, 0 packets/sec
    5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes
  Received 0 unicast, 0 broadcast, 0 multicast
    0 runts, 0 giants, 0 input errors, 0 CRC
    0 frame, 0 overrun, 0 pause input
    0 packets output, 0 bytes
  Transmitted 0 unicast, 0 broadcast, 0 multicast
    0 underruns, 0 output errors, 0 pause output
```

Related Commands

show interface status

2.15 show interface summary

Command Purpose

Use this command to display the statistics on all interfaces or one interface.

Command Syntax

show interface summary (*IF_NAME* |)

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name to show	-

Command Mode

Privileged EXEC

Default

none

Usage

If the parameter “IF_NAME” is not specified, the command indicates that all interfaces on this device should be displayed; otherwise only the specified interface should be displayed.

Examples

The following example shows how to display the statistic of interface eth-0-1:

```

Switch# show interface summary eth-0-1

RXBS: rx rate (bits/sec)          RXPS: rx rate (pkts/sec)
TXBS: tx rate (bits/sec)          TXPS: tx rate (pkts/sec)
Interface  Link   RXBS      RXPS      TXBS      TXPS
-----+-----+-----+-----+-----+-----
eth-0-1    DOWN  0         0         0         0
  
```

Related Commands

show interface

2.16 show interface status

Command Purpose

Use this command to display brief information on all physical and link aggregation interfaces.

Command Syntax

```
show interface status
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the brief information on all physical and link aggregation interfaces:

```
Switch# show interface status
```

Name	Status	Duplex	Speed	Mode	Type	Description
eth-0-1	down	auto	auto	trunk	UNKNOWN	
eth-0-2	down	auto	auto	trunk	UNKNOWN	
eth-0-3	down	auto	auto	trunk	UNKNOWN	
eth-0-4	down	auto	auto	trunk	UNKNOWN	
eth-0-5	down	auto	auto	trunk	UNKNOWN	
eth-0-6	down	auto	auto	trunk	UNKNOWN	
eth-0-7	down	auto	auto	trunk	UNKNOWN	
eth-0-8	down	auto	auto	trunk	UNKNOWN	
eth-0-9	down	auto	auto	trunk	UNKNOWN	
eth-0-10	down	auto	auto	trunk	UNKNOWN	
eth-0-11	down	auto	auto	trunk	UNKNOWN	
eth-0-12	down	auto	auto	trunk	UNKNOWN	
eth-0-13	down	auto	auto	trunk	UNKNOWN	

eth-0-14	down	auto	auto	trunk	UNKNOWN
eth-0-15	down	auto	auto	trunk	UNKNOWN
eth-0-16	down	auto	auto	trunk	UNKNOWN
eth-0-17	down	auto	auto	trunk	UNKNOWN
eth-0-18	down	auto	auto	trunk	UNKNOWN
eth-0-19	down	auto	auto	trunk	UNKNOWN
eth-0-20	down	auto	auto	trunk	UNKNOWN
eth-0-21	down	auto	auto	trunk	UNKNOWN
eth-0-22	down	auto	auto	trunk	UNKNOWN
eth-0-23	down	auto	auto	trunk	UNKNOWN
eth-0-24	down	auto	auto	trunk	UNKNOWN
eth-0-25	down	auto	auto	trunk	UNKNOWN
eth-0-26	down	auto	auto	trunk	UNKNOWN
eth-0-27	down	auto	auto	trunk	UNKNOWN
eth-0-28	down	auto	auto	trunk	UNKNOWN
eth-0-29	down	auto	auto	trunk	UNKNOWN
eth-0-30	down	auto	auto	trunk	UNKNOWN
eth-0-31	down	auto	auto	trunk	UNKNOWN
eth-0-32	down	auto	auto	trunk	UNKNOWN
FGE0/33	down	full	40000	trunk	UNKNOWN
FGE0/34	down	full	40000	trunk	UNKNOWN
agg5	down	auto	auto	trunk	LAG

Related Commands

show interface

2.17 show interface description

Command Purpose

Use this command to display the description information on all interfaces.

Command Syntax

show interface description

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the description on all physical and link aggregation interfaces:

```
Switch# show interface description
```

Name	Status	Description
eth-0-1	down	TenGigabitEthernet
eth-0-2	down	
eth-0-3	down	
eth-0-4	down	
eth-0-5	down	
eth-0-6	down	
eth-0-7	down	
eth-0-8	down	
eth-0-9	down	
eth-0-10	down	
eth-0-11	down	
eth-0-12	down	
eth-0-13	down	
eth-0-14	down	
eth-0-15	down	
eth-0-16	down	
eth-0-17	down	
eth-0-18	down	
eth-0-19	down	
eth-0-20	down	
eth-0-21	down	
eth-0-22	down	
eth-0-23	down	
eth-0-24	down	
eth-0-25	down	
eth-0-26	down	
eth-0-27	down	
eth-0-28	down	
eth-0-29	down	
eth-0-30	down	
eth-0-31	down	
eth-0-32	down	
FGE0/33	down	
FGE0/34	down	
agg5	down	LinkAgg5

Related Commands

show interface

2.18 show interface bandwidth-in-use

Command Purpose

Use this command to display the physical port bandwidth usage information and the current configured log-threshold.

Command Syntax

```
show interface bandwidth-in-use [ INTERFACE-NAME [ input | output ] ]
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display percentage of current bandwidth usage and configuration of current log-threshold:

```
Switch# show interface bandwidth-in-use eth-0-1/1
```

Name	Direction	Speed	Load-interval	Threshold	ResumeRate	Usage
eth-0-1/1	input	40Gb/s	150s	90%	70%	60%
eth-0-1/1	output	40Gb/s	150s	80%	60%	85%

Related Commands

None

2.19 clear counters

Command Purpose

Use this command to clear the statistical information on the interfaces.

Command Syntax

clear counters (*IF_NAME* |)

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name to clear the statistics counters.	-

Command Mode

Privileged EXEC

Default

None

Usage

If the parameter “IF_NAME” is not specified, the command indicates that all interfaces’ statistics counters information on this device should be cleared; otherwise only the specified interface should be cleared.

Examples

The following example shows how to clear the statistics information on all interfaces:

```
Switch# clear counters
```

The following example shows how to clear the statistics information on the interface eth-0-1:

```
Switch# clear counters eth-0-1
```


Related Commands

show interface

2.20 crc-check

Command Purpose

Use this command to set CRC check function for a port.

Command Syntax

crc-check enable

no crc-check enable

Parameter	Parameter Description	Parameter Value
enable	crc check function enable	-

Command Mode

Interface Configuration

Default

Disable

Usage

None

Examples

The following example shows how to enable CRC check function for a port:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# crc-check enable
```

The following example shows how to disable CRC check function for a port:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no crc-check enable
```

Related Commands

None

2.21 crc-recalculation

Command Purpose

Use this command to set CRC recalculation function for a port.

Command Syntax

crc-recalculation enable

no crc-recalculation enable

Parameter	Parameter Description	Parameter Value
enable	crc recalculation function enable	-

Command Mode

Interface Configuration

Default

enable

Usage

None

Examples

The following example shows how to enable CRC recalculation function for a port:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# crc-recalculation enable
```

The following example shows how to disable CRC recalculation function for a port:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no crc-recalculation enable
```

Related Commands

None

2.22 log-threshold

Command Purpose

Use this command to configure physical port Percentage of the bandwidth utilization warning threshold.

Use the no form of this command to stop this function.

Command Syntax

log-threshold { input-rate | output-rate } *BANDWIDTH-IN-USE* resume-rate *RESUME-THRESHOLD*

no log-threshold { input-rate | output-rate }

Parameter	Parameter Description	Parameter Value
BANDWIDTH-IN-USE	Percentage of the bandwidth utilization warning threshold	range is 1-100
RESUME-THRESHOLD	Percentage of bandwidth utilization recovery logs	range is 1-BANDWIDTH-IN-USE

Command Mode

Interface Configuration

Default

Disable

Usage

To avoid fluctuation of log and alarm information, values of bandwidth-in-use and resume-threshold should be kept as far as possible.

Examples

The following example shows how to set configure physical port input direction Percentage of the bandwidth utilization warning threshold:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# log-threshold input-rate 80 resume-rate 60
```

The following example shows how to unset the input direction bandwidth utilization of log-threshold on an interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no log-threshold input-rate
```

Related Commands

None

2.23 log-threshold output-discard

Command Purpose

Use this command to configure the function of physical port discard packet number warning threshold on output direction.

Use the no form of this command to stop this function.

Command Syntax

```
log-threshold output-discard THRESHOLD_VALUE interval INTERVAL-VALUE
```

```
no log-threshold output-discard
```

Parameter	Parameter Description	Parameter Value
THRESHOLD_VALUE	Exit direction lost count	range is 100-4294967295
INTERVAL-VALUE	Statistical time	range is 1-1440, unit is minutes

Command Mode

Interface Configuration

Default

Disable

Usage

None

Examples

The following example shows, how to configure physical port output direction discard packet number warning threshold in five minutes:

```
Switch(config-if-eth-0-1)# log-threshold output-discard 100000 interval 5
```

The following example shows how to unset the interface output direction discard packet of log-threshold:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no log-threshold output-discard
```

Related Commands

None

2.24 show this

Command Purpose

Use this command to show the interface information

Command Syntax

show this

Command Mode

Interface Configuration

Default

None

Usage

None

Examples

The following example shows how to show interface information:

```
Switch(config-if-eth-0-1)# show this  
  
interface eth-0-1  
!
```

Related Commands

None

3 ErrDisable Commands

3.1 errdisable detect

Command Purpose

Use this command to enable link error status detection function for ports.

Use the no form of this command to restore to default value.

Command Syntax

errdisable detect reason link-flap

no errdisable detect reason link-flap

Parameter	Parameter Description	Parameter Value
link-flap	Link oscillation detection	-

Command Mode

Global Configuration

Default

Default link-flap is enabled

Usage

None

Examples

The following example shows how to enable link error status detection function for port:

```
Switch# configure terminal
Switch(config)# errdisable detect reason link-flap
```

The following example shows how to disable link error status detection function for port:

```
Switch# configure terminal
Switch(config)# no errdisable detect reason link-flap
```

Related Commands

show errdisable detect

3.2 errdisable recovery interval

Command Purpose

Use this command to set the recovery time of the link from the error state.

Use the no form of this command to restore recovery time to default value.

Command Syntax

errdisable recovery interval *ERRDIS_RECOVER_TIMER_PARAM*

no errdisable recovery interval

Parameter	Parameter Description	Parameter Value
ERRDIS_RECOVER_TIMER_P ARA	Time interval to recover from error state	range is 30-86400, unit is second

Command Mode

Global Configuration

Default

300

Usage

None

Examples

The following example shows how to set the interval for error status recovery to 100 seconds:

```
Switch# configure terminal
Switch(config)# errdisable recover interval 100
```

The following example shows how to restore the interval to default value:

```
Switch# configure terminal
Switch(config)# no errdisable recover interval
```

Related Commands

show errdisable recovery

3.3 errdisable recovery reason

Command Purpose

Use this command to enable the error recovery function for the specified reason. Use the no form of this command to disable this function.

Command Syntax

errdisable recovery reason link-flap

no errdisable recovery reason link-flap

Parameter	Parameter Description	Parameter Value
link-flap	Enable or disable the error recovery function for link oscillation	-

Command Mode

Global Configuration

Default

Disable

Usage

Use this command to enable or disable the error recovery function for the specified reason.

Examples

The following example shows how to enable the error recovery function for port:

```
Switch# configure terminal
Switch(config)# errdisable recover reason link-flap
```

The following example shows how to disable the error recovery function for port:

```
Switch# configure terminal
Switch(config)# no errdisable recover reason link-flap
```

Related Commands

show errdisable recovery

3.4 errdisable flap

Command Purpose

Use this command set link oscillation parameters.

Use the no form of this command to restore to default setting.

Command Syntax

errdisable flap reason link-flap *ERRDIS_FLAP_COUNT ERRDIS_FLAP_TIME*

no errdisable flap reason link-flap

Parameter	Parameter Description	Parameter Value
ERRDIS_FLAP_COUNT	The maximum number of possible oscillations before setting the port to errdisable	range is 1-100

ERRDIS_FLAP_TIME	The time of possible oscillations before setting the port to errdisable	range is 1-120
------------------	---	----------------

Command Mode

Global Configuration

Default

10

Usage

There are two parameters in link flap error detection, one is flap count, the other is flap time, if the count of flap reach the max flap count in time of flap time specified, the port will enter errdisable state.

Examples

The following example shows how to set link oscillation parameters:

```
Switch# configure terminal
Switch(config)# errdisable flap reason link-flap 30 40
```

The following example shows how to restore link oscillation parameters to default value:

```
Switch# configure terminal
Switch(config)# no errdisable flap reason link-flap
```

Related Commands

show errdisable flap

3.5 show errdisable detect

Command Purpose

Use this command to display whether error detection is enabled.

Command Syntax

show errdisable detect

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display whether error detection is enabled:

```
Switch# show errdisable detect

ErrDisable Reason      Detection status
-----+-----
link-flap              Enabled
```

Related Commands

errdisable detect reason

3.6 show errdisable recovery

Command Purpose

Use this command to display whether error recovery is enabled.

Command Syntax

show errdisable recovery

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to get the recovery status of all error reasons. If a link error has happened, it can get the recovery information.

Examples

The following example shows how to display whether error recovery is enabled:

```
Switch# show errdisable recovery

ErrDisable Reason      Timer status
-----+-----
link-flap              Enabled
Timer interval: 300 seconds
```

Related Commands

errdisable recovery interval

errdisable recovery reason

3.7 show errdisable flap

Command Purpose

This command is used to display parameters for link oscillation error detection.

Command Syntax

show errdisable flap

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to display the link oscillation error detection time, unit is second.

Examples

The following example shows how to display the link oscillation error detection time:

```
Switch# show errdisable flap

ErrDisable Reason Flaps      Time (sec)
-----+-----+-----
link-flap          10          10
```

Related Commands

errdisable flap

4 FLOW Commands

4.1 show interface flow statistics

Command Purpose

Use this command to show statistical information which matched the flow on the interface.

Command Syntax

show interface flow statistics *IF_NAME* (*FLOW_SEQ_NUM* |)

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify an interface name to show flow statistics. This command supports physical or link aggregation interfaces.	-
FLOW_SEQ_NUM	Specify sequence-number to show flow statistics. If the sequence-number is not specified, this command indicates that all rules on this interface should be shown.	-

Command Mode

Privileged EXEC

Default

None

Usage

Interface name must be specified.

Examples

The following example shows how to display the flow statistic on interface eth-0-1:

```
Switch# show interface flow statistics eth-0-1

TAP group name: g1
flow name: f1
sequence-num 10 permit any src-ip 10.10.10.0 0.0.0.255 dst-ip any ( bytes 100
packets 1 )
sequence-num 20 deny any src-ip any dst-ip any ( bytes 86 packets 1 )
(total bytes 186 total packets 2 )
```

Related Commands

show flow

clear interface flow statistics

4.2 clear interface flow statistics

Command Purpose

Use this command to clear statistical information which matched the flow on the interface.

Command Syntax

clear interface flow statistics *IF_NAME*

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

IF_NAME	Specify an interface name to clear flow statistics. This command supports physical or link aggregation interfaces.	-
---------	--	---

Command Mode

Privileged EXEC

Default

None

Usage

Interface name must be specified.

Examples

The following example shows how to clear statistics information which matched the flow on the interface:

```
Switch# clear interface flow statistics eth-0-1
```

The following example shows the result after using the command in the example above:

```
Switch# show interface flow statistics eth-0-1

TAP group name: g1
flow name: f1
sequence-num 10 permit any src-ip 10.10.10.0 0.0.0.255 dst-ip any ( bytes 0 packets 0 )
sequence-num 20 deny any src-ip any dst-ip any ( bytes 0 packets 0 )
(total bytes 0 total packets 0 )
```

Related Commands

show interface flow statistics

4.3 show flow

Command Purpose

Use this command to show the configuration of flow.

Command Syntax

show flow (*NAME_STRING* |)

Parameter	Parameter Description	Parameter Value
NAME_STRING	Flow name, up to 20 characters. If the flow name is not specified, this command indicates that all flows should be shown.	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This example shows the configuration of flow:

```
Switch# show flow

flow f1
remark flowlipdeny
sequence-num 10 permit any src-ip 10.10.10.0 0.0.0.255 dst-ip any
sequence-num 20 deny any src-ip any dst-ip any
```

```
flow f2
sequence-num 10 permit tcp src-port range 10 200 src-ip any dst-ip any
```

Related Commands

flow

4.4 flow

Command Purpose

Use this command to create Flow and then enter Flow configuration mode.

Use the no form of this command to delete the flow.

Command Syntax

flow *NAME_STRING* (type decap |)

no flow *NAME_STRING*

Parameter	Parameter Description	Parameter Value
NAME_STRING	Flow name	up to 20 characters
type decap	Set the flow type as tunnel decap. Flow with “type decap” parameter can use “inner-match” fields.	-

Command Mode

Global Configuration

Default

None

Usage

If the system already has a flow with the same name, this command will enter the flow configuration mode.

When the name is not used by any flow, this command is to create the flow and then enter the flow configuration mode. When configured with parameter "type decap" means this flow matches tunnel decap, which flow entries can configure "inner-match" fields.

Examples

This example shows how to create a flow named f1 and then enter the flow configuration mode:

```
Switch(config)# flow f1
Switch(config-flow-f1)#
```

The following example shows how to delete the flow:

```
Switch(config)# no flow f1
```

Related Commands

show flow

4.5 remark

Command Purpose

Use this command to add remarks for the flow.

Use the no form of this command to delete the remarks.

Command Syntax

remark *NAME_STRING*

no remark

Parameter	Parameter Description	Parameter Value

NAME_STRING	Remark string for the flow	Remark string for the flow, which should begin with a-z/A-Z/0-9, valid characters are 0-9/A-Z/a-z and maximum length is 100 characters.
-------------	----------------------------	---

Command Mode

Flow Configuration

Default

None

Usage

None

Examples

This example shows how to add a remark to describe the flow:

```
Switch(config-flow-f1)# remark flowlipdeny
```

This example shows how to delete the remark of the flow:

```
Switch(config-flow-f1)# no remark
```

Related Commands

show flow

4.6 no sequence-num

Command Purpose

Use this command to delete a filter from flow.

Command Syntax

no sequence-num *FLOW_SEQ_NUM*

Parameter	Parameter Description	Parameter Value
FLOW_SEQ_NUM	Sequence-number	1 - 65535

Command Mode

Flow Configuration

Default

None

Usage

None

Examples

This example shows how to delete a flow filter with sequence number 10 from flow f1:

```
Switch(config-acl-acl1)# no sequence-num 10
```

Related Commands

show flow

sequence-num

4.7 sequence-num

Command Purpose

Use this command to add a rule in a flow filter.

Command Syntax

```
( sequence-num FLOW_SEQ_NUM | ) ( permit | deny ) ( PROTOCOL_NUM | any |
mpls ( any | label-num ( any | MPLS_LABEL_NUM_WITHOUT_0 ) ( mpls-label1 ( any
| FLOW_LABEL_VALUE ) | ) ( mpls-label2 ( any | FLOW_LABEL_VALUE ) | ) ( mpls-
label3 ( any | FLOW_LABEL_VALUE ) | ) ) | pppoe ppp-type ( ipv4 | ipv6 ) | tcp
( src-port ( range L4_PORT_NUM L4_PORT_NUM | eq L4_PORT_NUM | gt
L4_PORT_NUM | lt L4_PORT_NUM | any ) | dst-port ( range L4_PORT_NUM
L4_PORT_NUM | eq L4_PORT_NUM | gt L4_PORT_NUM | lt L4_PORT_NUM | any ) |
tcp-code ( match-all | match-any ) ( ack | fin | psh | rst | syn | urg ) | ) | udp
( src-port ( range L4_PORT_NUM1 L4_PORT_NUM2 | eq L4_PORT_NUM | gt
L4_PORT_NUM | lt L4_PORT_NUM | any ) | dst-port ( range L4_PORT_NUM1
L4_PORT_NUM2 | eq L4_PORT_NUM | gt L4_PORT_NUM | lt L4_PORT_NUM | any ) |
vxlan-vni ( VNI_VALUE VNI_VALUE_WILD | any ) | ) | icmp | igmp | gre ( gre-key
( GRE_KEY_VALUE GRE_KEY_WILD | any ) | ) | ( erspan ( *ERSPAN_KEY_VALUE
ERSPAN_KEY_WILD* | any ) | ) | nvgre ( nvgre-vsids ( *NVGRE_VSID_VALUE NVGRE_
VSID_WILD* | any ) | ) ) ( src-ip ( IP_ADDR IP_ADDR_WILD | any | host IP_ADDR ) |
src-ipv6 ( IPv6_ADDR IPv6_ADDR_WILD | any | host IPv6_ADDR ) ) ( dst-ip ( IP_ADDR
IP_ADDR_WILD | any | host IP_ADDR ) | dst-ipv6 ( IPv6_ADDR IPv6_ADDR_WILD |
any | host IPv6_ADDR ) ) ( flow-label ( *FLOW_LABEL LABEL_WILD* | any ) | )
( dscp DSCP_VALUE | ip-precedence PRECEDENCE_VALUE | ) ( first-fragment | non-
first-fragment | non-fragment | non-or-first-fragment | small-fragment | any-
fragment | ) ( options | ) ( truncation | ) ( vlan ( VLAN_ID VLAN_WILD | any ) | )
( inner-vlan ( VLAN_ID VLAN_WILD | any ) | ) ( cos COS_ID | ) ( inner-cos COS_ID | )
( ether-type ( ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE | any ) | ) ( src-mac
( FLOW_MAC_ADDR FLOW_MAC_ADDR_WILD | any | host FLOW_MAC_ADDR ) | )
( dest-mac ( FLOW_MAC_ADDR FLOW_MAC_ADDR_WILD | any | host
FLOW_MAC_ADDR ) | ) ( edit-macda MAC_ADDRESS | ) ( edit-macsa MAC_ADDRESS
| ) ( edit-ipsa IP_ADDRESS | ) ( edit-ipda IP_ADDRESS | ) ( edit-ipv6sa IPv6_ADDRESS
| ) ( edit-ipv6da IPv6_ADDRESS | ) ( edit-vlan VLAN_ID | ) ( un-tag | un-tag-outer-
vlan | un-tag-inner-vlan | ) ( mark-source VLAN_ID | ) ( strip-header ( strip-position
( l2 | l3 | l4 ) | ) ( strip-offset OFFSET_VALUE | ) | ) ( udf udf-id UDF_ID ( udf0
UDF_VALUE UDF_VALUE_WILD | udf1 UDF_VALUE UDF_VALUE_WILD | udf2
UDF_VALUE UDF_VALUE_WILD | udf3 UDF_VALUE UDF_VALUE_WILD | ) | ) ( strip-
inner-vxlan-header | ) ( inner-match MATCH_NAME | ) ( add-l2gre l2gre-sip
L2GRE_SRC_IP l2gre-dip L2GRE_DEST_IP l2gre-dmac L2GRE_DEST_MAC l2gre-key
L2GRE_KEY_NUM l2gre-key-length ( 16 | 20 | 24 | 32 ) | ) ( add-l3gre l3gre-sip
```

`L3GRE_SRC_IP l3gre-dip L3GRE_DEST_IP l3gre-dmac L3GRE_DEST_MAC |) (de-
duplicate |) (hash-value VALUE_NAME |) (edit-l4-src-port L4_SRC_PORT |)
(edit-l4-dst-port L4_DST_PORT |)`

Parameter	Parameter Description	Parameter Value
FLOW_SEQ_NUM	Specify a sequence number to create the flow rule. The valid range for sequence number is 1-65535. If the sequence number is not specified, system should automatically assign one number according to the base number and the step length. The base number is the maximum number in the flow (0 for empty flow), the step length is 10.	1-65535
permit	Specify the action of the flow rule. Use the parameter “permit” to indicate packets match this rule is allowed to forward.	-
deny	Specify the action of the flow rule. Use the parameter “deny” indicating packets match this rule is not allowed to forward.	-

<p>PROTOCOL_NUM any tcp udp icmp igmp gre nvgre</p>	<p>Specify the IP protocol number of the flow rule.</p>	<p>The valid range for IP protocol number is 0-255. Well known IP protocols can also be specified by name. e.g. IP protocol 1 = icmp, 2 = igmp, 6 = tcp, 17 = udp, 47 = gre/nvgre (gre protocol 0x0800 = gre, 0x6558 = nvgre). Specify the IP protocol number of the flow rule.</p>
<p>mpls (any label-num (any MPLS_LABEL_NUM_WITHOUT_0) (mpls-label1 (any FLOW_LABEL_VALUE)) (mpls-label2 (any FLOW_LABEL_VALUE)) (mpls-label3 (any FLOW_LABEL_VALUE)))</p>	<p>Specify the mpls label of the flow rule.</p>	<p>The mpls label number is 0-9.It can match 3 layers of MPLS label values at most.</p>
<p>pppoe ppp-type (ipv4 ipv6)</p>	<p>Specify the pppoe ppp-type of the flow rule.</p>	<p>The ppp-type is ipv4 or ipv6.</p>

<pre>src-port (range L4_PORT_NUM L4_PORT_NUM eq L4_PORT_NUM gt L4_PORT_NUM lt L4_PORT_NUM any)</pre>	<p>Specify the layer 4 source port of the inner-match rule.</p>	<p>The valid range for L4 source port number is 0 - 65535.</p> <p>This field is valid only if the IP protocol is TCP or UDP.</p> <p>There are 4 methods to specify the L4 port:</p> <ol style="list-style-type: none"> 1, eq (equal to) 2, lt (less than) 3, gt (greater than) 4, range <p>Specify the layer 4 source port of the inner-match rule.</p>
<pre>dst-port (range L4_PORT_NUM L4_PORT_NUM eq L4_PORT_NUM gt L4_PORT_NUM lt L4_PORT_NUM any)</pre>	<p>Specify the layer 4 destination port of the inner-match rule.</p>	<p>The valid range for L4 destination port number is 0 - 65535.</p> <p>This field is valid only if the IP protocol is TCP or UDP.</p> <p>There are 4 methods to specify the L4 port:</p> <ol style="list-style-type: none"> 1, eq (equal to) 2, lt (less than) 3, gt (greater than) 4, range <p>Parameter “any” indicates packets with any L4 port can match this rule.</p>

<p>vxlan-vni (VNI_VALUE VNI_VALUE_WILD any)</p>	<p>Specify the vxlan vni number of the flow rule. This filed is valid only if the IP protocol is UDP and L4 destination port 4789. VNI (VXLAN Network Identifier) is the identifier on the VXLAN network, which is similar to the traditional VLAN. Terminals in different VXLANs cannot connect with each other based on L2 network. One tenant uses one VNI (even if several terminals are in same VNI, they are regarding as one tenant).</p>	<p>The valid range for VNI value is 0-16777215. The valid range for VNI wildcard bits is range 0x0-0xFFFFFFFF. VNI value and VNI wildcard bits both have 24bits. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any VNI value can match this rule.</p>
---	--	---

<p>geneve-vni (GENEVE_VNI_VALUE GENEVE_VNI_VALUE_WILD any)</p>	<p>Specify the geneve vni number of the flow rule. This filed is valid only if the IP protocol is UDP and L4 destination port 6081. GENEVE_VNI (GENEVE Network Identifier in geneve header) is the identifier on the GENEVE network, which is similar to the traditional VLAN. Terminals in different GENEVEs cannot connect with each other based on L2 network. One tenant uses one GENEVE_VNI (even if several terminals are in same GENEVE_VNI, they are regarding as one tenant).</p>	<p>The valid range for GENEVE_VNI value is 0-16777215. The valid range for GENEVE_VNI wildcard bits is range 0x0-0xFFFFFFFF. GENEVE_VNI value and GENEVE_VNI wildcard bits both have 24bits. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any GENEVE_VNI value can match this rule.</p>
<p>gre-key (GRE_KEY_VALUE GRE_KEY_WILD any)</p>	<p>Specify the gre key of the flow rule. This filed is valid only if the IP protocol is gre (Generic Routing Encapsulation).</p>	<p>The valid range for gre key value is 0-4294967295. The valid range for gre key wildcard bits is range 0x0- 0xFFFFFFFF. Gre key value and wildcard bits both have 32bits, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any gre key value can match this rule.</p>

<p>erspan (ERSPAN_KEY_VALUE ERSPAN_KEY_WILD any)</p>	<p>Specify the erspan key value of the flow rule. ERSPAN = Enhanced Remote SPAN.</p>	<p>Valid range for ERSPAN key value is 0-1023 Valid range for ERSPAN key wildcard bits is 0x0-0x3FF ERSPAN key value and wildcard bits both have 10bits, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit.</p>
<p>nvgre-ssid (NVGRE_VSID_VALUE NVGRE_VSID_WILD any)</p>	<p>Specify the nvgre ssid value of the flow rule. Nvgre = Network Virtualization using Generic Routing Encapsulation.</p>	<p>Valid range for NVGRE VSID value is 0-16777215. Valid range for NVGRE VSID wildcard bits is 0x0-0xFFFFF VSID is in the low 24 bit of GRE head. VSID value and wildcard bits both have 24 bits, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any nvgre ssid value can match this rule.</p>

<p>src ip (IP_ADDR IP_ADDR_WILD any host IP_ADDR)</p>	<p>Specify the source IPv4 address of the flow rule. Use an IPv4 address and an IPv4 address wildcard to specify a network.</p>	<p>Use an IPv4 address and an IPv4 address wildcard to specify a network (e.g. 192.168.1.1 0.0.0.255). If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv4 address to specify an exactly address. Use the parameter “any” to indicate packets with any source IPv4 address value can match this rule.</p>
<p>dst ip (IP_ADDR IP_ADDR_WILD any host IP_ADDR)</p>	<p>Specify the destination IPv4 address of the flow rule. Use an IPv4 address and an IPv4 address wildcard to specify a network.</p>	<p>Use an IPv4 address and an IPv4 address wildcard to specify a network (e.g. 192.168.1.1 0.0.0.255). If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv4 address to specify an exactly address. Use the parameter “any” to indicate packets with any destination IPv4 address value can match this rule.</p>

<p>src ipv6 (IPv6_ADDR IPv6_ADDR_WILD any host IPv6_ADDR)</p>	<p>Specify the source IPv6 address of the flow rule. Use an IPv6 address and an IPv6 address wildcard to specify a network. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.</p>	<p>Use the parameter “host” and an IPv6 address to specify an exactly address. Use the parameter “any” to indicate packets with any destination IPv6 address value can match this rule.</p>
<p>dst ipv6 (IPv6_ADDR IPv6_ADDR_WILD any host IPv6_ADDR)</p>	<p>Specify the destination IPv6 address of the flow rule. Use an IPv6 address and an IPv6 address wildcard to specify a network. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.</p>	<p>Use the parameter “host” and an IPv6 address to specify an exactly address. Use the parameter “any” to indicate packets with any destination IPv6 address value can match this rule.</p>
<p>flow-label (FLOW_LABEL LABEL_WILD any)</p>	<p>Specify the IPv6 Flow label of the flow rule.</p>	<p>The valid range for flow label is 0-1048575. Valid range for flow-label wildcard bits is 0x0-0xFFFF Flow label value and wildcard bits both have 20bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates ipv6 packets with any flow label value can match this rule.</p>

dscp DSCP_VALUE	Specify the DSCP in IPv4 packets value of the inner-match rule. DSCP = Differentiated Services Code Point. Specify the DSCP in IPv4 packets value of the inner-match rule. DSCP = Differentiated Services Code Point. Valid range of DSCP value is 0 - 63.	0-63
ip-precedence PRECEDENCE_VALUE	Specify the IP precedence in IPv4 packets of the inner-match rule. Valid range of IP precedence value is 0 - 7. Specify the IP precedence in IPv4 packets of the inner-match rule. Valid range of IP precedence value is 0 - 7. DSCP & ip precedence configurations are exclusive	0-7
first-fragment	Match packets with first fragment	-
non-first-fragment	Match packets with non-first fragment	-
non-fragment	Match packets with non-fragment	-
non-or-first-fragment	Match packets with non-first fragment	-

small-fragment	Match packets with small fragment	-
any-fragment	Match packets with any fragment	-
options	Match packets with IP options	-
truncation	Use this parameter to truncate the packets matched this rule. Use this parameter to truncate the packets matched this rule. The length of truncation is configured by the “truncation” command in global configuration mode.	-
vlan (VLAN_ID VLAN_WILD any)	Specify the outer vlan id of the flow rule.	The valid range for vlan id is 0-4095. The valid range for vlan id wildcard bits is 0x0-0xFFF. Vlan id and wildcard bits both have 12bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any outer vlan id can match this rule.

<p>inner-vlan (VLAN_ID VLAN_WILD any)</p>	<p>Specify the inner vlan id of the flow rule.</p>	<p>The valid range for vlan id is 0-4095. The valid range for vlan id wildcard bits is 0x0-0xFFF. Vlan id and wildcard bits both have 12bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any outer vlan id can match this rule.</p>
<p>cos COS_ID</p>	<p>Specify the outer CoS value of the inner-match rule. CoS = Class of Service. Specify the outer CoS value of the inner-match rule. CoS = Class of Service.</p>	<p>0-7</p>
<p>inner-cos COS_ID</p>	<p>Specify the inner CoS value of the inner-match rule. CoS = Class of Service. Specify the inner CoS value of the inner-match rule. CoS = Class of Service.</p>	<p>0-7</p>

<p>ether-type (ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE any)</p>	<p>Specify the ether-type of the flow rule.</p>	<p>The valid range for ether-type is 0x600-0xFFFF. The valid range for wildcard bits is 0x600-0xFFFF. Ether-type value and wildcard bits both have 16bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any ethertype value can match this rule.</p>
<p>src-mac (FLOW_MAC_ADDR FLOW_MAC_ADDR_WILD any host FLOW_MAC_ADDR)</p>	<p>Specify the source mac address</p>	<p>Specify the source mac address in HHHH.HHHH.HHHH format. Use a mac address and wildcard bits to specify a batch of mac addresses. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and a mac address to specify an exact mac address. Use the parameter “any” to indicate packets with any source mac address value can match this rule.</p>

<p>dest-mac (FLOW_MAC_ADDR FLOW_MAC_ADDR_WILD any host FLOW_MAC_ADDR)</p>	<p>Specify the destination mac address</p>	<p>Specify the destination mac address in HHHH.HHHH.HHHH format. Use a mac address and wildcard bits to specify a batch of mac addresses. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and a mac address to specify an exact mac address. Use the parameter “any” to indicate packets with any destination mac address value can match this rule.</p>
<p>edit-macda MAC_ADDRESS</p>	<p>Specify the destination mac address of the outgoing packets</p>	<p>Specify the destination mac address of the outgoing packets in HHHH.HHHH.HHHH format.</p>
<p>edit-macsa MAC_ADDRESS</p>	<p>Specify the source mac address of the outgoing packets</p>	<p>Specify the source mac address of the outgoing packets in HHHH.HHHH.HHHH format.</p>
<p>edit-ipsa IP_ADDRESS</p>	<p>Specify the source IP address of the outgoing packets</p>	<p>Specify the source IP address of the outgoing packets in A.B.C.D format.</p>

edit-ipda IP_ADDRESS	Specify the destination IP address of the outgoing packets	Specify the destination IP address of the outgoing packets in A.B.C.D format.
edit-ipv6sa IPv6_ADDRESS	Specify the source IPv6 address of the outgoing packets.	Specify the source IPv6 address of the outgoing packets.
edit-ipv6da IPv6_ADDRESS	Specify the destination IPv6 address of the outgoing packets.	Specify the destination IPv6 address of the outgoing packets.
edit-vlan VLAN_ID	Specify the vlan id of the outgoing packets.	The valid range for vlan id is 1 - 4094.
un-tag	Remove vlan tags of the packets.	-
un-tag-outer-vlan	Remove outer vlan tag of the packets.	-
un-tag-inner-vlan	Remove inner vlan tag of the packets.	-
mark-source VLAN_ID	Specify the vlan id of the outgoing packets.	The valid range for vlan id is 1 - 4094.

<p>strip-header (strip-position (l2 l3 l4)) (strip-offset OFFSET_VALUE)</p>	<p>Remove the outer header of the tunnel packets. The strip-positon and strip-offset cannot set and when the packet is gre/nvgre/vxlan/ipip/mpls/ppoe.</p>	<p>The parameter “strip-position” specifies the begging of the outer header. “l2” means begin with the layer 2 tunnel header. “l3” means begin with the layer 3 tunnel header. “l4” means begin with the layer 4 tunnel header. The parameter “strip-offset” specifies the user-defined offset to strip the tunnel outer header. The valid range for strip-offset is 0-30.</p>
<p>strip-inner-vxlan-header</p>	<p>Remove the inner vxlan header in the erspan packets. Remove the inner vxlan header in the erspan packets. This parameter is only valid when the packet is ERSPAN + VXLAN.</p>	<p>-</p>
<p>udf udf-id UDF_ID (udf0 UDF_VALUE UDF_VALUE_WILD udf1 UDF_VALUE UDF_VALUE_WILD udf2 UDF_VALUE UDF_VALUE_WILD udf3 UDF_VALUE UDF_VALUE_WILD)</p>	<p>Use this command to configure UDF based ACL. UDF entry should be created and configured previously. There are maximum three UDF value corresponding three UDF offset field.</p>	<p>The range of UDF_ID is 0-15, UDF value and wildcard bits both have 32 bits, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.</p>

inner-match MATCH_NAME	Specify the inner match profile of the flow rule. Specify the inner match profile of the flow rule. The inner-match profile is created by “inner-match” command in global configuration mode.	-
add-l2gre l2gre-sip L2GRE_SRC_IP l2gre-dip L2GRE_DEST_IP l2gre-dmac L2GRE_DEST_MAC l2gre-key L2GRE_KEY_NUM l2gre-key-length (16 20 24 32)	Use this action to add l2gre header. L2GRE_SRC_IP: L2GRE Source IP L2GRE_DEST_IP: L2GRE Destination IP L2GRE_DEST_MAC: L2GRE Destination MAC L2GRE_KEY_NUM: L2GRE Key Number	-
add-l3gre l3gre-sip L3GRE_SRC_IP l3gre-dip L3GRE_DEST_IP l3gre-dmac L3GRE_DEST_MAC	Use this action to add l3gre header. L3GRE_SRC_IP: L3GRE Source IP L3GRE_DEST_IP: L3GRE Destination IP L3GRE_DEST_MAC: L3GRE Destination MAC	-
de-duplicate	Use this action to config de-duplicate packet of match. The de-duplicate is configured by the “de-duplicate global” command in global configuration mode.	-

hash-value VALUE_NAME	Use this action to configure hash-value for hash load-balance. The hash-value profile if configured by the “hash-value” command in global configuration mode	-
edit-l4-src-port L4_SRC_PORT	Use this action to configure edit l4 source port for TCP or UDP packets	0-65535
edit-l4-dst-port L4_DST_PORT	Use this action to configure edit l4 destination port for TCP or UDP packets	0-65535

Command Mode

Flow Configuration

Default

None

Usage

Wildcard bits in this command are used as reversed. That means value and wildcard bits have same length, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. E.g. IP address 10.10.10.0 wildcard 0.0.0.255 means 256 ip addresses from 10.10.10.0 to 10.10.10.255. Layer 4 information (e.g. tcp/udp port) and fragment information are exclusive. The parameters “erspan” and “edit-vlan, un-tag” after “stripe-head” are not supported

Examples

This example shows how to add a flow filter with sequence number 10 to flow f1:


```
Switch(config)# flow f1
Switch(config-flow-f1)# sequence-num 10 permit any src-ip 10.10.10.0 0.0.0.255 dst-
ip any
```

Related Commands

no sequence-num

4.8 flow statistics rate interval

Command Purpose

Use this command to calculate flow rule statistics rate and configure calculating interval .

Use the no form of this command to stop calculating flow rule statistics rate.

Command Syntax

flow statistics rate interval *INTERVAL*

no flow statistics rate interval

Parameter	Parameter Description	Parameter Value
INTERVAL	The interval of calculating flow rule statistics rate	1-5 minutes

Command Mode

Global Configuration

Default

None

Usage

If flow statistics rate interval is configured, the statistics rate of flow rules will be calculated according to the interval.

Examples

This example shows how to configure flow rule statistics rate interval:

```
Switch(config)# flow statistics rate interval 1
```

The following example shows how to delete flow rule statistics rate interval:

```
Switch(config)# no flow statistics rate interval
```

Related Commands

show interface flow statistics

5 UDF Commands

5.1 show udf

Command Purpose

Use this command to show the configuration of UDF entries.

Command Syntax

```
show udf ( UDF_ID | )
```

Parameter	Parameter Description	Parameter Value
UDF_ID	Specify an index to show the configuration of a specific UDF entry.	The range is 0-15

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This example shows the configuration of UDF entries:

```
Switch# show udf
```

```
Udf Global Information:
  Offset Unit : 4 Bytes
Udf Index 0
  Udf Type : 12 header
  Udf Match-Field:
    ether-type 0x8100 0x0
  Offset : n/a|8|n/a|n/a
Udf Index 1
  Udf Type : 13 header
  Udf Match-Field:
    any
  Offset : 4|n/a|n/a|n/a
```

Related Commands

udf

5.2 udf

Command Purpose

Use this command to create a UDF entry or enter the configuration mode of a specific DUF entry.

Command Syntax

udf *UDF_ID* (offset-type *OFFSET_TYPE* |)

Parameter	Parameter Description	Parameter Value
UDF_ID	Specify an index of a UDF entry.	The range is 0-15
OFFSET_TYPE	The offset type should be configured when a UDF entry was first created.	The offset type can be l2-header, l3-header, l4-header.

Command Mode

Global Configuration

Default

None

Usage

The UDF-ID also means the priority of UDF entries, smaller id is a higher priority.

Examples

This example shows how to create a UDF entry and enter its configuration mode:

```
Switch(config)# udf 1 offset-type 13-header
Switch(config-udf-1)#
```

Related Commands

show udf

5.3 match

Command Purpose

Use this command to configure the match field for an UDF entry.

Command Syntax

```
match ( any | ether-type ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE | ip-
protocol ( PROTOCOL_NUM | any | tcp | udp | gre | icmp | igmp ) | src-port
( L4_PORT_NUM | any ) | dst-port ( L4_PORT_NUM | any ) | vlan-num VLAN_NUM |
mpls-label-num MPLS_LABEL_NUM | )
```

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

ether-type (ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE any)	Specify the ether-type of the flow rule.	The valid range for ether-type is 0x600-0xFFFF. The valid range for wildcard bits is 0x600-0xFFFF. Ether-type value and wildcard bits both have 16bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.
PROTOCOL_NUM any tcp udp icmp igmp	Specify the IP protocol number of the udf match field.	Specify the IP protocol number of the udf match field. The valid range for IP protocol number is 0-255.
L4_PORT_NUM	Specify the layer 4 source port of the udf match field.	The valid range for L4 source port number is 0 - 65535.
VLAN_NUM	The vlan number of the packets	range is 0-2.
MPLS_LABEL_NUM	The mpls label number of the packets	range is 0-9.

Command Mode

UDF Configuration

Default

None

Usage

None

Examples

This example shows how to configure the match field for an UDF entry:

```
Switch(config-udf-1)# match ether-type 0x8100 0x0 ip-protocol tcp
```

Related Commands

show udf

5.4 offset

Command Purpose

Use this command to configure the detailed offset value for a UDF entry.

Command Syntax

```
match ( offset0 UDF_OFFSET | offset1 UDF_OFFSET | offset2 UDF_OFFSET | offset3 UDF_OFFSET | )
```

Parameter	Parameter Description	Parameter Value
UDF_OFFSET	Specifies the offset in bytes from the beginning.	The valid range of the offset is 0-124 bytes.

Command Mode

UDF Configuration

Default

None

Usage

The offset number must be multiple of 4 bytes because UDF would extract 4 bytes data from a specific offset in packets.

Examples

This example shows how to configure the detailed offset value for an UDF entry:

```
Switch(config-udf-1)# offset offset0 4 offset1 20 offset3 36
```

Related Commands

show udf

6 PORT-GROUP Commands

6.1 port-group

Command Purpose

Use this command to create a port-group and enter the port-group configuration mode.

Use the no form of this command to delete the port-group.

Command Syntax

port-group *NAME_STRING* (*PORT_GROUP_ID* |)

no port-group *NAME_STRING*

Parameter	Parameter Description	Parameter Value
NAME_STRING	Port-group Name string	The first character should be a-z or A-Z, character only can be 0-9/A-Z/a-z and the max length is 31.
PORT_GROUP_ID	Port Group ID, range 1-48	1-48

Command Mode

Global Configuration

Default

None

Usage

This device supports at most 48 port-groups.

Examples

The following example shows how to add a port-group:

```
Switch(config)# port-group portgroup1
Switch(config-port-portgroup1)#
```

The following example shows how to delete a port-group:

```
Switch(config)# no port-group portgroup1
```

Related Commands

show port-group

6.2 member interface

Command Purpose

Use this command to add a member interface in port-group.

Use the no form of this command to delete the member interface.

Command Syntax

member interface *IF_NAME_EA*

no member interface *IF_NAME_EA*

Parameter	Parameter Description	Parameter Value
IF_NAME_EA	member interface Name string	Specify the interface name to enter the mode. e.g.eth-0-1, agg1.

Command Mode

Port-group Configuration

Default

None

Usage

This device supports at most a 16-member interface.

Examples

The following example shows how to add a member interface in port-group:

```
Switch(config-port-portgroup1)# member interface eth-0-1
```

The following example shows how to delete a member interface in port-group:

```
Switch(config-port-portgroup1)# no member interface eth-0-1
```

Related Commands

show port-group

6.3 show port-group

Command Purpose

Use this command to display the configurations of port-group.

Command Syntax

show port-group (*NAME_STRING* |)

Parameter	Parameter Description	Parameter Value
NAME_STRING	Specify the port-group name to show	-

Command Mode

Privileged EXEC

Default

None

Usage

If the parameter “NAME_STRING” is not specified, the command indicates that all port-groups on this device should be displayed; otherwise only the specified port-group should be displayed.

Examples

The following example shows how to display the configurations port-group portgroup1:

```
Switch# show port-group

port-group portgroup1 1
  member interface eth-0-1
  member interface eth-0-2
```

Related Commands

show port-group flow statistics

6.4 show port-group flow statistics

Command Purpose

Use this command to display the statistics of port-group.

Command Syntax

show port-group flow statistics *NAME_STRING* (*FLOW_SEQ_NUM* |)

Parameter	Parameter Description	Parameter Value
NAME_STRING	Specify the port-group name to show	-

FLOW_SEQ_NUM	Specify sequence-number to show flow statistics. If the sequence-number is not specified, this command indicates that all rules on this interface should be shown.	-
--------------	--	---

Command Mode

Privileged EXEC

Default

None

Usage

The specified port-group statistics should be displayed.

Examples

The following example shows how to display the statistics port-group portgroup1:

```
Switch# show port-group flow statistics

portgroup1
TAP group name: tapgroup1
flow name: flow1
sequence-num 10 permit gre src-ip any dst-ip any ( bytes 0 packets 0 )
sequence-num 20 permit mpls any ( bytes 0 packets 0 )
(total bytes 0 total packets 0 )
```

Related Commands

show port-group

7 INNER-MATCH Commands

7.1 show inner-match

Command Purpose

Use this command to show the configuration of inner-match.

Command Syntax

show inner-match (*INNER_MATCH_NAME* |)

Parameter	Parameter Description	Parameter Value
INNER_MATCH_NAME	Specify an inner-match name to display.	<p>The inner match's name should begin with [a-z/A-Z/0-9], valid characters are [0-9/A-Z/a-z], and maximum length is 20 characters.</p> <p>If the parameter "INNER_MATCH_NAME" is not specified, the command indicates that all inner-matches on this device should be displayed; otherwise only the specified one should be displayed</p>

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This example shows the configuration of all inner-match:

```
Switch# show inner-match

inner-match im1
  sequence-num 1 match icmp src-ip any dst-ip any vlan any
inner-match im2
  sequence-num 1 match udp dst-port eq 4758 src-ip any dst-ip host 2.2.2.2
```

Related Commands

inner-match

7.2 inner-match

Command Purpose

Use this command to create inner-match and then enter Inner-match configuration mode.

Use the no form of this command to delete the inner-match.

Command Syntax

inner-match *INNER_MATCH_NAME*

no inner-match *INNER_MATCH_NAME*

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

INNER_MATCH_NAME	Specify an inner-match name to create and enter the mode.	The inner match's name should begin with a-z/A-Z/0-9, valid characters are 0-9/A-Z/a-z and maximum length is 20 characters.
------------------	---	---

Command Mode

Global Configuration

Default

None

Usage

If the system already has an inner-match with the same name, this command will enter the inner-match configuration mode.

When the name is not used by any inner-match, this command is to create the inner-match first and then enter the inner-match configuration mode.

Examples

This example shows how to create an inner-match named im1 and then enter the inner-match configuration mode:

```
Switch(config)# inner-match im1
Switch(config-inner-match-im1)#
```

This example shows how to delete an inner-match named im1:

```
Switch(config)# no inner-match im1
```

Related Commands

show inner-match

7.3 remark

Command Purpose

Use this command to add remarks for the inner-match.

Command Syntax

remark *NAME_STRING*

no remark

Parameter	Parameter Description	Parameter Value
NAME_STRING	Remark string for the inner-match	Begin with a-z/A-Z/0-9, valid characters are 0-9/A-Z/a-z, maximum length is 100 characters.

Command Mode

Inner-match Configuration

Default

None

Usage

None

Examples

This example shows how to add a remark to describe the inner-match:

```
Switch(config-inner-match-im1)# remark inner-match-1
```

This example shows how to delete the remark of the inner-match:

```
Switch(config-inner-match-im1)# no remark
```

Related Commands

show inner-match

7.4 no sequence-num

Command Purpose

Use this command to delete a filter from inner-match.

Command Syntax

no sequence-num *MATCH_SEQ_NUM*

Parameter	Parameter Description	Parameter Value
MATCH_SEQ_NUM	Sequence-number with the valid range 1 - 65535.	1-65535

Command Mode

Inner-match Configuration

Default

None

Usage

None

Examples

This example shows how to delete an inner-match filter with sequence number 10 from im1:

```
Switch(config-inner-match-im1)# no sequence-num 10
```

Related Commands

show inner-match

match

7.5 sequence-num

Command Purpose

Use this command to set matching rules for the inner-match filter.

Command Syntax

```
( sequence-num MATCH_SEQ_NUM | ) match ( PROTOCOL_NUM | any | mpls ( any |
label-num ( any | MPLS_LABEL_NUM_WITHOUT_0 ) ( mpls-label1 ( any |
FLOW_LABEL_VALUE ) | ) ( mpls-label2 ( any | FLOW_LABEL_VALUE ) | ) ( mpls-
label3 ( any | FLOW_LABEL_VALUE ) | ) ) | pppoe ppp-type ( ipv4 | ipv6 ) | tcp
( src-port ( range L4_PORT_NUM L4_PORT_NUM | eq L4_PORT_NUM | gt
L4_PORT_NUM | lt L4_PORT_NUM | any ) | dst-port ( range L4_PORT_NUM
L4_PORT_NUM | eq L4_PORT_NUM | gt L4_PORT_NUM | lt L4_PORT_NUM | any ) |
tcp-code ( match-all | match-any ) ( ack | fin | psh | rst | syn | urg ) | ) | udp
( src-port ( range L4_PORT_NUM1 L4_PORT_NUM2 | eq L4_PORT_NUM | gt
L4_PORT_NUM | lt L4_PORT_NUM | any ) | dst-port ( range L4_PORT_NUM1
L4_PORT_NUM2 | eq L4_PORT_NUM | gt L4_PORT_NUM | lt L4_PORT_NUM | any )
| ) | icmp | igmp ) ( src-ip ( IP_ADDR IP_ADDR_WILD | any | host IP_ADDR ) | src-
ipv6 ( IPv6_ADDR IPv6_ADDR_WILD | any | host IPv6_ADDR ) ) ( dst-ip ( IP_ADDR
IP_ADDR_WILD | any | host IP_ADDR ) | dst-ipv6 ( IPv6_ADDR IPv6_ADDR_WILD |
any | host IPv6_ADDR ) ) ( flow-label ( *FLOW_LABEL LABEL _WILD* | any ) | )
( dscp DSCP_VALUE | ip-precedence PRECEDENCE_VALUE | ) ( first-fragment | non-
first-fragment | non-fragment | non-or-first-fragment | small-fragment | any-
fragment | ) ( options | ) ( vlan ( VLAN_ID VLAN_WILD | any ) | ) ( inner-vlan
( VLAN_ID VLAN_WILD | any ) | ) ( cos COS_ID | ) ( inner-cos COS_ID | ) ( ether-
type ( ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE | any ) | ) ( src-mac
( MATCH_MAC_ADDR MATCH_MAC_ADDR_WILD | any | host *MATCH_MAC_ADDR* )
| ) ( dest-mac ( MATCH_MAC_ADDR MATCH_MAC_ADDR_WILD | any | host
MATCH_MAC_ADDR ) | )
```

Parameter	Parameter Description	Parameter Value
sequence-num MATCH_SEQ_NUM	Specify a sequence number to create the inner-match rule.	The valid range for sequence number is 1-65535. If the sequence number is not specified, system should automatically assign one number according to the base number and the step length. The base number is the maximum number in the inner-match (0 for empty inner-match), the step length is 10.
match	Match the packets according to the rule	-
PROTOCOL_NUM any tcp udp icmp igmp	Specify the IP protocol number of the inner-match rule.	The valid range for IP protocol number is 0-255. Well known IP protocols can also be specified by name. e.g. IP protocol 1 = icmp, 2 = igmp, 6 = tcp, 17 = udp. Parameter “any” indicates packets with any IP protocol can match this rule.

<p>mpls (any label-num (any MPLS_LABEL_NUM_WITHO UT_0) (mpls-label1 (any FLOW_LABEL_VALUE)) (mpls-label2 (any FLOW_LABEL_VALUE)) (mpls-label3 (any FLOW_LABEL_VALUE)))</p>	<p>Specify the mpls label of the flow rule.</p>	<p>The mpls label number is 0-9. It can match 3 layers of MPLS label values at most.</p>
<p>pppoe ppp-type (ipv4 ipv6)</p>	<p>Specify the pppoe ppp-type of the flow rule.</p>	<p>The ppp-type is ipv4 or ipv6.</p>
<p>src-port (range L4_PORT_NUM L4_PORT_NUM eq L4_PORT_NUM gt L4_PORT_NUM lt L4_PORT_NUM any)</p>	<p>Specify the layer 4 source port of the inner-match rule.</p>	<p>The valid range for L4 source port number is 0 - 65535. This field is valid only if the IP protocol is TCP or UDP. There are 4 methods to specify the L4 port: 1, eq (equal to) 2, lt (less than) 3, gt (greater than) 4, range Parameter “any” indicates packets with any L4 port can match this rule.</p>

<p>dst-port (range L4_PORT_NUM L4_PORT_NUM eq L4_PORT_NUM gt L4_PORT_NUM lt L4_PORT_NUM any)</p>	<p>Specify the layer 4 destination port of the inner-match rule.</p>	<p>The valid range for L4 destination port number is 0 - 65535.</p> <p>This field is valid only if the IP protocol is TCP or UDP.</p> <p>There are 4 methods to specify the L4 port:</p> <ol style="list-style-type: none"> 1, eq (equal to) 2, lt (less than) 3, gt (greater than) 4, range <p>Parameter “any” indicates packets with any L4 port can match this rule.</p>
<p>src-ip (IP_ADDR IP_ADDR_WILD any host IP_ADDR)</p>	<p>Specify the source IPv4 address of the inner-match rule.</p>	<p>Use an IPv4 address and an IPv4 address wildcard to specify a network (e.g. 192.168.1.1 0.0.0.255). If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.</p> <p>Use the parameter “host” and an IPv4 address to specify an exactly address.</p> <p>Use the parameter “any” to indicate packets with any source IPv4 address value can match this rule.</p>

<p>dst-ip (IP_ADDR IP_ADDR_WILD any host IP_ADDR)</p>	<p>Specify the destination IPv4 address of the inner-match rule.</p>	<p>Use an IPv4 address and an IPv4 address wildcard to specify a network (e.g. 192.168.1.1 0.0.0.255). If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.</p> <p>Use the parameter “host” and an IPv4 address to specify an exactly address.</p> <p>Use the parameter “any” to indicate packets with any destination IPv4 address value can match this rule.</p>
<p>src-ipv6 (IPv6_ADDR IPv6_ADDR_WILD any host IPv6_ADDR)</p>	<p>Specify the source IPv6 address of the inner-match rule.</p>	<p>Use an IPv6 address and an IPv6 address wildcard to specify a network. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.</p> <p>Use the parameter “host” and an IPv6 address to specify an exactly address.</p> <p>Use the parameter “any” to indicate packets with any source IPv6 address value can match this rule.</p>

<p>dst-ipv6 (IPv6_ADDR IPv6_ADDR_WILD any host IPv6_ADDR)</p>	<p>Specify the destination IPv6 address of the inner-match rule.</p>	<p>Use an IPv6 address and an IPv6 address wildcard to specify a network. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.</p> <p>Use the parameter “host” and an IPv6 address to specify an exactly address.</p> <p>Use the parameter “any” to indicate packets with any destination IPv6 address value can match this rule.</p>
<p>flow-label (FLOW_LABEL LABEL_WILD any)</p>	<p>Specify the IPv6 Flow label of the inner-match rule.</p>	<p>The valid range for flow label is 0-1048575. Valid range for flow-label wildcard bits is 0x0-0xFFFFF</p> <p>Flow label value and wildcard bits both have 20bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.</p> <p>Parameter “any” indicates ipv6 packets with any flow label value can match this rule.</p>

dscp DSCP_VALUE	Specify the DSCP in IPv4 packets value of the inner-match rule. DSCP = Differentiated Services Code Point. Specify the DSCP in IPv4 packets value of the inner-match rule. DSCP = Differentiated Services Code Point.	0-63
ip-precedence PRECEDENCE_VALUE	Specify the IP precedence in IPv4 packets of the inner-match rule. DSCP & ip precedence configurations are exclusive.	0-7
first-fragment	Match packets with first fragment	-
non-first-fragment	Match packets with non-first fragment	-
non-fragment	Match packets with non-fragment	-
non-or-first-fragment	Match packets with non-first fragment	-
small-fragment	Match packets with small fragment	-
any-fragment	Match packets with any fragment	-
options	Match packets with IP options	-

<p>vlan (VLAN_ID VLAN_WILD any)</p>	<p>Specify the outer vlan id of the inner-match rule.</p>	<p>The valid range for vlan id is 0-4095.</p> <p>The valid range for vlan id wildcard bits is 0x0-0xFFF. Vlan id and wildcard bits both have 12bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.</p> <p>Parameter “any” indicates packets with any outer vlan id can match this rule.</p>
<p>inner-vlan (VLAN_ID VLAN_WILD any)</p>	<p>Specify the inner vlan id of the inner-match rule.</p>	<p>The valid range for vlan id is 0-4095.</p> <p>The valid range for vlan id wildcard bits is 0x0-0xFFF. Vlan id and wildcard bits both have 12bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.</p> <p>Parameter “any” indicates packets with any inner vlan id can match this rule.</p>

<p>cos COS_ID</p>	<p>Specify the outer CoS value of the inner-match rule. CoS = Class of Service. Specify the outer CoS value of the inner-match rule. CoS = Class of Service.</p>	<p>0-7</p>
<p>inner-cos COS_ID</p>	<p>Specify the inner CoS value of the inner-match rule. CoS = Class of Service. Specify the inner CoS value of the inner-match rule. CoS = Class of Service.</p>	<p>0-7</p>
<p>ether-type (ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE any)</p>	<p>Specify the ether-type of the inner-match rule.</p>	<p>The valid range for ether-type is 0x600-0xFFFF. The valid range for wildcard bits is 0x600-0xFFFF. Ether-type value and wildcard bits both have 16bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any ethertype value can match this rule.</p>

<p>src-mac (MATCH_MAC_ADDR MATCH_MAC_ADDR_WILD any host MATCH_MAC_ADDR)</p>	<p>Specify the source mac address in HHHH.HHHH.HHHH format.</p>	<p>Use a mac address and wildcard bits to specify a batch of mac addresses. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and a mac address to specify an exact mac address. Use the parameter “any” to indicate packets with any source mac address value can match this rule.</p>
<p>dest-mac (MATCH_MAC_ADDR MATCH_MAC_ADDR_WILD any host MATCH_MAC_ADDR)</p>	<p>Specify the destination mac address in HHHH.HHHH.HHHH format.</p>	<p>Use a mac address and wildcard bits to specify a batch of mac addresses. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and a mac address to specify an exact mac address. Use the parameter “any” to indicate packets with any destination mac address value can match this rule.</p>

Command Mode

Inner-match Configuration

Default

None

Usage

Wildcard bits in this command are used as reversed. That means value and wildcard bits have same length, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.

E.g.: ip address 10.10.10.0 wildcard 0.0.0.255 means 256 ip addresses from 10.10.10.0 to 10.10.10.255.

Layer 4 information (e.g. tcp/udp port) and fragment information are exclusive.

Examples

This example shows how to add an inner-match filter with sequence number 10 to im1:

```
Switch(config)# inner-match im1
Switch(config-inner-match-im1)# sequence-num 10 match any src-ip 10.10.10.0
0.0.0.255 dst-ip any
```

Related Commands

no sequence-num

8 ACL Commands

8.1 show interface egress ip access-list

Command Purpose

Use this command to show egress statistics of ip access-list on an interface.

Command Syntax

show interface egress ip access-list statistics *IF_NAME*

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name to show IP ACL statistics. This command supports physical or link aggregation interfaces.	-

Command Mode

Privileged EXEC

Default

None

Usage

The interface name must be specified.

Examples

This example shows the egress ip access-list statistic of interface eth-0-1:

```
Switch# show interface egress ip access-list statistics eth-0-1

egress flow f2
sequence-num 10 permit tcp src-port range 10 200 src-ip any dst-ip any ( bytes 124
packets 1 )
(total bytes 124 total packets 1 )
```

Related Commands

clear interface egress ip access-list

8.2 clear interface egress ip access-list

Command Purpose

Use this command to clear egress statistics of ip access-list on an interface.

Command Syntax

clear interface egress ip access-list statistics *IF_NAME*

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name to clear IP ACL statistics. This command supports physical or link aggregation interfaces.	-

Command Mode

Privileged EXEC

Default

None

Usage

The interface name must be specified.

Examples

This example shows how to clear the egress ip access-list statistic of interface eth-0-1:

```
Switch# clear interface egress ip access-list statistics eth-0-1
```

This example shows the egress ip access-list statistic of interface eth-0-1:

```
Switch# show interface egress ip access-list statistics eth-0-1

egress flow f2
sequence-num 10 permit tcp src-port range 10 200 src-ip any dst-ip any ( bytes 0
packets 0 )
(total bytes 0 total packets 0 )
```

Related Commands

show interface egress ip access-list

8.3 show ip access-list

Command Purpose

Use this command to show the configuration of ip access-list.

Command Syntax

show ip access-list (*NAME_STRING* |)

Parameter	Parameter Description	Parameter Value
NAME_STRING	Ip access-list name	up to 20 characters

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This example shows the configuration of ip access-list:

```
Switch# show ip access-list
ip access-list f2
sequence-num 10 permit tcp src-port range 10 200 src-ip any dst-ip any
```

Related Commands

ip access-list

8.4 ip access-list

Command Purpose

Use this command to create IP ACL and then enter IP ACL configuration mode.

Use the no form of this command to delete the IP ACL.

Command Syntax

ip access-list *NAME_STRING*

no ip access-list *NAME_STRING*

Parameter	Parameter Description	Parameter Value
NAME_STRING	IP access-list name string	Begin with a-z/A-Z/0-9, valid characters are 0-9/A-Z/a-z, and maximum length is 20 characters.

Command Mode

Global Configuration

Default

None

Usage

If the system already has an IP ACL with the same name, this command will enter the IP ACL configuration mode

When the name is not used by any ACL, this command is to create the IP ACL first and then enter the IP ACL configuration mode.

Examples

This example shows how to create an IP ACL named f1 and then enter the IP ACL configuration mode:

```
Switch(config)# ip access-list f1  
Switch(config-acl-f1)#
```

Related Commands

show ip access-list

8.5 remark

Command Purpose

Use this command to add remarks for the flow or ip access-list.

Command Syntax

remark *NAME_STRING*

no remark

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

NAME_STRING	Remark string for the IP ACL	Begin with a-z/A-Z/0-9, valid characters are 0-9/A-Z/a-z, maximum length is 100 characters.
-------------	------------------------------	---

Command Mode

ACL Configuration

Default

None

Usage

None

Examples

This example shows how to add a remark to describe the IP ACL:

```
Switch(config-acl-acl1)# remark acllipdeny
```

This example shows how to remove the remark:

```
Switch(config-acl-acl1)# no remark
```

Related Commands

show ip access-list

8.6 no sequence-num

Command Purpose

Use this command to delete a filter from ip access-list.

Command Syntax

no sequence-num *ACL_SEQ_NUM*

Parameter	Parameter Description	Parameter Value
ACL_SEQ_NUM	Sequence-number with the valid range 1-65535.	1-65535

Command Mode

ACL Configuration

Default

None

Usage

None

Examples

This example shows how to delete a flow filter with sequence number 10 from ip acl acl1:

```
Switch(config-acl-acl1)# no sequence-num 10
```

Related Commands

show ip access-list

sequence-num

8.7 sequence-num

Command Purpose

Use this command to permit or deny packets matching the ip access-list filter.

Command Syntax

```
( sequence-num ACL_SEQ_NUM | ) ( permit | deny ) ( PROTOCOL_NUM | any | mpls  
( any | label-num ( any | MPLS_LABEL_NUM_WITHOUT_0 ) ( mpls-label1 ( any |
```

```

FLOW_LABEL_VALUE ) | ) ( mpls-label2 ( any | FLOW_LABEL_VALUE ) | ) ( mpls-
label3 ( any | FLOW_LABEL_VALUE ) | ) | pppoe ppp-type ( ipv4 | ipv6 ) | tcp
( src-port ( range L4_PORT_NUM L4_PORT_NUM | eq L4_PORT_NUM | gt
L4_PORT_NUM | lt L4_PORT_NUM | any ) | dst-port ( range L4_PORT_NUM
L4_PORT_NUM | eq L4_PORT_NUM | gt L4_PORT_NUM | lt L4_PORT_NUM | any ) |
tcp-code ( match-all | match-any ) ( ack | fin | psh | rst | syn | urg ) | ) | udp
( src-port ( range L4_PORT_NUM1 L4_PORT_NUM2 | eq L4_PORT_NUM | gt
L4_PORT_NUM | lt L4_PORT_NUM | any ) | dst-port ( range L4_PORT_NUM1
L4_PORT_NUM2 | eq L4_PORT_NUM | gt L4_PORT_NUM | lt L4_PORT_NUM | any )
| ) | icmp | igmp ) ( src-ip ( IP_ADDR IP_ADDR_WILD | any | host IP_ADDR ) | src-
ipv6 ( IPv6_ADDR IPv6_ADDR_WILD | any | host IPv6_ADDR ) ) ( dst-ip ( IP_ADDR
IP_ADDR_WILD | any | host IP_ADDR ) | dst-ipv6 ( IPv6_ADDR IPv6_ADDR_WILD |
any | host IPv6_ADDR ) ) ( flow-label ( *FLOW_LABEL LABEL _WILD* | any ) | )
( dscp DSCP_VALUE | ip-precedence PRECEDENCE_VALUE ) ( first-fragment | non-
first-fragment | non-fragment | non-or-first-fragment | small-fragment | any-
fragment | ) ( options | ) ( vlan ( VLAN_ID VLAN_WILD | any ) | ) ( inner-vlan
( VLAN_ID VLAN_WILD | any ) | ) ( cos COS_ID | ) ( inner-cos COS_ID | ) ( ether-
type ( ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE | any ) | ) ( src-mac
( ACL_MAC_ADDR ACL_MAC_ADDR_WILD | any | host ACL_MAC_ADDR ) | ) ( dest-
mac ( ACL_MAC_ADDR ACL_MAC_ADDR_WILD | any | host ACL_MAC_ADDR ) | )
( ( ipv4-head | l4-head ) UDF_VALUE UDF_VALUE_WILD UDF_OFFSET | ) | truncation
( LENGTH | )
  
```

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

<p>sequence-num ACL_SEQ_NUM</p>	<p>Specify a sequence number to create the acl rule.</p>	<p>The valid range for sequence number is 1-65535. If the sequence number is not specified, system should automatically assign one number according to the base number and the step length. The base number is the maximum number in the flow (0 for empty flow), the step length is 10.</p>
<p>permit</p>	<p>Specify the action of the acl rule. Use the parameter “permit” to indicate packets match this rule is allowed to forward.</p>	<p>-</p>
<p>deny</p>	<p>Specify the action of the acl rule. Use the parameter “deny” indicating packets match this rule is not allowed to forward.</p>	<p>-</p>

<p> PROTOCOL_NUM any tcp udp icmp igmp gre nvgre </p>	<p>Specify the IP protocol number of the acl rule.</p>	<p> The valid range for IP protocol number is 0-255. Well known IP protocols can also be specified by name. e.g. IP protocol 1 = icmp, 2 = igmp, 6 = tcp, 17 = udp, 47 = gre/nvgre (gre protocol 0x0800 = gre, 0x6558 = nvgre). Parameter “any” indicates packets with any IP protocol can match this rule. </p>
<p> mpls (any label-num (any MPLS_LABEL_NUM_WITHO UT_0) (mpls-label1 (any FLOW_LABEL_VALUE)) (mpls-label2 (any FLOW_LABEL_VALUE)) (mpls-label3 (any FLOW_LABEL_VALUE))) </p>	<p>Specify the mpls label of the flow rule.</p>	<p>The mpls label number is 0-9.It can match 3 layers of MPLS label values at most.</p>
<p>pppoe ppp-type (ipv4 ipv6)</p>	<p>Specify the pppoe ppp-type of the flow rule.</p>	<p>The ppp-type is ipv4 or ipv6.</p>

<pre>src-port (range L4_PORT_NUM L4_PORT_NUM eq L4_PORT_NUM gt L4_PORT_NUM lt L4_PORT_NUM any)</pre>	<p>Specify the layer 4 source port of the acl rule.</p>	<p>The valid range for L4 source port number is 0 - 65535.</p> <p>This field is valid only if the IP protocol is TCP or UDP.</p> <p>There are 4 methods to specify the L4 port:</p> <ol style="list-style-type: none"> 1, eq (equal to) 2, lt (less than) 3, gt (greater than) 4, range <p>Parameter “any” indicates packets with any L4 port can match this rule.</p>
<pre>dst-port (range L4_PORT_NUM L4_PORT_NUM eq L4_PORT_NUM gt L4_PORT_NUM lt L4_PORT_NUM any)</pre>	<p>Specify the layer 4 destination port of the acl rule.</p>	<p>The valid range for L4 destination port number is 0 - 65535.</p> <p>This field is valid only if the IP protocol is TCP or UDP.</p> <p>There are 4 methods to specify the L4 port:</p> <ol style="list-style-type: none"> 1, eq (equal to) 2, lt (less than) 3, gt (greater than) 4, range <p>Parameter “any” indicates packets with any L4 port can match this rule.</p>

<p>src-ip (IP_ADDR IP_ADDR_WILD any host IP_ADDR)</p>	<p>Specify the source IPv4 address of the acl rule.</p>	<p>Use an IPv4 address and an IPv4 address wildcard to specify a network (e.g. 192.168.1.1 0.0.0.255). If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv4 address to specify an exactly address. Use the parameter “any” to indicate packets with any source IPv4 address value can match this rule.</p>
<p>dst-ip (IP_ADDR IP_ADDR_WILD any host IP_ADDR)</p>	<p>Specify the destination IPv4 address of the acl rule.</p>	<p>Use an IPv4 address and an IPv4 address wildcard to specify a network (e.g. 192.168.1.1 0.0.0.255). If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv4 address to specify an exactly address. Use the parameter “any” to indicate packets with any destination IPv4 address value can match this rule.</p>

<p>src-ipv6 (IPv6_ADDR IPv6_ADDR_WILD any host IPv6_ADDR)</p>	<p>Specify the source IPv6 address of the acl rule.</p>	<p>Use an IPv6 address and an IPv6 address wildcard to specify a network. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv6 address to specify an exactly address. Use the parameter “any” to indicate packets with any source IPv6 address value can match this rule.</p>
<p>dst-ipv6 (IPv6_ADDR IPv6_ADDR_WILD any host IPv6_ADDR)</p>	<p>Specify the destination IPv6 address of the acl rule.</p>	<p>Use an IPv6 address and an IPv6 address wildcard to specify a network. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv6 address to specify an exactly address. Use the parameter “any” to indicate packets with any destination IPv6 address value can match this rule.</p>

flow-label (FLOW_LABEL LABEL_WILD any)	Specify the IPv6 Flow label of the acl rule.	Valid range for flow label is 0-1048575. Valid range for flow-label wildcard bits is 0x0-0xFFFF Flow label value and wildcard bits both have 20bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates ipv6 packets with any flow label value can match this rule.
dscp DSCP_VALUE	Specify the DSCP in IPv4 packets value of the acl rule. DSCP = Differentiated Services Code Point. Specify the DSCP in IPv4 packets value of the acl rule. DSCP = Differentiated Services Code Point.	Valid range of DSCP value is 0 - 63.
ip-precedence PRECEDENCE_VALUE	Specify the IP precedence in IPv4 packets of the acl rule. DSCP & ip precedence configurations are exclusive	Valid range of IP precedence value is 0 - 7.
first-fragment	Match packets with first fragment	-

non-first-fragment	Match packets with non-first fragment	-
non-fragment	Match packets with non-fragment	-
non-or-first-fragment	Match packets with non-first fragment	-
small-fragment	Match packets with small fragment	-
any-fragment	Match packets with any fragment	-
options	Match packets with IP options	-
vlan (VLAN_ID VLAN_WILD any)	Specify the outer vlan id of the acl rule.	The valid range for vlan id wildcard bits is 0x0-0xFFF. Vlan id and wildcard bits both have 12bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any outer vlan id can match this rule.

<p>inner-vlan (VLAN_ID VLAN_WILD any)</p>	<p>Specify the inner vlan id of the acl rule.</p>	<p>The valid range for vlan id is 0-4095. The valid range for vlan id wildcard bits is 0x0-0xFFF. Vlan id and wildcard bits both have 12bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any inner vlan id can match this rule.</p>
<p>cos COS_ID</p>	<p>Specify the outer CoS value of the acl rule. CoS = Class of Service. Specify the outer CoS value of the acl rule. CoS = Class of Service.</p>	<p>The valid range of Cos is 0 to 7.</p>
<p>inner-cos COS_ID</p>	<p>Specify the inner CoS value of the acl rule. CoS = Class of Service. Specify the inner CoS value of the acl rule. CoS = Class of Service.</p>	<p>The valid range of Cos is 0 to 7.</p>

<p>ether-type (ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE any)</p>	<p>Specify the ether-type of the acl rule.</p>	<p>The valid range for wildcard bits is 0x600-0xFFFF. Ether-type value and wildcard bits both have 16bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any ethertype value can match this rule.</p>
<p>src-mac (ACL_MAC_ADDR ACL_MAC_ADDR_WILD any host ACL_MAC_ADDR)</p>	<p>Specify the source mac address in HHHH.HHHH.HHHH format.</p>	<p>Use a mac address and wildcard bits to specify a batch of mac addresses. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and a mac address to specify an exact mac address. Use the parameter “any” to indicate packets with any source mac address value can match this rule.</p>

<pre> dest-mac (ACL_MAC_ADDR ACL_MAC_ADDR_WILD any host ACL_MAC_ADDR) </pre>	<p>Specify the destination mac address in HHHH.HHHH.HHHH format.</p>	<p>Use a mac address and wildcard bits to specify a batch of mac addresses. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.</p> <p>Use the parameter “host” and a mac address to specify an exact mac address.</p> <p>Use the parameter “any” to indicate packets with any destination mac address value can match this rule.</p>
<pre> (ipv4-head l4-head) UDF_VALUE UDF_VALUE_WILD UDF_OFFSET </pre>	<p>UDF = User Define Format.</p> <p>The parameter “ipv4-head” indicates the packet is parsed at the beginning with the IPv4 header.</p> <p>The parameter “l4-head” indicates the packet is parsed at the beginning with the layer4 header.</p>	<p>UDF value and wildcard bits both have 32 bits, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.</p> <p>The parameter “UDF_OFFSET” specifies the offset bits from the beginning. The valid range of the offset is 0 -60.</p>

truncation (LENGTH)	Use this parameter to truncate the packets matched this rule.	Set the packets length after truncation support different truncation length is 14, the value between 64 and 144.The length of truncation is configured by the “truncation” command in global configuration mode if not config it
-------------------------	---	--

Command Mode

ACL Configuration

Default

None

Usage

Wildcard bits in this command are used as reversed. That means value and wildcard bits have same length, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.

E.g.: ip address 10.10.10.0 wildcard 0.0.0.255 means 256 ip addresses from 10.10.10.0 to 10.10.10.255.

Layer 4 information (e.g. tcp/udp port) and fragment information are exclusive.

Examples

Create a rule with sequence number 10:

```
Switch(config)# ip access-list acl1
Switch(config-acl-acl1)# sequence-num 10 permit any src-ip 10.10.10.0 0.0.0.255
dst-ip any
```


Related Commands

no sequence-num
show ip access-list

8.8 egress

Command Purpose

Use this command to apply IPv4 access list on the outbound direction of an interface

Use the no form of this command to remove the IPv4 access list.

Command Syntax

egress *NAME_STRING*

no egress

Parameter	Parameter Description	Parameter Value
NAME_STRING	IP access-list name string	IP access-list name string, which should begin with a-z/A-Z/0-9, valid characters are 0-9/A-Z/a-z, maximum length is 20 characters.

Command Mode

Interface Configuration

Default

None

Usage

This command supports physical or link aggregation interfaces.

Examples

The example shows how to apply the access list f1 to egress direction eth-0-9:

```
Switch(config)# interface eth-0-19  
Switch(config-if-eth-0-19)# egress f1
```

Related Commands

ip access-list

9 TAP Commands

9.1 tap-group

Command Purpose

Use this command to create a TAP group and enter the tap configuration mode.

Use the no form of this command to delete the TAP group.

Command Syntax

tap-group *TAPNAME* (*NUM* |)

no tap-group *TAPNAME*

Parameter	Parameter Description	Parameter Value
TAPNAME	Tap Group Name string	Begin with a-z/A-Z, valid characters are 0-9/A-Z/a-z, maximum length is 20 characters.
NUM	Tap Group ID, range 1-10000	1-10000

Command Mode

Global Configuration

Default

None

Usage

This device supports at most 512 TAP groups.

Examples

The following example shows how to add an egress-interface agg1:

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)#
```

The following example shows how to delete a tap-group:

```
Switch(config)# no tap-group tap1
```

Related Commands

show tap-group

9.2 description

Command Purpose

Use this command to set the description of the TAP group.

Use the no form of this command to delete the description.

Command Syntax

description *LINE*

no description

Parameter	Parameter Description	Parameter Value
LINE	TAP group description string	Begin with a-z/A-Z, valid characters are 0-9/A-Z/a-z, maximum length is 80 characters

Command Mode

tap-group Configuration

Default

None

Usage

None

Examples

The following example shows how to config description:

```
Switch(config)# tap-group test001
Switch(config-tap-test001)# description test
Switch(config-tap-test001)#
```

Related Commands

tap-group

show tap-group

9.3 ingress

Command Purpose

Use this command to add a physical, link aggregation interface, iloop interface or port-group to the ingress direction of the TAP group.

This command can add/delete vlan and edit actions to the packets.

Use the no form of this command to remove the interface.

Command Syntax

```
ingress ( IF_NAME | range IF_NAME_LIST ) ( un-tag | un-tag-outer-vlan | un-tag-
inner-vlan | mark-source VLAN_ID | ) ( truncation | ) ( edit-macda MAC_ADDRESS | )
( edit-macsa MAC_ADDRESS | ) ( edit-ipsa IP_ADDRESS | ) ( edit-ipda IP_ADDRESS | )
( edit-ipv6sa IPv6_ADDRESS | ) ( edit-ipv6da IPv6_ADDRESS | ) ( edit-vlan VLAN_ID
| )
```

```
no ingress ( IF_NAME | range IF_NAME_LIST )
```

ingress (*IF_NAME* | *PORTGROUP_NAME* | range *IF_NAME_LIST*) flow *FLOW_NAME*

no ingress (*IF_NAME* | *PORTGROUP_NAME* | range *IF_NAME_LIST*) flow *FLOW_NAME*

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name. This command supports physical interface, iloop interface or link aggregation interface.	-
PORTGROUP_NAME	Specify the name of port-group.	The first character should be a-z or A-Z, character only can be 0-9/A-Z/a-z and the max length is 31.
range IF_NAME_LIST	Interface range, with “,” or “-” to distinguish the interface range set. Supports physical interface, and link aggregation interface.	The ‘-’ is range interface symbol, The ‘,’ is division symbol
un-tag	Remove vlan tags of the packets.	-
un-tag-outer-vlan	Remove outer vlan tag of the packets.	-
un-tag-inner-vlan	Remove inner vlan tag of the packets.	-
mark-source VLAN_ID	Specify additional outer vlan id of the outgoing packets.	Specify additional outer vlan id of the outgoing packets. The valid range for vlan id is 1 - 4094.

truncation	To truncate the packet.	-
edit-macda MAC_ADDRESS	Specify the destination mac address of the outgoing packets.	Specify the destination mac address of the outgoing packets in HHHH.HHHH.HHHH format.
edit-macsa MAC_ADDRESS	Specify the source mac address of the outgoing packets.	Specify the source mac address of the outgoing packets in HHHH.HHHH.HHHH format.
edit-ipsa IP_ADDRESS	Specify the source IP address of the outgoing packets.	Specify the source IP address of the outgoing packets in A.B.C.D format.
edit-ipda IP_ADDRESS	Specify the destination IP address of the outgoing packets.	Specify the destination IP address of the outgoing packets in A.B.C.D format.
edit-vlan VLAN_ID	Specify the vlan id of the outgoing packets.	The valid range for vlan id is 1 - 4094.
edit-ipv6sa IPv6_ADDRESS	Specify the source IPv6 address of the outgoing packets.	::- ffff:ffff:ffff:ffff:ffff:ffff:ff:ffff
edit-ipv6da IPv6_ADDRESS	Specify the destination IPv6 address of the outgoing packets.	::- ffff:ffff:ffff:ffff:ffff:ffff:ff:ffff
flow FLOW_NAME	Specify the name of flow to apply to tap group's ingress direction.	-

Command Mode

tap-group Configuration

Default

None

Usage

One interface without configuring a flow can only add to one TAP group.

The same interface with and without configuring a flow cannot exist in one TAP group.

Examples

The following example shows how to add an ingress-interface with mark-source 100:

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress eth-0-1 mark-source 100
Switch(config-tap-tap1)#
```

The following example shows how to add an ingress-interface with un-tag:

```
Switch(config)# tap-group tap1
Switch(config-tap-test001)# ingress eth-0-1 un-tag
Switch(config-tap-test001)#
```

The following example shows how to add interface eth-0-1,eth-0-2,eth-0-4:

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress range eth-0-1-2,eth-0-4
Switch(config-tap-tap1)#
```

The following example shows how to add an ingress-interface with flow flow001:

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress eth-0-1 flow flow001
Switch(config-tap-tap1)#
```

The following example shows how to add an ingress interface agg1:

```
Switch(config)# interface eth-0-2
Switch(config-if-eth-0-2)# static-channel-group 1
Switch(config-if-eth-0-2)# exit
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress agg1
```

The following example shows how to add an ingress interface agg1 with flow flow001:

```
Switch(config)# interface eth-0-2
Switch(config-if-eth-0-2)# static-channel-group 1
Switch(config-if-eth-0-2)# exit
```



```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress agg1 flow flow001
```

The following example shows how to add an ingress interface iloop1:

```
Switch(config)# interface iloop1
Switch(config-if-iloop1)# exit
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress iloop1
```

The following example shows how to add an ingress interface iloop1 with flow flow001:

```
Switch(config)# interface iloop1
Switch(config-if-iloop1)# exit
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress iloop1 flow flow001
```

The following example shows how to add an ingress port-group portgroup1 with flow flow001:

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress portgroup1 flow flow001
```

Related Commands

tap-group

egress

9.4 egress

Command Purpose

Use this command to add a physical, link aggregation interface, iloop interface to the egress direction of the TAP group.

Use the no form of this command to remove the interface.

Command Syntax

egress (*IF_NAME* | range *IF_NAME_LIST*) (timestamp |)

no egress (*IF_NAME* | range *IF_NAME_LIST*)

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

IF_NAME	Specify the interface name. This command supports physical interface, link aggregation interface or iloop interface.	-
range IF_NAME_LIST	Interface range, with “,” or “-” to distinguish the interface range set. Supports physical interface, and link aggregation interface.	The ‘-’ is range interface symbol, The ‘,’ is division symbol
timestamp	Add timestamp for packets on egress interfaces.	-

Command Mode

tap-group Configuration

Default

None

Usage

None

Examples

The following example shows how to add an egress-interface eth-0-9:

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# egress eth-0-9
```

The following example shows how to add interface eth-0-1,eth-0-2,eth-0-4 on egress direction:

```

Switch(config)# tap-group tap1
Switch(config-tap-tap1)# egress range eth-0-1-2,eth-0-4
Switch(config-tap-tap1)#
  
```

The following example shows how to add an egress-interface agg1:

```

Switch(config)# interface eth-0-10
Switch(config-if-eth-0-10)# static-channel-group 1
Switch(config)# interface eth-0-11
Switch(config-if-eth-0-11)# static-channel-group 1
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# egress agg1
  
```

The following example shows how to add an egress-interface iloop1:

```

Switch(config)# interface iloop1
Switch(config-if-iloop1)# exit
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# egress iloop1
  
```

Related Commands

tap-group

9.5 show tap-group

Command Purpose

This command displays the TAP group configurations.

Command Syntax

show tap-group (*TAPNAME* |)

Parameter	Parameter Description	Parameter Value
TAPNAME	Specify a TAP group name to display. If the parameter "TAPNAME" is not specified, the command indicates that all TAP groups on this device should be displayed.	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows the configuration of tap-group:

```
Switch# show tap-group

truncation          : 144
timestamp-over-ether : 0000.0000.0000 0000.0000.0000 0x0000
TAP-group tap1
  ID: 1
  Ingress:
    eth-0-1      flow f1
  Egress:
    eth-0-9
TAP-group tap2
  ID: 2
  Ingress:
    eth-0-21
  Egress:
    eth-0-22
```

Related Commands

tap-group

ingress

10 **TIMESTAMP Commands**

10.1 timestamp-over-ether

Command Purpose

Use this command to configure the TAP timestamp outer header information.

Use the no form of this command to remove the TAP timestamp configuration.

Command Syntax

timestamp-over-ether *MAC_ADDR_DA MAC_ADDR_SA ETHTYPE_ID*

no timestamp-over-ether

Parameter	Parameter Description	Parameter Value
MAC_ADDR_DA	Ethernet destination MAC address	MAC address in HHHH.HHHH.HHHH format, valid range is 0.0.0-FFFF.FFFF.FFFF
MAC_ADDR_SA	Ethernet source MAC address	MAC address in HHHH.HHHH.HHHH format, valid range is 0.0.0-FFFF.FFFF.FFFF
ETHTYPE_ID	Ethertype in hexadecimal	range is [0x0-0xffff]

Command Mode

Global Configuration

Default

None

Usage

TAP timestamp is a global configuration. TAP timestamp MUST be configured before using the TAP groups.

Examples

The following example shows how to configure timestamp-over-ether:

```
Switch# configure terminal
Switch(config)# timestamp-over-ether 1.1.1 2.2.2 0xff12
```

The following example shows how add timestamp for packets going out from tap1/interface eth-0-10:

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress eth-0-1
Switch(config-tap-tap1)# egress eth-0-10 timestamp
Switch(config-tap-tap1)# exit
```

Related Commands

tap-group

egress

10.2 show timestamp sync

Command Purpose

Use this command configure to display timestamp sync information.

Command Syntax

```
show timestamp sync
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display timestamp information:

```
Switch# show timestamp sync

Sync Type       : Disabled
Sync Count      : 0
Last Sync Time  : Tue Sep 12 07:57:08 2017
```

Related Commands

timestamp sync

10.3 timestamp sync

Command Purpose

Use this command configure to timestamp sync.

Use the no form of this command to restore the default value.

Command Syntax

timestamp sync (systime | none)

no timestamp sync

Parameter	Parameter Description	Parameter Value
systime	Use the system time as time source.	-
none	Use the chip time as time source.	-

Command Mode

Global Configuration

Default

The default value is “none”

Usage

None

Examples

The following example shows how to config timestamp sync:

```
Switch(config)# timestamp sync systemtime
```

Related Commands

show timestamp sync

11 TRUNCATION Commands

11.1 truncation

Command Purpose

Use this command to configure the truncation length information.

Use the no form of this command to restore the default value.

Command Syntax

truncation *TRUNCATION_LEN*

no truncation

Parameter	Parameter Description	Parameter Value
TRUNCATION_LEN	Truncation length in bytes.	Valid range is 64-9600.

Command Mode

Global Configuration

Default

144

Usage

CRC should be re-calculating after packet is truncated. The truncation length include CRC field.

Examples

The following example shows how to set truncation length as 64:

```
Switch(config)# truncation 64
```

The following example shows how to use truncation in TAP group:

```
Switch(config)# tap-group tap1  
Switch(config-tap-tap1)# ingress eth-0-1 truncation  
Switch(config-tap-tap1)# egress eth-0-10
```

Related Commands

tap-group

ingress

12 SSH Commands

12.1 ssh

Command Purpose

In privileged mode, use this command to log in remote ssh server.

Command Syntax

```
ssh -l NAME_STRING ( -i RSAKEYNAME | ) ( -p L4_PORT_NUM | ) ( -v ( 1 | 2 ) | ) ( -c ( 3des | des | 3des-cbc | aes128-cbc | aes192-cbc | aes256-cbc ) | ) ( -m ( hmac-md5-128 | hmac-md5-96 | hmac-sha1-160 | hmac-sha1-96 ) | ) ( -o number-of-password-prompts SSHPINPROMPTS | ) ( mgmt-if | ) ( IP_ADDR | STRING )
```

Parameter	Parameter Description	Parameter Value
NAME_STRING	Login name	-
RSAKEYNAME	Specify key name	-
L4_PORT_NUM	Remote ssh server port	range is <0-65535>
SSHPINPROMPTS	Number of password prompts	range is <1-7>
IP_ADDR STRING	Specify IP address of remote system /Specify hostname of remote system	-

Command Mode

Privileged EXEC

Default

Version default is 2

Usage

None

Examples

The following example shows how to establish connection by ssh:

```
Switch# ssh -l aaa 1.1.1.1  
aaa@1.1.1.1's password:  
Switch#
```

Related Commands

ip ssh server enable

12.2 ip ssh server enable

Command Purpose

In global mode, use this command to start ssh server.

Command Syntax

ip ssh server enable

Command Mode

Global Configuration

Default

Enabled

Usage

None

Examples

The following example enables the SSH server:

```
Switch(config)# ip ssh server enable
```

Related Commands

ip ssh server disable

12.3 ip ssh server disable

Command Purpose

In global mode, use this command to disable ssh server.

Command Syntax

ip ssh server disable

Command Mode

Global Configuration

Default

Enabled

Usage

None

Examples

The following example disable the SSH server:

```
Switch(config)# ip ssh server disable
```

Related Commands

ip ssh server enable

12.4 ip ssh server version

Command Purpose

In global configuration mode, use this command to configure Secure Shell (SSH) version on your switch.

Use the no form of this command to restore the default value.

Command Syntax

ip ssh server version (v1 | v2 | all)

no ip ssh server version

Parameter	Parameter Description	Parameter Value
v1	Support SSH version 1	-
v2	Support SSH version 2	-
all	Support SSH version 1 and 2	-

Command Mode

Global Configuration

Default

V2

Usage

SSH server and client will negotiate about the version when connecting. Server and client should select a higher version both supported.

Examples

The following example shows how to configure support SSH Version 1:

```
Switch(config)# ip ssh server version v1
```

The following example shows how to restore the default configuration:

```
Switch(config)# no ip ssh server version
```

Related Commands

show ip ssh server status

12.5 ip ssh server authentication-retries

Command Purpose

Use this command to set retry times when log in remote ssh server failed.

Use the no form of this command to reset retry times to default value.

Command Syntax

ip ssh server authentication-retries *SSHAUTHRETRIES*

no ip ssh server authentication-retries

Parameter	Parameter Description	Parameter Value
SSHAUTHRETRIES	Retry times	Range is <1-6>

Command Mode

Global Configuration

Default

6

Usage

None

Examples

The following examples configures SSH authentication retry times on your switch:

```
Switch(config)# ip ssh server authentication-retries 3
```

The following examples restore SSH authentication retry times to the default value:

```
Switch(config)# no ip ssh server authentication-retries
```

Related Commands

show ip ssh server status

12.6 ip ssh server authentication-timeout

Command Purpose

In global configuration mode, use this command to configure Secure Shell (SSH) authentication timeout on your switch.

Use the no form of this command to restore the default value of Secure Shell (SSH) authentication timeout on your switch

Command Syntax

ip ssh server authentication-timeout *SSHAUTHTIMEOUT*

no ip ssh server authentication-timeout

Parameter	Parameter Description	Parameter Value
SSHAUTHTIMEOUT	Timeout seconds	Range is <1-120>, unit is seconds

Command Mode

Global Configuration

Default

120

Usage

None

Examples

The following examples configures SSH authentication timeout on your switch:

```
Switch(config)# ip ssh server authentication-timeout 100
```

The following examples restore SSH authentication timeout to default value:

```
Switch(config)# no ip ssh server authentication-timeout
```

Related Commands

show ip ssh server status

12.7 ip ssh server authentication-type

Command Purpose

In global configuration mode, use this command to configure Secure Shell (SSH) authentication type.

Use the no form of this command to restore the default value of Secure Shell (SSH) authentication type.

Command Syntax

```
ip ssh server authentication-type ( all | ( password | public-key | rsa ) )
```

```
no ip ssh server authentication-type
```

Parameter	Parameter Description	Parameter Value
all	Enable all authentication type	-
password	Enable password	-
public-key	Enable public key	-

rsa	Enable rsa	-
-----	------------	---

Command Mode

Global Configuration

Default

Public-key and password

Usage

When logging in using SSH, the authentication mode will be negotiated at the beginning of establishing connection reply.

Examples

The following example configures SSH authentication type to password:

```
Switch(config)# ip ssh server authentication-type password
```

The following example restore SSH authentication type to default value:

```
Switch(config)# no ip ssh server authentication-type
```

Related Commands

show ip ssh server status

12.8 ip ssh server rekey-interval

Command Purpose

In global configuration mode, use this command to configure Secure Shell (SSH) rekey interval.

Use the no form of this command to restore the default value of Secure Shell (SSH) rekey interval.

Command Syntax

ip ssh server rekey-interval *SSHREKEYINTVL*

no ip ssh server rekey-interval

Parameter	Parameter Description	Parameter Value
SSHREKEYINTVL	Rekey interval in minutes	Range is <1-1440>

Command Mode

Global Configuration

Default

60

Usage

None

Examples

The following example configures SSH rekey interval to 30:

```
Switch(config)# ip ssh server rekey-interval 30
```

The following example restore SSH rekey interval to default value:

```
Switch(config)# no ip ssh server rekey-interval
```

Related Commands

show ip ssh server status

12.9 ip ssh server host-key

Command Purpose

In global configuration mode, use this command to configure Secure Shell (SSH) host-key.

Use the no form of this command to restore the default value of Secure Shell (SSH) host-key.

Command Syntax

```
ip ssh server host-key rsa key RSAKEYNAME
```

```
no ip ssh server host-key
```

Parameter	Parameter Description	Parameter Value
RSAKEYNAME	Key Name	=Y27

Command Mode

Global Configuration

Default

None

Usage

Host-key is used to generate session when establishing connection.

Examples

The following example shows how to configure SSH host key:

```
Switch(config)# ip ssh server host-key rsa key KEY1
```

The following example shows how to remove SSH host key:

```
Switch(config)# no ip ssh server host-key
```

Related Commands

```
show ip ssh server status
```

12.10 ip ssh server port

Command Purpose

Use this command to configure ssh service port.

Command Syntax

```
ip ssh server port SERVICE_PORT
```

```
no ip ssh server port
```

Parameter	Parameter Description	Parameter Value
SERVICE_PORT	port number	Range is 1025-65535

Command Mode

Global Configuration

Default

22

Usage

When change ssh service port, all users must be forced to disconnect.

Examples

The following example configures port number:

```
Switch# configure terminal
Switch(config)# ip ssh server port 2000
```

The following example recovers ssh port to default port:

```
Switch# configure terminal
Switch(config)# no ip ssh server port
```

Related Commands

None

12.11 ip ssh server acl

Command Purpose

Use this command to configure ssh service acl.

Command Syntax

ip ssh server acl *ACL_NAME*

no ip ssh server acl

Parameter	Parameter Description	Parameter Value
ACL_NAME	IP ACL NAME	The initial character name should be a-z/A-Z/0-9, character only can be 0-9/A-Z/a-z and the max length is 20

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example sets ssh service acl:

```
Switch# configure terminal
Switch(config)# ip access-list sac101
Switch(config-ip-acl-sac101)# exit
Switch(config)# ip ssh server acl sac101
```

The following example delete ssh service acl:

```
Switch# configure terminal  
Switch(config)# no ip ssh server acl
```

Related Commands

None

12.12 show ip ssh server status

Command Purpose

In privileged mode, use this command to show information of SSH.

Command Syntax

```
show ip ssh server status
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows information of ssh server:

```
Switch# show ip ssh server status  
  
SSH server enabled  
Version: v2  
Authentication timeout: 33 second(s)  
Authentication retries: 6 time(s)  
Server key lifetime: 60 minute(s)  
Authentication type: password, public-key
```

Related Commands

ssh

13 LACP Commands

13.1 port-channel load-balance-mode

Command Purpose

Use this command to set port-channel load balance mode from static to round-robin.

Use the no form of this command to set port-channel load balance mode to default static mode.

Command Syntax

port-channel *AGG_GID* load-balance-mode round-robin

no port-channel *AGG_GID* load-balance-mode

Parameter	Parameter Description	Parameter Value
AGG_GID	Channel group ID	Range is <1-55>

Command Mode

Global Configuration

Default

Disabled

Usage

None

Examples

The following example shows how to set port-channel load balance mode to round-robin:

```
Switch(config)# port-channel 9 load-balance-mode round-robin
```

The following example shows how to set port-channel load balance mode to the default:

```
Switch(config)# no port-channel 9 load-balance-mode
```

Related Commands

None

13.2 port-channel self-healing

Command Purpose

Use this command to set port-channel self-healing mode. Use the no form of this command to set port-channel to default static mode.

Command Syntax

port-channel *AGG_GID* self-healing

no port-channel *AGG_GID* self-healing

Parameter	Parameter Description	Parameter Value
AGG_GID	Channel group ID	Range is <1-16>

Command Mode

Global Configuration

Default

Disabled

Usage

None

Examples

The following example shows how to set port-channel self-healing mode:

```
Switch(config)# port-channel 1 self-healing
```

The following example shows how to set port channel to default mode:

```
Switch(config)# no port-channel 1 self-healing
```

Related Commands

None

13.3 show channel-group

Command Purpose

Use show channel-group summary command to display a summary of all the channel groups, or a specified channel group.

Use show channel-group detail command to display detailed information of all the channel groups, or a specified channel group.

Use show channel-group port command to display port information of all the channel groups, or a specified channel group.

Command Syntax

```
show channel-group ( AGG_GID | ) ( summary | detail | port | backup-ports )
```

Parameter	Parameter Description	Parameter Value
AGG_GID	Channel group ID	Range is <1-55>

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display detailed information of the channel group 10:

```

Switch# show channel-group 10 detail

Group: 10
-----
Mode          : switch
Ports         : 2           Maxports : 16
Bundle Ports  : 0
Protocol      : static

Port          : eth-0-3
-----
State         : Down Out-Bundle
Channel group : 10
Protocol      : static
Port index    : 3

Port          : eth-0-4
-----
State         : Down Out-Bundle
Channel group : 10
Protocol      : static
Port index    : 4
  
```

The following example shows how to display information of all channel groups:

```

Switch# show channel-group summary

Flags:  s - suspend           T - standby
        w - wait             B - in Bundle
        R - Layer3           S - Layer2
        D - down/admin down  U - in use

Mode:   SLB - static load balance
        DLB - dynamic load balance
        RR  - round robin load balance

Aggregator Mode Protocol Ports
-----+-----+-----+-----
  
```

```

agg5 (SD)    SLB  Static  eth-0-5 (D)
agg10 (SD)  SLB  Static  eth-0-3 (D)    eth-0-4 (D)
  
```

The following example shows how to display information of the channel group 10:

```

Switch# show channel-group 10 summary

port-channel load-balance hash-arithmetic: xor
port-channel load-balance tunnel-hash-mode: both
Port-channel load-balance hash-field-select:
  src-ip dst-ip src-port-l4 dst-port-l4
Flags:  s - suspend           T - standby
        w - wait             B - in Bundle
        R - Layer3           S - Layer2
        D - down/admin down  U - in use
Mode:   SLB - static load balance
        DLB - dynamic load balance
        RR  - round robin load balance
Aggregator Mode Protocol Ports
-----+---+-----+-----
agg10 (SD)  SLB  Static  eth-0-3 (D)    eth-0-4 (D)
  
```

Related Commands

`static-channel-group`

13.4 show channel-group interface

Command Purpose

Use this command to display link aggregation information for the port.

Command Syntax

`show channel-group interface IF_NAME`

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name to show	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display link aggregation information for the specified port:

```
Switch# show channel-group interface eth-0-3

Port          : eth-0-3
-----
State         : Down Out-Bundle
Channel group : 10
Protocol      : static
Port index    : 3
```

Related Commands

static-channel-group

14 NTP Commands

14.1 ntp minimum-distance

Command Purpose

In global configuration mode, use this command to configure the minimum distance between the switch and the NTP server.

Use the no form of this command to restore default ntp minimum distance configures.

Command Syntax

ntp minimum-distance *NTP_MIN_DISP*

no ntp minimum-distance

Parameter	Parameter Description	Parameter Value
NTP_MIN_DISP	Distance value time interval in milliseconds	Range is <1-1000>

Command Mode

Global Configuration

Default

1ms

Usage

None

Examples

The following example shows how to configure minimum distance to 1000ms:

```
Switch(config)# ntp minimum-distance 1000
```

The following example shows how to configure minimum distance to default:

```
Switch(config)# no ntp minimum-distance
```

Related Commands

show ntp status

14.2 ntp server

Command Purpose

Use this command to allow the software clock to be synchronized by a Network Time Protocol (NTP) time server.

Use the no form of this command to delete the NTP server

Command Syntax

```
ntp server mgmt-if IP_ADDR ( key NTP_KEYID | ) ( version NTP_VERSION | ) ( prefer | )
```

```
no ntp server IP_ADDR
```

Parameter	Parameter Description	Parameter Value
IP_ADDR	IP address of the time server or peer	-
NTP_KEYID	Authentication key to use when sending packets to this peer	Range is <1-64000>
NTP_VERSION	Defines the Network Time Protocol (NTP) version number	Range is <1-3>

prefer	Makes this peer the preferred peer that provides synchronization	-
--------	--	---

Command Mode

Global Configuration

Default

Not synchronized with any NTP server

Usage

None

Examples

The following example shows how to configure ntp server ip as 172.16.22.44, the version of NTP as 2:

```
Switch(config)# ntp server mgmt-if 172.16.22.44 version 2
```

The following example shows how to remove ntp server:

```
Switch(config)# no ntp server 172.16.22.44
```

Related Commands

show ntp status

14.3 ntp authentication

Command Purpose

Use the ntp authentication enable command to enable NTP authentication.

Use the ntp authentication disable command disable the NTP authentication.

Command Syntax

ntp authentication (enable | disable)

Command Mode

Global Configuration

Default

Disabled

Usage

When NTP authentication is enabled, the switch will synchronize the time with NTP servers with trusted key only.

For more information about trusted key, please see the “ntp trustedkey” command.

Examples

The following example shows how to enable NTP authentication:

```
Switch(config)# ntp authentication enable
```

Related Commands

show ntp

14.4 ntp key

Command Purpose

Use this command to create a value for a NTP key.

Use the no form of the command to remove the value of the NTP key.

Command Syntax

ntp key *NTP_KEYID* *KEY_STRING*

no ntp key *NTP_KEYID*

Parameter	Parameter Description	Parameter Value
NTP_KEYID	Authentication key ID	Range is <1-64000>
KEY_STRING	The value of the key	-

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example shows how to create a ntp key:

```
Switch(config)# ntp key 123 key123
```

The following example shows how to remove a ntp key:

```
Switch(config)# no ntp key 123
```

Related Commands

show ntp key

14.5 ntp trustedkey

Command Purpose

Use this command to authenticate the identity of a system to which Network Time Protocol (NTP) will synchronize.

Use the no form of this command to disable authentication of the identity of the system.

Command Syntax

`ntp trustedkey NTP_KEYID`

`no ntp trustedkey NTP_KEYID`

Parameter	Parameter Description	Parameter Value
NTP_KEYID	Authentication key to use when sending packets to this peer	Range is <1-64000>

Command Mode

Global Configuration

Default

None

Usage

If authentication is enabled, use this command to define one or more key numbers (corresponding to the keys defined with the `ntp key` command) that a peer NTP system must provide in its NTP packets, for this system to synchronize to it. This function provides protection against accidentally synchronizing the system to a system that is not trusted, because the other system must know the correct authentication key.

Examples

The following example shows how to configure the system to synchronize only to systems providing authentication key 123:

```
Switch(config)# ntp trustedkey 123
```

The following example shows how to disable authentication of the identity of the system:

```
Switch(config)# no ntp trustedkey 123
```

Related Commands

ntp key

14.6 show ntp

Command Purpose

Use this command to display NTP configuration.

Command Syntax

```
show ntp
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the NTP configurations:

```
Switch# show ntp

Unicast peer or server:
1.1.1.1 server
10.1.1.23 key 43 version 2 prefer server
10.10.25.8 server
172.16.22.44 version 2 server
192.16.22.44 version 2 server
Authentication: enabled
Local reference clock:
```

Related Commands

ntp server

14.7 show ntp status

Command Purpose

Use this command to display current NTP status.

Command Syntax

show ntp status

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display ntp status:

```
Switch# show ntp status

system peer          : 10.10.25.8
system peer mode     : client
leap indicator       : 00
stratum              : 5
precision            : -19
root distance        : 0.30511 s
minimum distance     : 0.00099 s
selection threshold  : 1.50000 s
root dispersion      : 0.28767 s
reference ID         : (10.10.25.8|)
reference time       : dd6e331f.6a9c7b92 Thu, Sep 21 2017 20:46:23.416
system flags         : auth monitor ntp kernel stats
```

```
jitter           : 0.000000 s  
stability        : 18.062 ppm  
broadcastdelay   : 3.000000 s  
authdelay        : 0.000000 s
```

Related Commands

`ntp minimum-distance`

14.8 show ntp statistics

Command Purpose

Use this command to display ntp statistics.

Command Syntax

`show ntp statistics`

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display ntp statistics:

```
Switch# show ntp statistics  
  
time since reset      :18748  
receive buffers       :10  
free receive buffers  :9  
used receive buffers  :0  
low water refills     :1  
dropped packets      :0
```

```
ignored packets      :0
received packets     :333
packets sent         :545
packets not sent     :0
interrupts handled   :19081
received by int      :333
```

Related Commands

ntp server
clear ntp statistics

14.9 show ntp associations

Command Purpose

Use this command to display the neighbor state of NTP.

Command Syntax

```
show ntp associations
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows the status of NTP associations:

```
Switch# show ntp associations

* synced,          + symmetric active mode, - symmetric passive mode,
= client mode,    ^ broadcast mode,          ~ broadcast client mode
```


remote	local	st	poll	reach	delay	offset	disp
=172.16.22.44	169.254.2.1	16	1024	0	0.000000	0.000000	3.99217
=10.1.1.23	169.254.2.1	16	1024	0	0.000000	0.000000	3.99217
=192.16.22.44	169.254.2.1	16	1024	0	0.000000	0.000000	3.99217
*10.10.25.8	169.254.2.1	4	128	377	0.00031	0.067999	0.09810
=1.1.1.1	169.254.2.1	16	1024	0	0.000000	0.000000	3.99217

Related Commands

ntp server

14.10 show ntp key

Command Purpose

Use this command to display NTP key.

Command Syntax

show ntp key

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows the keys of NTP:

```

Switch# show ntp key

Current NTP key configuration:
-+-----+-----+-----+-----+-----+-----+-----+-----+

```

```
43      key43
123     key123
```

Related Commands

ntp key

14.11 clear ntp statistics

Command Purpose

Use this command to clear NTP statistics.

Command Syntax

```
clear ntp statistics
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to clear ntp statistics:

```
Switch# clear ntp statistics
```

Related Commands

show ntp statistics

15 NETWORK DIAGNOSIS Commands

15.1 ping

Command Purpose

Use this command to check whether a specific IPv4 address is available through the management interface.

Command Syntax

ping mgmt-if (-b |) *WORD*

Parameter	Parameter Description	Parameter Value
mgmt-if	Send packet from management interface	-
-b	To check a broadcast address	-
WORD	Ping destination address	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to check whether 10.10.38.160 is available:

```
Switch# ping mgmt-if 10.10.38.160

PING 10.10.38.160 (10.10.38.160) 56(84) bytes of data.
64 bytes from 10.10.38.160: icmp_seq=1 ttl=64 time=0.513 ms
64 bytes from 10.10.38.160: icmp_seq=2 ttl=64 time=0.229 ms
64 bytes from 10.10.38.160: icmp_seq=3 ttl=64 time=0.261 ms
64 bytes from 10.10.38.160: icmp_seq=4 ttl=64 time=0.265 ms
64 bytes from 10.10.38.160: icmp_seq=5 ttl=64 time=0.387 ms

--- 10.10.38.160 ping statistics ---
5 packets transmitted, 5 received, 0% packet loss, time 3999ms
rtt min/avg/max/mdev = 0.229/0.331/0.513/0.105 ms
```

Related Commands

traceroute

15.2 traceroute

Command Purpose

Use this command to show the path from the current device to the destination device.

Command Syntax

traceroute mgmt-if *WORD*

Parameter	Parameter Description	Parameter Value
mgmt-if	Send packet from management interface	-
WORD	Traceroute destination address	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to show the path from current device to 10.108.1.29:

```
Switch# traceroute mgmt-if 10.108.1.29

traceroute to 10.108.1.29 (10.108.1.29), 30 hops max, 38 byte packets
 1  10.108.1.27 (10.108.1.27)  2998.076 ms !H  3000.361 ms !H  3007.748 ms !H
```

Related Commands

ping

16 MONITOR CAPTURE Commands

16.1 monitor-capture global

Command Purpose

Use this command to enter monitor-capture global mode.

Command Syntax

```
monitor-capture global
```

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example shows how to enter monitor-capture global:

```
Switch(config)# monitor-capture global  
Switch(config-capture)#
```

Related Commands

None

16.2 monitor-capture packet

Command Purpose

Use this command to set monitor-capture attribute.

Command Syntax

monitor-capture packet ((length *LEN*) | (number *NUM*) | (time *TIME*))

Parameter	Parameter Description	Parameter Value
length <i>LEN</i>	The Truncation length of packet	64-144
number <i>NUM</i>	The total capture of monitor capture. Auto stop when capture assign packet number	1-1000
time <i>TIME</i>	The time of monitor capture packet, auto stop when time-out	1-120

Command Mode

Monitor-capture Configuration

Default

no-limit

Usage

None

Examples

The following example shows how to set monitor capture truncation length:

```
Switch(config)# monitor-capture global
Switch(config-capture)# monitor-capture packet length 64
```

The following example shows how to set total number of monitor capture packet:

```
Switch(config)# monitor-capture global
Switch(config-capture)# monitor-capture packet number 10
```

The following example shows how to set time of monitor capture:

```
Switch(config)# monitor-capture global
Switch(config-capture)# monitor-capture packet time 60
```

Related Commands

None

16.3 monitor-capture input

Command Purpose

Use this command to set capture source node on ingress direction

Command Syntax

monitor-capture input *IF_NAME* ((flow *FLOW_NAME*) |)

Parameter	Parameter Description	Parameter Value
IF_NAME	interface name support phy port, agg port, port group	-
flow FLOW_NAME	flow name	-

Command Mode

Monitor-capture Configuration

Default

None

Usage

None

Examples

The following example shows how to set capture packet of input on interface eth-0-1:

```
Switch(config)# monitor-capture global
Switch(config-capture)# monitor-capture input eth-0-1
```

The following example shows how to set capture packet of input on interface eth-0-1 and match flow1 rules:

```
Switch(config)# flow flow1
Switch(config-flow-flow1)# permit any src-ip host 1.1.1.1 dst-ip any
Switch(config-flow-flow1)# exit
Switch(config)# monitor-capture global
Switch(config-capture)# monitor-capture input eth-0-1 flow flow1
```

Related Commands

None

16.4 monitor-capture output

Command Purpose

Use this command to set capture source node on egress direction

Command Syntax

monitor-capture output *IF_NAME* ((access-list *ACL_NAME*) |)

Parameter	Parameter Description	Parameter Value
IF_NAME	interface name support phy port, agg port.	-
access-list ACL_NAME	acl name	-

Command Mode

Monitor-capture Configuration

Default

None

Usage

None

Examples

The following example shows how to set capture packet of output on interface eth-0-1:

```
Switch(config)# monitor-capture global
Switch(config-capture)# monitor-capture output eth-0-1
```

The following example shows how to set capture packet for output on interface eth-0-1 and match acl1 rules:

```
Switch(config)# ip access-list acl1
Switch(config-acl-acl1)# permit any src-ip host 1.1.1.1 dst-ip any
Switch(config-acl-acl1)# exit
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# egress acl1
Switch(config-if-eth-0-1)# exit
Switch(config)# monitor-capture global
Switch(config-capture)# monitor-capture output eth-0-1 access-list acl1
```

Related Commands

None

16.5 monitor-capture packet start

Command Purpose

Use this command to start monitor-capture

Command Syntax

monitor-capture packet start

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example show how to start monitor-capture:

```
Switch# monitor-capture packet start
```

Related Commands

None

16.6 monitor-capture packet stop

Command Purpose

Use this command to stop monitor-capture

Command Syntax

monitor-capture packet stop

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example show how to stop monitor-capture:

```
Switch# monitor-capture packet stop
```

Related Commands

None

16.7 monitor-capture packet restart

Command Purpose

Use this command to restart monitor-capture

Command Syntax

```
monitor-capture packet start
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example show how to restart monitor-capture:

```
Switch# monitor-capture packet restart
```

Related Commands

None

16.8 show monitor-capture packet

Command Purpose

Use this command to show capture packet

Command Syntax

show monitor-capture packet (all | *PACKET-ID*)

Parameter	Parameter Description	Parameter Value
all	show all packets	-
PACKET-ID	show the specified packet	1-1000

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example show all packet of monitor-capture:

```
Switch# show monitor-capture packet all

-----
Packet      : 1
Source port: eth-0-1
MACDA:0000.0000.0002, MACSA:0000.0000.0001
VLAN Tag: 20, priority: 0
IPDA: 30.30.30.3, IPSA: 10.0.0.2
IPv4 Packet, IP Protocol is 0
Data length: 64
Data:
 0000 0000 0002 0000 0000 0001 8100 0014
 0800 4500 0044 0001 0000 4000 3497 0a00
 0002 1e1e 1e03 5858 5858 5858 5858 5858
 5858 5858 5858 5858 5858 5858 5858 5858
-----
Packet      : 2
Source port: eth-0-1
MACDA:0000.0000.0002, MACSA:0000.0000.0001
VLAN Tag: 20, priority: 0
IPDA: 30.30.30.3, IPSA: 10.0.0.2
IPv4 Packet, IP Protocol is 0
Data length: 64
Data:
 0000 0000 0002 0000 0000 0001 8100 0014
 0800 4500 0044 0001 0000 4000 3497 0a00
 0002 1e1e 1e03 5858 5858 5858 5858 5858
 5858 5858 5858 5858 5858 5858 5858 5858
-----
```

The following example show packet-id of capture packet:

```
Switch# show monitor-capture packet 1

-----
Packet      : 1
Source port: port1
MACDA:0000.0000.0002, MACSA:0000.0000.0001
VLAN Tag: 20, priority: 0
IPDA: 30.30.30.3, IPSA: 10.0.0.2
IPv4 Packet, IP Protocol is 0
Data length: 64
Data:
 0000 0000 0002 0000 0000 0001 8100 0014
 0800 4500 0044 0001 0000 4000 3497 0a00
 0002 1e1e 1e03 5858 5858 5858 5858 5858
 5858 5858 5858 5858 5858 5858 5858 5858
```

Related Commands

None

16.9 clear monitor-capture packet all

Command Purpose

Use this command to clear monitor capture buffer

Command Syntax

```
clear monitor-capture packet all
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to clear monitor-capture buffer:

```
Switch# clear monitor-capture packet all
```

Related Commands

None

16.10 show monitor-capture global

Command Purpose

Use this command to show monitor-capture global configuration

Command Syntax

show monitor-capture global

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows monitor-capture global configuration:

```
Switch# show monitor-capture global

Monitor-capture global information:
  monitor-capture number           : no-limit
  monitor-capture timeout          : no-limit
  monitor-capture length           : 64
  monitor-capture source-nodes:
    Input:
      eth-0-1
      eth-0-1      flow flow1
    Output:
      eth-0-1
      eth-0-1      access-list acl1
```

Related Commands

None

17

SYSLOG Commands

17.1 logging sync

Command Purpose

Use this command to write the log in the memory buffer to the syslog file in flash.

Command Syntax

```
logging sync
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following shows how to enable logging sync function:

```
Switch# logging sync
```

Related Commands

```
show logging buffer
```

17.2 logging buffer

Command Purpose

Use this command to set the number of logs saved by the system temporary buffer.
Use the no form of this command to restore the default value.

Command Syntax

logging buffer *CFGLOGLINES*

no logging buffer

Parameter	Parameter Description	Parameter Value
CFGLOGLINES	Log quantity	Range is <10-1000>

Command Mode

Global Configuration

Default

500

Usage

None

Examples

The following shows how to set logging buffer line number to 10:

```
Switch(config)# logging buffer 10
```

The following shows how to set logging buffer line number to default value:

```
Switch(config)# no logging buffer
```

Related Commands

show logging buffer

17.3 logging file

Command Purpose

Use this command to set whether to write logs into log files.

Command Syntax

logging file (enable | disable)

Parameter	Parameter Description	Parameter Value
enable	Write log information into log files	-
disable	Cancel writing log information to log file	-

Command Mode

Global Configuration

Default

Enabled

Usage

Once enabled, the log writes the currently generated log to the flash:/syslogfile file every 10 minutes.

Examples

The following example shows how to enable logging file function:

```
Switch(config)# logging file enable
```

Related Commands

show logging

17.4 logging level file

Command Purpose

Use this command to set the level of log information, logs above or equal to this level will be counted into log files.

Use the no form of this command to restore the default value.

Command Syntax

logging level file (*LOGSEVERITY* | emergency | alert | critical | error | warning | notice | information | debug)

no logging level file

Parameter	Parameter Description	Parameter Value
0 emergency	System is unusable	-
1 alert	Immediate action needed	-
2 critical	Critical conditions	-
3 error	Error conditions	-
4 warning	Warning conditions	-
5 notice	Normal but significant conditions	-
6 information	Informational messages	-
7 debug	Debugging messages	-
LOGSEVERITY	Severity level	Range is <0-7>

Command Mode

Global Configuration

Default

Warning

Usage

Use this command to set the level of log information. Log information above or equal to this level will be logged to the log file, while log information below this level will not be logged to the file. If debug is specified, all log messages will be logged to the log file.

Examples

The following example shows how to configure the log message level to error:

```
Switch(config)# logging level file error
```

The following example shows how to restore the default value of log message level:

```
Switch(config)# no logging level file
```

Related Commands

logging level module

17.5 logging level module

Command Purpose

Use this command to set the level of log information sent to the terminal and entered the buffer. Logs higher than or equal to this level will be displayed on the terminal.

Use the no form of this command to restore the default value.

Command Syntax

logging level module (*LOGSEVERITY* | emergency | alert | critical | error | warning | notice | information | debug)

no logging level module

Parameter	Parameter Description	Parameter Value
0 emergency	System is unusable	-

1 alert	Immediate action needed	-
2 critical	Critical conditions	-
3 error	Error conditions	-
4 warning	Warning conditions	-
5 notice	Normal but significant conditions	-
6 information	Informational messages	-
7 debug	Debugging messages	-
LOGSEVERITY	Severity level.	Range is <0-7>

Command Mode

Global Configuration

Default

Debug

Usage

Use this command set to the level of log information sent to the terminal and recorded to the buffer. Log messages above or equal to this level will be displayed to the terminal and written to the log buffer, while those below this level will not be displayed at the terminal, nor will they be written to the log buffer.

Examples

The following example shows how to set logging level module to error:

```
Switch(config)# logging level module error
```

The following example shows how to restore the default value of logging level module:

```
Switch(config)# no logging level module
```

Related Commands

logging level file

17.6 logging timestamp

Command Purpose

Use this command to set the timestamp format of log information.

Use the no form of this command to restore the default value.

Command Syntax

logging timestamp (date | bsd | iso | rfc3164 | rfc3339 | none)

no logging timestamp

Parameter	Parameter Description	Parameter Value
date	The time format displayed when using the date command	-
bsd	BSD style (RFC 3164)	-
iso	ISO style (RFC 3339)	-
rfc3164	RFC 3164 style (bsd)	-
rfc3339	RFC 3339 style (iso)	-
none	No timestamp	-

Command Mode

Global Configuration

Default

BSD

Usage

None

Examples

The following example shows how to set the log message timestamp format to RFC3164:

```
Switch(config)# logging timestamp rfc3164
```

The following example shows how to recovery log message timestamp format to default:

```
Switch(config)# no logging timestamp
```

Related Commands

show logging

17.7 logging server

Command Purpose

Use this command to set whether to use a remote log server.

Command Syntax

logging server (enable | disable)

Parameter	Parameter Description	Parameter Value
enable	Enable logging server	-
disable	Disable logging server	-

Command Mode

Global Configuration

Default

Disabled

Usage

None

Examples

The following example shows how to enable log server:

```
Switch(config)# logging server enable
```

Related Commands

show logging

17.8 logging server severity

Command Purpose

Use this command to set the log level sent to the remote log server. Logs above or equal to this level will be sent to the log server.

Use the no form of this command to restore the default value.

Command Syntax

logging server severity (*LOGSEVERITY* | emergency | alert | critical | error | warning | notice | information | debug)

no logging server severity

Parameter	Parameter Description	Parameter Value
0 emergency	System is unusable	-
1 alert	Immediate action needed	-
2 critical	Critical conditions	-

3 error	Error conditions	-
4 warning	Warning conditions	-
5 notice	Normal but significant conditions	-
6 information	Informational messages	-
7 debug	Debugging messages	-
LOGSEVERITY	Severity level.	Range is <0-7>

Command Mode

Global Configuration

Default

Warning

Usage

This command is used to set the level of log information sent to the remote log server. Logs higher than or equal to this level will be sent to the log server. If the threshold value is debugged, all log messages will be sent to the log server.

Examples

The following example shows how to set the level of log messages sent to remote log servers to be error, and information above or equal to the level of error will be sent to remote servers:

```
Switch(config)# logging server severity error
```

The following example shows how to recovery the level of log messages sent to remote log servers by default:

```
Switch(config)# no logging server severity
```

Related Commands

show logging

17.9 logging server facility

Command Purpose

Use this command to configure the log daemon on the server.

Use the no form of this command to restore the default value.

Command Syntax

logging server facility (LOGFAC | auth | authpriv | cron | daemon | ftp | kern | local0 | local1 | local2 | local3 | local4 | local5 | local6 | local7 | lpr | mail | news | syslog | user | uucp)

no logging server facility

Parameter	Parameter Description	Parameter Value
LOGFAC	Log facility-type	Range is <0-11> and <16-23>
4 auth	Authorization system	-
10 authpriv	Authorization private system	-
9 cron	Cron facility	-
3 daemon	System daemon	-
11 ftp	FTP system	-
0 kern	Kernel	-
local0-7	Reserved for locally defined messages	-
6 lpr	Line printer system	-
2 mail	Mail system	-
7 news	USENET news	-
5 syslog	System log	-

1 user	User	-
8 uucp	UNIX-to-UNIX	-

Command Mode

Global Configuration

Default

Local4

Usage

None

Examples

The following example shows how to set logging server facility to local3:

```
Switch(config)# logging server facility local3
```

The following example shows how to set logging server facility to default:

```
Switch(config)# no logging server facility
```

Related Commands

show logging

17.10 logging server address

Command Purpose

Use this command to set the IP address of the log server. The switch can send log information to this server.

Use the no form of this command to delete the address.

Command Syntax

logging server address mgmt-if *IP_ADDR*

no logging server address mgmt-if *IP_ADDR*

Parameter	Parameter Description	Parameter Value
IP_ADDR	Remote server IP address	-

Command Mode

Global Configuration

Default

None

Usage

For the switch to send the system log information to the log server correctly, make sure that the server is in its normal functional state.

Examples

The following example shows how to set the IP address of log server to 10.10.38.236:

```
Switch(config)# logging server address mgmt-if 10.10.38.236
```

The following example shows how to delete log server:

```
Switch(config)# no logging server address mgmt-if 10.10.38.236
```

Related Commands

logging server

17.11 logging merge

Command Purpose

When this function is enabled, the switch merges the same logs that appear in a specified period into one. During this period, the switch places the received logs in a temporary buffer of a specified size in the background. The size of this period

can be specified by using the timeout parameter, and the size of the backstage temporary buffer can be specified by using fifo-size parameter.

Command Syntax

logging merge (enable | disable | timeout *MERGETIMEOUT* | fifo-size *MERGEFSIZE*)

no logging merge (timeout | fifo-size)

Parameter	Parameter Description	Parameter Value
enable	Enable logging merge	-
disable	Disable logging merge	-
MERGEFSIZE	Set the size of the background log merge buffer in terms of entries, default 1024 entries	Range is <100-10240>
MERGETIMEOUT	For a specified period, the same logs that appear during that period are merged into one	Range is <1-300>, unit is seconds

Command Mode

Global Configuration

Default

Logging merging is enabled. Timeout is 10.

Fifo-size is 1024.

Usage

The logging merge command merges all the same logs into one during a specified time range. During this time, the switch buffered these same logs. You can use the timeout keyword to set the time range and use the fifo-size to set the buffer size.

Examples

The following example shows how to enable logging merge:

```
Switch(config)# logging merge enable
```

The following example shows how to set logging merge timeout to default value:

```
Switch(config)# no logging merge timeout
```

Related Commands

show logging

17.12 show logging

Command Purpose

Use this command to display the configuration of logging.

Command Syntax

show logging

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the configuration of logging:

```
Switch# show logging  
Current logging configuration:
```

```

=====
logging buffer 500
logging timestamp bsd
logging file enable
logging level file warning
logging level module debug
logging server disable
logging server severity warning
logging server facility local4
logging merge disable
logging merge fifo-size 1024
logging merge timeout 10
  
```

Related Commands

- logging buff
- logging timestamp
- logging file
- logging level file
- logging level module
- logging server
- logging server severity
- logging server facility
- logging merge

17.13 show logging buffer

Command Purpose

In privileged mode, use this command to show logging buffer messages.

Command Syntax

show logging buffer (*SYSLOGLINES* |)

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

SYSLOGLINES	Specify the number of message(s)	(-1000..+1000)
-------------	----------------------------------	----------------

Command Mode

Privileged EXEC

Default

None

Usage

By default, syslog lines are sorted in reverse chronological order, which means the newest syslog is on top.

Examples

The following example shows how to display logging buffer:

```
Switch# show logging buffer

Sep 14 08:59:16 Switch init-6: starting pid 27391, tty \'/dev/ttyS0\':
\'/usr/sbin/klish\'
Sep 14 08:59:16 Switch init-6: process \'/usr/sbin/klish\' (pid 27327) exited.
Scheduling for restart.
Sep 14 08:49:40 Switch APP-1: logout, vty 1, location 169.254.1.2, by telnet
Sep 14 08:49:16 Switch init-6: starting pid 27327, tty \'/dev/ttyS0\':
\'/usr/sbin/klish\'
Sep 14 08:49:16 Switch init-6: process \'/usr/sbin/klish\' (pid 27259) exited.
Scheduling for restart.
Sep 14 08:39:15 Switch init-6: starting pid 27259, tty \'/dev/ttyS0\':
\'/usr/sbin/klish\'
Sep 14 08:39:15 Switch init-6: process \'/usr/sbin/klish\' (pid 27167) exited.
Scheduling for restart.
Sep 14 08:37:48 Switch APP-6: ready to service
```

Related Commands

clear logging buffer

17.14 show logging buffer statistics

Command Purpose

Use this command to display the amount of information stored in the log buffer.

Command Syntax

```
show logging buffer statistics
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the statistics of logging buffer:

```
Switch# show logging buffer statistics

Logging buffer statistics:
-----
Total processed 314 entries
Total dropped 0 entries
Current have 50 entries
```

Related Commands

```
clear logging buffer
```

17.15 show logging levels

Command Purpose

Use this command to show the severity level information of logging.

Command Syntax

```
show logging levels
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the severity level information of logging:

```
Switch# show logging levels

Severity  Name          Note
=====
0         emergency    system is unusable
1         alert        action must be taken immediately
2         critical     critical conditions
3         error        error conditions
4         warning     warning conditions
5         notice      normal but significant condition
6         information  informational
7         debug       debug-level messages
```

Related Commands

logging level file

17.16 show logging facilities

Command Purpose

Use this command to display log daemon tool information.

Command Syntax

```
show logging facilities
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the facility information of logging:

```
Switch# show logging facilities

Logging facility information:
Facility Name      Note
=====
0      kern      kernel messages
1      user      random user-level messages
2      mail      mail system
3      daemon    system daemons
4      auth      security/authorization messages
5      syslog    messages generated internally by syslogd
6      lpr       line printer subsystem
7      news      network news subsystem
8      uucp      UUCP subsystem
9      cron      clock daemon
10     authpriv   security/authorization messages (private)
11     ftp       ftp daemon
16     local0    reserved for local use 0
17     local1    reserved for local use 1
18     local2    reserved for local use 2
```

19	local3	reserved for local use 3
20	local4	reserved for local use 4
21	local5	reserved for local use 5
22	local6	reserved for local use 6
23	local7	reserved for local use 7

Related Commands

logging server facility

17.17 clear logging buffer

Command Purpose

Use this command to clear records in the log buffer.

Command Syntax

clear logging buffer

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to clear logging buffer:

```
Switch# clear logging buffer
```

Related Commands

show logging buffer

18 SNMP Commands

18.1 show snmp

Command Purpose

Use the show snmp command to display the services information of SNMP.

Command Syntax

```
show snmp
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the information of SNMP:

```
Switch# show snmp  
  
Switch# show snmp  
SNMP services: enable
```

Related Commands

snmp server enable

18.2 show snmp-server version

Command Purpose

Use the show snmp-server version command to display the supported version of SNMP.

Command Syntax

```
show snmp-server version
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the information of snmp-server version:

```
Switch# show snmp-server version
SNMP services: SNMPv1/SNMPv2c
```

Related Commands

snmp-server version

18.3 show snmp-server community

Command Purpose

Use the show snmp-server community command to display the SNMP community information.

Command Syntax

```
show snmp-server community
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the information of snmp-server community:

```
Switch # show snmp-server community

Community-Access  Community-String  Security-name
=====
read-write       sysname           comm1
```

Related Commands

```
snmp-server community
```

18.4 show snmp-server engineID

Command Purpose

Use the show snmp-server engineID command to display the identification of the local Simple Network Management Protocol (SNMP) engine and all remote engines that have been configured on the router.

Command Syntax

```
show snmp-server engineID
```

Command Mode

Privileged EXEC

Default

None

Usage

An SNMP engine is a copy of SNMP that can reside on a local or remote device.

Examples

The following example shows how to display the information of engineID:

```
Switch# show snmp-server engineID  
  
Engine ID   : 00000009020000000c025808
```

Related Commands

```
snmp-server engineID
```

18.5 show snmp-server sys-info

Command Purpose

Use the show snmp-server sys-info command to display the system information of SNMP.

Command Syntax

```
show snmp-server sys-info
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the information of snmp-server sys-info:

```
Switch# show snmp-server sys-info  
  
Contact: admin@example.com  
Location: Sample Place
```

Related Commands

snmp-server system-contact

snmp-server system-location

18.6 show snmp-server trap-receiver

Command Purpose

Use the show snmp-server trap-receiver command to display the SNMP traps receiver.

Command Syntax

```
show snmp-server trap-receiver
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the information of snmp-server trap-receiver:

```
Switch# show snmp-server trap-receiver

Target-ipaddress  mgmt-if udpport  version  pdu-type  community
=====
10.10.27.232      yes      162      v1        trap      sysname
10.10.27.232      yes      162      v2c       trap      sysname
```

Related Commands

snmp-server trap target-address

18.7 show snmp-server inform-receiver

Command Purpose

Use the show snmp-server inform-receiver command to display the SNMP informs receiver.

Command Syntax

show snmp-server inform-receiver

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the information of snmp-server inform-receiver:

```

Switch# show snmp-server inform-receiver

Target-ipaddress  mgmt-if  udpport  version  pdu-type  community
=====
10.10.27.233      yes      162    v2c     inform   sysname
  
```

Related Commands

snmp-server inform target-address

18.8 show snmp-server view

Command Purpose

Use the show snmp-server view command to display the family name, storage types, and status of a Simple Network Management Protocol (SNMP) configuration and associated MIB.

Command Syntax

show snmp-server view (*USERNAME* |)

Parameter	Parameter Description	Parameter Value
USERNAME	Specify a view name that want to show, WORD	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the information of snmp-server view:

```
Switch# show snmp-server view
```

View-name	View-type	Subtree
a	excluded	.1
a2	included	.1.2
abc	excluded	.1.3.6.2
all	included	.0
all	included	.1
all	included	.2
none	excluded	.0
none	excluded	.1
none	excluded	.2

Related Commands

snmp-server view

18.9 snmp-server enable

Command Purpose

Use the snmp-server enable command to enable the SNMP function.

Use the no form of this command to disable the SNMP-server.

Command Syntax

snmp-server enable
no snmp-server enable

Command Mode

Global Configuration

Default

Disabled

Usage

None

Examples

The following example shows how to set the snmp-server enable:

```
Switch(config)# snmp-server enable
```

The following example shows how to set the snmp-server disable:

```
Switch(config)# no snmp-server enable
```

Related Commands

show snmp

18.10 snmp-server engineID

Command Purpose

Use the snmp-server engineID command to specify the Simple Network Management Protocol (SNMP) engine ID on the local device.

Use the no form of this command to restore the default value.

Command Syntax

`snmp-server engineID ENGINEID`

`no snmp-server engineID`

Parameter	Parameter Description	Parameter Value
ENGINEID	octet string of hexadecimal characters	10-64 hexadecimal characters

Command Mode

Global Configuration

Default

An SNMP engine ID is generated automatically but is not displayed or stored in the running configuration. Default engine ID is 30383038303830383038. You can display the default or configured engine ID by using the `show snmp-server engineID` command.

Usage

The SNMP engine ID is a unique string used to identify the device for administration purposes. You do not need to specify an engine ID for the device. For further details on the SNMP engine ID, see RFC 2571.

Examples

The following example shows how to set the `snmp-server engineID`:

```
Switch(config)# snmp-server engineID 1234567890
```

The following example shows how to delete the `snmp-server engineID`:

```
Switch(config)# no snmp-server engineID
```

Related Commands

`show snmp-server engineID`

18.11 snmp-server system-contact

Command Purpose

Use the snmp-server system-contact command to set the system contact string.

Use the no form of this command to delete the contact string.

Command Syntax

snmp-server system-contact *KLINE*

no snmp-server system-contact

Parameter	Parameter Description	Parameter Value
KLINE	Specify SNMP system contact parameter	Up to 255 characters, valid characters are “0-9/A-Z/a-z/./-_*”

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example shows how to set the system contact string:

```
Switch(config)# snmp-server system-contact admin@example.com
```

The following example shows how to delete the system contact string:

```
Switch(config)# no snmp-server system-contact
```


Related Commands

show snmp-server sys-info

18.12 snmp-server system-location

Command Purpose

Use the snmp-server system-location command to set the system location string.

Use the no form of this command to delete the location string.

Command Syntax

snmp-server system-location *KLINE*

no snmp-server system-location

Parameter	Parameter Description	Parameter Value
KLINE	Specify SNMP system location parameter	Up to 255 characters, valid characters are “0-9/A-Z/a-z/._@*”

Command Mode

Global Configuration

Default

None

Usage

This command is used to set the system location of the SNMP agent so that these descriptions can be accessed through the configuration file.

Examples

The following example shows how to set the system location string:

```
Switch(config)# snmp-server system-location Sample_Place
```

The following example shows how to remove the system location string:

```
Switch(config)# no snmp-server system-location
```

Related Commands

show snmp-server sys-info

18.13 snmp-server version

Command Purpose

Use the snmp-server version command to specify the support of SNMP version.

Use the no form of this command to restore the default value.

Command Syntax

```
snmp-server version ( all | v1 | v2c )
```

```
no snmp-server version
```

Parameter	Parameter Description	Parameter Value
all	Support all versions (v1, v2c, and v3)	-
v1	Support only v1 version	-
v2c	Support only v2c version	-

Command Mode

Global Configuration

Default

Support v1 and v2c SNMP versions.

Usage

None

Examples

The following example shows how to set SNMP -server to support all versions:

```
Switch(config)# snmp-server version all
```

The following example shows how to restore the SNMP -server to support default versions:

```
Switch(config)# no snmp-server version
```

Related Commands

show snmp-server version

18.14 snmp-server view

Command Purpose

Use the snmp-server view command to create or update a view entry.

Use the no form of this command to delete the view.

Command Syntax

```
snmp-server view SNMPNAME ( excluded | included ) SNMPSUBTREE ( mask SNMPMASK )
```

```
no snmp-server view SNMPNAME ( excluded | included ) SNMPSUBTREE
```

Parameter	Parameter Description	Parameter Value
SNMPNAME	Label for the view record that you are updating or creating. The name is used to reference the record	-

excluded	Configures the OID (and subtree OIDs) specified in sub-tree argument to be included in the SNMP view	-
included	Configures the OID (and subtree OIDs) specified in sub-tree argument to be explicitly excluded from the SNMP view	-
SNMPSUBTREE	Object identifier of the ASN.1 subtree to be included or excluded from the view	-
SNMPMASK	Define the subtree mask	-

Command Mode

Global Configuration

Default

None

Usage

Other SNMP commands require an SNMP view as an argument. You use this command to create a view to be used as arguments for other commands.

Examples

The following example shows how to create a snmp-server view:

```
Switch(config)# snmp-server view abc excluded 1.3.6.2
```

The following example shows how to delete a snmp-server view:

```
Switch(config)# no snmp-server view abc excluded 1.3.6.2
```

Related Commands

show snmp-server view

18.15 snmp-server community

Command Purpose

Use the snmp-server community command to set up the community access string to permit access to the Simple Network Management Protocol (SNMP).

Use the no form of this command to delete the community.

Command Syntax

```
snmp-server community CONM_NAME ( read-only | read-write ) ( view VIEW_NAME | )
```

```
no snmp-server community CONM_NAME
```

Parameter	Parameter Description	Parameter Value
CONM_NAME	Specify a SNMP community name	A string with 1-256 characters. A blank means deny access.
read-only	Specifies read-only access. Authorized management stations can retrieve only MIB objects	-
read-write	Specifies read-write access. Authorized management stations can both retrieve and modify MIB objects	-
view VIEW_NAME	MIB view to which this community has access	-

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example shows how to create a community named test:

```
Switch(config)# snmp-server community test read-write
```

The following example shows how to delete the community:

```
Switch(config)# no snmp-server community test
```

Related Commands

show snmp-server community

18.16 snmp-server trap enable

Command Purpose

Use the snmp-server trap enable command to enable all Simple Network Management Protocol (SNMP) notification types that are available on your system.

Use the no form of this command to disable the trap.

Command Syntax

snmp-server trap enable (all | coldstart | warmstart | linkdown | linkup)

no snmp-server trap enable (all | coldstart | warmstart | linkdown | linkup)

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

all	Enable all traps	-
coldstart	Cold start traps	-
warmstart	Warm start traps	-
linkdown	Link down traps	-
linkup	Link up traps	-

Command Mode

Global Configuration

Default

Disabled

Usage

The snmp-server trap enable command is used in conjunction with the snmp-server trap target-address command. Use the snmp-server trap target-address command to specify which host or hosts receive SNMP notifications. To send notifications, you must configure at least one snmp-server trap target-address command.

Examples

The following example shows how to set all traps enable:

```
Switch(config)# snmp-server trap enable all
```

The following example shows how to set all traps disable:

```
Switch(config)# no snmp-server trap enable all
```

Related Commands

snmp-server trap target-address

18.17 snmp-server trap target-address

Command Purpose

Use the snmp-server target-address command to configure a remote trap management IP address.

Use the no form of this command to delete the target address.

Command Syntax

snmp-server trap target-address mgmt-if *IP_ADDR* community *COMNAME* (udpport *UDP_PROT*)

no snmp-server trap target-address *IP_ADDR* community *COMNAME* (udpport *UDP_PROT*)

Parameter	Parameter Description	Parameter Value
IP_ADDR	Specify a SNMP IPV4 address	-
COMNAME	Specify a SNMP community name	-
UDP_PORT	The port number which area is 0 to 65535, the default is 162	-

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example shows how to set the trap target address to 169.254.2.2 and set the udp port to 13:

```
Switch(config)# snmp-server trap target-address mgmt-if 169.254.2.2 community test
udpport 13
```

The following example shows how to delete the trap target address:

```
Switch(config)# no snmp-server trap target-address mgmt-if 169.254.2.2 community
test udp 13
```

Related Commands

show snmp-server trap-receiver

18.18 snmp-server trap delay linkup

Command Purpose

Use the snmp-server trap delay linkup command to configure the trap delay linkup time.

Use the no form of this command to restore the default value.

Command Syntax

snmp-server trap delay linkup *TRAP_DELAY_TIME*

no snmp-server trap delay linkup

Parameter	Parameter Description	Parameter Value
TRAP_DELAY_TIME	Linkup trap delay time	1-10 seconds

Command Mode

Global Configuration

Default

0

Usage

None

Examples

The following example shows how to set the delay time to 10 seconds:

```
Switch(config)# snmp-server trap delay linkup 10
```

The following example shows how to restore the delay time to default value:

```
Switch(config)# no snmp-server trap delay linkup
```

Related Commands

snmp-server trap enable

18.19 snmp-server trap delay linkdown

Command Purpose

Use the snmp-server trap delay linkdown command to configure the trap delay linkdown time.

Use the no form of this command to restore the default value.

Command Syntax

```
snmp-server trap delay linkdown TRAP_DELAY_TIME
```

```
no snmp-server trap delay linkdown
```

Parameter	Parameter Description	Parameter Value
TRAP_DELAY_TIME	Linkdown trap delay time	1-10 seconds

Command Mode

Global Configuration

Default

0

Usage

None

Examples

The following example shows how to set the delay time to 10 seconds:

```
Switch(config)# snmp-server trap delay linkdown 10
```

The following example shows how to restore the delay time to default value:

```
Switch(config)# no snmp-server trap delay linkdown
```

Related Commands

snmp-server trap enable

18.20 snmp-server inform target-address

Command Purpose

Use the snmp-server inform target-address command to specify the recipient of a Simple Network Management Protocol (SNMP) inform message.

Use the no form of this command to delete the configuration.

Command Syntax

```
snmp-server inform target-address mgmt-if IP_ADDR community COMNAME  
( udpport UDP_PROT | )
```

```
no snmp-server inform target-address IP_ADDR community COMNAME ( udpport  
UDP_PROT | )
```

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

IP_ADDR	Specify a SNMP IPV4 address	-
COMNAME	Specify a SNMP community name	-
UDP_PROT	The port number	The port number which area is 0 to 65535, the default is 162

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example shows how to set the target address for inform messages:

```
Switch(config)# snmp-server inform target-address 169.254.2.2 community test
udpport 100
```

The following example shows how to delete the target address for inform messages:

```
Switch(config)# no snmp-server inform target-address 169.254.2.2 community test
udpport 100
```

Related Commands

show snmp-server inform-receiver

18.21 snmp-server access-group

Command Purpose

Use this command to apply access list on Simple Network Management Protocol(SNMP).

Use the no form of this command to remove access list applied to SNMP.

Command Syntax

snmp-server access-group *NAME_STRING* in

no snmp-server access-group

Parameter	Parameter Description	Parameter Value
NAME_STRING	IP ACL NAME	The initial character name should be a-z, A-Z, 0-9 or ._, character only can be 0-9/A-Z/a-z/.-_ and the max length is 20

Command Mode

Global Configuration

Default

None

Usage

ACL applied on SNMP can only match source IP, destination IP, behavior as WhiteList by default.

Examples

The following example shows how to apply acl to SNMP:

```
Switch(config)# ip access-list a5  
Switch(config-ip-acl-a5)# exit  
Switch(config)# snmp-server access-group a5 in  
Notice: ACL applied on SNMP can only matching of source IP,destination IP,  
behaviour as WhiteList by default.
```

Related Commands

None

19 AUTH Commands

19.1 show usernames

Command Purpose

Use this command to show local user account names on the switch.

Command Syntax

```
show usernames
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following is sample output from the show usernames command:

```
Switch# show usernames

Number  User name                Privilege  Password  Rsa Key
-----+-----+-----+-----+-----
1       admin                    4         *
2       test                     4         *
Switch#
```

Related Commands

username

19.2 show users

Command Purpose

Use this command to display information about terminal lines.

Command Syntax

show users

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following is sample output from the show user's command:

```
Switch# show users

Line          Host(s)      Idle        Location      User
-----+-----+-----+-----+-----
 130 vty 0     idle        2d20h16m    Local
 131 vty 1     idle        20:42:32    10.10.25.25
*132 vty 2     idle        00:00:00    10.10.25.25
```

Related Commands

show usernames

19.3 show web users

Command Purpose

Use this command to display information of the web users.

Command Syntax

```
show web users
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following is sample to show web users:

```
Switch# show web users

Session Id                Expire Time                Client IP                User Name
-----+-----+-----+-----
320570bf7624e99f9c01912e82c4515b 2017-01-05 00:53:15 10.10.22.236  admin
```

Related Commands

username

19.4 show privilege

Command Purpose

Use this command to display the current privilege.

Command Syntax

show privilege

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display current privilege:

```
Switch# show privilege
Current privilege level is 4
```

Related Commands

username

19.5 clear line console 0

Command Purpose

Use this command to clear primary console terminal line login.

Command Syntax

clear line console 0

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following is sample to clear line console 0:

```
Switch# clear line console 0
[OK]
```

Related Commands

line console

19.6 clear line vty

Command Purpose

Use this command to clear virtual terminal line login. The line number range is 0 to 7.

Command Syntax

clear line vty *VTYID1* (*VTYID2* |)

Parameter	Parameter Description	Parameter Value
VTYID1	First Line number	0-7
VTYID2	Last Line number	0-7

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following is sample to clear virtual terminal line from 4 to 7:

```
Switch# clear line vty 4 7
[OK]
```

Related Commands

show users

19.7 clear web session

Command Purpose

Use this command to clear web sessions.

Command Syntax

clear web session (all | *WEBSESSION*)

Parameter	Parameter Description	Parameter Value
all	Clear all sessions	-
WEBSESSION	Session Name	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following is sample to clear all web sessions:

```
Switch# clear web session all  
[OK]
```

Related Commands

show web users

19.8 show console

Command Purpose

Use this command to show the current console configuration.

Command Syntax

show console

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following is sample output from the show console command:

```
Switch# show console

Current console configuration:
-----
line console 0
  speed 115200
  parity none
  databits 8
  stopbits 1
  exec-timeout 10 0
  privilege level 4
  no line-password
  no login
```

Related Commands

line console

19.9 show vty

Command Purpose

Use this command to show the current vty configuration.

Command Syntax

show vty

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following is sample output from the show vty command:

```
Switch# show vty

line vty maximum 8
line vty 0 7
  exec-timeout 35791 0
  privilege level 4
  no line-password
  no login
```

Related Commands

line vty

19.10 show rsa keys

Command Purpose

Use this command to show RSA key information.

Command Syntax

```
show rsa keys
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following is sample to show RSA key:

```

Switch# show rsa keys

Current RSA key configuration:
Name                               Type      Usage    Modulus
-----+-----+-----+-----
abc                                 private  0        1024
importkey                           public   1        1024
  
```

Related Commands

rsa key

19.11 show rsa key

Command Purpose

Use this command to show RSA key information.

Command Syntax

```

show rsa key RSAKEYNAME ( der | pem ( 3des RSAPASSWORD | aes128
RSAPASSWORD | aes192 RSAPASSWORD | aes256 RSAPASSWORD | des RSAPASSWORD
| ) )
  
```

Parameter	Parameter Description	Parameter Value
RSAKEYNAME	Key name	-
der	Certificate of der	-
pem	Certificate of pem	-
3des	Treble encryption standard	-
des	Data encryption standard	-
Aes128	Advanced encryption standard 128 bit	-
Aes192	Advanced encryption standard 192 bit	-

Aes256	Advanced encryption standard 256 bit	-
RSAPASSWORD	Passphrase used to protect the private key (length should >= 6)	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following is sample to show RSA key:

```
Switch# show rsa key abc

RSA key information:
-----
Name: abc
Type: private
Modulus: 1024 bit
Usage count: 0
Private key DER code:
30820258
 0201
 00
028180
 D4E93929 20C1014D D9C64EF3 A8AB905D FDCF2D08 6DEFAC26 691D3168 E4C2F812
 394390A1 A1D648BF 50DE534D 718FF606 69DDC302 F005FBC6 A3A3E616 4A9EEF47
 9093AD9B 42F436A8 71C3C8D2 ECF14DD1 EEEEC83AF 9EC5DF87 832A072F 5C02D463
 515753C2 EC610B25 4228B7F0 D9E99DF7 9AD011B5 7BA49B7F 1B838AA9 D92003CB
0203
 010001
028180
 2B45DBA0 484FF1FB E8AF2D8C C853565C 4421BF7D 5F1ABF5A 6F32C7C0 11FEAE7C
 C5B6BDC6 9C25F953 291486C9 CEB2FBC6 01EE589C 583C5F17 D85A8F81 28597538
 2F710C05 E9E4CAF9 A1639486 DF19DF70 69246C57 09570697 14C283EE 50786669
```

```

99483E8B A35129CC 61655216 859740C7 7D5E0610 460A265B BB97F546 9C6ED981
0240
F06C6D70 F348C0F8 5A6CFB99 215A04FB 9C9E295E 93BE6D9F 5FCBFF93 1EE3C6E8
B85B2E5C 98F51B66 74B35957 38896051 CCBD6875 A34AF5B7 71BC4FA1 6E448303
0240
E2B47BD7 7A5C7D8F 41FB8311 BFE43080 0DF24D7D 0FADCECF 7921975A A7B28623
1E19AB8D 57F12487 B284D4EA AA2EC370 06DB170F F2E72B96 1DF1F51A 38523D99
0240
098D855B B38EF47B E9BBE2D3 56CBE8DE C67E524E 7BB8594A B7D7B733 F54A3FA1
079237E9 5DFA7F38 36F2D95D E9D52B8A 9484021E 8A7A7400 F1F7F582 088B9859
0240
9FD333F7 CE990420 0A1981E6 F28CB230 A5246CC2 BD5A0092 3E489346 E33135E5
EE2394D1 39ED949E 6219C96D 82FB22E7 88BDCEBD 7CB6C300 BB2DC869 6AC97809
0240
BEFEFE99 CDBB2AAB BA1EB81B 7B189124 B73700BD 3F40B23A AAE648A4 CF07E99E
58261516 C58A1468 5603B90B 24CFD0FC 2609C215 E30375CA 0764FF71 1BF434FF
Public key DER code:
308188
028180
D4E93929 20C1014D D9C64EF3 A8AB905D FDCF2D08 6DEFAC26 691D3168 E4C2F812
394390A1 A1D648BF 50DE534D 718FF606 69DDC302 F005FBC6 A3A3E616 4A9EEF47
9093AD9B 42F436A8 71C3C8D2 ECF14DD1 EEEC83AF 9EC5DF87 832A072F 5C02D463
515753C2 EC610B25 4228B7F0 D9E99DF7 9AD011B5 7BA49B7F 1B838AA9 D92003CB
0203
010001

```

Related Commands

rsa key

19.12 show key config

Command Purpose

Use this command to display the details of the current key configuration.

Command Syntax

show key config

Command Mode

Rsa Key Configuration

Default

None

Usage

None

Examples

The following example shows how to display the current key configuration:

```
Switch(config-rsa-key)# show key config  
  
Current key configuration:  
key type: private  
key format: pem  
key password: unspecified
```

Related Commands

rsa key

19.13 show key string

Command Purpose

Use this command to display the details of the current key string.

Command Syntax

show key string

Command Mode

Rsa Key Configuration

Default

None

Usage

None

Examples

The following example shows how to display the current key string:

```
Switch(config)# rsa key a

Modify private key a
Switch(config-rsa-key)# show key string
Current key string:
30820258
 0201
  00
028180
 AD4F1364 4F46C9F9 25D7BA98 B7F266A4 F3448E83 71D51F84 EF225E90 7D0117F0
 CD81012F 50944BF3 17A5CA56 7A2DC3D2 6A33CD52 6FD2DBE3 442C6546 DC3DD48A
 D8A4020C 2333F039 53FD39DE 01E5038B F1B59E7A 5B355FA2 26148F58 48C16D89
 36828C61 00A518CD F7EEBFBF 68CDB456 DC08BF5F 550A1273 28EF8E7C 0469634F
0203
 010001
028180
 9321ACDE DE06C4F5 45D14DD2 D5676F08 DE95F73F 546690E9 B472C341 7B3E706A
 B8ACAAAA D687EFAA A30AD72A 6F7366E9 BDCBD8A6 01D54B64 37BE5104 C579A074
1206CD3C 70BA5E26 D22F0049 EABBCAA3 8AAAA932 C28DF32B 1C75EF5C 0052751C
 A5BA0D06 B0F9E6D2 9FE9281D FE2976C9 6C1A3288 590EB014 311AE5E2 0514AE41
0240
 D8F10ACD BA5EA745 A5C52F61 19498B76 C181D0A0 F1CA197B C3E5204A 09206E1E
 B5217249 B595CA01 EBF82649 B272511C 8AD5138C 553717CD 4120D026 5D8CAE51
0240
 CC82FA9D 866C95FA AE967B81 C343F9E0 2D41B59F 45C41197 28F37B3B 0C09D7B6
 4867858D 73876AEF 7692CCC6 A7A51A6C 8A1C62E6 FF75E209 75D02A51 E2346F9F
0240
 943B3F52 8B0199F1 F0EEE70C C5A686F0 C20FDD69 DB4C6855 34E91E42 F8317C8C
 E6DECFA4 A5BA8FA8 F87F3A4A 28F00B94 2118AE9E B8AB484C 2B302C89 CA6A11C1
0240
 3F15C828 FF664F7D 5C8D9EDB 90584FA4 0F51CDAC ABE0A76C 717D69ED F4F0B451
 CE53E0A6 9994942F F9EB9EAF 48D76D27 3E13338E FE0E6703 740C1A81 D7BD4511
0240
 90D784A0 EBF913CE 82A19E91 4A0C5437 120C758F F9C94932 919A36B5 5BB01C76
 7460665E 6A1E8227 1BF592D3 650FCE6A DE22C1CB FCCA9433 A2FA142C D9D75CC9

Switch(config-rsa-key)#
```

Related Commands

rsa key

19.14 show tacacs

Command Purpose

Use this command to display information about TACACS+ server's configurations.

Command Syntax

show tacacs

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following is sample output from the show tacacs command:

```
Switch# show tacacs
=====
Host          Port  Timeout Retries Dead Secret
=====
2.1.1.1      49    5        3      0    mykey
```

Related Commands

tacacs-server host

19.15 show aaa status

Command Purpose

Use this command to show authentication, authorization, accounting (AAA) status.

Command Syntax

show aaa status

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to show authentication, authorization, accounting status:

```
Switch# show aaa status  
  
AAA status:  
    Authentication enable
```

Related Commands

aaa new-model

19.16 show aaa privilege mapping

Command Purpose

Use this command to show privilege mapping relationship with server privilege.

Command Syntax

```
show aaa privilege mapping
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to show privilege mapping relationship:

```
Switch# show aaa privilege mapping
```

Server	Switch	Server
0	1	0
1	2	1
2~10	3	10
11~15	4	15

Related Commands

aaa privilege mapping

19.17 show aaa method-lists

Command Purpose

Use this command to show authentication, authorization, accounting (AAA) authentication method lists.

Command Syntax

```
show aaa method-lists authentication ( accounting | all | authentication | authorization )
```

Parameter	Parameter Description	Parameter Value
accounting	Accounting information	-
all	All information	-

authentication	Authentication information	-
authorization	Authorization information	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to show authentication method lists:

```
Switch# show aaa method-lists all

Authen queue = AAA ML AUTHEN LOGIN
  Name = default   state = ALIVE: local radius none
Author queue = AAA ML AUTHOR SHELL
  Name = default   state = ALIVE: tacplus none
Account queue = AAA ML ACCT SHELL
  Name = default   state = ALIVE: none
Account queue = AAA ML ACCT COMMAND
  Name = default   state = ALIVE: none
```

Related Commands

aaa authentication login

aaa authentication exec

aaa accounting exec

19.18 line console

Command Purpose

Use this command to set console configuration.

Command Syntax

line console 0

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following is an example of configure to line console 0:

```
Switch(config)# line console 0
Switch(config-line)#
```

Related Commands

show console

19.19 line vty

Command Purpose

Use line vty command to set virtual terminal line configuration.

Command Syntax

line vty *VTYID1* (*VTYID2* |)

Parameter	Parameter Description	Parameter Value
VTYID1	First Line number	0-7
VTYID2	Last Line number	0-7

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following is an example of configure to virtual terminal line 4 to 7:

```
Switch(config)# line vty 4 7
Switch(config-line)#
```

Related Commands

show vty

19.20 line vty maximum

Command Purpose

Use this command to set maximum vty users.

Use the no form of this command to set maximum vty users to its default value.

Command Syntax

line vty maximum *VTYMAX*

no line vty maximum

Parameter	Parameter Description	Parameter Value
VTYMAX	Max Line number	0-8. default is 8

Command Mode

Global Configuration

Default

8

Usage

None

Examples

The following is an example of configure to three vty users:

```
Switch(config)# line vty maximum 3
```

The following is an example to reset maximum vty users:

```
Switch(config)# no line vty maximum
```

Related Commands

show line vty

19.21 rsa key generate

Command Purpose

Use this command to create a key.

Use the no form of this command to delete the key.

Command Syntax

rsa key *RSAKEYNAME* generate (*RSAKEYBITS* |)

no rsa key *RSAKEYNAME*

Parameter	Parameter Description	Parameter Value
RSAKEYNAME	Key name	String begin with [a-z/A-Z], valid character is among [0-9/A-Z/a-z/._-], up to 255 characters.
RSAKEYBITS	RSA key bits number	768-4096, default is 1024

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example creates a key named test, length is 768:

```
Switch(config)# rsa key test generate 768

Generating RSA private key, 768 bit long modulus
Please waiting for a moment: done!
Public exponent is 65537 (0x10001)
Generate RSA key successfully
```

The following example deletes the key:

```
Switch(config)# no rsa key test
```

Related Commands

show rsa key

rsa key

19.22 rsa key import

Command Purpose

Use this command to import a key.

Command Syntax

rsa key *RSAKEYNAME* import mgmt-if url *STRING* (private | public) (der | der-hex | pem (*PASSPHRASE* |) | ssh1 (*PASSPHRASE* |) | ssh2 (*PASSPHRASE* |))

Parameter	Parameter Description	Parameter Value
RSAKEYNAME	Key name	-
STRING	The url to save the key file	-
private	Import from private key	-
public	Import from public key	-
der der-hex pem ssh1 ssh2	The format of the key to import	-
PASSPHRASE	Encrypt the key string	-

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example imports a key:

```
Switch(config)# rsa key importnewk import mgmt-if url tftp://10.10.38.160/newk.pub
public ssh2

Download from URL to temporary file.
Get file from tftp://10.10.38.160/newk.pub
.
Received 212 bytes in 0.1 seconds
Copy the temporary file to its destination.
.
File system synchronization. Please waiting...
212 bytes in 0.1 seconds, 2 kbytes/second
% Import RSA key succeeded
```

Related Commands

rsa key generate

rsa key export

19.23 rsa key export

Command Purpose

Use this command to export a key.

Command Syntax

```
rsa key RSAKEYNAME export mgmt-if url STRING ( private | public ) ( der | der-hex
| pem ( ( 3des | aes128 | aes192 | aes256 | des ) PASSPHRASE | ) | ssh1 ( 3des
PASSPHRASE | ) | ssh2 ( 3des PASSPHRASE | ) )
```

Parameter	Parameter Description	Parameter Value
RSAKEYNAME	Key name	-

STRING	The url to save the key file	-
private	Export to private key	-
public	Export to public key	-
der der-hex pem ssh1 ssh2	The format of the key to export	-
3des aes128 aes192 aes256 des	The encryption transmission algorithm of the exported key file.	-
PASSPHRASE	Encrypt the key string	-

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example exports a key:

```
Switch(config)# rsa key newk export mgmt-if url tftp://10.10.38.160/newk.pub public
ssh2

Send file to tftp://10.10.38.160/newk.pub
.
Sent 212 bytes in 0.0 seconds
% Export RSA key success
```

Related Commands

rsa key generate

rsa key import

19.24 rsa key

Command Purpose

Use this command to create a key and enter key configuration mode.

Use the no form of this command to delete the key.

Command Syntax

rsa key *RSAKEYNAME*

no rsa key *RSAKEYNAME*

Parameter	Parameter Description	Parameter Value
RSAKEYNAME	Key name	-

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example creates a key named test:

```
Switch(config)# rsa key test  
Switch(config-rsa-key)#
```

The following example deletes a key named test:

```
Switch(config)# no rsa key test
```


Related Commands

rsa key generate

19.25 reset

Command Purpose

To clear all key configurations, use the reset command in RSA key configuration mode.

Command Syntax

reset

Command Mode

Rsa Key Configuration

Default

None

Usage

None

Examples

The following example shows to clear all configurations for the key KEY1:

```
Switch(config)# rsa key KEY1  
Switch(config-rsa-key)# reset
```

Related Commands

rsa key

19.26 key type

Command Purpose

Use this command to specify the key type.

Command Syntax

key type (private | public)

Parameter	Parameter Description	Parameter Value
private	Private key	-
public	Public key	-

Command Mode

Rsa Key Configuration

Default

Public

Usage

None

Examples

The following example specifies the key type of KEY1 as public key:

```
Switch(config)# rsa key KEY1
Switch(config-rsa-key)# key type public
```

Related Commands

rsa key

19.27 key format

Command Purpose

Use this command to specify the key format.

Command Syntax

key format (der | pem)

Parameter	Parameter Description	Parameter Value
der	Der format	-
pem	Pem format	-

Command Mode

Rsa Key Configuration

Default

DER

Usage

None

Examples

The following example specifies the key format of KEY1 as pem:

```
Switch(config)# rsa key KEY1
Switch(config-rsa-key)# key format pem
```

Related Commands

rsa key

19.28 key string end

Command Purpose

Use this command to exit the rsa key configuration mode and apply all rsa key configurations. After using this command, the current command mode should be global configuration mode.

Command Syntax

key string end

Command Mode

Rsa Key Configuration

Default

None

Usage

None

Examples

The following example shows exit the rsa key configuration mode:

```
Switch(config)# rsa key KEY1  
Switch(config-rsa-key)# key string end  
Switch(config)#
```

Related Commands

rsa key

19.29 validate

Command Purpose

Use the validate command to check the validation of the key strings.

Command Syntax

validate

Command Mode

Rsa Key Configuration

Default

None

Usage

None

Examples

The following example shows to validate key strings of the key KEY1:

```
Switch(config)# rsa key a

Modify private key a
Switch(config-rsa-key)# 00302017 4A7D385B 1234EF29 335FC973
Switch(config-rsa-key)# 2DD50A37 C4F4B0FD 9DADE748 429618D5
Switch(config-rsa-key)# validate
% Validated Ok
```

Related Commands

rsa key

19.30 KEYLINE

Command Purpose

Use this command to add key strings from the screen directly.

Command Syntax

KEYLINE

Command Mode

Rsa Key Configuration

Default

None

Usage

None

Examples

The following example shows to type a key string of the key KEY1:

```
Switch(config)# rsa key KEY1
Switch(config-rsa-key)# 00302017 4A7D385B 1234EF29 335FC973
Switch(config-rsa-key)# 2DD50A37 C4F4B0FD 9DADE748
```

Related Commands

rsa key

validate

19.31 re-activate radius-server

Command Purpose

Use this command to re-activate the specified radius servers.

Command Syntax

re-activate radius-server (all | host *IP_ADDR* (auth-port *AUTHDPORT* |) |)

Parameter	Parameter Description	Parameter Value
all	Re-active all radius-servers	-

host IP_ADDR	Re-active the radius-server by server ip	-
auth-port AUTHDPORT	Re-active the radius-server by server ip and udp port	-

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to re-activate the radius server. It's unnecessary for users to wait for the radius-server dead time with this command.

Examples

This example shows how to re-activate radius-server:

```
Switch# re-activate radius-server all
```

Related Commands

radius-server host

19.32 show radius-server

Command Purpose

Use this command to display radius server states of each IEEE 802.1 x sessions.

Command Syntax

show radius-server

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to display the current radius-server and dead radius-servers of each IEEE 802.1x session.

Examples

This example shows how to show radius-server:

```
Switch# show radius-server
=====
radius servers in dead list:
server address   : 10.0.0.1:1812
dead timer      : 4
=====
```

Related Commands

radius-server host

19.33 radius-server host

Command Purpose

Use this command to specify a RADIUS server host.

Use the no form of this command to delete the host.

Command Syntax

```
radius-server host mgmt-if IP_ADDR ( auth-port AUTHDPORT | ) ( key ( 8 | )  
AUTHDKEY | ) ( retransmit AUTHDRETRIES | ) ( timeout AUTHDTIMEOUT | )
```

```
no radius-server host mgmt-if IP_ADDR ( auth-port AUTHDPORT | )
```


Parameter	Parameter Description	Parameter Value
mgmt-if	Use management interface	-
IP_ADDR	IP address of radius server	-
auth-port AUTHDPORT	RADIUS server port number (default 1812)	-
8	Specifies a hidden password will follow	-
key (8) AUTHDKEY		-
retransmit AUTHDRETRIES	RADIUS server retries (default 3)	-
timeout AUTHDTIMEOUT	RADIUS server timeout in seconds (default 5)	-

Command Mode

Global Configuration

Default

None

Usage

You can use multiple radius-server host commands to specify multiple hosts. The software searches for hosts in the order in which you specify them. If no host-specific timeout, retransmit, or key values are specified, the global values apply to each host.

Examples

This example shows how to set the radius-server key::

```
Switch(config)# radius-server host mgmt-if 10.0.0.1
```

This example shows how to delete radius-server key:

```
Switch(config)# no radius-server host mgmt-if 10.0.0.1
```

Related Commands

show radius-server

19.34 radius-server deadtime

Command Purpose

Use this command to improve RADIUS response times when some servers might be unavailable and cause the unavailable servers to be skipped immediately.

Use the no form of this command to restore the default value.

Command Syntax

radius-server deadtime *DEADTIME*

no radius-server deadtime

Parameter	Parameter Description	Parameter Value
DEAD_TIME	RADIUS server deadtime in minutes	1-20 minutes. default is 5 minutes.

Command Mode

Global Configuration

Default

5

Usage

Use this command to cause the switch to mark as “dead” any RADIUS servers that fail to respond to authentication requests, thus avoiding the wait for the request to time out before trying the next configured server. A RADIUS server marked as “dead”

is skipped by additional requests for the duration of minutes, unless there are no servers not marked “dead”.

Examples

This example shows how to set radius-server dead time:

```
Switch(config)# radius-server deadtime 10
```

This example shows how to restore the default radius-server dead time:

```
Switch(config)# no radius-server deadtime
```

Related Commands

show radius-server

19.35 radius-server retransmit

Command Purpose

Use this command to specify the number of times the switch searches the list of RADIUS server hosts before giving up.

Use the no form of this command to restore the default value.

Command Syntax

radius-server retransmit *RETRANSMIT*

no radius-server retransmit

Parameter	Parameter Description	Parameter Value
RETRANSMIT	RADIUS server retries	1-100, default is 3

Command Mode

Global Configuration

Default

3

Usage

The switch tries all servers, allowing each one to time out before increasing the retransmit count. If the RADIUS server is only a few hops from the switch, we recommend that you configure the RADIUS server retransmit rate to 5.

Examples

This example shows how to set radius-server retransmit:

```
Switch(config)# radius-server retransmit 10
```

This example shows how to set default radius-server retransmit:

```
Switch(config)# no radius-server retransmit
```

Related Commands

show radius-server

19.36 radius-server timeout

Command Purpose

Use this command to set the interval for which a switch waits for a server host to reply.

Use the no form of this command to restore the default value.

Command Syntax

radius-server timeout *TIMEOUT*

no radius-server timeout

Parameter	Parameter Description	Parameter Value
TIMEOUT	RADIUS server timeout in seconds	1-1000 seconds. default is 5 seconds

Command Mode

Global Configuration

Default

5

Usage

Use this command to set the number of seconds a switch waits for a server host to reply before timing out. If the RADIUS server is only a few hops from the switch, we recommend that you configure the RADIUS server timeout to 15 seconds.

Examples

This example shows how to set radius-server timeout:

```
Switch(config)# radius-server timeout 10
```

This example shows how to set default radius-server timeout:

```
Switch(config)# no radius-server timeout
```

Related Commands

show radius-server

19.37 radius-server key

Command Purpose

Use this command to set the shared encryption key of RADIUS server.

Use the no form of this command to delete the configuration.

Command Syntax

radius-server key (8 |) *STRING*

no radius-server timeout

Parameter	Parameter Description	Parameter Value
8	Specifies a hidden password will follow	-
STRING	RADIUS server key-string	-

Command Mode

Global Configuration

Default

None

Usage

Use this command to set the shared encryption key in a switch. Shared encryption key is the foundation of communication between switch and server. You need to set a same shared encryption string in authentication server and switch.

Examples

This example shows how to set the radius-server key:

```
Switch(config)# radius-server key 123456
```

This example shows how to unset radius-server key:

```
Switch(config)# no radius-server key
```

Related Commands

show radius-server

19.38 re-activate tacacs-server

Command Purpose

Use this command to re-activate the specified tacacs servers.

Command Syntax

re-activate tacacs-server (all | host *IP_ADDR* (auth-port *AUTHDPORT* |) |)

Parameter	Parameter Description	Parameter Value
all	Re-active all tacacs-servers	-
IP_ADDR	Set TACACS server IP address	-
AUTHDPORT	TACACS server port number (default 49)	-

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to re-activate the tacacs server. It's unnecessary for users to wait for the tacacs-server dead time with this command.

Examples

This example shows how to re-activate tacacs-server:

```
Switch# re-activate tacacs-server host 10.0.0.1 auth-port 49
```

Related Commands

tacacs-server host

19.39 tacacs-server host

Command Purpose

Use this command to set tacacs-server parameters.

Use the no form of this command to delete the tacacs server.

Command Syntax

```
tacacs-server host mgmt-if IP_ADDR ( auth-port AUTHDPORT | ) ( key ( 8 | )  
AUTHDKEY | ) ( retransmit AUTHDRETRIES | ) ( timeout AUTHDTIMEOUT | )
```

```
no tacacs-server host mgmt-if IP_ADDR ( auth-port AUTHDPORT | )
```

Parameter	Parameter Description	Parameter Value
mgmt-if	Use management interface	-
IP_ADDR	IP address of TACACS server	-
auth-port AUTHDPORT		-
8	Specifies a hidden password will follow	-
key (8) AUTHDKEY		-
retransmit AUTHDRETRIES	TACACS server retries (default 3)	-
timeout AUTHDTIMEOUT	TACACS server timeout in seconds (default 5)	-

Command Mode

Global Configuration

Default

None

Usage

Use this command to set tacacs-server parameters.

Use the no form of this command to delete the tacacs server.

Examples

The following example set tacacs-server 2.1.1.1:

```
Switch(config)# tacacs-server host 2.1.1.1 key mykey
```

The following example deletes tacacs-server 2.1.1.1:

```
Switch(config)# no tacacs-server host 2.1.1.1
```

Related Commands

show tacacs

19.40 username

Command Purpose

Use this command to create a local user account on the switch.

Use the no form of this command to delete the account.

Command Syntax

username *NAME_STRING*

no username *NAME_STRING*

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

NAME_STRING	Username	String begin with [a-z/A-Z], valid character is among [0-9/A-Z/a-z/._-], up to 31 characters.
-------------	----------	---

Command Mode

Global Configuration

Default

None

Usage

Use this command to create a local user account on the switch.

Use the no form of this command to delete the account.

Examples

This is a sample output from this command displaying how to add a user named testName:

```
Switch(config)# username testName
```

This is a sample output from this command displaying how to delete a user named testName:

```
Switch(config)# no username testName
```

Related Commands

show usernames

19.41 username password

Command Purpose

Use this command to add username and password.

Command Syntax

username *NAME_STRING* password (8 |) *PASSWORD* (privilege *PRIVILEGE* |)

Parameter	Parameter Description	Parameter Value
NAME_STRING	Username	-
8	Specifies a hidden password will follow	-
PASSWORD	User password string	-
privilege PRIVILEGE	Set user privilege level	-

Command Mode

Global Configuration

Default

None

Usage

Use this command to add username and password.

Examples

This is a sample output from this command displaying how to add a user named testName and with the password of 123456:

```
Switch(config)# username testName password 123456
```

Related Commands

show usernames

19.42 username assign

Command Purpose

Use this command to assign a public key to a user.

Use the no form of this command to remove the configuration.

Command Syntax

username *NAME_STRING* assign rsa key *RSAKEYNAME*

no username *USERNAME* assign rsa key

Parameter	Parameter Description	Parameter Value
NAME_STRING	Username	String begin with [a-z/A-Z], valid character is among [0-9/A-Z/a-z/._-], up to 31 characters.
RSAKEYNAME	Key Name	-

Command Mode

Global Configuration

Default

None

Usage

Use this command to assign a public key to a user.

Use the no form of this command to remove the configuration.

Examples

This is a sample output from this command displaying how to assign a key:

```
Switch(config)# username abc assign rsa key importkey
```

This is a sample output from this command displaying how to delete the assigned key:

```
Switch(config)# no username abc assign rsa key
```

Related Commands

username

rsa key

19.43 username privilege

Command Purpose

Use this command to set user privilege level.

Command Syntax

```
username NAME_STRING privilege PRIVILEGE ( password ( 8 | ) PASSWORD | secret PASSWORD | )
```

Parameter	Parameter Description	Parameter Value
NAME_STRING	Username	String begin with [a-z/A-Z], valid character is among [0-9/A-Z/a-z/._-], up to 31 characters.
PRIVILEGE	Set user privilege level	-
8	Specifies a hidden password will follow	-
PASSWORD	User password string	-
secret PASSWORD	User secret string	-

Command Mode

Global Configuration

Default

None

Usage

Use this command to set user privilege level.

Examples

This is a sample output from this command displaying how to add a user named testName and with the privilege 3 and password of 12345:

```
Switch(config)# username ul privilege 3 secret 12345
```

Related Commands

show usernames

19.44 username secret

Command Purpose

Use username command to create a local user account with secret password.

Command Syntax

username *NAME_STRING* secret *PASSWORD*

Parameter	Parameter Description	Parameter Value
NAME_STRING	Username	String begin with [a-z/A-Z], valid character is among [0-9/A-Z/a-z/._-], up to 31 characters.
secret PASSWORD	User secret string	-

Command Mode

Global Configuration

Default

None

Usage

Use username command to create a local user account with secret password.

Examples

This is a sample output from this command displaying how to add a user named u2 and with the secret 23:

```
Switch(config)# username u2 secret 23
```

Related Commands

show usernames

19.45 re-username

Command Purpose

Use re-username command to modify local user account on the switch.

Command Syntax

re-username *OLD_NAME NEW_NAME*

Parameter	Parameter Description	Parameter Value
OLD_NAME	Old username	String begin with [a-z/A-Z], valid character is among [0-9/A-Z/a-z/._-], up to 31 characters.
NEW_NAME	New username	String begin with [a-z/A-Z], valid character is among [0-9/A-Z/a-z/._-], up to 31 characters.

Command Mode

Global Configuration

Default

None

Usage

Use re-username command to modify local user account on the switch.

Examples

The following example shows how to change user account's name:

```
Switch(config)# re-username oldUser newUser
```

Related Commands

show usernames

19.46 enable password

Command Purpose

Use this command to set the password which is needed when user enter Privileged EXEC mode.

Command Syntax

enable password (8 |) *PASSWORD*

no enable password

Parameter	Parameter Description	Parameter Value
8	Specifies a hidden password will follow	-
PASSWORD	Enable password string	-

Command Mode

Global Configuration

Default

None

Usage

If this command is set, the user need to provide the password when enter Privileged EXEC mode.

Examples

The following example shows how to set the password:

```
Switch(config)# enable password 654321
Switch(config)# exit
Switch# disable
Switch> enable

Password:
Switch#
```

The following example shows how to unset the password:

```
Switch(config)# no enable password
```

Related Commands

enable

disable

19.47 enable password privilege

Command Purpose

Use this command to set the password which is needed when a user enter Privileged EXEC mode.

Use the no form of this command to unset the password when user enter Privileged EXEC mode.

Command Syntax

enable password privilege *PRIVILEGE* (8 |) *PASSWORD*

no enable password privilege *PRIVILEGE*

Parameter	Parameter Description	Parameter Value
PRIVILEGE	Set user privilege level	-
8	Specifies a hidden password will follow	-
PASSWORD	Enable password string	-

Command Mode

Global Configuration

Default

None

Usage

If this command is set, the user need to provide the password when enter Privileged EXEC mode.

Examples

The following example shows how to set the password:

```
Switch(config)# enable password privilege 2 abc123
Switch(config)# exit
Switch# disable
Switch> enable 2

Password:
Switch#
```

The following example shows how to unset the password:

```
Switch(config)# no enable password privilege 2
```

Related Commands

enable

disable

19.48 service password-encryption

Command Purpose

Use this command to set up the miscellaneous service encrypt system passwords.

Use the no form of this command to unset service encrypt system passwords.

Command Syntax

service password-encryption

no service password-encryption

Command Mode

Global Configuration

Default

Not encrypt

Usage

After using this command, the password in the display result of “show running-config” should be encrypted.

After using the no form of this command, the newly added password in the display result of “show current-configuration” should be plain text and the existing password should still be encrypted.

Examples

The following example shows how to set service password-encryption:

```
Switch(config)# service password-encryption
```

The following example shows how to unset service password-encryption:

```
Switch(config)# no service password-encryption
```

Related Commands

show running-config

19.49 aaa new-model

Command Purpose

Use this command to enable the authentication, authorization, accounting (AAA) access control model.

Use the no form of this command to disable the authentication, authorization, accounting (AAA) access control model.

Command Syntax

```
aaa new-model
```

```
no aaa new-model
```

Command Mode

Global Configuration

Default

Disabled

Usage

Use this command to enable the authentication, authorization, accounting (AAA) access control model.

Use the no form of this command to disable the authentication, authorization, accounting (AAA) access control model.

Examples

The following example shows how to enable AAA access control model:

```
Switch(config)# aaa new-model
```

The following example shows how to disable AAA access control model:

```
Switch(config)# no aaa new-model
```

Related Commands

show aaa status

19.50 aaa authentication login

Command Purpose

Use this command to set authentication, authorization, accounting (AAA) authentication at login.

Use the no form of this command to delete the configuration.

Command Syntax

```
aaa authentication login ( default | AUTHLISTNAME ) ( enable | ) ( line | ) ( radius | ) ( tacplus | ) ( local | ) ( none | )
```

```
no aaa authentication login ( default | AUTHLISTNAME )
```

Parameter	Parameter Description	Parameter Value
default	Default method list	-
<i>AUTHLISTNAME</i>	Named authentication list (a-z/A-Z/0-9/._-)	-
enable	Enable password	-
line	Line password	-
radius	RADIUS server	-
tacplus	TACACS+	-

local	Local username	-
none	No authentication	-

Command Mode

Global Configuration

Default

None

Usage

Use the aaa authentication login configuration command to specify one or more AAA methods.

Examples

The following example shows how to set authentication at login:

```
Switch(config)# aaa authentication login default local radius none
```

The following example shows how to delete authentication:

```
Switch(config)# no aaa authentication login default
```

Related Commands

show aaa method-lists authentication

19.51 aaa authorization exec

Command Purpose

Use this command to set authentication, authorization, accounting (AAA) authorization at login.

Command Syntax

aaa authorization exec (default | *AUTHLISTNAME*) (none |) (radius |) (local |)
(tacplus |)

no aaa authorization exec (default | *AUTHLISTNAME*)

Parameter	Parameter Description	Parameter Value
default	Default method list	-
<i>AUTHLISTNAME</i>	Named authentication list (a-z/A-Z/0-9/._-)	-
none	No authentication	-
radius	RADIUS server	-
local	Local username	-
tacplus	TACACS+	-

Command Mode

Global Configuration

Default

None

Usage

Use the aaa authorization exec configuration command to Set authentication, authorization, accounting (AAA) authorization at login

Examples

The following example shows how to set authorization exec:

```
Switch# configure terminal
Switch(config)# aaa authorization exec default tacplus none
```

Related Commands

show aaa method-lists authorization

19.52 aaa accounting exec

Command Purpose

Use this command to set authentication, authorization, accounting (AAA) accounting at login.

Use the no form of this command to delete the configuration.

Command Syntax

aaa accounting exec (default | *AUTHLISTNAME*) (start-stop (radius | tacplus | none) * | stop-only (radius | tacplus | none) * | none)

no aaa accounting exec (default | *AUTHLISTNAME*)

Parameter	Parameter Description	Parameter Value
default	Default method list	-
<i>AUTHLISTNAME</i>	Named authentication list (a-z/A-Z/0-9/._-)	-
start-stop	Send accounting request when user login and logout	-
stop-only	Send accounting request when user logout	-
radius	RADIUS server	-
tacplus	TACACS+	-
none	No authentication	-

Command Mode

Global Configuration

Default

None

Usage

Use this command to set authentication, authorization, accounting (AAA) accounting at login.

Examples

The following example shows how to set accounting exec:

```
Switch# configure terminal
Switch(config)# aaa accounting exec default start-stop tacplus
```

The following example shows how to delete accounting:

```
Switch# configure terminal
Switch(config)# no aaa accounting exec default
```

Related Commands

show aaa method-lists accounting

19.53 aaa accounting commands

Command Purpose

Use this command to set authentication, authorization, accounting (AAA) accounting for commands.

Use the no form of this command to delete the configuration.

Command Syntax

aaa accounting commands (default | *AUTHLISTNAME*) (tacplus | none) *

no aaa accounting commands (default | *AUTHLISTNAME*)

Parameter	Parameter Description	Parameter Value
default	Default method list	-
AUTHLISTNAME	Named authentication list (a-z/A-Z/0-9/._-)	-
tacplus	TACACS+	-
none	No authentication	-

Command Mode

Global Configuration

Default

None

Usage

Use this command to set authentication, authorization, accounting (AAA) accounting for commands.

Examples

The following example shows how to set accounting commands:

```
Switch# configure terminal
Switch(config)# aaa accounting commands default tacplus
```

The following example shows how to delete accounting for commands:

```
Switch# configure terminal
Switch(config)# no aaa accounting commands default
```

Related Commands

show aaa method-lists accounting

19.54 aaa privilege mapping

Command Purpose

Use this command to set the mapping range in AAA server and switch.

Use the no form of this command to restore the default mapping.

Command Syntax

aaa privilege mapping AAA_PRIVILEGE1 AAA_PRIVILEGE2 AAA_PRIVILEGE3

no aaa privilege mapping

Parameter	Parameter Description	Parameter Value
AAA_PRIVILEGE1	Max server privilege mapping to switch privilege 1(default is 0)	-
AAA_PRIVILEGE2	Max server privilege mapping to switch privilege 2(default is 1)	-
AAA_PRIVILEGE3	Max server privilege mapping to switch privilege 3(default is 10)	-

Command Mode

Global Configuration

Default

0, 1, 10

Usage

0: The server privilege 0 mapping to switch level 1

1: The server privilege 1 mapping to switch level 2

9: The server privilege 2-9 mapping to switch level 3

Other: The server privilege 10-15 mapping to switch level 4

Examples

The following example shows how to set the mapping range:

```
Switch(config)# aaa privilege mapping 0 1 14
```

The following example shows how to set default mapping range:

```
Switch# configure terminal
Switch(config)# no aaa privilege mapping
```

Related Commands

show aaa privilege mapping

19.55 debug aaa

Command Purpose

Use this command to enable debugging aaa.

Use the no form of this command to disable debugging aaa.

Command Syntax

debug aaa (all | packet | event | protocol | timer)

no debug aaa (all | packet | event | protocol | timer)

Parameter	Parameter Description	Parameter Value
all	Enable to report all aaa debug messages	-
packet	Enable to report aaa debug messages for sending and receiving packets	-

event	Enable to report aaa debug messages for events	-
protocol	Enable to report aaa debug messages for protocol states	-
timer	Enable to report aaa debug messages for timer	-

Command Mode

Privileged EXEC

Default

Disabled

Usage

None

Examples

In the following example shows how to enable debugging aaa all:

```
Switch# debug aaa all
```

In the following example shows how to disable debugging aaa all:

```
Switch# no debug aaa all
```

Related Commands

show debugging

19.56 exec-timeout

Command Purpose

Use this command to set console timeout value.

Use the no form of this command to restore the default value.

Command Syntax

exec-timeout *ETIMEOUTMIN* (*ETIMEOUTSEC* |)

no exec-timeout

Parameter	Parameter Description	Parameter Value
ETIMEOUTMIN	Timeout value in minute.	0-35791
ETIMEOUTSEC	Timeout value in second	0- 2147483

Command Mode

Line Configuration

Default

10

Usage

None

Examples

The following example shows how to set console exec-timeout to 2 minutes 30 seconds:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# exec-timeout 2 30
```

The following example shows how to set console exec-timeout to default value:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# no exec-timeout
```

Related Commands

show console

19.57 login

Command Purpose

Use this command to enable console password checking, you can choose local password checking.

Use the no form of this command to disable console password checking.

Command Syntax

login (local |)

no login (local |)

Parameter	Parameter Description	Parameter Value
local	Local username	-

Command Mode

Line Configuration

Default

no password checking

Usage

Use this command to enable console password checking, you can choose local password checking.

Use the no form of this command to disable console password checking.

Examples

The following example shows how to set console local password checking enable:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# login local
```

The following example shows how to set console local password checking disable:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# no login local
```

Related Commands

show console

19.58 privilege level

Command Purpose

Use this command to set console privilege level for line.

Use the no form of this command to restore the default value.

Command Syntax

privilege level *PRIVILEGE*

no privilege level

Parameter	Parameter Description	Parameter Value
PRIVILEGE	Default privilege level for line	-

Command Mode

Line Configuration

Default

1

Usage

Use this command to set console privilege level for line.

Use the no form of this command to restore the default value.

Examples

The following example shows how to set console privilege level for line to 2:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# privilege level 2
```

The following example shows how to set console privilege level for line to default value:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# no privilege level
```

Related Commands

show console

19.59 line-password

Command Purpose

Use this command to set console line-password specifies a hidden password will follow or user password string.

Use the no form of this command to unset console line-password.

Command Syntax

line-password (8 |) *NAME_STRING*

no line-password

Parameter	Parameter Description	Parameter Value
8	Specifies a hidden password will follow	-
NAME_STRING	User password string	-

Command Mode

Line Configuration

Default

No console line-password

Usage

Use this command to set console line-password specifies a hidden password will follow or user password string.

Use the no form of this command to unset console line-password.

Examples

The following example shows how to set console line-password specifies a hidden password will follow:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# line-password 8 test
```

The following example shows how to unset console line-password:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# no line-password
```

Related Commands

show console

19.60 stopbits

Command Purpose

Use this command to set console sync line stop bits.

Use no form of this command to set console sync line stop bits to default value.

Command Syntax

stopbits (1 | 2)

no stopbits

Parameter	Parameter Description	Parameter Value
1	Set 1 bit stop bit	-
2	Set 2 bits stop bits	-

Command Mode

Line Configuration

Default

One-bit stop

Usage

None

Examples

The following example shows how to set console sync line stop bits one-bit stop:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# stopbits 1
```

The following example shows how to set console sync line stop bits to default value:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# no stopbits
```

Related Commands

show console

19.61 databits

Command Purpose

Use this command to set console number of data bits.

Use the no form of this command to set console number of data bits per character to default value.

Command Syntax

databits (7 | 8)

no databits

Parameter	Parameter Description	Parameter Value
7	7-bit databits.	-
8	8-bit databits.	-

Command Mode

Line Configuration

Default

8-bit databits

Usage

Use this command to set console number of data bits.

Use the no form of this command to set console number of data bits per character to default value.

Examples

The following example shows how to set console number of data bits per character to 7-bit databits:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# databits 7
```

Related Commands

show console

19.62 parity

Command Purpose

Use this command to set console terminal parity.

Use the no form of this command to restore the default value.

Command Syntax

parity (even | odd | none)

no parity

Parameter	Parameter Description	Parameter Value
even	Parity mode even	-
odd	Parity mode odd	-
none	No parity	-

Command Mode

Line Configuration

Default

No parity

Usage

Use this command to set console terminal parity.

Use the no form of this command to restore the default value

Examples

The following example shows how to set console terminal parity type odd:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# parity odd
```

The following example shows how to set console terminal parity type to default value:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# no parity
```

Related Commands

line console
show console

19.63 speed

Command Purpose

Use this command to set the transmit and receive speeds of console terminal.

Use the no form of this command to restore the default value.

Command Syntax

```
speed ( 115200 | 57600 | 38400 | 19200 | 9600 | 4800 | 2400 | 1200 | 600 )
no speed
```

Command Mode

Line Configuration

Default

115200

Usage

None

Examples

The following is an example of set console terminal speed to 115200:

```
Switch(config)# line console 0
Switch(config-line)# speed 115200
```

The following is an example of set console terminal speed to default value:

```
Switch(config)# line console 0
Switch(config-line)# no speed
```

Related Commands

show console

19.64 authorization exec

Command Purpose

Use this command to enable authentication, authorization, accounting (AAA) authorization for logins.

Use the no form of this command to restore the default value.

Command Syntax

authorization exec (default | *LISTNAME*)

no authorization exec

Parameter	Parameter Description	Parameter Value
default	Default authorization list	-
LISTNAME	An authorization list with this name (a-zA-Z0-9._-)	-

Command Mode

Line Configuration

Default

None

Usage

Use this command to enable authentication, authorization, accounting (AAA) authorization for logins.

Use the no form of this command to restore the default value.

Examples

The following example shows how to enable authorization for logins:

```
Switch# configure terminal
Switch(config)# line vty 0 7
Switch(config-line)# authorization exec default
```

The following example shows how to set authorization to default method list:

```
Switch# configure terminal
Switch(config)# line vty 0 7
Switch(config-line)# no authorization exec
```

Related Commands

show vty

19.65 accounting exec

Command Purpose

Use this command to enable authentication, authorization, accounting (AAA) accounting for logins.

Use the no form of this command to restore the default value.

Command Syntax

accounting exec (default | *LISTNAME*)

no accounting exec

Parameter	Parameter Description	Parameter Value
default	Default accounting list	-

LISTNAME	An accounting list with this name (a-z/A-Z/0-9/._-)	-
----------	---	---

Command Mode

Line Configuration

Default

None

Usage

Use this command to enable authentication, authorization, accounting (AAA) accounting for logins.

Use the no form of this command to restore the default value.

Examples

The following example shows how to enable accounting for logins:

```
Switch# configure terminal
Switch(config)# line vty 0 7
Switch(config-line)# accounting exec default
```

The following example shows how to set accounting exec to default method list:

```
Switch# configure terminal
Switch(config)# line vty 0 7
Switch(config-line)# no accounting exec
```

Related Commands

show vty

19.66 accounting commands

Command Purpose

Use this command to enable accounting for commands.

Command Syntax

accounting commands (default | *LISTNAME*)

no accounting commands

Parameter	Parameter Description	Parameter Value
default	Default accounting list	-
LISTNAME	An accounting list with this name (a-z/A-Z/0-9/._-)	-

Command Mode

Line Configuration

Default

None

Usage

Use this command to enable accounting for commands.

Examples

The following example shows how to enable accounting for commands:

```
Switch# configure terminal
Switch(config)# line vty 0 7
Switch(config-line)# accounting commands default
```

Related Commands

show vty

19.67 end

Command Purpose

Use this command to end the current configuration session and return to Privileged EXEC mode.

Command Syntax

end

Command Mode

All Configuration Mode

Default

None

Usage

This command will bring you back to Privileged EXEC mode regardless of what configuration mode or configuration sub-mode you are in.

This global configuration command can be used in any configuration mode.

Use this command when you are done configuring the system and you want to return to EXEC mode to perform verification steps.

Examples

In the following example, the end command is used to exit from interface configuration mode and return to Privileged EXEC mode:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# end
Switch#
```

Related Commands

None

19.68 ip access-class

Command Purpose

Use this command to set vty IPv4 ACL.

Use the no form of this command to remove ACL from vty.

Command Syntax

ip access-class *NAME_STRING* in

no ip access-class in

Parameter	Parameter Description	Parameter Value
NAME_STRING	IP ACL NAME	The initial character name should be a-z, A-Z, 0-9 or ._, character only can be 0-9/A-Z/a-z/. _ and the max length is 20

Command Mode

Line Configuration

Default

None

Usage

None

Examples

The following example shows how to configure IPv4 ACL on vty:

```
Switch# configure terminal
Switch(config)# line vty 1
Switch(config-line)# ip access-class a4 in
```

Related Commands

ip access-list

19.69 cipher detect

Command Purpose

Use this command to set cipher detect mode.

Command Syntax

cipher detect (none | normal | strong (level (1 | 2) |))

Parameter	Parameter Description	Parameter Value
none	No cipher detect	-
normal	cipher's length must no less than 8 bytes	-
strong	cipher's length must no less than 8 bytes and consists of at least 2 types of characters, including letters, digits, and special characters	-
strong level 1	cipher's length must no less than 8 bytes and consists of at least 2 types of characters, including letters, digits, and special characters	-

strong level 2	cipher must contain upper-case letters, lower-case letters, digits, and special characters. Admin's password should not include the username or username revert.	-
----------------	--	---

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example shows how to set cipher detect:

```
Switch# configure terminal
Switch(config)# cipher detect normal
```

Related Commands

None

19.70 login-security enable

Command Purpose

Use this command to enable login-security function.

Use the no form of this command to disable login-security function.

Command Syntax

login-security enable

no login-security enable

Command Mode

Global Configuration

Default

Enable

Usage

None

Examples

The following example shows how to enable login-security function:

```
Switch# configure terminal
Switch(config)# login-security enable
```

The following example shows how to disable login-security function:

```
Switch# configure terminal
Switch(config)# no login-security enable
```

Related Commands

None

19.71 login-security max-fail-num

Command Purpose

Use this command to configure maximum number of failure and failure record period in login-security function.

Use the no form of this command to recover to default value

Command Syntax

login-security max-fail-num *MAX_FAIL_NUM* *FAIL_PERIOD*

no login-security max-fail-num

Parameter	Parameter Description	Parameter Value
MAX_FAIL_NUM	Maximum number of login failure	Range is 1-10
FAIL_PERIOD	Login failure record period	Range is 1-120, unit is minute

Command Mode

Global Configuration

Default

5

Usage

None

Examples

The following example shows how to configure maximum number of login failure and failure record period in login-security:

```
Switch# configure terminal
Switch(config)# no login-security max-fail-num 7 9
```

The following example shows how to recover maximum number of login failure and failure record period to default value login-security:

```
Switch# configure terminal
Switch(config)# no login-security max-fail-num
```

Related Commands

None

19.72 login-security lock-duration

Command Purpose

Use this command to configure lock duration of login-security.

Use the no form of this command to recover it to default value.

Command Syntax

login-security lock-duration *DURATION*

no login-security lock-duration

Parameter	Parameter Description	Parameter Value
DURATION	Lock duration of accounts	Range is 1-1000, uint is minute

Command Mode

Global Configuration

Default

Enable

Usage

None

Examples

The following example shows how to configure lock duration:

```
Switch# configure terminal
Switch(config)# login-security lock-duration
```

The following example shows how to recover lock duration to default value:

```
Switch# configure terminal
Switch(config)# no login-security lock-duration
```

Related Commands

None

20 SFLOW Commands

20.1 sflow enable

Command Purpose

Use this command to enable sFlow globally.

Use the no form of this command to disable sFlow.

Command Syntax

sflow enable

no sflow enable

Command Mode

Global Configuration

Default

Disabled

Usage

Before any other sFlow command can be configured, sFlow services must be enabled globally. Use the no parameter with this command to remove all sFlow configurations and disable sFlow globally.

Examples

This example shows how to enable sFlow services globally:

```
Switch(config)# sflow enable
```

This example shows how to disable sFlow services globally:

```
Switch(config)# no sflow enable
```

Related Commands

show sflow

20.2 sflow agent

Command Purpose

Use this command to configure sFlow agent.

Use the no form of this command to delete the sFlow agent.

Command Syntax

```
sflow agent ip IP_ADDR
```

```
no sflow agent ip
```

Parameter	Parameter Description	Parameter Value
IP_ADDR	IPv4 address	-

Command Mode

Global Configuration

Default

0.0.0.0

Usage

Use this command to configure IP address for sflow agent. If not configured, sflow agent IP address will be 0.0.0.0.

Examples

This example shows how to configure agent with IP address 10.0.0.254:

```
Switch(config)# sflow agent ip 10.0.0.254
```

This example shows how to configure agent with IP address 0.0.0.0:

```
Switch(config)# no sflow agent ip
```

Related Commands

show sflow

20.3 sflow collector

Command Purpose

Use this command to configure sFlow collector.

Use the no form of this command to delete the sFlow collector.

Command Syntax

```
sflow collector mgmt-if IP_ADDR ( UDP_PORT | )
```

```
no sflow collector IP_ADDR
```

Parameter	Parameter Description	Parameter Value
IP_ADDR	Collector IPv4 address	-
UDP_PORT	Collector UDP port number	1-65535, default is 6343

Command Mode

Global Configuration

Default

Default source ip is the ip address of interface which relates to sflow collector

Usage

Use this command to add a collector by specifying the combination of IP address and UDP port and source IP address. Only up to two unique combinations can be allowed to be added.

Examples

This example shows how to add a collector:

```
Switch(config)# sflow collector mgmt-if 10.0.0.254 3000
```

This example shows how to remove a collector:

```
Switch# configure terminal
Switch(config)# no sflow collector 10.0.0.254 3000
```

Related Commands

show sflow

20.4 sflow counter interval

Command Purpose

Use this command to configure sFlow polling-interval for counter sample.

Use the no form of this command to restore the default value.

Command Syntax

sflow counter interval *INTERVAL_VAL*

no sflow counter interval

Parameter	Parameter Description	Parameter Value
INTERVAL_VAL	Interval value in second	1-2000 seconds, default is 20 seconds.

Command Mode

Global Configuration

Default

20

Usage

Use this command to set sFlow polling-interval for counter sample. Use the no parameter with this command to restore to the default value. The default interval value is 20 seconds.

Examples

This example shows how to set sFlow polling-interval to 10 second:

```
Switch(config)# sflow counter interval 10
```

This example shows how to set sFlow polling-interval to default value:

```
Switch(config)# no sflow counter interval
```

Related Commands

show sflow

20.5 sflow counter-sampling enable

Command Purpose

Use this command to enable counter sampling on specified port.

Use the no form of this command to disable counter sampling.

Command Syntax

sflow counter-sampling enable

no sflow counter-sampling enable

Command Mode

Interface Configuration

Default

Disabled

Usage

Use this command to enable counter sampling on specified port. This command can only be configured on a port which is not a link-agg group member. The port can be either a physical port or a link-agg port.

Examples

This example shows how to set sFlow polling-interval to 10 second:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# sflow counter-sampling enable
```

This example shows how to disable sFlow counter sampling on interface eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no sflow counter-sampling enable
```

Related Commands

show sflow

20.6 sflow flow-sampling rate

Command Purpose

Use this command to configure flow sampling rate.

Use the no form of this command to restore the default value.

Command Syntax

sflow flow-sampling rate *RATE*

no sflow flow-sampling rate

Parameter	Parameter Description	Parameter Value
RATE	Sample rate value,	must be a power of 2. Range is 1-32768, default is 32768.

Command Mode

Interface Configuration

Default

32768

Usage

Use this command to set sFlow packet sampling rate. The rate value is packet number. When the value is 32768, one packet will be sampled when 32768 packets are passed, sFlow uses CPU resources to collect samples and send samples to the collector. If a low sampling rate is set, CPU utilization can become high. To protect CPU from overwhelming, exceeded flow samples would be dropped. If a sampling rate less than default value is configured, a prompt will be given to info the potential of involving a high CPU utilization. This command can only be configured on a port which is not a link-agg group member. The port can be either a physical port or a link-agg port.

Examples

This example shows how to enable sFlow counter sampling on interface eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# sflow flow-sampling rate 2048
% Warning: sFlow sampling requires high CPU usage, especially with a low rate.
   Suggested rate not less than 32768.
```

This example shows how to disable sFlow counter sampling on interface eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no sflow flow-sampling rate
```

Related Commands

show sflow

20.7 sflow flow-sampling enable

Command Purpose

Use this command to enable packet sampling on individual port.

Use the no form of this command to disable packet sampling.

Command Syntax

sflow flow-sampling enable (input | output | both)

no sflow flow-sampling enable (input | output | both)

Parameter	Parameter Description	Parameter Value
input	Sampling for input packets	-
output	Sampling for output packets	-
both	Sampling for packets on both direction	-

Command Mode

Interface Configuration

Default

Disabled

Usage

Use this command to enable packet sampling on individual port. This command can only be configured on a port which is not a link-agg group member. The port can be either a physical port or a link-agg port.

Examples

This example shows how to enable input packet sampling on route port eth-0-1:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# sflow flow-sampling enable input
```

Related Commands

show sflow

20.8 debug sflow

Command Purpose

Use this command to turn on the debug switches of sflow module.

Use the no form of this command to turn off the debug switches of sflow module.

Command Syntax

debug sflow (all | packet | counter | sample)

no debug sflow (all | packet | counter | sample)

Parameter	Parameter Description	Parameter Value
all	Enable to report all debug messages	-
counter	Enable to report sflow debug messages for counters	-
packet	Enable to report sflow debug messages for sending and receiving packets	-
sample	Enable to report sflow debug messages for sampling	-

Command Mode

Privileged EXEC

Default

Disabled

Usage

Use this command to turn on the debug switches of sflow module.

Examples

In the following example shows how to enable debugging sflow all:

```
Switch# Switch# debug sflow all
```

Related Commands

show debugging

20.9 show sflow

Command Purpose

Use this command to show the running information of sflow.

Command Syntax

show sflow

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to show the running information of sflow.

Examples

This example shows how to show the sflow running information:

```
Switch# show sflow

sFlow Version: 4
sFlow Global Information:
  Agent IPv4 address      : 10.0.0.254
  Counter Sampling Interval : 10 seconds
  Collector 1:
    IPv4 Address: 10.0.0.254
    Port: 3000
sFlow Port Information:

Port          Counter  Flow      Flow-Sample  Flow-Sample
              Counter  Flow      Direction    Rate
-----
eth-0-7      Enable   Enable    Input         2048
```

Related Commands

sflow enable

sflow agent

21 GLOBAL Commands

21.1 show debugging

Command Purpose

Use this command to display the debugging status.

Command Syntax

show debugging (aaa | sflow |) (detail |)

Parameter	Parameter Description	Parameter Value
aaa	Display the states of aaa debugging	-
sflow	Display the states of sflow debugging	-
detail	Display the detailed information of debugging	-

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to display the debugging status.

Examples

The following is sample output from the show debugging aaa command:

```
Switch# show debugging aaa detail
```

Module	Feature	Type	Status
auth	aaa	event	on
	aaa	packet	on
	aaa	protocol	off
	aaa	timer	on

Related Commands

debug aaa

debug sflow

21.2 no debug all

Command Purpose

Use this command to turn off all debugging switches.

Command Syntax

no debug all

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to turn off all debugging switches.

Examples

In the following example shows how to disable all debugging:

```
Switch# no debug all
```

Related Commands

show debugging

21.3 show history

Command Purpose

To display the history command lines, use the show history command in EXEC mode.

Command Syntax

```
show history
```

Command Mode

Privileged EXEC

Default

none

Usage

Use this command to display the history command lines.

Examples

This example shows how to display history commands information of device:

```
Switch# show history  
  
1 show version  
2 debug sflow all  
3 no debug sflow all  
4 show history 1 show history
```


Related Commands

None

21.4 show running-config

Command Purpose

Use this command to display the current operating configuration.

The default configuration don't display.

Command Syntax

```
show running-config
```

Command Mode

Privileged EXEC

Default

none

Usage

Use this command to display the current operating configuration.

Default configuration don't display

Examples

This example shows how to display current operating configuration of device:

```
Switch# show running-config

hostname Switch
timestamp sync systemtime
username admin privilege 4 password admin
username test privilege 4 password test
!
!
logging server enable
```

```
logging merge disable
logging merge timeout 23
!
ntp authentication enable
!
ntp server mgmt-if 1.1.1.1
ntp server mgmt-if 10.10.25.8
ntp server mgmt-if 192.16.22.44 version 2
!
snmp-server enable
snmp-server system-contact admin@example.com
!
snmp-server view view1 included .1.2.3.4 mask f
!
snmp-server community sysname read-write
!
snmp-server trap target-address mgmt-if 10.10.27.232 community sysname
!
management ip address 10.10.39.104/23
management route add gateway 10.10.39.254
!
port-channel load-balance hash-arithmetic crc
port-channel load-balance set vxlan-vni
port-channel load-balance set inner-dst-mac
!
flow f1
!
flow f2
!
sflow enable
sflow agent ip 10.0.0.254
sflow counter interval 10
!
interface eth-0-1
  description TenGigabitEthernet
  speed 1000
  shutdown
!
interface eth-0-2
  shutdown
!
interface eth-0-3
  shutdown
  static-channel-group 10
!
interface eth-0-4
  shutdown
  static-channel-group 10
!
interface eth-0-5
  shutdown
  static-channel-group 5
!
interface eth-0-6
  shutdown
```

```
!  
interface eth-0-7  
  shutdown  
  sflow counter-sampling enable  
  sflow flow-sampling enable input  
  sflow flow-sampling rate 2048  
!  
interface eth-0-8  
  shutdown  
!  
interface eth-0-9  
  shutdown  
!  
interface eth-0-10  
  shutdown  
!  
interface eth-0-11  
!  
interface eth-0-12  
!  
interface eth-0-13  
!  
interface eth-0-14  
!  
interface eth-0-15  
!  
interface eth-0-16  
!  
interface eth-0-17  
!  
interface eth-0-18  
!  
interface eth-0-19  
!  
interface eth-0-20  
!  
interface eth-0-21  
!  
interface eth-0-22  
!  
interface eth-0-23  
!  
interface eth-0-24  
!  
interface eth-0-25  
!  
interface eth-0-26  
!  
interface eth-0-27  
!  
interface eth-0-28  
!  
interface eth-0-29  
!  
interface eth-0-30
```

```
!  
interface eth-0-31  
!  
interface eth-0-32  
!  
interface eth-0-33  
!  
interface eth-0-34  
!  
interface agg5  
  description LinkAgg5  
!  
interface agg10  
!  
tap-group tap1 1  
  ingress eth-0-1 flow f1  
  egress eth-0-9  
!  
tap-group tap2 2  
  ingress eth-0-21  
  egress eth-0-22  
!  
tap-group g1 3  
  ingress eth-0-33  
!  
line console 0  
  privilege level 4  
  no line-password  
  no login  
line vty 0 7  
  exec-timeout 35791 0  
  privilege level 4  
  no line-password  
  no login
```

Related Commands

None

21.5 md5sum

Command Purpose

Use this command to calculate the md5sum of the file.

Command Syntax

md5sum *FILENAME*

Parameter	Parameter Description	Parameter Value
FILENAME	Specify the file name	-

Command Mode

Privileged EXEC

Default

none

Usage

Use this command to calculate the md5sum of the file.

Examples

This example shows how to calculate the md5sum of the file:

```
Switch# md5sum flash:/boot/SwitchOS-vXXX-tap-v3.0.8.bin
8771a9cb344cebb70f8baa4715f3f97d flash:/boot/SwitchOS-vXXX-tap-v3.0.8.bin
```

Related Commands

None

22 MANAGEMENT Commands

22.1 show diagnostic-information

Command Purpose

Use this command to display the diagnostic information of the system.

Command Syntax

```
show diagnostic-information
```

Command Mode

Privileged EXEC

Default

None

Usage

Diagnostic information includes “show version” information, “show clock” information, etc.

The result is usually very long and the user can print the result into a file on the flash.

Examples

The following example shows how to display the diagnostic information:

```
Switch# show diagnostic-information
```

Related Commands

show version

show clock

22.2 show services

Command Purpose

Use this command to display the networking services.

Command Syntax

show services

Command Mode

Privileged EXEC

Default

None

Usage

This command is used to display networking services of the switch.

Examples

In the following example shows how to display networking services of the switch:

```
Switch# show services

Networking services configuration:
Service Name Status Port Protocol
-----+-----+-----+-----
http enable 80 TCP
telnet enable 23 TCP
ssh enable 22 TCP
snmp disable 161 UDP
```

Related Commands

None

22.3 show services rpc-api

Command Purpose

Use this command to display the rpc-api service.

Command Syntax

```
show services rpc-api
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

```
Switch# show services rpc-api

RPC-API service configuration:
Server State      : disable
Port              : 80
Authentication Mode : none
SSL State         : disable
```

Related Commands

service rpc-api

22.4 hostname

Command Purpose

Use this command to specify or modify the host name for the network server.

Use the no form of this command to reset the default value.

Command Syntax

hostname *NAME_STRING*

no hostname

Parameter	Parameter Description	Parameter Value
NAME_STRING	This system's network name	Up to 63 characters.

Command Mode

Global Configuration

Default

Switch

Usage

The hostname is used in prompts and default configuration filenames.

The name must also follow the rules for ARPANET host names. They must start with a letter, and have as interior characters only letters, digits, hyphens, and underline. Names must be 63 characters or fewer.

Examples

The following example changes the host name to DUT1:

```
Switch(config)# hostname DUT1
```

The following example changes the host name to default:

```
DUT1(config)# no hostname
```

Related Commands

None

22.5 format

Command Purpose

Use this command to format file system.

Command Syntax

format (system | boot | *udisk:*)

Parameter	Parameter Description	Parameter Value
system	The system partition	-
boot	The boot partition	-
udisk:	The USB mass storage device (MSDOS file system)	-

Command Mode

Global Configuration

Default

None

Usage

Format the USB mass storage device (MSDOS file system)

Examples

The following shows an example to format USB mass storage device:

```
Switch(config)# format udisk:  
  
WARNING: All data on udisk: will be lost!!!  
And format operation may take a while. Are you sure to process with format?  
[yes/no]: yes
```

Related Commands

umount udisk:

22.6 umount udisk:

Command Purpose

To uninstall the USB mass storage device before removing it from the switch.

Command Syntax

umount *udisk*:

Command Mode

Global Configuration

Default

None

Usage

USB mass storage device must exist in the system. You can use the “umount” command to uninstall the USB mass storage device.

Examples

The following example umount USB mass storage device:

```
Switch(config)# umount udisk:
```

Related Commands

format udisk:

22.7 reset factory-config

Command Purpose

Use this command to reset factory configuration.

Command Syntax

```
reset factory-config
```

Command Mode

Privileged EXEC

Default

None

Usage

The flash/boot/.factory-config.conf needs to exist for resetting factory configuration.

Examples

The following shows an example to reset factory configuration:

```
Switch# reset factory-config  
Startup-config will be overwritten with factory-config. Continue? [yes/no]:y
```

Related Commands

None

22.8 management ip address dhcp

Command Purpose

Use this command to set the management IP address on the Switch from the dhcp protocol.

To remove the management IP address from the dhcp protocol, use the no form of this command.

Command Syntax

management ip address dhcp
no management ip address dhcp

Command Mode

Global Configuration

Default

None

Usage

Users cannot connect to the device via telnet and only console port is available for management after removing the IP address.

Examples

The following example sets the management ipv4 address from dhcp protocol:

```
Switch(config)# management ip address dhcp
```

The following example unsets the management ipv4 address from dhcp protocol:

```
Switch(config)# no management ip address dhcp
```

Related Commands

management ip address

22.9 management ip address

Command Purpose

Use this command to set the management IP address on the Switch.

To remove the management IP address, use the no form of this command.

Command Syntax

management ip address *IP_ADDR_MASK*

no management ip address

Parameter	Parameter Description	Parameter Value
IP_ADDR_MASK	IP address with mask length	In A.B.C.D/M format

Command Mode

Global Configuration

Default

None

Usage

Users cannot connect to the device via telnet and only console port is available for management after removing the IP address.

Examples

The following example sets the management ipv4 address:

```
Switch(config)# management ip address 10.10.39.104/23
```

The following example unsets the management ipv4 address:

```
Switch(config)# no management ip address
```

Related Commands

management route gateway

22.10 management ipv6 address

Command Purpose

Use this command to set the management IPv6 address on the Switch.

To remove the management IPv6 address, use the no form of this command.

Command Syntax

management ipv6 address *IPV6_ADDR_MASK*

no management ipv6 address

Parameter	Parameter Description	Parameter Value
IPV6_ADDR_MASK	IPv6 address with mask length	In X:X::X:X/M format

Command Mode

Global Configuration

Default

None

Usage

Users cannot connect to the device via telnet and only console port is available for management after removing the IP address.

Examples

The following example sets the management ipv6 address:

```
Switch(config)# management ipv6 address 2000::1/64
```

The following example unsets the management ipv6 address:

```
Switch(config)# no management ipv6 address
```

Related Commands

management ipv6 route gateway

22.11 management route gateway

Command Purpose

Use this command to set the gateway on the Switch for management ip.

Use no form of this command to delete the gateway on the Switch for management ip.

Command Syntax

management route (add |) gateway *IP_ADDR*

no management route gateway

Parameter	Parameter Description	Parameter Value
add	Add a gateway address	-
IP_ADDR	IP address	-

Command Mode

Global Configuration

Default

None

Usage

Use this command to set the gateway on the Switch for management ip.

Use no form of this command to delete the gateway on the Switch for management ip.

Examples

The following example sets the gateway of 192.168.100.254 for the switch:

```
Switch(config)# management route add gateway 192.168.100.254
```

The following example unsets the gateway of 192.168.100.254 for the switch:

```
Switch(config)# no management route gateway
```

Related Commands

management ip address

22.12 management ipv6 route gateway

Command Purpose

Use this command to set the gateway on the Switch for management ipv6 address.

Command Syntax

management ipv6 route (add | del) gateway *IPV6_ADDR*

Parameter	Parameter Description	Parameter Value
add	Add a gateway ipv6 address	-
del	Delete a gateway ipv6 address	-
IPV6_ADDR	IPv6 address	-

Command Mode

Global Configuration

Default

None

Usage

Use this command to set the gateway on the Switch for management ipv6 address.

Examples

The following example sets the gateway of 2000::64 for the switch:

```
Switch(config)# management ipv6 route add gateway 2000::64
```

Related Commands

management ipv6 address

22.13 service telnet enable

Command Purpose

Use this command to set service telnet enable.

Use the no form of this command to set service telnet disable.

Command Syntax

service telnet enable

no service telnet enable

Command Mode

Global Configuration

Default

Enabled

Usage

Uses this command to enable the telnet service.

Examples

The following example set telnet service enable for the switch:

```
Switch# configure terminal
Switch(config)# service telnet enable
```

The following example set telnet service disable for the switch:

```
Switch(config)# no service telnet enable
Connection closed by foreign host.
```

Related Commands

telnet

22.14 service telnet acl

Command Purpose

Use this command to set telnet ACL.

Use the no form of the command to recover to default.

Command Syntax

service telnet acl *ACL_NAME*

no service telnet acl

Parameter	Parameter Description	Parameter Value
ACL_NAME	IP ACL NAME	The initial character name should be a-z, A-Z, or 0-9, character only can be 0-9/A-Z/a-z/.-_ and the max length is 20

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example sets telnet service acl:

```
Switch# configure terminal
Switch# ip access-list sac101
Switch(config-ip-acl-sac101)# exit
Switch(config)# service telnet acl sac101
```

The following example delete telnet service acl:

```
Switch# configure terminal
Switch(config)# no service telnet acl
```

Related Commands

None

22.15 service http

Command Purpose

Use this command to set service http enable or disable or restart or timeout.

Command Syntax

service http (enable | disable | restart | timeout *TIMEOUT_VALUE*)

Parameter	Parameter Description	Parameter Value
enable	Enable the http service	-
disable	Disable the http service	-
restart	Restart the http service	-

timeout TIMEOUT_VALUE	Set http timeout value, unit is minute	1-60
-----------------------	--	------

Command Mode

Global Configuration

Default

Enabled

Timeout default value is 10 minutes

Usage

Uses this command to enable or disable or restart http service or set timeout value.

Examples

The following example set http service enable for the switch:

```
Switch(config)# service http enable
```

The following example set http service disable for the switch:

```
Switch(config)# service http disable
```

The following example set http service restart for the switch:

```
Switch(config)# service http restart
```

Related Commands

show web users

22.16 service http port

Command Purpose

Use this command to set the http service L4 port number

Use the no command to set the default http service L4 port number.

Command Syntax

service http port *L4_NUM_PORT*

no service http port

Parameter	Parameter Description	Parameter Value
L4_NUM_PORT	Http service L4 port number	The range is 1025-65535

Command Mode

Global Configuration

Default

80

Usage

None

Examples

The following example set http service L4 port number for the switch:

```
Switch(config)# service http port 2000
```

The following example set the default http service L4 port number for the switch:

```
Switch(config)# no service http port
```

Related Commands

show web users

22.17 service http acl

Command Purpose

Use this command to set http ACL.

Use the no form of the command to recover to default.

Command Syntax

```
service http acl ACL_NAME
```

```
no service http acl
```

Parameter	Parameter Description	Parameter Value
ACL_NAME	IP ACL NAME	The initial character name should be a-z, A-Z, or 0-9, character only can be 0-9/A-Z/a-z/._ and the max length is 20

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example sets http service acl:

```
Switch# configure terminal
Switch# ip access-list sacl01
Switch(config-ip-acl-sacl01)# exit
Switch(config)# service http acl sacl01
```

The following example delete http service acl:

```
Switch# configure terminal
Switch(config)# no service http acl
```

Related Commands

None

22.18 service https

Command Purpose

Use this command to set service https enable or disable or restart or set timeout.

Command Syntax

service https (enable | disable | restart | timeout *TIMEOUT_VALUE*)

Parameter	Parameter Description	Parameter Value
enable	Enable the https service	-
disable	Disable the https service	-
restart	Restart the https service	-
timeout <i>TIMEOUT_VALUE</i>	Set https timeout value, unit is minute	1-60

Command Mode

Global Configuration

Default

Enabled

Usage

Uses this command to enable or disable or restart https service.

Examples

The following example set https service enable for the switch:


```
Switch(config)# service https enable
```

The following example set https service disable for the switch:

```
Switch(config)# service https disable
```

The following example set https service restart for the switch:

```
Switch(config)# service https restart
```

Related Commands

show web users

22.19 service http load

Command Purpose

Use this command to set web image

Command Syntax

service http load *FILENAME*

no service http load

Parameter	Parameter Description	Parameter Value
FILENAME	WEB Image file	-

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example set web image:

```
Switch(config)# service http load flash:/webImage.bin
```

The following example set default web image:

```
Switch(config)# no service http load
```

Related Commands

service http enable service https enable

22.20 service https port

Command Purpose

Use this command to set the https service L4 port number.

Use the no command to set the default https service L4 port number.

Command Syntax

service https port *L4_NUM_PORT*

no service https port

Parameter	Parameter Description	Parameter Value
L4_NUM_PORT	Https service L4 port number	The range is 1025-65535

Command Mode

Global Configuration

Default

443

Usage

None

Examples

The following example set https service L4 port number for the switch:

```
Switch(config)# service https port 2000
```

The following example set the default https service L4 port number for the switch:

```
Switch(config)# no service https port
```

Related Commands

show web users

22.21 service https acl

Command Purpose

Use this command to set https ACL.

Use the no form of the command to recover to default.

Command Syntax

```
service https acl ACL_NAME
```

```
no service https acl
```

Parameter	Parameter Description	Parameter Value
ACL_NAME	IP ACL NAME	The initial character name should be a-z, A-Z, or 0-9, character only can be 0-9/A-Z/a-z/.-_ and the max length is 20

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example sets https service acl:

```
Switch# configure terminal
Switch# ip access-list sacl01
Switch(config-ip-acl-sacl01)# exit
Switch(config)# service https acl sacl01
```

The following example delete https service acl:

```
Switch# configure terminal
Switch(config)# no service https acl
```

Related Commands

None

22.22 service rpc-api enable

Command Purpose

Use the command to enable rpc-api service.

Use disable command to disable rpc-api service.

Command Syntax

```
service rpc-api enable ( port PORT_NUM | ) ( ssl ( ssl-port SSL_PORT_NUM | )  
(connect-timeout TIME_OUT) | )
```

service rpc-api disable

Parameter	Parameter Description	Parameter Value
PORT_NUM	port number of https service	Default port number is 80
SSL_PORT_NUM	port number of SSL service	Default port number is 443
TIME_OUT	time of persistent connection timeout, unit is second	1-7200

Command Mode

Global Configuration

Default

Disabled

Usage

Use this command to enable RPC-API service. If parameters need to be modified, RPC-API service need to be disable. RPC-API service cannot be enable when http has been enable.

Examples

The following example enables encrypted RPC-API service:

```
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# service rpc-api enable ssl
Switch(config)#
```

The following example disables encrypted RPC-API service:

```
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# service rpc-api disable
Switch(config)#
```

Related Commands

service rpc-api auth-mode

22.23 service rpc-api auth-mode

Command Purpose

Use the command to configure the auth mode of RPC-API.

Command Syntax

service rpc-api auth-mode (basic)

no service rpc-api auth-mode

Command Mode

Global Configuration

Default

Configure the auth mode of RPC-API

Usage

Use this command to enable or disable the RPC-API auth mode.

Examples

The following example enables the auth mode of RPC-API:

```
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# service rpc-api auth-mode basic
```

The following example disables the auth mode of RPC-API:

```
Switch(config)# no service rpc-api auth-mode basic
```

Related Commands

services rpc-api enable

22.24 service rpc-api acl

Command Purpose

Use this command to set RPC-API ACL.

Use the no form of the command to recover to default.

Command Syntax

```
service rpc-api acl ACL_NAME
```

```
no service telnet acl
```

Parameter	Parameter Description	Parameter Value
ACL_NAME	IP ACL NAME	The initial character name should be a-z, A-Z, or 0-9, character only can be 0-9/A-Z/a-z/._ and the max length is 20

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example sets rpc-api service acl:

```
Switch# configure terminal
Switch# ip access-list sacl01
Switch(config-ip-acl-sacl01)# exit
Switch(config)# service rpc-api acl sacl01
```

The following example delete rpc-api service acl:

```
Switch# configure terminal
Switch(config)# no service rpc-api acl
```

Related Commands

None

22.25 certificate load pem-cert

Command Purpose

Use the command to import the new certificate file.

Use the no command to restore the default certificate file.

Command Syntax

certificate load pem-cert (*FILENAME* | *GFLASHFILE*)

no certificate load pem-cert

Parameter	Parameter Description	Parameter Value
FILENAME	certificate file name, no path but suffix	-
GFLASHFILE	certificate file name with path	-

Command Mode

Global Configuration

Default

Default certificate file

Usage

The private key and certificate need to be placed in the same file as the new certificate file. You need to upload the new certificate file to the any directory under the flash/ directory on the device before using this command. Ensure that the HTTPS service is turned on at the time of command execution and restart the HTTPS service after execution to take effect.

Examples

The following example import new certificate file cert.pem:

```
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# certificate load pem-cert flash:/boot/cert.pem
Switch(config)#
```

The following example restore the default certificate file:

```
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# no certificate load pem-cert
Switch(config)#
```

Related Commands

None

22.26 statistics unit

Command Purpose

Use the command to change the unit of traffic statistics.

Command Syntax

statistics unit (1 | K | M | G)

Parameter	Parameter Description	Parameter Value
1	statistics/1	-
K	statistics/1,000	-

M	statistics/1,000,000	-
G	statistics/1,000,000,000	-

Command Mode

Global Configuration

Default

default unit is 1

Usage

change the unit of statistics

Examples

The following example change the unit:

```
Switch(config)#statistics unit K
```

Related Commands

None

23 SYSTEM CONFIGURATION Commands

23.1 disable

Command Purpose

Enter the disable command in EXEC mode to exit Privileged EXEC mode and return to user EXEC mode.

Command Syntax

disable

Command Mode

Privileged EXEC

Default

None

Usage

To exit Privileged EXEC mode and return to user EXEC mode, enter the disable command in EXEC mode.

The prompt for Privileged EXEC mode is “#”, for EXEC mode is “>”.

Examples

In the following example, the user enters Privileged EXEC mode using the enable command, then exits back to user EXEC mode using the disable command:

```
Switch# disable  
Switch>
```

Related Commands

enable

23.2 enable

Command Purpose

Use the enable command in user EXEC or Privileged EXEC mode to enter Privileged EXEC mode.

Command Syntax

enable

Command Mode

User EXEC

Default

None

Usage

To enter Privileged EXEC mod, use the enable command in user EXEC or Privileged EXEC mode.

The prompt for Privileged EXEC mode is “#”, for EXEC mode is “>”.

Examples

In the following example, the user enters Privileged EXEC mode using the enable command. The system prompts the user for a password before allowing access to the Privileged EXEC mode. The password is not printed to the screen. The user then exits back to user EXEC mode using the disable command:

```
Switch# disable
Switch> enable
Password:
Switch#

Password:
Switch#
```

Related Commands

disable
enable password

23.3 logout

Command Purpose

To logout of the current CLI session, enter the logout command in EXEC mode.

Command Syntax

logout

Command Mode

Privileged EXEC

Default

None

Usage

To logout of the current CLI session, enter the logout command in EXEC mode.

Examples

In the following example, the user logout of the current CLI session using the logout command:

```
Switch# logout  
Connection closed by foreign host.
```

Related Commands

None

23.4 reboot

Command Purpose

Use the reboot command to reload the operating system.

Command Syntax

reboot

Command Mode

Privileged EXEC

Default

None

Usage

The reboot command halts the system. Use the reboot command after configuration information is entered into a file and saved to the startup configuration.

Examples

The following example is sample dialog from the reboot command:

```
Switch# reboot  
Building configuration...  
Reboot system? [confirm]y  
Waiting ...  
% Connection is closed by administrator!
```

Related Commands

write

23.5 show file system

Command Purpose

Use this command to show file system information.

Command Syntax

show file system

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to show file system information.

Examples

The following example is to show file system information:

```
Switch# show file system

Type           Size      Used      Free      Use%
=====
flash:/        887M     56M       827M      7%
flash:/boot    776M     360M     412M     47%
udisk:         0B       0B        0B       100%
```

Related Commands

None

23.6 show management ip address

Command Purpose

Use this command to show management interface ip address.

Command Syntax

```
show management ip address
```

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to show management interface ip address.

Examples

The following example is to show management interface ip address:

```
Switch# show management ip address  
  
Management IP address: 10.10.39.131/23  
Gateway: 0.0.0.0
```

Related Commands

management ip address

management route gateway

23.7 show startup-config

Command Purpose

Use this command to show contents of startup configuration. Default configuration don't display.

Command Syntax

```
show startup-config
```

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to show contents of startup configuration. Default configuration don't display.

Examples

The following example is to show contents of startup configuration:

```
Switch# show startup-config

hostname Switch
timestamp sync systemtime
enable password abc
!
username admin privilege 4 password admin
username test privilege 4 password test
!
!
logging server enable
!
radius-server host mgmt-if 1.1.1.1
!
tacacs-server host mgmt-if 1.1.1.2
!
tacacs-server host mgmt-if 2.1.1.1 key mykey
```

```
!  
!  
ntp authentication enable  
!  
ntp key 43 aNickKey  
ntp trustedkey 43  
ntp key 123 ntpkty123  
!  
ntp server mgmt-if 1.1.1.1  
ntp server mgmt-if 10.10.25.8  
ntp server mgmt-if 192.16.22.44 version 2  
!  
snmp-server enable  
snmp-server system-contact admin@example.com  
!  
snmp-server view view1 included .1.2.3.4 mask f  
!  
snmp-server trap target-address mgmt-if 10.10.27.232 community sysname  
!  
snmp-server inform target-address mgmt-if 10.10.27.233 community sysname  
!  
management ip address 10.10.39.104/23  
management route add gateway 10.10.39.254  
!  
port-channel load-balance hash-arithmetic crc  
port-channel load-balance set vxlan-vni  
port-channel load-balance set inner-dst-mac  
!  
ip access-list a  
!  
ip access-list e1  
!  
ip access-list aaaa  
!  
flow f1  
!  
flow f2  
!  
sflow enable  
sflow agent ip 10.0.0.254  
sflow counter interval 10  
!  
interface eth-0-1  
  description TenGigabitEthernet  
  speed 1000  
  shutdown  
!  
interface eth-0-2  
  shutdown  
!  
interface eth-0-3  
  shutdown  
  static-channel-group 10  
!  
interface eth-0-4
```

```
shutdown
static-channel-group 10
!
interface eth-0-5
shutdown
static-channel-group 5
!
interface eth-0-6
shutdown
!
interface eth-0-7
shutdown
sflow counter-sampling enable
sflow flow-sampling enable input
sflow flow-sampling rate 2048
!
interface eth-0-8
shutdown
!
interface eth-0-9
shutdown
!
interface eth-0-10
shutdown
!
interface eth-0-11
!
interface eth-0-12
!
interface eth-0-13
!
interface eth-0-14
!
interface eth-0-15
!
interface eth-0-16
!
interface eth-0-17
!
interface eth-0-18
!
interface eth-0-19
!
interface eth-0-20
!
interface eth-0-21
!
interface eth-0-22
!
interface eth-0-23
!
interface eth-0-24
!
interface eth-0-25
!
```

```
interface eth-0-26
!
interface eth-0-27
!
interface eth-0-28
!
interface eth-0-29
!
interface eth-0-30
!
interface eth-0-31
!
interface eth-0-32
!
interface eth-0-33
!
interface eth-0-34
!
interface agg5
  description LinkAgg5
!
interface agg10
!
tap-group tap1 1
  ingress eth-0-1 flow f1
  egress eth-0-9
!
tap-group tap2 2
  ingress eth-0-21
  egress eth-0-22
!
tap-group g1 3
  ingress eth-0-33
!
line console 0
  privilege level 4
  no line-password
  no login
line vty 0 7
  exec-timeout 35791 0
  privilege level 4
  no line-password
  no login
```

Related Commands

write

23.8 write

Command Purpose

Use this command to write startup configuration.

Command Syntax

write

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to write startup configuration.

Examples

The following example is to write startup configuration:

```
Switch# write  
[OK]
```

Related Commands

show startup-config

23.9 boot system flash

Command Purpose

Use this command to specify the system image that the switch loads at startup in flash.

Command Syntax

boot system flash *STRING*

Parameter	Parameter Description	Parameter Value
STRING	System image file for next booting	-

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to specify an image to boot system.

This command will take effect after reboot.

Examples

The following example is sample dialog from the boot system command:

```
Switch# boot system flash:/boot/SecPathTAP2000A-IMW110-E6601.BIN.01

Are you sure to use flash:/boot/SecPathTAP2000A-IMW110-E6601.BIN.01 as the next
boot image? [confirm]y
Waiting ..... success
```

Related Commands

reboot

23.10 boot system tftp:

Command Purpose

Use this command to specify the system image that the switch loads at startup in tftp.

Command Syntax

boot system *tftp*: mgmt-if *IP_ADDR STRING*

Parameter	Parameter Description	Parameter Value
IP_ADDR	Server IP	-
STRING	Image file name	-

Command Mode

Privileged EXEC

Default

None

Usage

Management IP address in startup-config file will be used as source address when system boot via TFTP.

This command will take effect after reboot.

Examples

The following example is sample dialog from the boot system via tftp command:

```
Switch# boot system tftp: mgmt-if 10.10.38.160 SecPathTAP2000A-IMW110-E6601.BIN.01
Waiting . success
```

Related Commands

reboot

23.11 show boot

Command Purpose

Use this command to display the current image and the image the next startup will load.

Command Syntax

show boot (image |)

Parameter	Parameter Description	Parameter Value
image	Show the detailed information about the boot image.	-

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to display the current image and the image the next startup will load.

Examples

The following is sample output from the show boot command:

```
Switch# show boot

The current boot image version is: 1.10, ESS 6601
The current running image is: flash:/boot/SecPathTAP2000A-IMW110-E6601.BIN.01
The next running image is: tftp://10.10.38.160/SecPathTAP2000A-IMW110-E6601.BIN.01
```

The following is sample output from the show boot image command:


```

Switch# show boot image

Current boot image version: E580-1.10, ESS 6601
System image files list:
  Create Time          Version          File name
-----+-----+-----
  2017-08-02 13:32:31  v5.1.4          CNOS-e580-hybrid-v5.1.4.bin
* 2017-09-21 15:43:52  v1.10, ESS 6601 SecPathTAP2000A-IMW110-E6601.BIN.01
  
```

Related Commands

boot system flash

boot system tftp:

23.12 show memory

Command Purpose

Use this command to show memory.

Command Syntax

show memory (ccs | cds | switch | chsm | appcfg | fea | authd | all)

Parameter	Parameter Description	Parameter Value
ccs	Configure center service	-
cds	Data center service	-
switch	Switch process	-
chsm	Chassis manage process	-
appcfg	Application configure process	-
fea	Forwarding process	-
authd	Authentication daemon process	-
all	All processes	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following is sample output from the show memory appcfg command:

```
Switch# show memory appcfg

AppCfg Memory Information:
Type      Description                               Alloc Count  Alloc Size
-----
0         MEM_TEMP                                   : 1          8188
2         MEM_LIB_HASH                              : 16         320
3         MEM_LIB_HASH_BUCKET_LIST                  : 16         131008
4         MEM_LIB_HASH_BUCKET                       : 37         444
9         MEM_LIB SOCK_MASTER                       : 1          192
10        MEM_LIB SOCK                               : 5          1280
11        MEM_LIB SOCK_SESSION                      : 7          229348
12        MEM_LIB SOCK_DATA                         : 1          16
16        MEM_LIB SLIST                             : 113        2260
17        MEM_LIB SLISTNODE                         : 57         684
22        MEM_TBL_MASTER                           : 44         9788
23        MEM_TBL_INTERFACE                        : 37         28416
67        MEM_TBL_SYS_GLOBAL                       : 1          384
68        MEM_TBL_VERSION                          : 1          768
72        MEM_TBL_CHASSIS                          : 1          64
77        MEM_TBL_SYS_SPEC                         : 8          3072
84        MEM_TBL_MEM_SUMMARY                      : 1          28
112       MEM_TBL_SSH_CFG                          : 1          48
113       MEM_TBL_SNMP_CFG                         : 1          768
114       MEM_TBL_SNMP_VIEW                        : 1          256
116       MEM_TBL_SNMP_TRAP                        : 1          384
117       MEM_TBL_SNMP_INFORM                      : 1          384
118       MEM_TBL_SYSLOG_CFG                       : 1          384
119       MEM_TBL_NTP_SERVER                       : 3          288
121       MEM_TBL_NTP_KEY                           : 2          80
122       MEM_TBL_NTP_CFG                           : 1          64
123       MEM_TBL_NTP_IF                           : 1          8
124       MEM_TBL_NTP_IF                           : 1          256
125       MEM_TBL_USER                             : 2          1536
```

126	MEM_TBL_VTY	: 8	32736
127	MEM_TBL_CONSOLE	: 1	768
128	MEM_TBL_AUTHEN	: 1	192
129	MEM_TBL_LOGIN	: 3	1152
161	MEM_TBL_LOG_GLOBAL	: 1	12
163	MEM_TBL_SYS_LOAD	: 1	32
165	MEM_TBL_CLOCK	: 1	40
177	MEM_TBL_OPM_GLOBAL	: 1	4
180	MEM_TBL_OPM_DEBUG	: 1	4
194	MEM_TBL_DOT1X_GLOBAL	: 1	768
198	MEM_TBL_ENABLE	: 4	3072
199	MEM_TBL_CHIP	: 1	4
201	MEM_TBL_AUTHOR	: 1	192
202	MEM_TBL_ACCOUNT	: 1	192
203	MEM_TBL_ACCOUNTCMD	: 1	192
229	MEM_TBL_SFLOW_GLOBAL	: 1	48
234	MEM_DS_BRGIF	: 36	27648
235	MEM_DS_LAG	: 5	80
245	MEM_DS_ACLQOS_IF	: 3	3072
247	MEM_DS_DHCLIENT_IF	: 36	9216
262	MEM_PM_TEMP	: 1	4092
263	MEM_PM_LIB_MASTER	: 1	1024

Related Commands

show memory summary

23.13 show memory summary

Command Purpose

Use this command to show the summary of memory states.

Command Syntax

show memory summary total

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following is sample output from the show memory summary command:

```
Switch# show memory summary total

Total memory      : 940428 KB
Used memory       : 259228 KB
Freed memory      : 681200 KB
Buffer memory     : 0 KB
Cached memory     : 125848 KB
Memory utilization: 27.56%
```

Related Commands

show memory

23.14 show cpu utilization

Command Purpose

Use this command to show the cpu utilizations.

Command Syntax

show cpu utilization

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to show utilizations of cpu.

Examples

The following is sample output from the show cpu utilization command:

```

Switch# show cpu utilization

Process                Usage (%)
-----+-----
python                 3.42
fea                   2.62
switch                 0.20
appcfg                 0.10
cds                    0.10
snmpd                  0.10
ccs                    0.10
kworker                0.10
Others                 5.55
-----+-----
Total                  12.29
  
```

Related Commands

None

23.15 terminal length

Command Purpose

Use this command to set the number of terminal lines on a screen. Range is 0 to 512.

Use the no form of this command to restore the default value.

Command Syntax

terminal length *TERM_LINES*

terminal no length

Parameter	Parameter Description	Parameter Value
TERM_LINES	Number of lines on screen (0 for no pausing)	-

Command Mode

Privileged EXEC

Default

0 (no pausing)

Usage

None

Examples

The following is sample to set terminal length lines:

```
Switch# terminal length 100
```

The following is sample to unset terminal length lines:

```
Switch# terminal no length
```

Related Commands

None

23.16 terminal monitor

Command Purpose

Use this command to copy debug output to the current terminal line.

Use the no form of this command to close the debug output to the current terminal line.

Command Syntax

terminal monitor

terminal no monitor

Command Mode

Privileged EXEC

Default

Debug output to the current terminal line is closed

Usage

To copy debug output to the current terminal line, use the terminal monitor command in Privileged EXEC mode.

To close the debug output to the current terminal line, use the no form of this command.

Examples

The following is sample output from the terminal monitor command:

```
Switch# terminal monitor
```

The following is sample close the debug output to the current terminal line:

```
Switch# terminal no monitor
```

Related Commands

debug aaa

debug sflow

23.17 cd

Command Purpose

Use this command to change the current directory to dir.

Command Syntax

```
cd ( STRING | )
```

Parameter	Parameter Description	Parameter Value
STRING	Directory name	-

Command Mode

Privileged EXEC

Default

The initial default file system is flash. If you do not specify a directory on a file system, the default is the root directory on that file system.

Usage

Change the current directory to dir.

Examples

In the following example, the cd command is set the flash:/boot file system to the Flash memory:

```
Switch# cd flash:/boot
Switch# pwd

flash:/boot
```

Related Commands

pwd

23.18 mkdir

Command Purpose

Use this command to create a new directory in a Flash file system.

Command Syntax

mkdir *STRING*

Parameter	Parameter Description	Parameter Value
STRING	Directory name or file name	-

Command Mode

Privileged EXEC

Default

None

Usage

This command is valid only for local file systems.

Examples

The following example creates a directory named newdir in Flash:

```
Switch# mkdir flash:/newdir
```

Related Commands

rmdir

dir

23.19 rmdir

Command Purpose

Use this command to remove an existing directory in a Flash file system or udisk device.

Command Syntax

rmdir *STRING*

Parameter	Parameter Description	Parameter Value
STRING	Directory name or file name	-

Command Mode

Privileged EXEC

Default

None

Usage

This command is valid only for local file systems.

Examples

The following example deletes a directory named newdir:

```
Switch# rmdir flash:/newdir
Are you sure to delete flash:/newdir ? [no]y
```

Related Commands

mkdir

23.20 pwd

Command Purpose

Use this command to print the working directory.

Command Syntax

pwd

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to print the working directory.

Examples

The following example print current working directory:

```
Switch# pwd
flash:/
```

Related Commands

cd

23.21 ls

Command Purpose

To display a list of files on a file system, use the ls command in EXEC mode.

Command Syntax

ls (*flash:* | *flash:/boot* | *udisk:* |) (*STRING* |)

Parameter	Parameter Description	Parameter Value
flash:	File system on the flash	-
flash:/boot	File path “flash:/boot”	-
udisk:	USB storage devices	-

STRING	Directory name or file name	-
--------	-----------------------------	---

Command Mode

Privileged EXEC

Default

None

Usage

Use the ls (Flash file system) command to display flash information.

Examples

The following is sample output from the ls command:

```
Switch# ls

Directory of flash:/

total 3196
-rw-r--r-- 1    1371 May 31 22:32 001E080BE6C2.1.lic
-rwxr-xr-x 1 295938 Aug 15 10:26 AQR-G2 v3.2.5 ID19866 VER537.cld
-rw-r--r-- 1    39861 Jul  5 15:07 E580 48X2Q4Z EPLD-4.1 0410 POWERDOWN.tar.gz
drwxr-xr-x 2    2464 Sep 22 14:41 boot
drwxr-xr-x 7     760 Aug 15 10:26 cold
drwxr-xr-x 3    1016 Sep 22 14:42 conf
-rw-r--r-- 1    147 Aug 15 10:31 dhcpsnooping
-rw----- 1    151 Aug 15 10:31 dhcpv6snooping
drwxr-xr-x 2    728 Sep  4 20:53 info
-rw-r--r-- 1    909 Jul 18 13:30 init flow
-rw-r--r-- 1   3181 Aug 15 10:09 jinl_astp
drwxr-xr-x 3    224 Aug 10 11:25 lib
-rw-r--r-- 1   2180 Jul 13 16:09 liujy_lab.conf
drwxr-xr-x 2    288 Jul  1 2016 log
drwxr-xr-x 7    488 Aug 23 2016 monitor
drwxr-xr-x 2    232 May  2 19:03 reboot-info
-rw-r--r-- 1   11963 Mar 30 18:21 route.txt
-rw-r--r-- 1    2624 Sep 22 14:41 startup-config.conf
-rw----- 1   13686 Apr 10 18:57 startup-config.conf.2017-4-10
-rw-r--r-- 1    1314 May  4 18:48 startup-config.conf.empty
-rw-r--r-- 1    1694 Apr 21 17:40 startup-config.conf_0421
-rwxr-xr-x 1 1015068 Mar 18 2017 stressapptest
-rw-r--r-- 1 1155521 Sep 22 15:56 syslog
drwxr-xr-x 2    4192 Sep 12 06:09 syslogfile
```

Total 887.00M bytes (875.00M bytes free)

Related Commands

dir

23.22 copy running-config

Command Purpose

Use this command to copy the current device configuration to other files.

Command Syntax

copy running-config (mgmt-if |) (*STRING* |)

Parameter	Parameter Description	Parameter Value
mgmt-if	Need to connect to the URL via management interface	-
STRING	Copy to URL and local file name	-

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to copy the current running-config to destination file.

Examples

The following example copies the current configuration to the file named current-config.conf:

```
Switch# copy running-config flash:/current-config.conf
flash:/current-config.conf
[OK]
```

Related Commands

delete

23.23 copy startup-config

Command Purpose

Use this command to copy startup-config to tftp server or dest file.

Command Syntax

copy startup-config (mgmt-if |) (*STRING* |)

Parameter	Parameter Description	Parameter Value
mgmt-if	Need to connect to the URL via management interface	-
STRING	Copy to URL and local file name	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This is a sample output from the command displaying how to copy startup-config to tftp server:

```
Switch# copy startup-config mgmt-if tftp://10.10.38.160/

TFTP server [10.10.38.160]
Name of the TFTP file to access [] startup-config
Send file to tftp://10.10.38.160/startup-config
.
Sent 2337 bytes in 0.0 seconds
```

Related Commands

delete

23.24 copy mgmt-if

Command Purpose

Use this command to copy file from tftp server to local.

Command Syntax

copy mgmt-if *SRC_STRING DST_STRING*

Parameter	Parameter Description	Parameter Value
SRC_STRING	Copy from URL	-
DST_STRING	Copy to local file	-

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to copy file from tftp server to local.

Examples

This is a sample output from the command displaying how to copy file from tftp server to local:

```
Switch# copy mgmt-if tftp://10.10.38.160 flash:/boot

TFTP server [10.10.38.160]
Name of the TFTP file to access [] collections.py
Download from URL to temporary file.
Get file from tftp://10.10.38.160/collections.py
.
Received 25403 bytes in 0.2 seconds
Copy the temporary file to its destination.
.
File system synchronization. Please waiting...
25403 bytes in 0.1 seconds, 248 kbytes/second
```

Related Commands

delete

23.25 copy

Command Purpose

Use this command to copy file from local file to tftp server or local.

Command Syntax

copy *SRC_STRING* mgmt-if *DST_STRING*

Parameter	Parameter Description	Parameter Value
SRC_STRING	Copy from URL	-

DST_STRING	Copy to local file	-
------------	--------------------	---

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This is a sample output from the command displaying how to copy file from local file to tftp server:

```
Switch# copy flash:/startup-config.conf mgmt-if tftp://10.10.38.160

TFTP server [10.10.38.160]
Name of the TFTP file to access [] startup-config.conf
Send file to tftp://10.10.38.160/startup-config.conf
.
Sent 2177 bytes in 0.1 seconds
```

Related Commands

delete

23.26 more

Command Purpose

To display the contents of a file, use the more command in EXEC mode.

Command Syntax

more *STRING*,

Parameter	Parameter Description	Parameter Value
STRING	Text file name	-

Command Mode

Privileged EXEC

Default

None

Usage

The system can only display a file in ASCII format.

Examples

The following partial sample output displays the configuration file named startup-config in flash:

```
Switch# more flash:/startup-config.conf
```

Related Commands

dir

23.27 delete

Command Purpose

Use this command to delete a file on the flash.

Command Syntax

delete *STRING*,

Parameter	Parameter Description	Parameter Value
STRING	File name for delete	-

Command Mode

Privileged EXEC

Default

None

Usage

If you attempt to delete the configuration file or image, the system prompts you to confirm the deletion.

Examples

The following example deletes the file named test from the flash:

```
Switch# delete flash:/test
Are you sure to delete flash:/test? [no]y
```

Related Commands

copy

23.28 rename

Command Purpose

Use this command to rename a file in a Class C Flash file system or udisk device.

Command Syntax

rename *OLD_STRING NEW_STRING*

Parameter	Parameter Description	Parameter Value
OLD_STRING		-
NEW_STRING		-

Command Mode

Privileged EXEC

Default

None

Usage

This command is valid only for local file systems.

Examples

In the following example, the file named startup-config.conf-bak is renamed startup-config.conf-bak1:

```
Switch# rename flash:/startup-config.conf-bak flash:/startup-config.conf-bak1
Are you sure to rename flash:/startup-config.conf-bak ? [confirm]y
.
File system synchronization. Please waiting...
1061 bytes in 0.1 seconds, 10 kbytes/second
```

Related Commands

ls

23.29 source

Command Purpose

Read and execute commands from filenames in the shell environment.

Command Syntax

source *STRING*

Parameter	Parameter Description	Parameter Value
STRING	Configuration file	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following is show how to source commands from a file:

```
Switch# source flash:/bash shutdown.txt
Switch# configure terminal

Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# interface range eth-0-5 - 7
Switch(config-if-range)# shutdown
Switch(config-if-range)# end
Switch#
```

Related Commands

None

23.30 system min-frame check

Command Purpose

Use this command enable the system minimum frame check. The system minimum frame size is 64bytes.

Use the no form of this command to disable.

Command Syntax

system min-frame check enable

no system min-frame check enable

Parameter	Parameter Description	Parameter Value
enable	enable system minimum frame check	-

Command Mode

Global Configuration

Default

enable

Usage

None

Examples

The following example shows how to enable system minimum frame check:

```
Switch(config)# system min-frame check enable
```

The following example shows how to disable system minimum frame check:

```
Switch(config)# no system min-frame check enable
```

Related Commands

None

23.31 banner

Command Purpose

Use this command to define a banner.

Command Syntax

```
banner ( exec | login ) STRING
```

```
no banner ( exec | login )
```

Parameter	Parameter Description	Parameter Value
exec	exec banner	-
login	login banner	-
STRING	banner text information	c banner-text c, where 'c' is a delimiting character, only allow '0-9/A-Z/a-z/,@. _-'

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example shows how to define an exec banner:

```
Switch(config)# banner exec @no_delete_configuration@
```

Related Commands

None

23.32 do

Command Purpose

Use this command to execute the commands in EXEC mode.

Command Syntax

do *COMMAND_STRING*

Parameter	Parameter Description	Parameter Value
COMMAND_STRING	The string of the command	-

Command Mode

All Configuration Mode

Default

None

Usage

None

Examples

The following example shows how to execute the do command:

```
Switch# configure terminal
Switch(config)# do show interface eth-0-1

Interface eth-0-1
  Interface current state: DOWN
  Hardware is Port, address is 001e.080b.e6c2
  Bandwidth 1000000 kbits
  Index 1 , Metric 1
  Speed - auto , Duplex - auto , Metadata - Disable , Media type is UNKNOWN
  Link type is autonegotiation
  Admin input flow-control is off, output flow-control is off
  Oper input flow-control is off, output flow-control is off
  The Maximum Frame Size is 12800 bytes
    5 minute input rate 0 bits/sec, 0 packets/sec
    5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes
    Received 0 unicast, 0 broadcast, 0 multicast
    0 runts, 0 giants, 0 input errors, 0 CRC
    0 frame, 0 overrun, 0 pause input
    0 packets output, 0 bytes
    Transmitted 0 unicast, 0 broadcast, 0 multicast
    0 underruns, 0 output errors, 0 pause output
```


Related Commands

None

24 DEVICE Commands

24.1 show version

Command Purpose

Use this command to display the version information of the hardware and firmware.

Command Syntax

```
show version
```

Command Mode

Privileged EXEC

Default

None

Usage

This command can display the version information of the hardware and firmware.

Examples

This example shows how to display version information of the hardware and firmware:

```
Switch# show version

i-Ware Software, Version 1.10, ESS 6601 01
Vendor Information
SecPath FW uptime is 0 weeks, 1 day, 1 hours, 16 minutes
Boot image: flash:/boot/SecPathTAP2000S-IMW110-E6601.BIN
Boot image version: 1.10, ESS 6601 01
Next running image : flash:/boot/SecPathTAP2000S-IMW110-E6601.BIN
```

```

SLOT 1
Hardware Type      : switch
SDRAM size        : 2048M
Flash size        : 2048M
Hardware Version   : 1.2
EPLD Version      : 2.1
BootRom Version   : 6.1.1
System serial number : E101ZB142025
  
```

Related Commands

None

24.2 show stm prefer

Command Purpose

Use this command to display information about the profiles that can be used to maximize system resources for a particular feature.

Command Syntax

show stm prefer (current | next | default)

Parameter	Parameter Description	Parameter Value
current	Current profile information	-
next	Next profile information	-
default	Balance on all kinds of tables size	-

Command Mode

Privileged EXEC

Default

None

Usage

The numbers displayed for each profile represent an approximate maximum number for each feature resource. Use this command to show the default balance on all kinds of tables size.

Examples

This is an example of output from the show stm prefer current command:

```
Switch# show stm prefer current

number of tap group                : 1/512
number of tap ingress truncation    : 0/4
number of link aggregation(static)  : 0/31
number of Flow features:
  Flow entry ingress entries        : 0/1024
  Flow entry egress entries         : 0/255
  System Flow configure             : 2/4096
  System Flow entry configure       : 0/8192
  System L4 Port Range entries      : 0/7
```

Related Commands

stm prefer

24.3 show transceiver

Command Purpose

Use this command to show the transceiver information.

Command Syntax

show transceiver (*IF_NAME_E* |) (detail |)

Parameter	Parameter Description	Parameter Value
IF_NAME_E	Ethernet interface name	-
detail	Show detailed information	-

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to show the interface transceiver information, or the transceiver detail information.

Examples

This example shows how to display transceiver information:

```
Switch# show transceiver detail

Port eth-0-17 transceiver info:
Transceiver Type: 1000BASE-T_SFP
  Transceiver Vendor Name : INNOLIGHT
  Transceiver PN          : TC-SORJZ-N00
  Transceiver S/N         : IN0912SZ01025C
Transceiver Output Wavelength: N/A
Supported Link Type and Length:
  Link Length for copper: 100 m
Digital diagnostic is not implemented.
Port eth-0-21 transceiver info:
Transceiver Type: 1000BASE-SX
  Transceiver Vendor Name : FINISAR CORP.
  Transceiver PN          : FTLF8519P3BTL
  Transceiver S/N         : PPB2DL1
Transceiver Output Wavelength: 850 nm
Supported Link Type and Length:
  Link Length for 50/125um multi-mode fiber: 300 m
  Link Length for 62.5/125um multi-mode fiber: 150 m
-----
Transceiver is internally calibrated.
mA: milliampere, dBm: decibels (milliwatts), NA or N/A: not applicable.
++ : high alarm, + : high warning, - : low warning, -- : low alarm.
The threshold values are calibrated.
-----
```

Port	Temperature (Celsius)	High Alarm Threshold (Celsius)	High Warn Threshold (Celsius)	Low Warn Threshold (Celsius)	Low Alarm Threshold (Celsius)
eth-0-21	32.92	110.00	93.00	-30.00	-40.00

Port	Voltage (Volts)	High Alarm Threshold (Volts)	High Warn Threshold (Volts)	Low Warn Threshold (Volts)	Low Alarm Threshold (Volts)
eth-0-21	3.29	3.60	3.50	3.10	3.00

Port	Current (milliamperes)	High Alarm Threshold (mA)	High Warn Threshold (mA)	Low Warn Threshold (mA)	Low Alarm Threshold (mA)
eth-0-21	6.53	13.00	12.50	2.00	1.00

Port	Optical Transmit Power (dBm)	High Alarm Threshold (dBm)	High Warn Threshold (dBm)	Low Warn Threshold (dBm)	Low Alarm Threshold (dBm)
eth-0-21	-5.08	0.00	-3.00	-9.50	-13.50

Port	Optical Receive Power (dBm)	High Alarm Threshold (dBm)	High Warn Threshold (dBm)	Low Warn Threshold (dBm)	Low Alarm Threshold (dBm)
eth-0-21	-6.68	0.50	-1.00	-16.99	-21.02

Related Commands

None

24.4 show system summary

Command Purpose

Use this command to show the summary of the system information.

Command Syntax

```
show system summary
```

Command Mode

Privileged EXEC

Default

None

Usage

This command to show the summary of system information.

Examples

This example shows how to display the summary of system information:

```
Switch# show system summary

##### Version Table #####
i-Ware Software, Version 1.10, ESS 6601 01
Vendor Information
SecPath FW uptime is 0 weeks, 0 day, 0 hours, 52 minutes
Boot image: flash:/boot/SecPathTAP2000A-IMW110-E6601.BIN.03
Boot image version: 1.10, ESS 6601 01
Next running image : flash:/boot/SecPathTAP2000A-IMW110-E6601.BIN.03
SLOT 1
Hardware Type      : switch
SDRAM size         : 1024M
Flash size         : 2048M
Hardware Version   : 2.0
EPLD Version       : 1.2
BootRom Version    : 8.1.3
System serial number : E142GD16107A
##### Management IP Table #####
Management IP address: 10.10.39.104/23
Gateway: 10.10.39.254
##### Route Mac Table #####
Route MAC is: 001e.080b.e6c2
##### Users Table #####
  Line      Host(s)  Idle      Location      User
-----+-----+-----+-----+-----
  130 vty 0   idle      00:51:05   Local
  131 vty 1   idle      00:50:30   10.10.25.25
 *132 vty 2   idle      00:00:00   10.10.25.25
##### Memory Summary Table #####
Total memory      : 940428 KB
Used memory       : 260220 KB
Freed memory      : 680208 KB
Buffer memory     : 0 KB
Cached memory     : 125840 KB
Memory utilization: 27.67%
```

Related Commands

None

24.5 show reboot-info

Command Purpose

Use this command to show reboot information.

Command Syntax

```
show reboot-info
```

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to show reboot information.

Examples

The following example shows how to display reboot information:

```
Switch# show reboot-info
```

Times	Reboot Type	Reboot Time
1	MANUAL	2017-06-27 06:46:19
2	MANUAL	2017-06-28 02:12:28
3	MANUAL	2017-06-30 08:34:57
4	MANUAL	2017-07-05 09:45:01
5	MANUAL	2017-07-13 08:12:08
6	POWER	2017-07-23 09:47:32
7	POWER	2017-07-30 05:47:48
8	POWER	2017-07-30 08:37:03
9	POWER	2017-08-03 02:14:48
10	MANUAL	2017-08-03 12:07:06
11	MANUAL	2017-08-05 03:41:58
12	MANUAL	2017-08-05 06:30:18
13	BHMDOG	2017-08-05 16:48:30
14	POWER	2017-08-10 03:19:47
15	MANUAL	2017-08-10 03:27:31
16	MANUAL	2017-08-10 03:34:27

17	UNKNOWN	2017-08-11 06:48:21
18	MANUAL	2017/08/15 02:13:55
19	POWER	2017/08/15 02:22:21
20	MANUAL	2017/08/15 02:26:27
21	MANUAL	2017/08/15 02:29:39
22	MANUAL	2017/08/15 02:32:37
23	MANUAL	2017/08/15 02:35:11
24	POWER	2017-08-15 07:51:14
25	MANUAL	2017-08-15 08:19:48
26	UNKNOWN	2017-08-15 08:40:01
27	MANUAL	2017-08-15 08:44:19
28	MANUAL	2017-08-16 03:43:38
29	MANUAL	2017-08-17 07:00:46
30	MANUAL	2017-08-18 07:23:43
31	POWER	2017-09-12 02:34:24
32	UNKNOWN	2017-09-12 05:56:16
33	POWER	2017-09-12 07:17:19
34	POWER	2017-09-12 07:22:47
35	ABNORMAL	2017-09-12 07:31:32
36	MANUAL	2017-09-12 07:44:43
37	MANUAL	2017-09-12 07:50:12
38	MANUAL	2017-09-12 07:57:50
39	MANUAL	2017-09-19 13:07:38
40	POWER	2017-09-20 10:07:18
41	MANUAL	2017-09-20 10:26:10
42	ABNORMAL	2017-09-21 06:38:38
43	MANUAL	2017-09-21 06:50:39
44	MANUAL	2017-09-21 07:13:14
45	MANUAL	2017-09-21 07:36:41
46	MANUAL	2017-09-21 07:47:01
47	MANUAL	2017-09-21 13:05:42
48	MANUAL	2017-09-22 06:42:49
49	MANUAL	2017-09-26 11:48:08
50	MANUAL	2017-09-26 13:03:57

Related Commands

clear reboot-info

24.6 clear reboot-info

Command Purpose

Use this command to clear reboot information.

Command Syntax

clear reboot-info

Command Mode

Privileged EXEC

Default

None

Usage

The clear reboot-info command can clear reboot information.

Examples

The following example shows how to clear reboot information:

```
Switch# clear reboot-info
```

Related Commands

show reboot-info

24.7 set device id-led

Command Purpose

Use this command to set the device indicate led force on or force off.

Command Syntax

set device id-led (on | off)

Parameter	Parameter Description	Parameter Value
on	Turn on the led	-
off	Turn off the led	-

Command Mode

Privileged EXEC

Default

None

Usage

The command can set device indicate led force on or force off.

Examples

The following example shows how to set device indicate led force on:

```
Switch# set device id-led on
```

Related Commands

show device id-led

24.8 show device id-led

Command Purpose

Use this command to show device indicate led information.

Command Syntax

show device id-led

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to show device indicate led information.

Examples

The following example shows the device indicates led information:

```
Switch# show device id-led  
Indicate led is forced on
```

Related Commands

set device id-led

24.9 show schedule reboot

Command Purpose

Use this command to show schedule reboot information.

Command Syntax

```
show schedule reboot
```

Command Mode

Privileged EXEC

Default

None

Usage

Use this command to show schedule reboot information.

Examples

The following example shows schedule reboot information:

```
Switch# show schedule reboot  
Current time is : 2017-09-26 22:14:49  
Will reboot at : 2017-09-26 23:48:44
```

Related Commands

schedule reboot delay

schedule reboot at

24.10 stm prefer

Command Purpose

Use this command to configure the profile used in Switch Table Management (STM) resource allocation. You can use profile to allocate system memory to best support the features being used in your application. Use profile to approximate the maximum number of unicast MAC addresses, quality of service (QoS) access control entries (ACEs) and unicast routes.

Command Syntax

```
stm prefer default
```

Command Mode

Global Configuration

Default

System use the default profile when first boot up, this profile balances all the features.

Usage

Users must reload the switch for the configuration to take effect.

Examples

This example shows how to configure the default profile on the switch:

```
Switch(config)# stm prefer default

% Changes to STM profile have been stored but cannot take effect until the next
reload. Use 'show stm prefer current' to see what STM profile is currently active.
```

Related Commands

show stm prefer current

show stm prefer next

24.11 temperature

Command Purpose

Use this command to specify the system temperature monitor threshold.

Use the no form of this command to restore the default value.

Command Syntax

temperature *TEMP_LOW TEMP_HIGH TEMP_CRIT*

no temperature

Parameter	Parameter Description	Parameter Value
TEMP_LOW	Low alarm temperature degree Celsius	range -15 to 50
TEMP_HIGH	High alarm temperature degree Celsius	range 50 to 85
TEMP_CRIT	Critical temperature degree Celsius	range 55 to 90

Command Mode

Global Configuration

Default

The default threshold is low temperature 5, high temperature 65, and critical temperature 80.

Usage

The unit for temperature is centigrade. The critical temperature must be higher than high temperature 5 Celsius degrees. The high temperature must be higher than low temperature 5 Celsius degrees.

Examples

This example shows how to specify the temperature thresholds:

```
Switch(config)# temperature 5 70 80
```

This example shows how to specify the temperature thresholds to default value:

```
Switch(config)# no temperature
```

Related Commands

show environment

24.12 clock set datetime

Command Purpose

Use this command to set system current date and time on the Switch.

Command Syntax

clock set datetime *ABS_TIME CLOCK_MONTH ABS_DAY ABS_YEAR*

Parameter	Parameter Description	Parameter Value
ABS_TIME	Current time	-
CLOCK_MONTH	Month of the year	1-12
ABS_DAY	Day of the month	1-31
ABS_YEAR	Year	2000-2037

Command Mode

Global Configuration

Default

The default time is based on UTC.

Usage

If no other source of time is available, you can manually configure the time and date after the system is restarted. The time remains accurate until the next system restarts. We recommend that you use manual configuration only as a last resort. If you have an outside source to which the switch can synchronize, you do not need to manually set the system clock.

Examples

This example shows how to manually set the system clock:

```
Switch(config)# clock set datetime 22:43:23 9 26 2017
```

Related Commands

show clock

24.13 clock set timezone

Command Purpose

Use this command to set the timezone.

Use the no form of this command to restore the default value.

Command Syntax

```
clock set timezone Z_NAME ( add | minus ) TZ_HOURS ( TZ_MIN ( TZ_SEC | ) | )
```

```
no clock set timezone
```

Parameter	Parameter Description	Parameter Value
Z_NAME	Zone name,	Valid characters are among "A-Z/a-z_", must be less than 32 characters

add	Specify the time offset is positive from UTC	-
minus	Specify the time offset is negative from UTC	-
TZ_HOURS	Hours offset from UTC	0-23
TZ_MIN	Minutes offset from UTC	0-59
TZ_SEC	Seconds offset from UTC	0-59

Command Mode

Global Configuration

Default

None

Usage

None

Examples

This example shows how to set the clock timezone:

```
Switch(config)# clock set timezone Beijing add 8
```

This example shows how to recover the clock timezone:

```
Switch(config)# no clock set timezone
```

Related Commands

show clock

24.14 update bootrom

Command Purpose

Use this command to upgrade the bootrom image.

Command Syntax

update bootrom *STRING*

Parameter	Parameter Description	Parameter Value
STRING	Source file direction	-

Command Mode

Global Configuration

Default

None

Usage

This command can upgrade bootrom image.

Examples

This example shows how to update bootrom image:

```
Switch(config)# update bootrom flash:/boot/bootrom.bin
```

Related Commands

reboot

24.15 schedule reboot at

Command Purpose

Use this command to set schedule reboot at a time.

Use the no form of this command to cancel the schedule.

Command Syntax

schedule reboot at *HOURL_MIN* (*YEAR_MON_DAY* |)

no schedule reboot

Parameter	Parameter Description	Parameter Value
HOURL_MIN	Specify the hour and minute	-
YEAR_MON_DAY	Specify the date for current year, year range is [2000, 2037]	-

Command Mode

Global Configuration

Default

None

Usage

The reboot time could select time with format HH:MM, and optional date with format YYYY/MM/DD or MM/DD/YYYY or MM/DD.

Examples

The following example shows how to set schedule reboot at a time:

```
Switch(config)# schedule reboot at 10:20 2016/10/2
```

Related Commands

show schedule reboot

24.16 schedule reboot delay

Command Purpose

Use this command to set schedule reboot after a time.

Command Syntax

schedule reboot delay *DELAY_TIME*

no schedule reboot

Parameter	Parameter Description	Parameter Value
DELAY_TIME	Specify the delay time	-

Command Mode

Global Configuration

Default

None

Usage

The reboot delay time could select be format HH:MM, or minutes in range of [1,720].

Examples

The following example shows how to set schedule reboot after a time:

```
Switch(config)# schedule reboot delay 100
```

Related Commands

show schedule reboot

24.17 telnet

Command Purpose

Use this command to remote access to other devices

Command Syntax

telnet mgmt-if *NAME_STRING* (*TCP_PORT* |)

Parameter	Parameter Description	Parameter Value
mgmt-if	Establish a remote connection through the management port	-
NAME_STRING	IP address or hostname of a remote system	-
TCP_PORT	Specify the tcp port number, the default number is 23	1-65535

Command Mode

Privileged EXEC

Default

None

Usage

The command is used to establish a connection to other devices through the management port. The default tcp port is 23.

Examples

The following example shows how to remote access to other devices:

```
Switch# telnet mgmt-if 10.10.39.101
```

Related Commands

None

25 Hash load-balance Commands

25.1 hash field

Command Purpose

Use this command to set hash field or create a new hash field and enter hash field configure view.

Use the no command to delete user-defined hash field.

Command Syntax

hash field (port-channel | *NAME*)

no hash-field *NAME*

Parameter	Parameter Description	Parameter Value
port-channel	Port-channel of system default hash field	-
NAME	Hash field name string	The initial character of name should be a-z, A-Z, or 0-9, character only can be 0-9/A-Z/a-z/.-_ and the max length is 64

Command Mode

Global Configuration

Default

None

Usage

The system support the max number of hash fields is 4, including 1 system default hash fields named port-channel and 3 user-defined hash fields. When applied to the hash value, it can't be deleted.

Examples

The following example shows how to create a new hash field named user:

```
Switch(config)# hash-field user
Switch(config-hash-field-user)#
```

Related Commands

show hash-field

25.2 l2

Command Purpose

Use this command to set l2 packet hash field; use the no command to set the l2 packet field to default.

Command Syntax

l2 (macda | macsa | vlan | eth-type | src-interface)

no l2

Parameter	Parameter Description	Parameter Value
macda	MAC Destination Address	-
macsa	MAC Source Address	-
vlan	Vlan	-
eth-type	Ethernet Type	-
src-interface	Source Interface	-

Command Mode

Config-hash-field

Default

l2 macsa macda

Usage

None

Examples

The following example shows how to select macsa for l2 packet load balance in port-channel:

```
Switch(config)# hash-field port-channel  
Switch(config-hash-field-port-channel)# l2 macsa
```

The following example shows how to select default l2 packet load balance in port-channel:

```
Switch(config)# hash-field port-channel  
Switch(config-hash-field-port-channel)# no l2
```

Related Commands

show hash-field port-channel

25.3 ip

Command Purpose

Use this command to set ip packet hash field.

Use the no command to set the ip packet field to default.

Command Syntax

ip (ipda | ipsa | ip-protocol | sourceport | destport | src-interface)

no ip

Parameter	Parameter Description	Parameter Value
ipda	IP Destination Address	-
ipsa	IP Source Address	-
ip-protocol	IP Header protocol	-
sourceport	Layer4 Source Port	-
destport	Layer4 Destination Port	-
src-interface	Source Interface	-

Command Mode

Config-hash-field

Default

ip ipsa ipda sourceport destport ip-protocol

Usage

None

Examples

The following example shows how to select ipsa for ip packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# ip ipsa
```

The following example shows how to select default ip packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no ip
```

Related Commands

show hash-field port-channel

25.4 ipv6

Command Purpose

Use this command to set ipv6 packet hash field.

Use the no command to set the ipv6 field to default.

Command Syntax

ipv6 (ipda | ipsa | ip-protocol | sourceport | destport | src-interface)

no ipv6

Parameter	Parameter Description	Parameter Value
ipda	IP Destination Address	-
ipsa	IP Source Address	-
ip-protocol	IP Header protocol	-
sourceport	Layer4 Source Port	-
destport	Layer4 Destination Port	-
src-interface	Source Interface	-

Command Mode

Config-hash-field

Default

ipv6 ipsa ipda sourceport destport ip-protocol

Usage

Only when the system is in ipv6 mode, the ipv6 packet hash field can work normally.

Examples

The following example shows how to select ipsa for ipv6 packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# ipv6 ipsa
```

The following example shows how to select default ipv6 packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no ipv6
```

Related Commands

show hash-field port-channel

25.5 vxlan

Command Purpose

Use this command to set VxLAN packet hash field.

To return the configuration to default value use the no form of this command.

Command Syntax

VxLAN { vni | src-interface }

VxLAN ({ vni | src-interface } |) outer { ipsa | ipda | sourceport | destport | vlan }

VxLAN ({ vni | src-interface } |) inner-layer2 { macsa | macda | eth-type }

VxLAN ({ vni | src-interface } |) inner-layer3 { ipsa | ipda | sourceport | destport | ip-protocol }

no VxLAN

Parameter	Parameter Description	Parameter Value
vni	VXLAN VNI	-
src-interface	Source Interface	-

outer ipsa	Outer header's IP Source Address	-
outer ipda	Outer header's IP Destination Address	-
outer sourceport	Outer header's Layer4 Source Port	-
outer destport	Outer header's Layer4 Destination Port	-
outer vlan	Outer header's Vlan ID	-
inner macsa	Inner header's MAC Source Address	-
inner macda	Inner header's MAC Destination Address	-
inner eth-type	Inner header's Ethernet Type	-
inner ipsa	Inner header's IP Source Address	-
inner ipda	Inner header's IP Destination Address	-
inner sourceport	Inner header's Layer4 Source Port	-
inner destport	Inner header's Layer4 Destination Port	-
inner ip-protocol	Inner header's IP Header protocol	-

Command Mode

Config-hash-field

Default

VxLAN vni outer ipsa ipda sourceport

Usage

Outer configuration and inner configuration cannot take effect at the same time.

Examples

The following example shows how to select outer ipsa and vni for VxLAN packet load balance in port-channel:

```
Switch(config)# hash-field port-channel  
Switch(config-hash-field-port-channel)# vxlan vni outer ipda
```

The following example shows how to select default VxLAN packet load balance in port-channel:

```
Switch(config)# hash-field port-channel  
Switch(config-hash-field-port-channel)# no vxlan
```

Related Commands

show hash-field port-channel

25.6 nvgre

Command Purpose

Use this command to set nvgre packet hash field.

Use the no form of this command to return the configuration to default value.

Command Syntax

```
nvgre { vsid | src-interface }
```

```
nvgre ( { vsid | src-interface } | ) outer { ipsa | ipda | gre-protocol }
```

```
nvgre ( { vsid | src-interface } | ) inner-layer2 { macsa | macda | eth-type }
```

```
nvgre ( { vsid | src-interface } | ) inner-layer3 { ipsa | ipda | sourceport | destport  
| ip-protocol }
```

no nvgre

Parameter	Parameter Description	Parameter Value
vsid	NVGRE VSID	-
src-interface	Source Interface	-
outer ipsa	Outer header's IP Source Address	-
outer ipda	Outer header's IP Destination Address	-
outer gre-protocol	Outer header's GRE Protocol	-
inner macsa	Inner header's MAC Source Address	-
inner macda	Inner header's MAC Destination Address	-
inner eth-type	Inner header's Ethernet Type	-
inner ipsa	Inner header's IP Source Address	-
inner ipda	Inner header's IP Destination Address	-
inner sourceport	Inner header's Layer4 Source Port	-
inner destport	Inner header's Layer4 Destination Port	-
inner ip-protocol	Inner header's IP Header protocol	-

Command Mode

Config-hash-field

Default

`nvgre vsid outer ipsa ipda`

Usage

Outer configuration and inner configuration cannot take effect at the same time.

Examples

The following example shows how to select outer ipsa and vsid for nvgre packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# nvgre vsid outer ipda
```

The following example shows how to select default nvgre packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no nvgre
```

Related Commands

`show hash-field port-channel`

25.7 mpls

Command Purpose

Use this command to set mpls packet hash field.

Use the no form of this command to return the configuration to default value.

Command Syntax

`mpls { top-label | 2nd-label | 3rd-label | src-interface }`

`no mpls`

Parameter	Parameter Description	Parameter Value
top-label	Mpls Top Label	-

2nd-label	Mpls Second Label	-
3rd-label	Mpls Third Label	-
src-interface	Source Interface	-

Command Mode

Config-hash-field

Default

mpls top-label 2nd-label

Usage

None

Examples

The following example shows how to select top-label for mpls packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# mpls top-label
```

The following example shows how to select default mpls packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no mpls
```

Related Commands

show hash-field port-channel

25.8 udf

Command Purpose

Use this command to set udf hash field; use the no command to delete the udf hash field.

Command Syntax

udf *UDF_ID*

no udf *UDF_ID*

Parameter	Parameter Description	Parameter Value
UDF_ID	UDF ID	0-15

Command Mode

Config-hash-field

Default

use the value which is truncated by udf to calculate hash value

Usage

only used for openflow select group

Examples

The following example shows how to configure udf hash field:

```
Switch(config)# hash-field aaa
Switch(config-hash-field-aaa)# udf 0

Switch(config)# hash-field aaa
Switch(config-hash-field-aaa)# no udf 0
```

Related Commands

show hash-field

25.9 disable control

Command Purpose

Use this command to force ip packet ,ipv6 packet or mpls packet to follow l2 hash configuration.

To return the configuration to default value use the no form of this command.

Command Syntax

ip disable
no ip disable
ipv6 disable
no ipv6 disable
mpls disable
no mpls disable

Command Mode

Config-hash-field

Default

no ip disable
no ipv6 disable
no mpls disable

Usage

None

Examples

The following example shows how to not select ipv6 packet field to hash in port-channel:

```
Switch(config)# hash-field port-channel  
Switch(config-hash-field-port-channel)# ipv6 disable
```

The following example shows how to select ipv6 packet field to hash in port-channel:

```
Switch(config)# hash-field port-channel  
Switch(config-hash-field-port-channel)# no ipv6 disable
```

Related Commands

show hash-field port-channel

25.10 ipv6 adres compress mode

Command Purpose

Use this command to set compress arithmetic for ipv6 address.

Use the no form of this command to return the configuration to default value.

Command Syntax

ipv6 address compress mode (lsb | xor)

no ipv6 address compress mode

Parameter	Parameter Description	Parameter Value
lsb	Least Significant bit arithmetic	-
xor	Exclusive or arithmetic	-

Command Mode

Config-hash-field

Default

lsb

Usage

None

Examples

The following example shows how to set ipv6 address compress arithmetic in port-channel:

```
Switch(config-hash-field-port-channel)# ipv6 address compress mode lsb
```

The following example shows how set default compress arithmetic of ipv6 address in port-channel:

```
Switch(config-hash-field-port-channel)# no ipv6 address compress mode
```

Related Commands

show hash-field

25.11 hash arithmetic

Command Purpose

Use this command to set hash arithmetic.

Use the no form of this command to return the configuration to default value.

Command Syntax

hash-arithmetic (crc | xor)

no hash-arithmetic

Parameter	Parameter Description	Parameter Value
crc	Cyclical redundancy check arithmetic	-
xor	Exclusive or arithmetic	-

Command Mode

Config-hash-field

Default

xor

Usage

None

Examples

The following example shows how to set hash arithmetic in port-channel:

```
Switch(config)# hash-field port-channel  
Switch(config-hash-field-port-channel)# hash-arithmetic crc
```

The following example shows how set default hash arithmetic in port-channel:

```
Switch(config)# hash-field port-channel  
Switch(config-hash-field-port-channel)# no hash-arithmetic
```

Related Commands

show hash-field

25.12 hash symmetry

Command Purpose

Use this command to enable hash symmetry function.

Use the no form of this command to return the configuration to default value.

Command Syntax

mode symmetry

no mode symmetry

Command Mode

Config-hash-field

Default

no mode symmetry

Usage

None

Examples

The following example shows how to set hash symmetry in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# mode symmetry
```

The following example shows how to set hash symmetry to default in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no mode symmetry
```

Related Commands

show hash-field port-channel

25.13 description

Command Purpose

Use this command to configure the description for hash field.

Use the no command to delete the description.

Command Syntax

description *NAME*

no description

Parameter	Parameter Description	Parameter Value
NAME	Hash field description	The initial character of name should be a-z, A-Z, or 0-9, character only can be 0-9/A-Z/a-z/._ and the max length is 64

Command Mode

Config-hash-field

Default

None

Usage

None

Examples

The following example shows how to set description for port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# description linkagg
```

The following example shows how to delete description for port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no description
```

Related Commands

show hash-field port-channel

25.14 show hash-field

Command Purpose

Use this command to display the configurations and statistics on all hash fields or a hash field.

Command Syntax

show hash-field (port-channel | *NAME* |)

Parameter	Parameter Description	Parameter Value
port-channel	Port-channel of system default hash field	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the configurations and statistics on the port-channel:

```
Switch# show hash-field port-channel

hash-field name: port-channel
Option                               Control type
-----
hash-arithmetic                       xor
hash symmetry                         disable
ip                                     enable
ipv6                                   enable
mpls                                   enable
-----

hash field select
Packet                                HashField
-----
l2:                                   macsa                                macda

ip:                                   ipsa                                ipda
                                     l4-sourceport                       l4-destport
                                     ip-protocol

ipv6:                                 ipsa                                ipda
                                     l4-sourceport                       l4-destport
                                     ip-protocol

gre:                                   ipsa                                ipda
                                     gre-key

vxlan:                                vni                                outer-l4-sourceport
                                     outer-ipda                           outer-ipda

nvgre:                                vsid                                outer-ipda
                                     outer-ipsa
```

```
mpls:                top-label                2nd-label
```

Related Commands

None

25.15 hash value

Command Purpose

Use this command to create a hash value and enter hash value configure view.

Use the no command to delete the hash value.

Command Syntax

hash-value *NAME*

no hash-value *NAME*

Parameter	Parameter Description	Parameter Value
NAME	Hash value name string	The initial character of name should be a-z, A-Z, or 0-9, character only can be 0-9/A-Z/a-z/.-_ and the max length is 64

Command Mode

Global Configuration

Default

None

Usage

The system support the max number of hash value is 63.when applied to the interface, it can't be deleted.

Examples

The following example shows how to create hash value aaa:

```
Switch(config)# hash-value aaa
Switch(config-hash-value-aaa)#
```

The following example shows how to delete hash value aaa:

```
Switch(config)# no hash-value aaa
Switch(config)#
```

Related Commands

show hash-value

25.16 port-channel select

Command Purpose

Use this command to select hash field for all mode linkagg.

Use the no command to delete the configuration.

Command Syntax

port-channel select *NAME*

no port-channel select

Parameter	Parameter Description	Parameter Value
NAME	Hash field name string	-

Command Mode

Config-hash-value

Default

None

Usage

the hash value can apply on the agg input or the port input.

Examples

The following example shows how to select hash field for in hash value user:

```
Switch(config)# hash-value aaa
Switch(config-hash-value-aaa)# port-channel select user
```

The following example shows how to delete hash field and hash arithmetic for linkagg in hash value aaa:

```
Switch(config)# hash-value aaa
Switch(config-hash-value-aaa)# no port-channel select
```

Related Commands

show hash-value

25.17 description

Command Purpose

Use this command to configure the description for hash value.

Use the no command to delete the description.

Command Syntax

description *NAME*

no description

Parameter	Parameter Description	Parameter Value
NAME	Hash value description	The initial character of name should be a-z, A-Z, or 0-9, character only can be 0-9/A-Z/a-z/._ and the max length is 64

Command Mode

Config-hash-value

Default

None

Usage

None

Examples

The following example shows how set description for hash value aaa:

```
Switch(config)# hash-value aaa
Switch(config-hash-value-aaa)# description valueaaa
```

The following example shows how delete description for hash value aaa:

```
Switch(config)# hash-value aaa
Switch(config-hash-value-aaa)# no description
```

Related Commands

show hash-value

25.18 show hash-value

Command Purpose

Use this command to display the configurations of a hash value or all hash value.

Command Syntax

show hash-value (*NAME* |)

Parameter	Parameter Description	Parameter Value
NAME	Hash value name string	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the configurations of hash value:

```

Switch# show hash-value

LBT:load balance type          LBM:load balance mode
PT :packet type                HF :hash field name
HA :hash arithmetic
hash-value name: aaa
LBT          LBM          PT          HF          HA
-----
port-channel -          all          NOCFG          NOCFG
  
```

Related Commands

None

25.19 hash-value global

Command Purpose

Use this command to enter hash value global configure view.

Command Syntax

hash-value global

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example shows how to enter hash value global view:

```
Switch(config)# hash-value global
Switch(config-hash-value-global)#
```

Related Commands

show hash-value global

25.20 port-channel select

Command Purpose

Use this command to select hash field for linkagg.

Use the no command to set the default configuration.

Command Syntax

port-channel select *NAME*

no port-channel select

Parameter	Parameter Description	Parameter Value
NAME	Hash field name string	-

Command Mode

Config-hash-value-global

Default

port-channel

Usage

Compared with hash value configuration, this command has lower priority

Examples

The following example shows how to select hash field for linkagg in hash value global:

```
Switch(config)# hash-value global  
Switch(config-hash-value-global)# port-channel select user
```

The following example shows how to set default hash field for linkagg in hash value global:

```
Switch(config)# hash-value global  
Switch(config-hash-value-global)# no port-channel select
```

Related Commands

show hash-value global

25.21 show hash-value global

Command Purpose

Use this command to display the configurations of hash value global.

Command Syntax

show hash-value global

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the configurations of hash value global:

```
Switch# show hash-value global

LBT:load balance type          LBM :load balance mode
PT :packet type                HF  :hash field name
HA :hash arithmetic
hash-value global
  LBT          LBM          PT          HF          HA
-----
port-channel  -            all          port-channel  xor
```

Related Commands

None

25.22 hash value applied to interface

Command Purpose

Use this command to apply a hash value to interface.

Use the no command to remove the hash-value from interface.

Command Syntax

load-balance hash-value *NAME* input

no load-balance hash-value input

Parameter	Parameter Description	Parameter Value
NAME	Hash value name	-

Command Mode

Interface Configuration

Default

None

Usage

Physical port and linkagg port can select input direction .linkagg port of output direction only support hash-value global. Agg member port can't configure the command.

Examples

The following example shows how to apply a hash value to eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if)# load-balance hash-value aaa input
```

The following example shows how to remove a hash value from eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if)# no load-balance hash-value input
```

Related Commands

show hash-value interface-applied

25.23 show hash-value interface-applied

Command Purpose

Use this command to display the relationship between hash value and interface.

Command Syntax

show hash-value interface-applied

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the relationship between hash value profile and interface:

```
Switch# show hash-value interface-applied  
  
eth-0-1  
hash-value aaa input
```

Related Commands

None

26 IPFIX Commands

26.1 ipfix enable

Command Purpose

Use this command to enable ipfix globally.

Command Syntax

```
ipfix enable
```

Command Mode

Global Configuration

Default

None

Usage

None

Examples

This example shows how to enable ipfix globally:

```
Switch# configure terminal
Switch(config)# ipfix enable
```

Related Commands

None

26.2 ipfix recorder

Command Purpose

Use this command to create an ipfix recorder and enter recorder configure mode.
Use the no form of this command to remove the ipfix recorder.

Command Syntax

ipfix recorder *NAME*
no ipfix recorder *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix recorder name	Up to 32 characters

Command Mode

Global Configuration

Default

None

Usage

If ipfix recorder has existed, it will enter IPFIX recorder Configuration; if ipfix recorder is new, it will create a recorder and enter IPFIX recorder Configuration; this command should work with the commands of match and collect.

Examples

This example shows how to create ipfix recorder recorder1 in global configuration and enter IPFIX recorder Configuration:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocorder)#

Switch# configure terminal
Switch(config)# no ipfix recorder recorder1
```

Related Commands

description
match ipv4
match ipv6
match transport
collect ttl
collect flow
collect counter

26.3 description

Command Purpose

Use this command to describe an ipfix recorder.

Use the no form of this command to delete this description.

Command Syntax

description *DESCRIPTION*

Parameter	Parameter Description	Parameter Value
DESCRIPTION	ipfix monitor description	The length of ipfix monitor description should not exceed 64 characters

Command Mode

IPFIX recorder Configuration

Default

None

Usage

None

Examples

This example shows how to describe recorder in IPFIX recorder Configuration:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# description this is a ipfix recorder
```

This example shows how to delete the description of the recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# no description
```

Related Commands

None

26.4 match ipv4

Command Purpose

This command configures the fields of ipv4 in ipfix recorder.

Use the no form of this command to delete this configure.

Command Syntax

match ipv4 (source | destination) address (mask *IP_MASK_LEN* |)

match ipv4 (dscp | ecn | ttl)

no match ipv4 (source | destination) address

no match ipv4 (dscp | ecn | ttl)

Parameter	Parameter Description	Parameter Value
source	ipv4 source address	-

destination	ipv4 destination address	-
dscp	ipv4 dscp value	-
ecn	ipv4 ecn value	-
ttl	ipv4 ttl value	-
IP_MASK_LEN	mask length for ipv4 address	1-32

Command Mode

IPFIX recorder Configuration

Default

Default value is 32

Usage

None

Examples

This example shows how to configure to use ipv4 source address and ipv4 destination address in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match ipv4 source address

Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match ipv4 destination address
```

Related Commands

None

26.5 match ipv6

Command Purpose

Use this command to configure the ipv6 fields in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

match ipv6 (source | destination) address (mask *IPV6_MASK_LEN* |)

no match ipv6 (source | destination) address

match ipv6 (flowlabel | dscp)

no match ipv6 (flowlabel | dscp)

Parameter	Parameter Description	Parameter Value
source	ipv6 source address	-
destination	ipv4 destination address	-
dscp	ipv6 dscp value	-
flowlabel	ipv6 flow label value	-
IPV6_MASK_LEN	mask length for ipv6 address	range is 1-128 and must be the multiple of 4

Command Mode

IPFIX recorder Configuration

Default

Default value is 128

Usage

None

Examples

This example shows how to configure to use ipv6 source address and ipv6 destination address in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match ipv6 source address

Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match ipv6 destination address
```

Related Commands

None

26.6 match mac

Command Purpose

Use this command to configure the mac fields in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

match mac (destination | source) address

no match mac (destination | source) address

Parameter	Parameter Description	Parameter Value
source	Source mac address	-
destination	Destination mac address	-

Command Mode

IPFIX recorder Configuration

Default

None

Usage

None

Examples

This example shows how to configure to use source mac address in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match mac source address
```

Related Commands

None

26.7 match transport

Command Purpose

Use this command to configure the transport fields in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

match transport (destination-port | source-port | type)

no match transport (destination-port | source-port | type)

match transport icmp (opcode | type)

no match transport icmp (opcode | type)

Parameter	Parameter Description	Parameter Value
destination-port	Destination port	-
source-port	Source port	-

type	Transport layer type	-
opcode	Icmp operated code	-

Command Mode

IPFIX recorder Configuration

Default

None

Usage

None

Examples

This example shows how to configure to use source port and destination port of transport in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match transport source-port

Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match transport destination-port
```

Related Commands

None

26.8 match vlan

Command Purpose

Use this command to configure the vlan fields in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

match vlan (inner |)

no match vlan (inner |)

Parameter	Parameter Description	Parameter Value
inner	Inner VLAN	-

Command Mode

IPFIX recorder Configuration

Default

None

Usage

None

Examples

This example shows how to configure to use inner vlan in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match vlan inner
```

Related Commands

None

26.9 match cos

Command Purpose

Use this command to configure the cos fields in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

match cos (inner |)

no match cos (inner |)

Parameter	Parameter Description	Parameter Value
inner	Inner COS	-

Command Mode

IPFIX recorder Configuration

Default

None

Usage

None

Examples

This example shows how to configure to use inner cos in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match cos inner
```

Related Commands

None

26.10 match interface (input | output)

Command Purpose

Use this command to configure the interface fields in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

match interface (input | output)

no match interface (input | output)

Parameter	Parameter Description	Parameter Value
input	input direction	-
output	output direction	-

Command Mode

IPFIX recorder Configuration

Default

None

Usage

None

Examples

This example shows how to configure input direction in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match interface input
```

Related Commands

None

26.11 match interface input

Command Purpose

Use this command to configure the interface fields in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

match interface input

no match interface input

Parameter	Parameter Description	Parameter Value
input	input direction	-

Command Mode

IPFIX recorder Configuration

Default

None

Usage

None

Examples

This example shows how to configure input direction in ipfix recorder:

```

Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match interface input
  
```

Related Commands

None

26.12 match vxlan-vni

Command Purpose

Use this command to configure the vxlan-vni fields in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

match vxlan-vni

no match vxlan-vni

Command Mode

IPFIX recorder Configuration

Default

None

Usage

None

Examples

This example shows how to configure to use vxlan-vni in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match vxlan-vni
```

Related Commands

None

26.13 match nvgre-key

Command Purpose

Use this command to configure the nvgre-key fields in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

match nvgre-key

no match nvgre-key

Command Mode

IPFIX recorder Configuration

Default

None

Usage

None

Examples

This example shows how to configure to use nvgre-key in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match nvgre-key
```

Related Commands

None

26.14 match transport tcp flags

Command Purpose

Use this command to configure the packet tcp flag fields in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

match transport tcp flags ({ ack | cwr | ece | fin | psh | rst | syn | urg } |)

no match transport tcp flags ({ ack | cwr | ece | fin | psh | rst | syn | urg } |)

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

ack	TCP acknowledgement	-
cwr	TCP congestion window reduced	-
ece	TCP Explicit Notification Congestion echo	-
fin	TCP finish	-
psh	TCP push	-
rst	TCP reset	-
syn	TCP synchronize	-
urg	TCP urgent	-

Command Mode

IPFIX recorder Configuration

Default

None

Usage

None

Examples

This example shows how to configure to use tcp flags:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match transport tcp flags ack
```

Related Commands

None

26.15 match packet (drop | non-drop)

Command Purpose

Use this command to configure the packet fields in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

match packet (drop | non-drop)

no match packet (drop | non-drop)

Parameter	Parameter Description	Parameter Value
drop	Drop packet	-
non-drop	Non-drop packet	-

Command Mode

IPFIX recorder Configuration

Default

None

Usage

None

Examples

This example shows how to configure to use drop packet:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match packet drop
```

Related Commands

None

26.16 collect counter

Command Purpose

Use this command to configure the byte number and packet number that needs to be collected in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

collect counter (delta |) (bytes | packets)

no collect counter (delta |) (bytes | packets)

Parameter	Parameter Description	Parameter Value
delta	delta counter	-
bytes	Collect flow with byte number	-
packets	Collect flow with packet number	-

Command Mode

IPFIX recorder Configuration

Default

Without collecting any information

Usage

None

Examples

This example shows how to configure to collect the number of flow's byte in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# collect counter bytes
```

Related Commands

None

26.17 collect flow

Command Purpose

Use this command to configure the collect ipfix flow information in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

collect flow (drop | destination | fragmentation)

no collect flow (drop | destination | fragmentation)

Parameter	Parameter Description	Parameter Value
drop	Only collect the dropped flows	-
destination	Collect destination address of flows	-
fragmentation	Only collect the fragmented flows	-

Command Mode

IPFIX recorder Configuration

Default

None

Usage

None

Examples

This example shows how to configure to collect the destination address of flows in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# collect flow destination
```

Related Commands

None

26.18 collect ttl

Command Purpose

Use this command to configure to collect ipfix flow information about ttl in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

collect ttl (maximum | minimum | changed |)

no collect ttl (maximum | minimum | changed |)

Parameter	Parameter Description	Parameter Value
maximum	Collect flow max ttl value	-
minimum	Collect flow min ttl value	-
changed	Collect flow ttl changed history	-

Command Mode

IPFIX recorder Configuration

Default

None

Usage

None

Examples

This example shows how to configure to collect the maximum ttl and minimum ttl of the flows in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# collect ttl maximum
Switch(Config-ipfix-reocrder)# collect ttl minimum
```

Related Commands

None

26.19 collect timestamp

Command Purpose

Use this command to configure to collect ipfix flow information about timestamp in an ipfix recorder.

Use the no form of this command to delete this configuration.

Command Syntax

collect timestamp (first | last)

no collect timestamp (first | last)

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

first	Collect flow start timestamp	-
last	Collect flow end timestamp	-

Command Mode

IPFIX recorder Configuration

Default

None

Usage

None

Examples

This example shows how to configure to collect the timestamp of the flows in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# collect timestamp first
```

Related Commands

None

26.20 ipfix exporter

Command Purpose

Use this command to create an ipfix exporter and enter exporter configure mode.

Use the no form of this command to remove the ipfix exporter.

Command Syntax

ipfix exporter *NAME*

no ipfix exporter *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix exporter name	Up to 32 characters

Command Mode

Global Configuration

Default

None

Usage

If ipfix exporter has existed, it will enter IPFIX exporter Configuration; if ipfix exporter is new, it will create exporter and enter IPFIX exporter Configuration; this command should work with the other commands .

Examples

This example shows how to create ipfix exporter exporter1 in global configuration and enter IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)#
```

This example shows how to delete ipfix exporter exporter1:

```
Switch# configure terminal
Switch(config)# no ipfix exporter exporter1
```

Related Commands

template data timeout

flow data timeout

event flow start

event flow end (tcp-end|timeout)

transport protocol udp

26.21 description

Command Purpose

Use this command to describe an ipfix exporter.

Use the no form of this command to delete this description.

Command Syntax

description *DESCRIPTION*

Parameter	Parameter Description	Parameter Value
DESCRIPTION	Ipfix exporter description	Up to 64 characters

Command Mode

IPFIX exporter Configuration

Default

None

Usage

None

Examples

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# description this is a ipfix exporter

Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# no description
```

Related Commands

None

26.22 destination

Command Purpose

Use this command to configure a collector host name that needs to receive flow records in an ipfix exporter.

Use the no form of this command to delete this description.

Command Syntax

destination mgmt-if ipv4 *IPV4_ADDR*

no destination

Parameter	Parameter Description	Parameter Value
IPV4_ADDR	IP address of collector	-

Command Mode

IPFIX exporter Configuration

Default

None

Usage

None

Examples

This example shows how to create a host named host1 in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# destination mgmt-if ipv4 9.0.0.2
```

Related Commands

None

26.23 dscp

Command Purpose

Use this command to configure the dscp value of the message that needs to be sent in an ipfix exporter.

Use the no form of this command to delete this description.

Command Syntax

dscp *DSCP*

Parameter	Parameter Description	Parameter Value
DSCP	dscp value	0-63

Command Mode

IPFIX exporter Configuration

Default

63

Usage

None

Examples

This example shows how to configure dscp to be 20 in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# dscp 20
```

Related Commands

None

26.24 domain-id

Command Purpose

Use this command to configure the ipfix domain value of the message that needs to be sent in an ipfix exporter.

Use the no form of this command to delete this description.

Command Syntax

domain-id *ID*

Parameter	Parameter Description	Parameter Value
ID	domain id	1-65535

Command Mode

IPFIX exporter Configuration

Default

None

Usage

None

Examples

This example shows how to configure domain-id to be 1000 in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# domain-id 1000
```

Related Commands

None

26.25 template data timeout

Command Purpose

Use this command to configure the time interval of sending the template data in an ipfix exporter.

Use the no form of this command to delete this description.

Command Syntax

template data timeout *TIMEOUT*

no template data timeout

Parameter	Parameter Description	Parameter Value
TIMEOUT	template data timeout	1-86400

Command Mode

IPFIX exporter Configuration

Default

600

Usage

None

Examples

This example shows how to configure time interval of sending template data to be 200 seconds in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# template data timeout 200
```

Related Commands

None

26.26 flow data timeout

Command Purpose

Use this command to configure the time interval of sending the flow data in an ipfix exporter.

Use the no form of this command to delete this description.

Command Syntax

flow data timeout *TIMEOUT*

no flow data timeout

Parameter	Parameter Description	Parameter Value
TIMEOUT	flow data timeout	1-86400

Command Mode

IPFIX exporter Configuration

Default

600

Usage

None

Examples

This example shows how to configure time interval of sending flow data to be 200 seconds in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# flow data timeout 200
```

Related Commands

None

26.27 transport protocol

Command Purpose

Use this command to configure the transport used when sending a message in an ipfix exporter.

Use the no form of this command to delete this description.

Command Syntax

transport protocol udp port *UDP_PORT*

no transport protocol

Parameter	Parameter Description	Parameter Value
UDP_PORT	transport protocol number	Range is 2000 to 65535, Default is 2055

Command Mode

IPFIX exporter Configuration

Default

2055

Usage

None

Examples

This example shows how to configure the transport protocol of flow data to be udp and its port is 3500 in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# transport protocol udp 3500
```

Related Commands

None

26.28 ttl

Command Purpose

Use this command to configure the ttl of the sent message in an ipfix exporter.

Use the no form of this command to delete this description.

Command Syntax

ttl *TTL*

no ttl

Parameter	Parameter Description	Parameter Value
TTL	TTL value	1-255

Command Mode

IPFIX exporter Configuration

Default

255

Usage

None

Examples

This example shows how to configure ttl value of flow data to be 255 in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# ttl 255
```

Related Commands

None

26.29 event flow

Command Purpose

Use this command to configure which event should trigger to send flow information in an ipfix exporter.

Use the no form of this command to delete this description.

Command Syntax

event flow start

no event flow start

event flow end (tcp-end | timeout)

no event flow end (tcp-end | timeout)

Command Mode

IPFIX exporter Configuration

Default

None

Usage

None

Examples

This example shows how to configure the event about ending tcp transmission of flow data will trigger to send flow information in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# event flow tcp-end
```

Related Commands

None

26.30 flow data flush threshold length

Command Purpose

Use this command to configure the threshold when flow information should be sent in an ipfix exporter.

Command Syntax

flow data flush threshold length *LENGTH*

Parameter	Parameter Description	Parameter Value
LENGTH	length threshold value	1000-60000

Command Mode

IPFIX exporter Configuration

Default

1416

Usage

None

Examples

This example shows how to configure the length threshold value of the flow data in IPFIX exporter Configuration. When the threshold is reached, flow data information will be sent:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# flow data flush threshold length 2000
```

Related Commands

None

26.31 flow data flush threshold timer

Command Purpose

Use this command to configure the threshold when the flow information should be sent in an ipfix exporter.

Command Syntax

flow data flush threshold timer *TIMER*

Parameter	Parameter Description	Parameter Value
TIMER	timer threshold value	100-60000

Command Mode

IPFIX exporter Configuration

Default

500

Usage

None

Examples

This example shows how to configure the timer threshold value in the IPFIX exporter configuration. When the threshold is reached, flow data information will be sent:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# flow data flush threshold timer 1000
```

Related Commands

None

26.32 flow data flush threshold count

Command Purpose

Use this command to configure the threshold when the flow information should be sent in an ipfix exporter.

Command Syntax

flow data flush threshold count *COUNT*

Parameter	Parameter Description	Parameter Value
COUNT	count threshold value	1-100

Command Mode

IPFIX exporter Configuration

Default

10

Usage

None

Examples

This example shows how to configure the count threshold value for flow data in IPFIX exporter Configuration. When the threshold is reached, flow data information will be sent:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# flow data flush threshold count 20
```

Related Commands

None

26.33 ipfix sampler

Command Purpose

Use this command to create an ipfix sampler and enter sampler configure mode. Use the no form of this command to remove the ipfix sampler.

Command Syntax

ipfix sampler *NAME*

no ipfix sampler *NAME*

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

NAME	ipfix sampler name	Up to 32 characters
------	--------------------	---------------------

Command Mode

Global Configuration

Default

None

Usage

If ipfix sampler has existed, it will enter IPFIX sampler Configuration; if ipfix sampler is new, it will create sampler and enter IPFIX sampler Configuration; this command should work with the command of match and collect.

Examples

This example shows how to create ipfix sampler sampler1 in global configuration and enter IPFIX sampler Configuration:

```
Switch# configure terminal
Switch(config)# ipfix sampler sampler 1
Switch(Config-ipfix-sampler)#
```

This example shows how to delete ipfix sampler sampler1:

```
Switch# configure terminal
Switch(config)# no ipfix sampler sampler1
```

Related Commands

1 out-of

26.34 description

Command Purpose

Command Syntax

description *DESCRIPTION*

Parameter	Parameter Description	Parameter Value
DESCRIPTION	ipfix sampler description	Up to 64 characters

Command Mode

IPFIX sampler Configuration

Default

None

Usage

None

Examples

```
Switch# configure terminal
Switch(config)# ipfix sampler sampler 1
Switch(Config-ipfix-sampler)# description this is a ipfix sampler

Switch# configure terminal
Switch(config)# ipfix sampler sampler 1
Switch(Config-ipfix-sampler)# no description
```

Related Commands

None

26.35 1 out-of

Command Purpose

Use this command to configure the rate of an ipfix sampler.

Use the no form of this command to delete this configuration.

Command Syntax

1 out of *CLI_IPFIX_SAMPLER_RATE_RNG*

Parameter	Parameter Description	Parameter Value
CLI_IPFIX_SAMPLER_RATE_RNG	How many packets will sample one packet	2-8191

Command Mode

IPFIX sampler Configuration

Default

None

Usage

None

Examples

This example shows how to configure the rate of sampling is 1/100 in IPFIX sampler Configuration:

```
Switch# configure terminal
Switch(config)# ipfix sampler sampler 1
Switch(Config-ipfix-sampler)# 1 out of 100
```

Related Commands

None

26.36 mode

Command Purpose

Use this command to configure the mode of an ipfix sampler.

Command Syntax

mode (random | determinate)

Parameter	Parameter Description	Parameter Value
random	random sample mode	-
determinate	determinate sample mode	-

Command Mode

IPFIX sampler Configuration

Default

determinate

Usage

None

Examples

This example shows how to configure the determinate sampler mode in IPFIX sampler configuration:

```
Switch# configure terminal
Switch(config)# ipfix sampler sampler 1
Switch(Config-ipfix-sampler)# mode determinate
```

Related Commands

None

26.37 mode flow

Command Purpose

Use this command to configure the mode flow of an ipfix sampler.

Command Syntax

mode flow (new | all)

Parameter	Parameter Description	Parameter Value
new	only sample new flow	-
all	sample all flow	-

Command Mode

IPFIX sampler Configuration

Default

all

Usage

None

Examples

This example shows how to configure the ipfix sampler to sample all flow in IPFIX sampler configuration:

```
Switch# configure terminal
Switch(config)# ipfix sampler sampler 1
Switch(Config-ipfix-sampler)# mode flow all
```

Related Commands

None

26.38 ipfix monitor

Command Purpose

Use this command to create an ipfix monitor and enter monitor configure mode.

Use the no form of this command to remove the ipfix monitor.

Command Syntax

ipfix monitor *NAME*

no ipfix monitor *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix monitor name	Up to 32 characters

Command Mode

Global Configuration

Default

None

Usage

None

Examples

This example shows how to create ipfix monitor monitor1 in global configuration and enter IPFIX monitor configuration:

```
Switch# configure terminal
Switch(config)# ipfix monitor monitor1
Switch(Config-ipfix-monitor)#
```

This example shows how to delete ipfix monitor monitor1:

```
Switch# configure terminal
Switch(config)# no ipfix monitor monitor1
```

Related Commands

recorder

exporter

26.39 description

Command Purpose

Use this command to describe an ipfix monitor.

Use the no form of this command to delete this description.

Command Syntax

description *DESCRIPTION*

Parameter	Parameter Description	Parameter Value
DESCRIPTION	The length of ipfix monitor description should not exceed 64 characters	Up to 64 characters

Command Mode

IPFIX monitor Configuration

Default

None

Usage

None

Examples

Add description for IPFIX monitor:

```
Switch# configure terminal
Switch(config)# ipfix monitor monitor1
Switch(Config-ipfix-monitor)# description this is a ipfix monitor
```

Remove description:

```
Switch# configure terminal
Switch(config)# ipfix monitor monitor1
Switch(Config-ipfix-monitor)# no description
```

Related Commands

None

26.40 recorder

Command Purpose

Use this command to create an ipfix recorder for the ipfix monitor.

Use the no form of this command to remove the configuration.

Command Syntax

recorder *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix recorder name	Up to 32 characters

Command Mode

IPFIX monitor Configuration

Default

None

Usage

None

Examples

This example shows how to create a recorder of the ipfix monitor configure mode:

```
Switch# configure terminal
Switch(config)# ipfix monitor monitor1
Switch(Config-ipfix-monitor)# recorder recorder1
```

Related Commands

None

26.41 exporter

Command Purpose

Use this command to create an ipfix exporter for the ipfix monitor.

Use the no form of this command to remove the configuration.

Command Syntax

exporter *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix exporter name	Up to 32 characters

Command Mode

IPFIX monitor Configuration

Default

None

Usage

None

Examples

This example shows how to create an exporter of the ipfix monitor configure mode:

```
Switch# configure terminal
Switch(config)# ipfix monitor monitor1
Switch(Config-ipfix-monitor)# exporter exporter1
```


Related Commands

None

26.42 ipfix monitor

Command Purpose

Use this command to enable ipfix monitor for an interface.

Use the no form of this command to remove the configuration.

Command Syntax

ipfix monitor (input | output) *NAME* (sampler *NAME* |)

no ipfix monitor (input | output)

Parameter	Parameter Description	Parameter Value
input	do ipfix for the input packets	-
output	do ipfix for the output packets	-
NAME	IPFIX monitor name	Up to 32 characters
sampler NAME	IPFIX sampler name	Up to 32 characters

Command Mode

Interface Configuration

Default

None

Usage

None

Examples

This example shows how to enable ipfix:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if)# ipfix monitor input monitor sampler test-sample
```

Related Commands

None

26.43 ipfix global

Command Purpose

Use this command to enter ipfix global configure mode.

Command Syntax

```
ipfix global
```

Command Mode

Global Configuration

Default

None

Usage

None

Examples

This example shows how to enter ipfix global configure mode:

```
Switch# configure terminal
Switch(config)# ipfix global
```

Related Commands

None

26.44 flow aging

Command Purpose

Use this command to configure the ipfix global flow aging interval.

Command Syntax

flow aging *INTERVAL*

Parameter	Parameter Description	Parameter Value
INTERVAL	The aging time of the flow	Range is 15 to 65535, the default is 1800 seconds

Command Mode

IPFIX Global Configuration

Default

None

Usage

None

Examples

This example shows how to configure the aging time to be 200 seconds in global configure mode:

```
Switch# configure terminal
Switch(config)# ipfix global
Switch(config-ipfix-global)# flow aging 200
```

Related Commands

None

26.45 flow export

Command Purpose

Use this command to configure the ipfix global flow export interval.

Command Syntax

flow export *INTERVAL*

Parameter	Parameter Description	Parameter Value
INTERVAL	The export time of the flow	Range is 0 to 1000, the default is 5 seconds

Command Mode

IPFIX Global Configuration

Default

None

Usage

None

Examples

This example shows how to configure the export time to be 200 seconds in global configure mode:

```
Switch# configure terminal
Switch(config)# ipfix global
Switch(config-ipfix-global)# flow export 200
```

Related Commands

None

26.46 show ipfix global

Command Purpose

Use this command to show the ipfix global information.

Command Syntax

```
show ipfix global
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This example shows how to display configuration about ipfix global in privileged EXEC mode:

```
Switch# show ipfix global
```

Related Commands

None

26.47 show ipfix recorder

Command Purpose

Use this command to display the ipfix recorder.

Command Syntax

show ipfix recorder *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix recorder name	Up to 32 characters

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This example shows how to show ipfix recorder command:

```
Switch# show ipfix recorder recorder1

IPFIX recorder information:
  Name           : recorder1
  Description    :
  Match info     :
    match Source Mac Address
    match IPv4 Source Address
    match IPv4 Destination Address
    match Vxlanvni
  Collect info   :
    collect Flow Byte Number
    collect Flow Packet Number
```

Related Commands

None

26.48 show ipfix exporter

Command Purpose

Use this command to display the ipfix exporter.

Command Syntax

show ipfix exporter *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix exporter name	Up to 32 characters

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This example shows how to display configuration about exporter1 in privileged EXEC mode:

```
Switch# show ipfix exporter exporter1

IPFIX exporter information:
  Name                : exporter1
  Description          :
  Domain ID           : 0
  Collector Name       : 9.0.0.2
```

```

IPFIX message protocol      : UDP
IPFIX message destination Port : 2055
IPFIX message TTL value    : 255
IPFIX message DSCP value   : 63
IPFIX data interval        : 200
IPFIX template interval    : 1800
IPFIX exporter events      :
    Flow aging event
  
```

Related Commands

None

26.49 show ipfix cache

Command Purpose

Use this command to display the state information of the ipfix on an interface.

Command Syntax

show ipfix cache observe-point interface *IFNAME* (input | output)

show ipfix cache monitor *NAME*

show ipfix cache counter observe-point interface *IFNAME*

show ipfix cache counter monitor *NAME*

Parameter	Parameter Description	Parameter Value
IFNAME	Interface name	Support physical/aggregation
NAME	ipfix monitor name	Up to 32 characters

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This example shows how to show the state information of the ipfix on the interface eth-0-1 in privileged EXEC mode:

```

Switch# show ipfix cache observe-point interface eth-0-1 input

Cache dir                : input
Cache flow profile       : 0
Cache key profile        : 0
Cache key info          :
  Source mac             : 0000.0002.0001
  ipsa                   : 10.10.10.3/32
  ipda                   : 10.10.10.1/32
Cache collect info:
  Byte number of ingress : 64
  Packet number of ingress : 1
  
```

Related Commands

None

26.50 show ipfix monitor

Command Purpose

Use this command to display the configuration of an ipfix monitor.

Command Syntax

show ipfix monitor *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix monitor name	Up to 32 characters

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This example shows how to display configuration of monitor 1 in privileged EXEC mode:

```
Switch# show ipfix monitor monitor1

IPFIX monitor information:
  Name           : monitor1
  Description    :
  Recorder      : recorder1
  exporter      : exporter1
```

Related Commands

None

26.51 show ipfix sampler

Command Purpose

Use this command to display the configuration of an ipfix sampler.

Command Syntax

show ipfix sampler *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix sampler name	Up to 32 characters

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This example shows how to display configuration of sampler1 in privileged EXEC mode:

```
Switch# show ipfix sampler sampler1

IPFIX sampler information:
  Name           : sampler1
  Description    :
  Rate          : 100
  Sample mode   : determinate
  Flow mode     : all
```

Related Commands

None

26.52 clear ipfix cache monitor

Command Purpose

Use this command to clear the cache of an ipfix monitor.

Command Syntax

clear ipfix cache monitor *NAME*

Parameter	Parameter Description	Parameter Value
NAME	IPFIX monitor name	Up to 32 characters

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This example shows how to clear ipfix cache with name test in privileged EXEC mode:

```
Switch# clear ipfix cache monitor test
```

Related Commands

None

26.53 clear ipfix cache observe-point interface

Command Purpose

Use this command to clear the cache of an ipfix interface.

Command Syntax

clear ipfix cache observe-point interface (*IFNAME*) (input | output)

Parameter	Parameter Description	Parameter Value
IFPHYSICAL	Name of interface	Support physical/aggregation
input	the input packets	-
output	the output packets	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This example shows how to clear ipfix cache on interface eth-0-1 in privileged EXEC mode:

```
Switch# clear ipfix cache observe-point interface eth-0-1 input
```

Related Commands

None

27

DIAG Commands

27.1 show interface queue discard

Command Purpose

Use this command to display an interface queue discard.

Command Syntax

show interface queue discard (*IF_NAME_E* |)

clear interface queue discard (*IF_NAME_E* |)

Parameter	Parameter Description	Parameter Value
IF_NAME_E	interface Name string	Specify the interface name to enter the mode. e.g.eth-0-1.

Command Mode

Privileged EXEC

Default

None

Usage

If the parameter “IF_NAME_E” is not specified, the command indicates that all interfaces on this device should be displayed; otherwise only the specified interface should be displayed.

Examples

The following example shows how to display the situation of interface queue discard:

```
Switch# show interface queue discard

Interface Queue Drop-Packets Stats:
Interface          Drop-Packets      Drop-Bytes
-----+-----+-----
eth-0-1            0                  0
eth-0-2            0                  0
eth-0-3            0                  0
eth-0-4            0                  0
eth-0-5            0                  0
eth-0-6            0                  0
eth-0-7            0                  0
eth-0-8            0                  0
eth-0-9            0                  0
eth-0-10           0                  0
eth-0-11           0                  0
eth-0-12           0                  0
eth-0-13           0                  0
eth-0-14           0                  0
eth-0-15           0                  0
eth-0-16           0                  0
eth-0-17           0                  0
eth-0-18           0                  0
eth-0-19           0                  0
eth-0-20           0                  0
eth-0-21           0                  0
eth-0-22           0                  0
eth-0-23           0                  0
eth-0-24           0                  0
```

The following example shows how to clear interface queue discard:

```
Switch# clear interface queue discard
```

Related Commands

N/A

27.2 diagnostic-information discard

Command Purpose

Use this command to enable diagnostic-information discard.

Use the no form of this command to disable.

Command Syntax

diagnostic-information discard enable

no diagnostic-information discard enable

Parameter	Parameter Description	Parameter Value
enable	enable	The string of enable.

Command Mode

Global Configuration

Default

no diagnostic-information discard enable

Usage

The command is used to enable the function of diagnostic-information discard.

Examples

The following example shows how to enable the function of diagnostic-information discard:

```
Switch(config)# diagnostic-information discard enable
```

The following example shows how to disable the function of diagnostic-information discard:

```
Switch(config)# no diagnostic-information discard enable
```

Related Commands

N/A

27.3 show diagnostic-information

Command Purpose

Use this command to display packet discard information.

Command Syntax

show diagnostic-information discard

clear diagnostic-information discard

Parameter	Parameter Description	Parameter Value
discard	discard	The string of discard.

Command Mode

Privileged EXEC

Default

None

Usage

The command is used to display the situation of packet discard.

Examples

The following example shows how to display the situation of packet discard:

```

Switch# show diagnostic-information discard

Diagnostic-Information Discard:
Drop-Reason          Description
-----+-----
CTC_DROP_TTL_CHK     TTL check fail
CTC_DROP_ACL_DENY    Acl deny
CTC_DROP_PKT_ERR     Packet check error
CTC_DROP_ISOLATE_CHK Port isolate check fail
CTC_DROP_TRANSIT_DISABLE Transit disable
CTC_DROP_IP_CHK      Ip address or packet check fail
CTC_DROP_VLAN_FILTER Vlan filtering
  
```

CTC DROP STP CHK	Stp check fail
CTC DROP CHKSUM ERR	Checksum error
CTC DROP PARSER ERR	Parser error
CTC DROP TRAFFIC MANAGER	Traffic manager check fail
CTC DROP NET RX	Netrx check fail
CTC DROP NET TX	Nettx check fail
Others	Other drop reasons

The following example shows how to clear packet discard:

```
Switch# clear diagnostic-information discard
```

Related Commands

N/A

28 De-duplicate Commands

28.1 de-duplicate global

Command Purpose

Use this command to enter the de-duplicate global configure mode.

Command Syntax

```
de-duplicate global
```

Command Mode

Global Configuration

Default

None

Usage

None

Examples

This example shows how to enter de-duplicate global configure mode:

```
Switch(config)# de-duplicate global  
Switch(config-duplicate)#
```

Related Commands

None

28.2 de-duplicate enable

Command Purpose

Use this command to enable the de-duplicate function.

Use the no form of this command to disable.

Command Syntax

de-duplicate enable

no de-duplicate enable

Command Mode

De-duplicate Configuration

Default

disabled

Usage

None

Examples

This example shows how to enable de-duplicate function:

```
Switch(config-duplicate)# de-duplicate enable
```

This example shows how to disable de-duplicate function:

```
Switch(config-duplicate)# no de-duplicate enable
```

Related Commands

show de-duplicate global

28.3 de-duplicate mode

Command Purpose

Use this command to configure the de-duplicate mode.

Command Syntax

de-duplicate mode { 0 | 1 | 2 | 3 | 4 }

Parameter	Parameter Description	Parameter Value
0	Mode0:is considered a duplicate packet if the five-tuple, tcpflag, TCP/UDP checksum, IP identification, TCP sequence number and TCP acknowledgement number is the same.	-
1	Mode1:is considered a duplicate packet if the five-tuple, tcpflag, TCP/UDP checksum, IP identification, TCP sequence number, TCP acknowledgement number and payload is the same.	-

2	Mode2:is considered to be a duplicate packet if the five-tuple, tcpflag, TCP/UDP checksum, IP identification, TCP sequence number, TCP acknowledgement number, ipv4 header(except TTL, IP checksum and IPV4 extend header) and payload is the same.	-
3	Mode3:is considered to be a duplicate packet if the five-tuple, tcpflag, TCP/UDP checksum, IP identification, TCP sequence number, TCP acknowledgement number, vlan(include SP-VLAN and CE-VLAN), ipv4 header(except TTL, IP checksum and IPV4 extend header) and payload is the same.	-

4	Mode4:is considered to be a duplicate packet if the five-tuple, tcpflag, TCP/UDP checksum, IP identification, TCP sequence number, TCP acknowledgement number, destination mac address, source mac address, vlan(include SP-VLAN and CE-VLAN), ipv4 header(except TTL, IP checksum and IPV4 extend header) and payload is the same.	-
---	---	---

Command Mode

De-duplicate Configuration

Default

mode 1

Usage

None

Examples

This example shows how to configure de-duplicate mode 3:

```
Switch(config-duplicate)# de-duplicate mode 3
```

Related Commands

show de-duplicate global

28.4 de-duplicate times

Command Purpose

Use this command to configure the de-duplicate times.

Command Syntax

de-duplicate times { *NUM* | no-limit }

Parameter	Parameter Description	Parameter Value
NUM	de-duplicate times	1-10
no-limit	no-limit de-duplicate times	-

Command Mode

De-duplicate Configuration

Default

no-limit

Usage

None

Examples

This example shows how to configure de-duplicate times 5:

```
Switch(config-duplicate)# de-duplicate times 5
```

Related Commands

show de-duplicate global

28.5 de-duplicate aging-time

Command Purpose

Use this command to configure the de-duplicate aging-time.

Command Syntax

de-duplicate aging-time *TIME*

Parameter	Parameter Description	Parameter Value
TIME	de-duplicate entry age time	100-30000ms

Command Mode

De-duplicate Configuration

Default

100ms

Usage

None

Examples

This example shows how to configure de-duplicate aging-time 500ms:

```
Switch(config-duplicate)# de-duplicate aging-time 500
```

Related Commands

show de-duplicate global

28.6 de-duplicate ignore

Command Purpose

Use this command to configure the de-duplicate ignore fields.

Command Syntax

```
de-duplicate { ignore-tcpflag | ignore-checksum | ignore-ip-id | ignore-seqnum |
ignore-acknum | ignore-interface } enable
```

```
no de-duplicate { ignore-tcpflag | ignore-checksum | ignore-ip-id | ignore-seqnum
| ignore-acknum | ignore-interface } enable
```

Parameter	Parameter Description	Parameter Value
ignore-tcpflag	ignore tcpflag field	-
ignore-checksum	ignore TCP/UDP checksum field	-
ignore-ip-id	ignore IP identification field	-
ignore-seqnum	ignore TCP sequence number field	-
ignore-acknum	ignore TCP acknowledgement number field	-
ignore-interface	ignore interface of packet coming in	-

Command Mode

De-duplicate Configuration

Default

```
de-duplicate ignore-tcpflag enable
```

de-duplicate ignore-checksum enable
de-duplicate ignore-ip-id enable
de-duplicate ignore-seqnum enable
de-duplicate ignore-acknum enable
no de-duplicate ignore-interface enable

Usage

None

Examples

This example shows how to enable de-duplicate ignore-interface field:

```
Switch(config-duplicate)# de-duplicate ignore-interface enable
```

This example shows how to disable de-duplicate ignore-interface field:

```
Switch(config-duplicate)# no de-duplicate ignore-interface enable
```

Related Commands

show de-duplicate global

28.7 show de-duplicate global

Command Purpose

Use this command to display the de-duplicate global configuration.

Command Syntax

show de-duplicate global

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This example shows how to display de-duplicate global configuration:

```
Switch# show de-duplicate global

De-duplicate global information:
  de-duplicate enable           : disable
  de-duplicate mode            : 1
  de-duplicate times           : 5
  de-duplicate aging-time      : 500 ms

De-duplicate ignore-field information:
  de-duplicate ignore-tcpflag  : disable
  de-duplicate ignore-checksum : disable
  de-duplicate ignore-ip-id    : disable
  de-duplicate ignore-seqnum   : disable
  de-duplicate ignore-acknum   : disable
  de-duplicate ignore-interface : enable
```

Related Commands

de-duplicate global

28.8 show de-duplicate stats

Command Purpose

Use this command to display the de-duplicate stats.

Command Syntax

```
show de-duplicate stats
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

This example shows how to display de-duplicate stats:

```
Switch# show de-duplicate stats

tap-group tap2,ingress eth-0-1_2:
  pkt_in:0 pkt_out:0 pkt_delta:0
  byte_in:0 byte_out:0 byte_delta:0
tap-group tap1,ingress eth-0-1_1,flow flow1,sequence-num 10:
  pkt_in:0 pkt_out:0 pkt_delta:0
  byte_in:0 byte_out:0 byte_delta:0
```

Related Commands

de-duplicate global

29 DDOS Prevent Commands

29.1 ip intercept

Command Purpose

Using the IP intercept ICMP command to configure the system to defend against ICMP flooding attacks.

Configuring switches to defend against Smurf attacks using the IP intercept Smurf command.

Configuring switches to defend against Fraggle attacks using the IP intercept Fraggle command.

Using the IP intercept UDP command to configure the system to defend against UDP flooding attacks.

Using the IP intercept TCP command to configure the system to defend against SYN flooding attacks.

Using the IP intercept maceq command, configure the system to filter ports whose source MAC address is equal to the destination MAC address.

Using IP intercept ipeq command, configure the system to filter ports whose source IP address is equal to the destination IP address.

Command Syntax

```
ip intercept ( smurf | fraggle | maceq | ipeq | icmp ( maxcount IPT_MAXCOUNT | )
tcp ( maxcount IPT_MAXCOUNT | ) udp ( maxcount IPT_MAXCOUNT | ) )
```

```
no ip intercept ( smurf | fraggle | maceq | ipeq | icmp | tcp | udp )
```

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

IPT_MAXCOUNT	Set the maximum rate of receiving packets	Range is 0-1000
--------------	---	-----------------

Command Mode

Global Configuration

Default

Prevent SYN attacks is enabled by default; Prevent other attacks are disabled by default.

The default number of packets to defend against ICMP flooding attacks is 500 per second.

The default number of packets to defend against UDP flooding attacks is 500 per second.

The default number of packets to defend against SYN flooding attacks is 500 per second.

Usage

None

Examples

The following example shows how to configures the ip intercept:

```
Switch# configure terminal
Switch(config)# ip intercept icmp maxcount 100
Switch(config)# ip intercept fraggle
Switch(config)# ip intercept maceq
Switch(config)# ip intercept tcp maxcount 200
```

The following example shows how to convert the ip intercept icmp:

```
Switch# configure terminal
Switch(config)# no ip intercept icmp
```

Related Commands

show ip-intercept statistics

show ip-intercept config

29.2 show ip-intercept config

Command Purpose

Use this command to display the current DDoS defense configuration.

Command Syntax

show ip-intercept config

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows to the current ddos defense config:

```
Switch# show ip-intercept config

Current DDoS Prevent configuration:
-----+-----+-----+-----
Fraggle Attack Intercept      :Enable
ICMP Flood Intercept          :Enable  Maxcount:500
IP Equal Intercept            :Disable
MAC Equal Intercept           :Disable
Smurf Attack Intercept        :Enable
SYN Flood Intercept           :Enable  Maxcount:200
UDP Flood Intercept           :Disable
```

Related Commands

ip intercept

29.3 clear ip-intercept statistics

Command Purpose

Use this command to clear current attack detection packet loss statistics.

Command Syntax

```
clear ip-intercept statistics
```

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to clear statistic of the intercept packets:

```
Switch# clear ip-intercept statistics
```

Related Commands

```
show ip-intercept statistics
```

29.4 show ip-intercept statistics

Command Purpose

Use this command to display current attack detection packet loss statistics.

Command Syntax

show ip-intercept statistics

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to the statistics of the intercept packets:

```
Switch# show ip-intercept statistics

Current DDoS Prevent statistics:
-----+-----
mgmt-if Resist Fraggle Attack packets number      : 0
mgmt-if Resist ICMP Flood packets number          : 0
mgmt-if Resist Smurf Attack packets number        : 0
mgmt-if Resist SYN Flood packets number           : 0
mgmt-if Resist UDP Flood packets number           : 0
```

Related Commands

clear ip-intercept statistics

30 LLDP Commands

30.1 lldp enable

Command Purpose

Use this command to enable lldp globally.

Use the no form of this command to disable.

Command Syntax

lldp enable

no lldp enable

Command Mode

Global Configuration

Default

Disabled

Usage

None

Examples

The following example shows how to enable and disable lldp function globally:

```
Switch# configure terminal
Switch(config)# lldp enable
Switch(config)# no lldp enable
```

Related Commands

show lldp local config

30.2 lldp timer tx-interval

Command Purpose

Use this command to set the lldp timer tx interval.

Use the no form of this command to restore the default.

Command Syntax

lldp timer tx-interval *INTERVAL_VALUE*

no lldp timer tx-interval

Parameter	Parameter Description	Parameter Value
INTERVAL_VALUE	INTERVAL VALUE	5-32768

Command Mode

Global Configuration

Default

30s

Usage

The range of INTERVAL_VALUE is 5s-32768s, Its value must be greater than or equal to four times tx-delay, default value is 30s.

Examples

The following example shows how to set lldp tx hold time value:

```
Switch# configure terminal
Switch(config)# lldp timer tx-interval 20
```

The following example shows how to recover lldp tx hold time to default value:

```
Switch# configure terminal  
Switch(config)# no lldp timer tx-interval
```

Related Commands

show lldp local config

30.3 lldp timer tx-hold

Command Purpose

Use this command to set the lldp tx hold time value.

Use the no form of this command to restore the default.

Command Syntax

lldp timer tx-hold *HOLD_VALUE*

no lldp timer tx-hold

Parameter	Parameter Description	Parameter Value
HOLD_VALUE	Multiplier	2-10

Command Mode

Global Configuration

Default

4

Usage

The range of HOLD_VALUE is 2-10, default value is 4.

Examples

The following example shows how to set lldp tx hold time value:

```
Switch# configure terminal
Switch(config)# lldp timer tx-hold 3
```

The following example shows how to recover lldp reinit delay time to default value:

```
Switch# configure terminal
Switch(config)# no lldp timer tx-hold
```

Related Commands

show lldp local config

30.4 lldp timer tx-delay

Command Purpose

Use this command to set the lldp tx delay time value.

Use the no form of this command to restore the default.

Command Syntax

lldp timer tx-delay *DELAY_VALUE*

no lldp timer tx-delay

Parameter	Parameter Description	Parameter Value
DELAY_VALUE	DELAY VALUE	1-8192

Command Mode

Global Configuration

Default

2s

Usage

The range of DELAY_VALUE is 1s-8192s, It must be less than or equal to a quarter of its value tx-interval, default value is 2s.

Examples

The following example shows how to set lldp tx delay time value:

```
Switch# configure terminal
Switch(config)# lldp timer tx-delay 1
```

The following example shows how to recover lldp tx delay time to default value:

```
Switch# configure terminal
Switch(config)# no lldp timer tx-delay
```

Related Commands

show lldp local config

30.5 lldp timer reinit-delay

Command Purpose

Use this command to set the lldp reinit delay time value.

Use the no form of this command to restore the default.

Command Syntax

lldp timer reinit-delay *RE_DELAY_VALUE*

no lldp timer reinit-delay

Parameter	Parameter Description	Parameter Value
RE_DELAY_VALUE	RE_DELAY VALUE	1-10

Command Mode

Global Configuration

Default

2s

Usage

The range of RE_DELAY_VALUE is 1s-8192s, default value is 2s.

Examples

The following example shows how to set lldp reinit delay time value:

```
Switch# configure terminal
Switch(config)# lldp timer reinit-delay 1
```

The following example shows how to recover lldp reinit delay time to default value:

```
Switch# configure terminal
Switch(config)# no lldp timer reinit-delay
```

Related Commands

show lldp local config

30.6 lldp management ip

Command Purpose

Use this command to set the lldp management ip address.

Use the no form of this command to restore the default.

Command Syntax

lldp management ip *IP_ADDRESS*

no lldp management ip

Parameter	Parameter Description	Parameter Value
IP_ADDRESS	IP ADDRESS	-

Command Mode

Global Configuration

Default

None

Usage

None

Examples

The following example shows how to set the lldp management ip address:

```
Switch# configure terminal
Switch(config)# lldp management ip 1.2.3.4
```

The following example shows how to recover lldp management ip address to default value:

```
Switch# configure terminal
Switch(config)# no lldp management ip
```

Related Commands

show lldp local tlv-info

30.7 lldp system-name

Command Purpose

Use this command to set the lldp system name.

Use the no form of this command to remove the configuration.

Command Syntax

lldp system-name *SYSTEM_NAME*

no lldp system-name

Parameter	Parameter Description	Parameter Value
-----------	-----------------------	-----------------

SYSTEM_NAME	SYSTEM NAME	The first character should be a-z or A-Z or 0-9, character only can be 0-9/A-Z/a-z/.__ and the max length is 64
-------------	-------------	---

Command Mode

Global Configuration

Default

Default value is the value of hostname

Usage

None

Examples

The following example shows how to set the lldp system name:

```
Switch# configure terminal
Switch(config)# lldp system-name lldpname
```

The following example shows how to recover the lldp system name to default value:

```
Switch# configure terminal
Switch(config)# no lldp system-name
```

Related Commands

show lldp local tlv-info

30.8 lldp system-description

Command Purpose

Use this command to configure the lldp system description.

Use the no form of this command to remove the configuration.

Command Syntax

lldp system-description *SYSTEM_DESCRIPTION*

no lldp system-description

Parameter	Parameter Description	Parameter Value
SYSTEM_DESCRIPTION	SYSTEM DESCRIPTION	Length range is 1-255

Command Mode

Global Configuration

Default

Default value is the system description of “show version” command

Usage

None

Examples

The following example set the lldp system description:

```
Switch# configure terminal
Switch(config)# lldp system-description string
```

The following example shows how to reset the lldp system description:

```
Switch# configure terminal
Switch(config)# no lldp system-description
```

Related Commands

show lldp local tlv-info

30.9 lldp enable

Command Purpose

Use this command to enable the lldp admin status on an interface, txonly, rxonly, tx rx.

Use the no form of this command to disable.

Command Syntax

lldp enable (txonly | rxonly | txrx)

no lldp enable

Parameter	Parameter Description	Parameter Value
txonly	enable packet to send	-
txrx	enable packet to send and receive	-
rxonly	enable packet to receive	-

Command Mode

Interface Configuration

Default

enable txrx

Usage

None

Examples

The following example shows how to turn on LLDP on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# lldp enable txrx
```

The following example shows how to turn off LLDP on interface:

```

Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no lldp enable
  
```

Related Commands

show lldp local config

30.10 lldp tlv basic

Command Purpose

Use this command to configure the lldp basic tlv on an interface.

Use the no form of this command to remove the configuration.

Command Syntax

lldp tlv basic (all | management-address | port-description | system-capabilities | system-description | system-name)

no lldp tlv basic (all | management-address | port-description | system-capabilities | system-description | system-name)

Parameter	Parameter Description	Parameter Value
all	all basic TLV	-
management-address	management-address TLV	-
port-description	port-description TLV	-
system-capabilities	system-capabilities TLV	-
system-description	system-description TLV	-
system-name	system-name TLV	-

Command Mode

Interface Configuration

Default

All basic tlv have been enabled

Usage

None

Examples

The following example shows how to set the lldp basic tlv on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# lldp tlv basic port-description
Switch(config-if-eth-0-1)# lldp tlv basic all
```

The following example shows how to unset the lldp basic tlv on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no lldp tlv basic port-description
Switch(config-if-eth-0-1)# no lldp tlv basic all
```

Related Commands

show lldp local config

30.11 lldp tlv med

Command Purpose

Use this command to set the lldp med tlv inventory on an interface.

Use the no form of this command to cancel.

Command Syntax

lldp tlv med (inventory)

Parameter	Parameter Description	Parameter Value
inventory	select Inventory TLV	-

Command Mode

Interface Configuration

Default

Inventory MED TLV have been enabled

Usage

None

Examples

The following example shows how to set the lldp med tlv on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# lldp tlv med inventory
```

The following example shows how to unset the lldp med tlv on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no lldp tlv med inventory
```

Related Commands

show lldp local config

30.12 lldp tlv 8023-org-specific

Command Purpose

Use this command to set the lldp 8023-org-specific tlv on an interface.

Use the no form of this command to remove the configuration.

Command Syntax

lldp tlv 8023-org-specific (all | mac-phy-cfg | max-frame-size | link-aggregation)

no lldp tlv 8023-org-specific (all | mac-phy-cfg | max-frame-size | link-aggregation)

Parameter	Parameter Description	Parameter Value
all	select all IEEE 802.3 TLV	-
mac-phy-cfg	select MAC/PHY Configuration/Status TLV	-
max-frame-size	select Maximum Frame Size TLV	-
link-aggregation	select Link Aggregation TLV	-

Command Mode

Interface Configuration

Default

All IEEE 802.3 tlv have been enabled

Usage

None

Examples

The following example shows how to set the lldp 8023-org-specific tlv on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# lldp tlv 8023-org-specific mac-phy-cfg
Switch(config-if-eth-0-1)# lldp tlv 8023-org-specific all
```

The following example shows how to unset the lldp 8023-org-specific tlv on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no lldp tlv 8023-org-specific mac-phy-cfg
Switch(config-if-eth-0-1)# no lldp tlv 8023-org-specific all
```


Related Commands

show lldp local config

30.13 show lldp local config

Command Purpose

Use this command to display the lldp local config interface information.

Command Syntax

show lldp local config (interface *IFNAME*)

Parameter	Parameter Description	Parameter Value
IFNAME	Interface name	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the global time information and lldp enable or disable:

```

Switch# show lldp local config

LLDP global configuration:
-----+-----
LLDP function global enabled: YES
LLDP TxHold           : 4
LLDP TxInterval       : 10s
  
```

```

LLDP ReinitDelay      : 2s
LLDP TxDelay          : 2s

switch# show lldp local config interface eth-0-1
LLDP configuration on interface eth-0-1:
-----+-----
LLDP admin status      : TXRX
Basic optional TLV Enabled:
  Port Description TLV
  System Name TLV
  System Description TLV
  System Capabilities TLV
  Management Address TLV

IEEE 802.3 TLV Enabled:
  MAC/PHY Configuration/Status TLV
  Link Aggregation TLV
  Maximum Frame Size TLV

LLDP-MED TLV Enabled:
  Med Capabilities TLV
  Inventory TLV
  
```

Related Commands

None

30.14 show lldp local tlv-info

Command Purpose

Use this command to display the lldp local tlv-info interface information.

Command Syntax

show lldp local tlv-info (interface *IFNAMEE*)

Parameter	Parameter Description	Parameter Value
IFNAME	Interface name	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display the global tlv information:

```
Switch# show lldp local tlv-info

LLDP global TLV information:
-----+-----
System Name           : switch

System Description    : XXXXX , XXXXX, XXXXX, Vendor information

System Capabilities   :
    Other             : Enabled

Configured Management IP Address:

LLDP MED Inventory Information:
Hardware Revision     : XXXXX
Firmware Revision    : 1.0
Software Revision     : 3.0.13.4
Serial Number         : XXXXX
Manufacturer Name     : Vendor information
Model Name           : XXXXX

switch# show lldp local tlv-info interface eth-0-1
LLDP TLV information on interface eth-0-1:
-----+-----
Link Aggregation status : Supported

MAC/PHY Configuration/Status:
AutoNego Support       : Supported, Enabled
AutoNego Capability    : 0
Operational MAU Type   : 0

Maximum Frame Size    : 16127
```

Related Commands

None

30.15 show lldp neighbor

Command Purpose

Use this command to display the remote device information.

Command Syntax

show lldp neighbor (brief |) (interface *IFNAMEE*)

Parameter	Parameter Description	Parameter Value
IFNAMEE	Interface name	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to lldp neighbor information:

```
Switch# show lldp neighbor

Remote LLDP Information of port eth-0-1
=====
Neighbor Index : 1
Basic Information
  Chassis Info:
    Chassis ID type      : Mac address
    Chassis ID           : 001E.0820.6665

  Port Info:
    Port ID type        : Interface Name
    Port ID              : eth-0-1
```

```
Time To Live:
  TTL                : 40
  ExpireTime         : 33

Port Description      : eth-0-1
System Name          : bianzh
System Description    : XXXXX, XXXXX, XXXXX, Vendor information
System Capabilities:
  Other              : Enabled

Management info:
  Management Address Type : IPv4
  Management Address      : 10.10.39.157

IEEE 802.3
Link Aggregation:
  Link Aggregation Capability : Support
  Link Aggregation Status     : Disabled
  Link Aggregation Port ID    : Unknown

MAC/PHY Configuration/Status:
  AutoNego Support           : Support, Enabled
  AutoNego Capability        : Unknown
  Operational MAU Type       : Unknown - Unknown

Maximum Frame Size     : 16127

LLDP MED Information
Med capabilities:
  LLDP-MED Capabiliies
  Inventory

Inventory Information:
  Hardware Rivision         : XXXXX
  Firmware Rivision         : 1.0
  Software Rivision         : 3.0.13.4
  Serial Number             : XXXXX
  Manufacturer Name         : Vendor information
  Model Name                : XXXXX

switch# show lldp neighbor brief
Local Port              : eth-0-1
ChassisID               : 001E.0820.6665
Remote Port             : eth-0-1
HoldTime                : 40
ExpireTime              : 27
System Name             : switch
```

Related Commands

None

30.16 show lldp statistics

Command Purpose

Use this command to display the lldp statistics.

Command Syntax

show lldp statistics (interface *IFNAMEE*)

Parameter	Parameter Description	Parameter Value
IFNAME	Interface Name	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to display lldp statistics:

```
Switch# show lldp statistics
-----+-----
LLDP Port statistics for : eth-0-1
Frames Transmitted      : 10
Frames Aged             : 0
Frames Discarded       : 0
Frames with Error      : 0
Frames received        : 0
TLVs Discarded         : 0
TLVs Unrecognized     : 0
Switch# show lldp statistics interface eth-0-1
LLDP statistics information:
```

```

-----+-----
LLDP Port statistics for : eth-0-1
Frames Transmitted      : 10
Frames Aged             : 0
Frames Discarded        : 0
Frames with Error       : 0
Frames received         : 0
TLVs Discarded          : 0
TLVs Unrecognized      : 0
  
```

Related Commands

None

30.17 clear lldp statistics

Command Purpose

Use this command to clear the lldp statistics.

Command Syntax

clear lldp statistics (interface *IFNAMEE*)

Parameter	Parameter Description	Parameter Value
IFNAME	Interface Name	-

Command Mode

Privileged EXEC

Default

None

Usage

None

Examples

The following example shows how to clear lldp statistics:

```
Switch# clear lldp statistics  
Switch# clear lldp statistics interface eth-0-1
```

Related Commands

None

31 ECMP-GROUP Commands

31.1 ecmp-group

Command Purpose

Use this command to create an ecmp-group and enter the ecmp-group configuration mode.

Use the no form of this command to delete the ecmp-group.

Command Syntax

ecmp-group *ECMP_GROUP_ID*

no ecmp-group *ECMP_GROUP_ID*

Parameter	Parameter Description	Parameter Value
ECMP_GROUP_ID	Specify the ecmp-group ID to configure or create	1-512

Command Mode

Global Configuration

Default

None

Usage

This device supports up to 512 ecmp-groups.

Examples

The following example shows how to add an ecmp-group:

```
Switch(config)# ecmp-group 1
Switch(config-ecmp-group1)#
```

The following example shows how to delete an ecmp-group:

```
Switch(config)# no ecmp-group 1
```

Related Commands

show ecmp-group

31.2 member interface

Command Purpose

Use this command to add an ecmp-group member interface.

Use the no form of this command to delete the member interface.

Command Syntax

member interface *IF_NAME_EA*

no member interface *IF_NAME_EA*

Parameter	Parameter Description	Parameter Value
IF_NAME_EA	member interface Name string	Specify the interface name to enter the mode. e.g.eth-0-1, agg1.

Command Mode

ecmp-group Configuration

Default

None

Usage

This device supports up to 64 members.

Examples

The following example shows how to add an ecmp-group member interface:

```
Switch(config-ecmp-group1)# member interface eth-0-1
```

The following example shows how to delete a member interface:

```
Switch(config-ecmp-group1)# no member interface eth-0-1
```

Related Commands

show ecmp-group

31.3 show ecmp-group

Command Purpose

Use this command to display the ecmp-group configuration.

Command Syntax

show ecmp-group (*ECMP_GROUP_ID* |)

Parameter	Parameter Description	Parameter Value
ECMP_GROUP_ID	Specify the ecmp-group ID to show	-

Command Mode

Privileged EXEC

Default

None

Usage

If the parameter “ECMP_GROUP_ID” is not specified, the command indicates that all ecmp-groups on this device should be displayed; otherwise only the specified ecmp-group should be displayed.

Examples

The following example shows how to display the configurations ecmp-group 1:

```
Switch# show ecmp-group 1
ecmp-group 1
sequence-num 1 member interface eth-0-15
```

Related Commands

None