


# Quick Start Guide

# AF10G4ACEv2

10/2026

Release Version: 49410c03

Copyright © 2026 Garland Technology, LLC. All rights reserved.

No part of this document may be reproduced in any form or by any means without prior written permission of Garland Technology, LLC.

The Garland Technology trademarks, service marks ("Marks") and other Garland Technology trademarks are the property of Garland Technology, LLC. PacketMAX Series products of marks are trademarks or registered trademarks of Garland Technology, LLC. You are not permitted to use these Marks without the prior written consent of Garland Technology.

All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between Garland Technology and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute the warranty of any kind, express or implied.


Copyright © 2026 Garland Technology, LLC. All rights reserved.

# Table of Contents

AF10G4ACEv2 ..... 4
Connect to the AF10G4ACEv2 ..... 4
Main Menu ..... 4


Copyright © 2026 Garland Technology, LLC. All rights reserved.

# AF10G4ACEv2

After unpacking the AF10G4ACEv2, connect the AC (110/220V) cord to the Power Input Socket on the back of the unit. Switch the Power Input Switch to the ON position. The Power Input Switch will illuminate GREEN. The MGMT and LAN interfaces are currently N/A.

## Connect to the AF10G4ACEv2

1. Connect a Serial cable from a COM port on the laptop or PC to the RJ-45 Serial Interface on the unit.

2. Launch Putty and configure the Console connection as follows:

| | |
|---|---|
| Speed (baud) | 115200 |
| Data bits | 8 |
| Stop bits | 1 |
| Parity | None |
| Flow Control | XON/XOFF |

3. Press the Return key.

4. Enter the Username, admin

```
Ubuntu 20.04.2 LTS AF10G4ACEv2 ttyS4

AF10G4ACEv2 login: admin
```

5. Enter the Password, gtadmin1.

```
Password: gtadmin1
```

*The Main Menu will be displayed. All applications may be configured from this menu.*

## Main Menu

The main menu provides access to the supported applications. Select the desired application by entering the designated number.

1. Login to the AF10G4ACEv2, admin/gtadmin1.

*The main menu will be displayed.*

```
0: menu exit
1: deduplication control
2: slicing control
3: parser control
4: egress insertion control
5: egress stripping control
6: stats
7: configuration
8: restart application
9: reboot/shutdown appliance
10: interface mode
11: timing mode
```

*2. Enter 1-11 (rt) for the desired option.*


Copyright © 2026 Garland Technology, LLC. All rights reserved.