GARLAND TECHNOLOGY

See every bit, byte, and packet®



User Guide

PacketMAX: Advanced Features | AF40G34

3.0.15

Copyright © 2023 Garland Technology, LLC. All rights reserved.

No part of this document may be reproduced in any form or by any means without prior written permission of Garland Technology, LLC.

The Garland Technology trademarks, service marks ("Marks") and other Garland Technology trademarks are the property of Garland Technology, LLC. PacketMAX Series products of marks are trademarks or registered trademarks of Garland Technology, LLC. You are not permitted to use these Marks without the prior written consent of Garland Technology.

All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between Garland Technology and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute the warranty of any kind, express or implied.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Table of Contents

1 Preface **106**

1.1 Declaration 106

1.2 Suggestion feedback 106

1.1 Audience 106

1.2 Conventions 106

2 INTERFACE Commands **108**

2.1 interface range 108

1 Command Purpose 108

2 Command Syntax 108

3 Command Mode 108

4 Default 108

5 Usage 108

6 Examples 108

7 Related Commands 109

2.2 interface 109

1 Command Purpose 109

2 Command Syntax 109

3 Command Mode 109

4 Default 109

5 Usage 109

6 Examples 109

7 Related Commands 110

2.3 no interface 110

1 Command Purpose 110

2 Command Syntax 110

3 Command Mode 110

4 Default 110

5 Usage 111

6 Examples 111

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 111
2.4 shutdown 111
1 Command Purpose 111
2 Command Syntax 111
3 Command Mode 111
4 Default 111
5 Usage 111
6 Examples 112
7 Related Commands 112
2.5 description 112
1 Command Purpose 112
2 Command Syntax 112
3 Command Mode 112
4 Default 112
5 Usage 113
6 Examples 113
7 Related Commands 113
2.6 speed 113
1 Command Purpose 113
2 Command Syntax 113
3 Command Mode 114
4 Default 114
5 Usage 114
6 Examples 114
7 Related Commands 115
2.7 duplex 115
1 Command Purpose 115
2 Command Syntax 115
3 Command Mode 116
4 Default 116
5 Usage 116
6 Examples 116

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 116
2.8 unidirectional 116
1 Command Purpose 116
2 Command Syntax 117
3 Command Mode 117
4 Default 117
5 Usage 117
6 Examples 117
7 Related Commands 117
2.9 fec 118
1 Command Purpose 118
2 Command Syntax 118
3 Command Mode 118
4 Default 118
5 Usage 118
6 Examples 118
7 Related Commands 119
2.10 static-channel-group 119
1 Command Purpose 119
2 Command Syntax 119
3 Command Mode 119
4 Default 119
5 Usage 119
6 Examples 119
7 Related Commands 120
2.11 media-type 120
1 Command Purpose 120
2 Command Syntax 120
3 Command Mode 120
4 Default 120
5 Usage 120
6 Examples 121

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 121
2.12 show management interface 121
1 Command Purpose 121
2 Command Syntax 121
3 Command Mode 121
4 Default 121
5 Usage 121
6 Examples 121
7 Related Commands 122
2.13 show interface 122
1 Command Purpose 122
2 Command Syntax 122
3 Command Mode 122
4 Default 122
5 Usage 123
6 Examples 123
7 Related Commands 123
2.14 show interface summary 123
1 Command Purpose 123
2 Command Syntax 123
3 Command Mode 124
4 Default 124
5 Usage 124
6 Examples 124
7 Related Commands 124
2.15 show interface status 124
1 Command Purpose 124
2 Command Syntax 124
3 Command Mode 124
4 Default 124
5 Usage 124
6 Examples 124

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 125
2.16 show interface description 125
1 Command Purpose 125
2 Command Syntax 125
3 Command Mode 126
4 Default 126
5 Usage 126
6 Examples 126
7 Related Commands 126
2.17 show interface bandwidth-in-use 126
1 Command Purpose 126
2 Command Syntax 127
3 Command Mode 127
4 Default 127
5 Usage 127
6 Examples 127
7 Related Commands 128
2.18 clear counters 128
1 Command Purpose 128
2 Command Syntax 128
3 Command Mode 128
4 Default 128
5 Usage 128
6 Examples 129
7 Related Commands 129
2.19 crc-check 129
1 Command Purpose 129
2 Command Syntax 129
3 Command Mode 129
4 Default 129
5 Usage 130
6 Examples 130

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 130
2.20 crc-recalculation 130
1 Command Purpose 130
2 Command Syntax 130
3 Command Mode 130
4 Default 131
5 Usage 131
6 Examples 131
7 Related Commands 131
2.21 log-threshold 131
1 Command Purpose 131
2 Command Syntax 131
3 Command Mode 132
4 Default 132
5 Usage 132
6 Examples 132
7 Related Commands 132
2.22 log-threshold output-discard 132
1 Command Purpose 132
2 Command Syntax 133
3 Command Mode 133
4 Default 133
5 Usage 133
6 Examples 133
7 Related Commands 134
2.23 show this 134
1 Command Purpose 134
2 Command Syntax 134
3 Command Mode 134
4 Default 134
5 Usage 134
6 Examples 134

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 135

3 ErrDisable Commands 136

3.1 errdisable detect 136

1 Command Purpose 136
2 Command Syntax 136
3 Command Mode 136
4 Default 136
5 Usage 136
6 Examples 136
7 Related Commands 137

3.2 errdisable recovery interval 137

1 Command Purpose 137
2 Command Syntax 137
3 Command Mode 137
4 Default 137
5 Usage 137
6 Examples 137
7 Related Commands 138

3.3 errdisable recovery reason 138

1 Command Purpose 138
2 Command Syntax 138
3 Command Mode 138
4 Default 138
5 Usage 138
6 Examples 139
7 Related Commands 139

3.4 errdisable flap 139

1 Command Purpose 139
2 Command Syntax 139
3 Command Mode 140
4 Default 140
5 Usage 140

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 140
7 Related Commands 140
3.5 show errdisable detect 140
1 Command Purpose 140
2 Command Syntax 140
3 Command Mode 141
4 Default 141
5 Usage 141
6 Examples 141
7 Related Commands 141
3.6 show errdisable recovery 141
1 Command Purpose 141
2 Command Syntax 141
3 Command Mode 141
4 Default 141
5 Usage 141
6 Examples 142
7 Related Commands 142
3.7 show errdisable flap 142
1 Command Purpose 142
2 Command Syntax 142
3 Command Mode 142
4 Default 142
5 Usage 142
6 Examples 143
7 Related Commands 143
4 FLOW Commands 144
4.1 show interface flow statistics 144
1 Command Purpose 144
2 Command Syntax 144
3 Command Mode 144
4 Default 144

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage 144
6 Examples 144
7 Related Commands 145
4.2 clear interface flow statistics 145
1 Command Purpose 145
2 Command Syntax 145
3 Command Mode 146
4 Default 146
5 Usage 146
6 Examples 146
7 Related Commands 146
4.3 show flow 146
1 Command Purpose 146
2 Command Syntax 146
3 Command Mode 147
4 Default 147
5 Usage 147
6 Examples 147
7 Related Commands 148
4.4 flow 148
1 Command Purpose 148
2 Command Syntax 148
3 Command Mode 148
4 Default 148
5 Usage 148
6 Examples 149
7 Related Commands 149
4.5 remark 149
1 Command Purpose 149
2 Command Syntax 149
3 Command Mode 150
4 Default 150

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage 150
6 Examples 150
7 Related Commands 150
4.6 no sequence-num 150
1 Command Purpose 150
2 Command Syntax 151
3 Command Mode 151
4 Default 151
5 Usage 151
6 Examples 151
7 Related Commands 151
4.7 sequence-num 151
1 Command Purpose 151
2 Command Syntax 152
3 Command Mode 170
4 Default 170
5 Usage 170
6 Examples 170
7 Related Commands 170
5 UDF Commands 170
5.1 show udf 170
1 Command Purpose 170
2 Command Syntax 172
3 Command Mode 172
4 Default 172
5 Usage 172
6 Examples 172
7 Related Commands 173
5.2 udf 173
1 Command Purpose 173
2 Command Syntax 173
3 Command Mode 173

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default 173
5 Usage 173
6 Examples 174
7 Related Commands 174
5.3 match 174
1 Command Purpose 174
2 Command Syntax 174
3 Command Mode 175
4 Default 175
5 Usage 175
6 Examples 175
7 Related Commands 176
5.4 offset 176
1 Command Purpose 176
2 Command Syntax 176
3 Command Mode 176
4 Default 176
5 Usage 176
6 Examples 177
7 Related Commands 177
6 PORT-GROUP Commands 177
6.1 port-group 178
1 Command Purpose 178
2 Command Syntax 178
3 Command Mode 178
4 Default 178
5 Usage 178
6 Examples 179
7 Related Commands 179
6.2 member interface 179
1 Command Purpose 179
2 Command Syntax 179

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode 179
4 Default 179
5 Usage 179
6 Examples 180
7 Related Commands 180
6.3 show port-group 180
1 Command Purpose 180
2 Command Syntax 180
3 Command Mode 180
4 Default 180
5 Usage 180
6 Examples 181
7 Related Commands 181
6.4 show port-group flow statistics 181
1 Command Purpose 181
2 Command Syntax 181
3 Command Mode 182
4 Default 182
5 Usage 182
6 Examples 182
7 Related Commands 182
7 INNER-MATCH Commands 182
7.1 show inner-match 182
1 Command Purpose 182
2 Command Syntax 183
3 Command Mode 184
4 Default 184
5 Usage 184
6 Examples 184
7 Related Commands 184
7.2 inner-match 184
1 Command Purpose 184

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax 184
3 Command Mode 185
4 Default 185
5 Usage 185
6 Examples 185
7 Related Commands 185
7.3 remark 185
1 Command Purpose 185
2 Command Syntax 186
3 Command Mode 186
4 Default 186
5 Usage 186
6 Examples 186
7 Related Commands 186
7.4 no sequence-num 186
1 Command Purpose 187
2 Command Syntax 187
3 Command Mode 187
4 Default 187
5 Usage 187
6 Examples 187
7 Related Commands 187
7.5 sequence-num 188
1 Command Purpose 188
2 Command Syntax 188
3 Command Mode 197
4 Default 197
5 Usage 197
6 Examples 198
7 Related Commands 198
8 ACL Commands 198
8.1 show interface egress ip access-list 199

Copyright © 2023 Garland Technology, LLC. All rights reserved.

1 Command Purpose 199
2 Command Syntax 199
3 Command Mode 199
4 Default 199
5 Usage 199
6 Examples 199
7 Related Commands 200
8.2 clear interface egress ip access-list 200
1 Command Purpose 200
2 Command Syntax 200
3 Command Mode 200
4 Default 200
5 Usage 200
6 Examples 200
7 Related Commands 201
8.3 show ip access-list 201
1 Command Purpose 201
2 Command Syntax 201
3 Command Mode 201
4 Default 201
5 Usage 201
6 Examples 202
7 Related Commands 202
8.4 ip access-list 202
1 Command Purpose 202
2 Command Syntax 202
3 Command Mode 202
4 Default 202
5 Usage 203
6 Examples 203
7 Related Commands 203
8.5 remark 203

Copyright © 2023 Garland Technology, LLC. All rights reserved.

1 Command Purpose 203
2 Command Syntax 203
3 Command Mode 204
4 Default 204
5 Usage 204
6 Examples 204
7 Related Commands 204
8.6 no sequence-num 204
1 Command Purpose 204
2 Command Syntax 204
3 Command Mode 205
4 Default 205
5 Usage 205
6 Examples 205
7 Related Commands 205
8.7 sequence-num 205
1 Command Purpose 205
2 Command Syntax 205
3 Command Mode 217
4 Default 217
5 Usage 217
6 Examples 217
7 Related Commands 217
8.8 egress 217
1 Command Purpose 217
2 Command Syntax 218
3 Command Mode 218
4 Default 218
5 Usage 218
6 Examples 218
7 Related Commands 219
9 TAP Commands 219

Copyright © 2023 Garland Technology, LLC. All rights reserved.

9.1 tap-group 219
1 Command Purpose 219
2 Command Syntax 220
3 Command Mode 220
4 Default 220
5 Usage 220
6 Examples 221
7 Related Commands 221
9.2 description 221
1 Command Purpose 221
2 Command Syntax 221
3 Command Mode 222
4 Default 222
5 Usage 222
6 Examples 222
7 Related Commands 222
9.3 ingress 222
1 Command Purpose 222
2 Command Syntax 222
3 Command Mode 225
4 Default 225
5 Usage 225
6 Examples 225
7 Related Commands 226
9.4 egress 226
1 Command Purpose 226
2 Command Syntax 226
3 Command Mode 227
4 Default 227
5 Usage 227
6 Examples 227
7 Related Commands 228

Copyright © 2023 Garland Technology, LLC. All rights reserved.

9.5 show tap-group 228
1 Command Purpose 228
2 Command Syntax 228
3 Command Mode 229
4 Default 229
5 Usage 229
6 Examples 229
7 Related Commands 229
10 TIMESTAMP Commands 229
10.1 timestamp-over-ether 229
1 Command Purpose 230
2 Command Syntax 230
3 Command Mode 230
4 Default 230
5 Usage 231
6 Examples 231
7 Related Commands 231
10.2 show timestamp sync 231
1 Command Purpose 231
2 Command Syntax 231
3 Command Mode 231
4 Default 231
5 Usage 232
6 Examples 232
7 Related Commands 232
10.3 timestamp sync 232
1 Command Purpose 232
2 Command Syntax 232
3 Command Mode 233
4 Default 233
5 Usage 233
6 Examples 233

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 233

11 TRUNCATION Commands 234

11.1 truncation 234

1 Command Purpose 234
2 Command Syntax 234
3 Command Mode 234
4 Default 234
5 Usage 234
6 Examples 234
7 Related Commands 235

12 SSH Commands 235

12.1 ssh 235

1 Command Purpose 235
2 Command Syntax 236
3 Command Mode 236
4 Default 236
5 Usage 237
6 Examples 237
7 Related Commands 237

12.2 ip ssh server enable 237

1 Command Purpose 237
2 Command Syntax 237
3 Command Mode 237
4 Default 237
5 Usage 238
6 Examples 238
7 Related Commands 238

12.3 ip ssh server disable 238

1 Command Purpose 238
2 Command Syntax 238
3 Command Mode 238
4 Default 238

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage 238
6 Examples 238
7 Related Commands 239
12.4 ip ssh server version 239
1 Command Purpose 239
2 Command Syntax 239
3 Command Mode 239
4 Default 239
5 Usage 239
6 Examples 240
7 Related Commands 240
12.5 ip ssh server authentication-retries 240
1 Command Purpose 240
2 Command Syntax 240
3 Command Mode 240
4 Default 240
5 Usage 240
6 Examples 240
7 Related Commands 241
12.6 ip ssh server authentication-timeout 241
1 Command Purpose 241
2 Command Syntax 241
3 Command Mode 241
4 Default 241
5 Usage 241
6 Examples 241
7 Related Commands 242
12.7 ip ssh server authentication-type 242
1 Command Purpose 242
2 Command Syntax 242
3 Command Mode 242
4 Default 242

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage 243
6 Examples 243
7 Related Commands 243
12.8 ip ssh server rekey-interval 243
1 Command Purpose 243
2 Command Syntax 243
3 Command Mode 244
4 Default 244
5 Usage 244
6 Examples 244
7 Related Commands 244
12.9 ip ssh server host-key 244
1 Command Purpose 244
2 Command Syntax 244
3 Command Mode 245
4 Default 245
5 Usage 245
6 Examples 245
7 Related Commands 245
12.10 ip ssh server port 245
1 Command Purpose 245
2 Command Syntax 245
3 Command Mode 246
4 Default 246
5 Usage 246
6 Examples 246
7 Related Commands 246
12.11 show ip ssh server status 246
1 Command Purpose 246
2 Command Syntax 247
3 Command Mode 247
4 Default 247

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage 247
6 Examples 247
7 Related Commands 247

13 LACP Commands 248

13.1 port-channel load-balance-mode 248
1 Command Purpose 248
2 Command Syntax 248
3 Command Mode 248
4 Default 248
5 Usage 248
6 Examples 248
7 Related Commands 249

13.2 show channel-group 249
1 Command Purpose 249
2 Command Syntax 249
3 Command Mode 249
4 Default 249
5 Usage 249
6 Examples 249
7 Related Commands 250

13.3 show channel-group interface 250
1 Command Purpose 250
2 Command Syntax 250
3 Command Mode 250
4 Default 250
5 Usage 250
6 Examples 250
7 Related Commands 251

14 NTP Commands 252

14.1 ntp minimum-distance 252
1 Command Purpose 252
2 Command Syntax 252

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode 252
4 Default 252
5 Usage 252
6 Examples 252
7 Related Commands 253
14.2 ntp server 253
1 Command Purpose 253
2 Command Syntax 253
3 Command Mode 254
4 Default 254
5 Usage 254
6 Examples 254
7 Related Commands 254
14.3 ntp authentication 254
1 Command Purpose 254
2 Command Syntax 254
3 Command Mode 254
4 Default 254
5 Usage 255
6 Examples 255
7 Related Commands 255
14.4 ntp key 255
1 Command Purpose 255
2 Command Syntax 255
3 Command Mode 256
4 Default 256
5 Usage 256
6 Examples 256
7 Related Commands 256
14.5 ntp trustedkey 256
1 Command Purpose 256
2 Command Syntax 256

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode 257
4 Default 257
5 Usage 257
6 Examples 257
7 Related Commands 257
14.6 show ntp 257
1 Command Purpose 257
2 Command Syntax 258
3 Command Mode 258
4 Default 258
5 Usage 258
6 Examples 258
7 Related Commands 258
14.7 show ntp status 259
1 Command Purpose 259
2 Command Syntax 259
3 Command Mode 259
4 Default 259
5 Usage 259
6 Examples 259
7 Related Commands 259
14.8 show ntp statistics 259
1 Command Purpose 259
2 Command Syntax 259
3 Command Mode 259
4 Default 259
5 Usage 259
6 Examples 259
7 Related Commands 260
14.9 show ntp associations 260
1 Command Purpose 260
2 Command Syntax 260

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode 260
4 Default 260
5 Usage 260
6 Examples 260
7 Related Commands 261
14.10 show ntp key 261
1 Command Purpose 261
2 Command Syntax 261
3 Command Mode 261
4 Default 261
5 Usage 261
6 Examples 261
7 Related Commands 262
14.11 clear ntp statistics 262
1 Command Purpose 262
2 Command Syntax 262
3 Command Mode 263
4 Default 263
5 Usage 263
6 Examples 263
7 Related Commands 263
15 NETWORK DIAGNOSIS Commands 264
15.1 ping 264
1 Command Purpose 264
2 Command Syntax 264
3 Command Mode 264
4 Default 264
5 Usage 264
6 Examples 265
7 Related Commands 265
15.2 traceroute 265
1 Command Purpose 265

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax 265
3 Command Mode 265
4 Default 265
5 Usage 266
6 Examples 266
7 Related Commands 266

16 MONITOR CAPTURE Commands 267

16.1 monitor-capture global 267
1 Command Purpose 267
2 Command Syntax 267
3 Command Mode 267
4 Default 267
5 Usage 267
6 Examples 267
7 Related Commands 267

16.2 monitor-capture packet 268
1 Command Purpose 268
2 Command Syntax 268
3 Command Mode 268
4 Default 268
5 Usage 268
6 Examples 268
7 Related Commands 269

16.3 monitor-capture input 269
1 Command Purpose 269
2 Command Syntax 269
3 Command Mode 269
4 Default 269
5 Usage 269
6 Examples 270
7 Related Commands 270

16.4 monitor-capture output 270

Copyright © 2023 Garland Technology, LLC. All rights reserved.

1 Command Purpose 270
2 Command Syntax 270
3 Command Mode 270
4 Default 271
5 Usage 271
6 Examples 271
7 Related Commands 271
16.5 monitor-capture packet start 271
1 Command Purpose 271
2 Command Syntax 271
3 Command Mode 271
4 Default 271
5 Usage 271
6 Examples 271
7 Related Commands 271
16.6 monitor-capture packet stop 271
1 Command Purpose 272
2 Command Syntax 272
3 Command Mode 272
4 Default 272
5 Usage 272
6 Examples 272
7 Related Commands 273
16.7 monitor-capture packet restart 273
1 Command Purpose 273
2 Command Syntax 273
3 Command Mode 273
4 Default 273
5 Usage 273
6 Examples 273
7 Related Commands 273
16.8 show monitor-capture packet 274

Copyright © 2023 Garland Technology, LLC. All rights reserved.

1 Command Purpose 274
2 Command Syntax 274
3 Command Mode 274
4 Default 274
5 Usage 274
6 Examples 274
7 Related Commands 275
16.9 clear monitor-capture packet all 275
1 Command Purpose 275
2 Command Syntax 275
3 Command Mode 275
4 Default 275
5 Usage 275
6 Examples 275
7 Related Commands 275
16.10 show monitor-capture global 275
1 Command Purpose 276
2 Command Syntax 276
3 Command Mode 276
4 Default 276
5 Usage 276
6 Examples 276
7 Related Commands 277
17 SYSLOG Commands 277
17.1 logging sync 277
1 Command Purpose 277
2 Command Syntax 277
3 Command Mode 277
4 Default 277
5 Usage 277
6 Examples 277
7 Related Commands 277

Copyright © 2023 Garland Technology, LLC. All rights reserved.

17.2 logging buffer 277
1 Command Purpose 277
2 Command Syntax 279
3 Command Mode 279
4 Default 279
5 Usage 279
6 Examples 279
7 Related Commands 280
17.3 logging file 280
1 Command Purpose 280
2 Command Syntax 280
3 Command Mode 280
4 Default 280
5 Usage 280
6 Examples 280
7 Related Commands 281
17.4 logging level file 281
1 Command Purpose 281
2 Command Syntax 281
3 Command Mode 281
4 Default 282
5 Usage 282
6 Examples 282
7 Related Commands 282
17.5 logging level module 282
1 Command Purpose 282
2 Command Syntax 283
3 Command Mode 283
4 Default 283
5 Usage 283
6 Examples 284
7 Related Commands 284

Copyright © 2023 Garland Technology, LLC. All rights reserved.

17.6 logging timestamp 284
1 Command Purpose 284
2 Command Syntax 284
3 Command Mode 285
4 Default 285
5 Usage 285
6 Examples 285
7 Related Commands 285
17.7 logging server 285
1 Command Purpose 285
2 Command Syntax 285
3 Command Mode 286
4 Default 286
5 Usage 286
6 Examples 286
7 Related Commands 286
17.8 logging server severity 286
1 Command Purpose 286
2 Command Syntax 287
3 Command Mode 287
4 Default 287
5 Usage 287
6 Examples 288
7 Related Commands 288
17.9 logging server facility 288
1 Command Purpose 288
2 Command Syntax 288
3 Command Mode 289
4 Default 289
5 Usage 290
6 Examples 290
7 Related Commands 290

Copyright © 2023 Garland Technology, LLC. All rights reserved.

17.10 logging server address 290
1 Command Purpose 290
2 Command Syntax 290
3 Command Mode 290
4 Default 290
5 Usage 291
6 Examples 291
7 Related Commands 291
17.11 logging merge 291
1 Command Purpose 291
2 Command Syntax 291
3 Command Mode 291
4 Default 292
5 Usage 292
6 Examples 292
7 Related Commands 293
17.12 show logging 293
1 Command Purpose 293
2 Command Syntax 293
3 Command Mode 293
4 Default 293
5 Usage 293
6 Examples 293
7 Related Commands 293
17.13 show logging buffer 293
1 Command Purpose 293
2 Command Syntax 293
3 Command Mode 293
4 Default 293
5 Usage 293
6 Examples 295
7 Related Commands 295

Copyright © 2023 Garland Technology, LLC. All rights reserved.

17.14 show logging buffer statistics 295
1 Command Purpose 295
2 Command Syntax 295
3 Command Mode 295
4 Default 295
5 Usage 295
6 Examples 295
7 Related Commands 295
17.15 show logging levels 296
1 Command Purpose 296
2 Command Syntax 296
3 Command Mode 296
4 Default 296
5 Usage 296
6 Examples 297
7 Related Commands 297
17.16 show logging facilities 297
1 Command Purpose 297
2 Command Syntax 297
3 Command Mode 297
4 Default 297
5 Usage 297
6 Examples 297
7 Related Commands 298
17.17 clear logging buffer 298
1 Command Purpose 298
2 Command Syntax 298
3 Command Mode 298
4 Default 298
5 Usage 298
6 Examples 298
7 Related Commands 298

Copyright © 2023 Garland Technology, LLC. All rights reserved.

18 SNMP Commands 298

18.1 show snmp 298

1 Command Purpose 298

2 Command Syntax 298

3 Command Mode 298

4 Default 298

5 Usage 298

6 Examples 298

7 Related Commands 300

18.2 show snmp-server version 301

1 Command Purpose 301

2 Command Syntax 301

3 Command Mode 301

4 Default 301

5 Usage 301

6 Examples 301

7 Related Commands 301

18.3 show snmp-server community 301

1 Command Purpose 301

2 Command Syntax 301

3 Command Mode 302

4 Default 302

5 Usage 302

6 Examples 302

7 Related Commands 302

18.4 show snmp-server engineID 302

1 Command Purpose 302

2 Command Syntax 302

3 Command Mode 303

4 Default 303

5 Usage 303

6 Examples 303

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 303
18.5 show snmp-server sys-info 303
1 Command Purpose 303
2 Command Syntax 303
3 Command Mode 303
4 Default 303
5 Usage 303
6 Examples 303
7 Related Commands 304
18.6 show snmp-server trap-receiver 304
1 Command Purpose 304
2 Command Syntax 304
3 Command Mode 304
4 Default 304
5 Usage 304
6 Examples 305
7 Related Commands 305
18.7 show snmp-server inform-receiver 305
1 Command Purpose 305
2 Command Syntax 305
3 Command Mode 305
4 Default 305
5 Usage 305
6 Examples 306
7 Related Commands 306
18.8 show snmp-server view 306
1 Command Purpose 306
2 Command Syntax 306
3 Command Mode 306
4 Default 306
5 Usage 306
6 Examples 306

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 307
18.9 snmp-server enable 307
1 Command Purpose 307
2 Command Syntax 307
3 Command Mode 307
4 Default 307
5 Usage 307
6 Examples 307
7 Related Commands 307
18.10 snmp-server engineID 307
1 Command Purpose 307
2 Command Syntax 308
3 Command Mode 308
4 Default 308
5 Usage 309
6 Examples 309
7 Related Commands 309
18.11 snmp-server system-contact 309
1 Command Purpose 309
2 Command Syntax 309
3 Command Mode 310
4 Default 310
5 Usage 310
6 Examples 310
7 Related Commands 310
18.12 snmp-server system-location 310
1 Command Purpose 310
2 Command Syntax 310
3 Command Mode 311
4 Default 311
5 Usage 311
6 Examples 311

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 311
18.13 snmp-server version 311
1 Command Purpose 311
2 Command Syntax 312
3 Command Mode 312
4 Default 312
5 Usage 312
6 Examples 312
7 Related Commands 313
18.14 snmp-server view 313
1 Command Purpose 313
2 Command Syntax 313
3 Command Mode 314
4 Default 314
5 Usage 314
6 Examples 314
7 Related Commands 314
18.15 snmp-server community 314
1 Command Purpose 314
2 Command Syntax 315
3 Command Mode 315
4 Default 315
5 Usage 316
6 Examples 316
7 Related Commands 316
18.16 snmp-server trap enable 316
1 Command Purpose 316
2 Command Syntax 316
3 Command Mode 317
4 Default 317
5 Usage 317
6 Examples 317

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 317
18.17 snmp-server trap target-address 318
1 Command Purpose 318
2 Command Syntax 318
3 Command Mode 318
4 Default 318
5 Usage 318
6 Examples 318
7 Related Commands 319
18.18 snmp-server trap delay linkup 319
1 Command Purpose 319
2 Command Syntax 319
3 Command Mode 319
4 Default 319
5 Usage 319
6 Examples 320
7 Related Commands 320
18.19 snmp-server trap delay linkdown 320
1 Command Purpose 320
2 Command Syntax 320
3 Command Mode 320
4 Default 321
5 Usage 321
6 Examples 321
7 Related Commands 321
18.20 snmp-server inform target-address 321
1 Command Purpose 321
2 Command Syntax 321
3 Command Mode 322
4 Default 322
5 Usage 322
6 Examples 322

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 322
18.21 snmp-server access-group 322
1 Command Purpose 322
2 Command Syntax 322
3 Command Mode 323
4 Default 323
5 Usage 323
6 Examples 323
7 Related Commands 323
19 AUTH Commands 323
19.1 show usernames 324
1 Command Purpose 324
2 Command Syntax 324
3 Command Mode 324
4 Default 324
5 Usage 324
6 Examples 324
7 Related Commands 324
19.2 show users 325
1 Command Purpose 325
2 Command Syntax 325
3 Command Mode 325
4 Default 325
5 Usage 325
6 Examples 325
7 Related Commands 325
19.3 show web users 325
1 Command Purpose 325
2 Command Syntax 326
3 Command Mode 326
4 Default 326
5 Usage 326

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 326
7 Related Commands 326
19.4 show privilege 326
1 Command Purpose 326
2 Command Syntax 326
3 Command Mode 327
4 Default 327
5 Usage 327
6 Examples 327
7 Related Commands 327
19.5 clear line console 0 327
1 Command Purpose 327
2 Command Syntax 327
3 Command Mode 327
4 Default 327
5 Usage 327
6 Examples 327
7 Related Commands 328
19.6 clear line vty 328
1 Command Purpose 328
2 Command Syntax 328
3 Command Mode 328
4 Default 328
5 Usage 328
6 Examples 328
7 Related Commands 329
19.7 clear web session 329
1 Command Purpose 329
2 Command Syntax 329
3 Command Mode 329
4 Default 329
5 Usage 329

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 329
7 Related Commands 330
19.8 show console 330
1 Command Purpose 330
2 Command Syntax 330
3 Command Mode 330
4 Default 330
5 Usage 330
6 Examples 330
7 Related Commands 331
19.9 show vty 331
1 Command Purpose 331
2 Command Syntax 331
3 Command Mode 331
4 Default 331
5 Usage 331
6 Examples 331
7 Related Commands 332
19.10 show rsa keys 332
1 Command Purpose 332
2 Command Syntax 332
3 Command Mode 332
4 Default 332
5 Usage 332
6 Examples 332
7 Related Commands 332
19.11 show rsa key 333
1 Command Purpose 333
2 Command Syntax 333
3 Command Mode 334
4 Default 334
5 Usage 334

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 334
7 Related Commands 334
19.12 show key config 334
1 Command Purpose 334
2 Command Syntax 334
3 Command Mode 334
4 Default 334
5 Usage 334
6 Examples 334
7 Related Commands 334
19.13 show key string 334
1 Command Purpose 334
2 Command Syntax 334
3 Command Mode 334
4 Default 334
5 Usage 334
6 Examples 334
7 Related Commands 337
19.14 show tacacs 337
1 Command Purpose 337
2 Command Syntax 337
3 Command Mode 337
4 Default 337
5 Usage 337
6 Examples 337
7 Related Commands 337
19.15 show aaa status 337
1 Command Purpose 337
2 Command Syntax 337
3 Command Mode 337
4 Default 337
5 Usage 337

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 337
7 Related Commands 337
19.16 show aaa privilege mapping 337
1 Command Purpose 337
2 Command Syntax 337
3 Command Mode 337
4 Default 337
5 Usage 337
6 Examples 337
7 Related Commands 339
19.17 show aaa method-lists 340
1 Command Purpose 340
2 Command Syntax 340
3 Command Mode 340
4 Default 340
5 Usage 340
6 Examples 340
7 Related Commands 341
19.18 line console 341
1 Command Purpose 341
2 Command Syntax 341
3 Command Mode 341
4 Default 341
5 Usage 341
6 Examples 341
7 Related Commands 342
19.19 line vty 342
1 Command Purpose 342
2 Command Syntax 342
3 Command Mode 342
4 Default 342
5 Usage 342

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 342
7 Related Commands 343
19.20 line vty maximum 343
1 Command Purpose 343
2 Command Syntax 343
3 Command Mode 343
4 Default 343
5 Usage 343
6 Examples 343
7 Related Commands 344
19.21 rsa key generate 344
1 Command Purpose 344
2 Command Syntax 344
3 Command Mode 344
4 Default 344
5 Usage 344
6 Examples 345
7 Related Commands 345
19.22 rsa key import 345
1 Command Purpose 345
2 Command Syntax 345
3 Command Mode 346
4 Default 346
5 Usage 346
6 Examples 346
7 Related Commands 346
19.23 rsa key export 346
1 Command Purpose 346
2 Command Syntax 346
3 Command Mode 347
4 Default 347
5 Usage 347

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 347
7 Related Commands 348
19.24 rsa key 348
1 Command Purpose 348
2 Command Syntax 348
3 Command Mode 348
4 Default 348
5 Usage 348
6 Examples 349
7 Related Commands 349
19.25 reset 349
1 Command Purpose 349
2 Command Syntax 349
3 Command Mode 349
4 Default 349
5 Usage 349
6 Examples 349
7 Related Commands 350
19.26 key type 350
1 Command Purpose 350
2 Command Syntax 350
3 Command Mode 350
4 Default 350
5 Usage 350
6 Examples 350
7 Related Commands 351
19.27 key format 351
1 Command Purpose 351
2 Command Syntax 351
3 Command Mode 351
4 Default 351
5 Usage 351

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 352
7 Related Commands 352
19.28 key string end 352
1 Command Purpose 352
2 Command Syntax 352
3 Command Mode 352
4 Default 352
5 Usage 352
6 Examples 352
7 Related Commands 353
19.29 validate 353
1 Command Purpose 353
2 Command Syntax 353
3 Command Mode 353
4 Default 353
5 Usage 353
6 Examples 353
7 Related Commands 353
19.30 KEYLINE 354
1 Command Purpose 354
2 Command Syntax 354
3 Command Mode 354
4 Default 354
5 Usage 354
6 Examples 354
7 Related Commands 354
19.31 re-activate radius-server 354
1 Command Purpose 354
2 Command Syntax 354
3 Command Mode 355
4 Default 355
5 Usage 355

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 355
7 Related Commands 355
19.32 show radius-server 355
1 Command Purpose 356
2 Command Syntax 356
3 Command Mode 356
4 Default 356
5 Usage 356
6 Examples 356
7 Related Commands 356
19.33 radius-server host 357
1 Command Purpose 357
2 Command Syntax 357
3 Command Mode 357
4 Default 358
5 Usage 358
6 Examples 358
7 Related Commands 358
19.34 radius-server deadtime 358
1 Command Purpose 358
2 Command Syntax 358
3 Command Mode 358
4 Default 358
5 Usage 358
6 Examples 359
7 Related Commands 359
19.35 radius-server retransmit 359
1 Command Purpose 359
2 Command Syntax 359
3 Command Mode 360
4 Default 360
5 Usage 360

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 360
7 Related Commands 360
19.36 radius-server timeout 361
1 Command Purpose 361
2 Command Syntax 361
3 Command Mode 361
4 Default 361
5 Usage 361
6 Examples 361
7 Related Commands 361
19.37 radius-server key 362
1 Command Purpose 362
2 Command Syntax 362
3 Command Mode 362
4 Default 362
5 Usage 362
6 Examples 363
7 Related Commands 363
19.38 re-activate tacacs-server 363
1 Command Purpose 363
2 Command Syntax 363
3 Command Mode 363
4 Default 363
5 Usage 363
6 Examples 364
7 Related Commands 364
19.39 tacacs-server host 364
1 Command Purpose 364
2 Command Syntax 364
3 Command Mode 365
4 Default 365
5 Usage 365

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 365
7 Related Commands 366
19.40 username 366
1 Command Purpose 366
2 Command Syntax 366
3 Command Mode 366
4 Default 366
5 Usage 366
6 Examples 367
7 Related Commands 367
19.41 username password 367
1 Command Purpose 367
2 Command Syntax 367
3 Command Mode 367
4 Default 368
5 Usage 368
6 Examples 368
7 Related Commands 368
19.42 username assign 368
1 Command Purpose 368
2 Command Syntax 368
3 Command Mode 369
4 Default 369
5 Usage 369
6 Examples 369
7 Related Commands 369
19.43 username privilege 369
1 Command Purpose 369
2 Command Syntax 369
3 Command Mode 370
4 Default 370
5 Usage 370

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 370
7 Related Commands 370
19.44 username secret 370
1 Command Purpose 370
2 Command Syntax 371
3 Command Mode 371
4 Default 371
5 Usage 371
6 Examples 371
7 Related Commands 371
19.45 re-username 372
1 Command Purpose 372
2 Command Syntax 372
3 Command Mode 372
4 Default 372
5 Usage 372
6 Examples 372
7 Related Commands 373
19.46 enable password 373
1 Command Purpose 373
2 Command Syntax 373
3 Command Mode 373
4 Default 373
5 Usage 373
6 Examples 374
7 Related Commands 374
19.47 enable password privilege 374
1 Command Purpose 374
2 Command Syntax 374
3 Command Mode 374
4 Default 374
5 Usage 374

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 375
7 Related Commands 375
19.48 service password-encryption 375
1 Command Purpose 375
2 Command Syntax 375
3 Command Mode 376
4 Default 376
5 Usage 376
6 Examples 376
7 Related Commands 376
19.49 aaa new-model 376
1 Command Purpose 376
2 Command Syntax 377
3 Command Mode 377
4 Default 377
5 Usage 377
6 Examples 377
7 Related Commands 377
19.50 aaa authentication login 377
1 Command Purpose 377
2 Command Syntax 378
3 Command Mode 378
4 Default 378
5 Usage 378
6 Examples 378
7 Related Commands 379
19.51 aaa authorization exec 379
1 Command Purpose 379
2 Command Syntax 379
3 Command Mode 380
4 Default 380
5 Usage 380

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 380
7 Related Commands 380
19.52 aaa accounting exec 380
1 Command Purpose 380
2 Command Syntax 380
3 Command Mode 381
4 Default 381
5 Usage 381
6 Examples 381
7 Related Commands 381
19.53 aaa accounting commands 382
1 Command Purpose 382
2 Command Syntax 382
3 Command Mode 382
4 Default 382
5 Usage 382
6 Examples 382
7 Related Commands 383
19.54 aaa privilege mapping 383
1 Command Purpose 383
2 Command Syntax 383
3 Command Mode 384
4 Default 384
5 Usage 384
6 Examples 384
7 Related Commands 384
19.55 debug aaa 384
1 Command Purpose 384
2 Command Syntax 385
3 Command Mode 385
4 Default 385
5 Usage 385

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 386
7 Related Commands 386
19.56 exec-timeout 386
1 Command Purpose 386
2 Command Syntax 386
3 Command Mode 386
4 Default 386
5 Usage 386
6 Examples 386
7 Related Commands 387
19.57 login 387
1 Command Purpose 387
2 Command Syntax 387
3 Command Mode 387
4 Default 387
5 Usage 387
6 Examples 388
7 Related Commands 388
19.58 privilege level 388
1 Command Purpose 388
2 Command Syntax 388
3 Command Mode 389
4 Default 389
5 Usage 389
6 Examples 389
7 Related Commands 389
19.59 line-password 389
1 Command Purpose 389
2 Command Syntax 389
3 Command Mode 390
4 Default 390
5 Usage 390

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 390
7 Related Commands 391
19.60 stopbits 391
1 Command Purpose 391
2 Command Syntax 391
3 Command Mode 391
4 Default 391
5 Usage 391
6 Examples 391
7 Related Commands 392
19.61 databits 392
1 Command Purpose 392
2 Command Syntax 392
3 Command Mode 392
4 Default 392
5 Usage 392
6 Examples 393
7 Related Commands 393
19.62 parity 393
1 Command Purpose 393
2 Command Syntax 393
3 Command Mode 393
4 Default 393
5 Usage 393
6 Examples 394
7 Related Commands 394
19.63 speed 394
1 Command Purpose 394
2 Command Syntax 394
3 Command Mode 394
4 Default 394
5 Usage 395

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 395
7 Related Commands 395
19.64 authorization exec 395
1 Command Purpose 395
2 Command Syntax 395
3 Command Mode 396
4 Default 396
5 Usage 396
6 Examples 396
7 Related Commands 396
19.65 accounting exec 397
1 Command Purpose 397
2 Command Syntax 397
3 Command Mode 397
4 Default 397
5 Usage 397
6 Examples 397
7 Related Commands 398
19.66 accounting commands 398
1 Command Purpose 398
2 Command Syntax 398
3 Command Mode 398
4 Default 398
5 Usage 398
6 Examples 398
7 Related Commands 399
19.67 end 399
1 Command Purpose 399
2 Command Syntax 399
3 Command Mode 399
4 Default 399
5 Usage 399

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 399
7 Related Commands 400
19.68 ip access-class 400
1 Command Purpose 400
2 Command Syntax 400
3 Command Mode 400
4 Default 400
5 Usage 400
6 Examples 400
7 Related Commands 401
20 SFLOW Commands 402
20.1 sflow enable 402
1 Command Purpose 402
2 Command Syntax 402
3 Command Mode 402
4 Default 402
5 Usage 402
6 Examples 402
7 Related Commands 402
20.2 sflow agent 403
1 Command Purpose 403
2 Command Syntax 403
3 Command Mode 403
4 Default 403
5 Usage 403
6 Examples 403
7 Related Commands 404
20.3 sflow collector 404
1 Command Purpose 404
2 Command Syntax 404
3 Command Mode 404
4 Default 404

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage 404
6 Examples 405
7 Related Commands 405
20.4 sflow counter interval 405
1 Command Purpose 405
2 Command Syntax 405
3 Command Mode 405
4 Default 405
5 Usage 405
6 Examples 406
7 Related Commands 406
20.5 sflow counter-sampling enable 406
1 Command Purpose 406
2 Command Syntax 406
3 Command Mode 406
4 Default 406
5 Usage 407
6 Examples 407
7 Related Commands 407
20.6 sflow flow-sampling rate 407
1 Command Purpose 407
2 Command Syntax 407
3 Command Mode 408
4 Default 408
5 Usage 408
6 Examples 408
7 Related Commands 408
20.7 sflow flow-sampling enable 409
1 Command Purpose 409
2 Command Syntax 409
3 Command Mode 409
4 Default 409

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage 409
6 Examples 409
7 Related Commands 410
20.8 debug sflow 410
1 Command Purpose 410
2 Command Syntax 410
3 Command Mode 410
4 Default 410
5 Usage 410
6 Examples 410
7 Related Commands 411
20.9 show sflow 411
1 Command Purpose 411
2 Command Syntax 411
3 Command Mode 411
4 Default 411
5 Usage 411
6 Examples 412
7 Related Commands 412
21 GLOBAL Commands 412
21.1 show debugging 413
1 Command Purpose 413
2 Command Syntax 413
3 Command Mode 413
4 Default 413
5 Usage 413
6 Examples 413
7 Related Commands 414
21.2 no debug all 414
1 Command Purpose 414
2 Command Syntax 414
3 Command Mode 414

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default 414
5 Usage 414
6 Examples 414
7 Related Commands 415
21.3 show history 415
1 Command Purpose 415
2 Command Syntax 415
3 Command Mode 415
4 Default 415
5 Usage 415
6 Examples 415
7 Related Commands 415
21.4 show running-config 416
1 Command Purpose 416
2 Command Syntax 416
3 Command Mode 416
4 Default 416
5 Usage 416
6 Examples 416
7 Related Commands 418
21.5 md5sum 418
1 Command Purpose 418
2 Command Syntax 418
3 Command Mode 418
4 Default 418
5 Usage 418
6 Examples 418
7 Related Commands 418
22 MANAGEMENT Commands 418
22.1 show diagnostic-information 418
1 Command Purpose 419
2 Command Syntax 419

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode 419
4 Default 419
5 Usage 419
6 Examples 419
7 Related Commands 419
22.2 show services 419
1 Command Purpose 419
2 Command Syntax 419
3 Command Mode 419
4 Default 419
5 Usage 419
6 Examples 419
7 Related Commands 419
22.3 show services rpc-api 419
1 Command Purpose 1
2 Command Syntax 1
3 Command Mode 1
4 Default 1
5 Usage 1
6 Examples 1
7 Related Commands 1
22.4 hostname 1
1 Command Purpose 1
2 Command Syntax 1
3 Command Mode 423
4 Default 423
5 Usage 423
6 Examples 423
7 Related Commands 423
22.5 format 423
1 Command Purpose 423
2 Command Syntax 424

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode 424
4 Default 424
5 Usage 424
6 Examples 424
7 Related Commands 424
22.6 umount udisk: 424
1 Command Purpose 425
2 Command Syntax 425
3 Command Mode 425
4 Default 425
5 Usage 425
6 Examples 425
7 Related Commands 425
22.7 reset factory-config 425
1 Command Purpose 425
2 Command Syntax 426
3 Command Mode 426
4 Default 426
5 Usage 426
6 Examples 426
7 Related Commands 426
22.8 management ip address dhcp 426
1 Command Purpose 426
2 Command Syntax 426
3 Command Mode 427
4 Default 427
5 Usage 427
6 Examples 427
7 Related Commands 427
22.9 management ip address 427
1 Command Purpose 427
2 Command Syntax 428

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode 428
4 Default 428
5 Usage 428
6 Examples 428
7 Related Commands 428
22.10 management ipv6 address 429
1 Command Purpose 429
2 Command Syntax 429
3 Command Mode 429
4 Default 429
5 Usage 429
6 Examples 429
7 Related Commands 429
22.11 management route gateway 429
1 Command Purpose 429
2 Command Syntax 430
3 Command Mode 430
4 Default 430
5 Usage 430
6 Examples 430
7 Related Commands 431
22.12 management ipv6 route gateway 431
1 Command Purpose 431
2 Command Syntax 431
3 Command Mode 431
4 Default 431
5 Usage 431
6 Examples 431
7 Related Commands 432
22.13 service telnet enable 432
1 Command Purpose 432
2 Command Syntax 432

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode 432
4 Default 432
5 Usage 432
6 Examples 433
7 Related Commands 433
22.14 service http 433
1 Command Purpose 433
2 Command Syntax 433
3 Command Mode 433
4 Default 433
5 Usage 433
6 Examples 434
7 Related Commands 434
22.15 service http port 434
1 Command Purpose 434
2 Command Syntax 434
3 Command Mode 435
4 Default 435
5 Usage 435
6 Examples 435
7 Related Commands 435
22.16 service https 435
1 Command Purpose 435
2 Command Syntax 435
3 Command Mode 436
4 Default 436
5 Usage 436
6 Examples 436
7 Related Commands 436
22.17 service https port 436
1 Command Purpose 437
2 Command Syntax 437

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode 437
4 Default 437
5 Usage 437
6 Examples 437
7 Related Commands 437
22.18 service rpc-api enable 438
1 Command Purpose 438
2 Command Syntax 438
3 Command Mode 438
4 Default 438
5 Usage 438
6 Examples 439
7 Related Commands 439
22.19 service rpc-api auth-mode 439
1 Command Purpose 439
2 Command Syntax 439
3 Command Mode 439
4 Default 439
5 Usage 439
6 Examples 440
7 Related Commands 440
22.20 certificate load pem-cert 440
1 Command Purpose 440
2 Command Syntax 440
3 Command Mode 440
4 Default 441
5 Usage 441
6 Examples 441
7 Related Commands 441
22.21 statistics unit 441
1 Command Purpose 441
2 Command Syntax 441

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode 442
4 Default 442
5 Usage 442
6 Examples 442
7 Related Commands 442

23 SYSTEM CONFIGURATION Commands 442

23.1 disable 442
1 Command Purpose 442
2 Command Syntax 443
3 Command Mode 443
4 Default 443
5 Usage 443
6 Examples 443
7 Related Commands 443

23.2 enable 443
1 Command Purpose 443
2 Command Syntax 444
3 Command Mode 444
4 Default 444
5 Usage 444
6 Examples 444
7 Related Commands 445

23.3 logout 445
1 Command Purpose 445
2 Command Syntax 445
3 Command Mode 445
4 Default 445
5 Usage 445
6 Examples 445
7 Related Commands 445

23.4 reboot 445
1 Command Purpose 446

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax 446
3 Command Mode 446
4 Default 446
5 Usage 446
6 Examples 446
7 Related Commands 446
23.5 show file system 446
1 Command Purpose 446
2 Command Syntax 447
3 Command Mode 447
4 Default 447
5 Usage 447
6 Examples 447
7 Related Commands 447
23.6 show management ip address 447
1 Command Purpose 447
2 Command Syntax 447
3 Command Mode 447
4 Default 447
5 Usage 447
6 Examples 448
7 Related Commands 448
23.7 show startup-config 448
1 Command Purpose 448
2 Command Syntax 448
3 Command Mode 448
4 Default 448
5 Usage 449
6 Examples 449
7 Related Commands 451
23.8 write 451
1 Command Purpose 451

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax 451
3 Command Mode 451
4 Default 451
5 Usage 451
6 Examples 452
7 Related Commands 452
23.9 boot system flash 452
1 Command Purpose 452
2 Command Syntax 452
3 Command Mode 452
4 Default 452
5 Usage 452
6 Examples 452
7 Related Commands 452
23.10 boot system tftp: 452
1 Command Purpose 452
2 Command Syntax 452
3 Command Mode 452
4 Default 452
5 Usage 452
6 Examples 452
7 Related Commands 452
23.11 show boot 452
1 Command Purpose 452
2 Command Syntax 452
3 Command Mode 452
4 Default 452
5 Usage 452
6 Examples 452
7 Related Commands 455
23.12 show memory 455
1 Command Purpose 455

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax 456
3 Command Mode 456
4 Default 456
5 Usage 456
6 Examples 456
7 Related Commands 457
23.13 show memory summary 457
1 Command Purpose 457
2 Command Syntax 457
3 Command Mode 457
4 Default 457
5 Usage 457
6 Examples 457
7 Related Commands 457
23.14 show cpu utilization 457
1 Command Purpose 457
2 Command Syntax 457
3 Command Mode 457
4 Default 457
5 Usage 457
6 Examples 457
7 Related Commands 457
23.15 terminal length 457
1 Command Purpose 457
2 Command Syntax 457
3 Command Mode 457
4 Default 457
5 Usage 457
6 Examples 457
7 Related Commands 457
23.16 terminal monitor 457
1 Command Purpose 457

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax 457
3 Command Mode 457
4 Default 457
5 Usage 457
6 Examples 457
7 Related Commands 457
23.17 cd 457
1 Command Purpose 457
2 Command Syntax 457
3 Command Mode 462
4 Default 462
5 Usage 462
6 Examples 462
7 Related Commands 462
23.18 mkdir 462
1 Command Purpose 463
2 Command Syntax 463
3 Command Mode 463
4 Default 463
5 Usage 463
6 Examples 463
7 Related Commands 463
23.19 rmdir 463
1 Command Purpose 463
2 Command Syntax 463
3 Command Mode 463
4 Default 463
5 Usage 463
6 Examples 463
7 Related Commands 464
23.20 pwd 464
1 Command Purpose 465

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax 465
3 Command Mode 465
4 Default 465
5 Usage 465
6 Examples 465
7 Related Commands 465
23.21 ls 465
1 Command Purpose 465
2 Command Syntax 465
3 Command Mode 466
4 Default 466
5 Usage 466
6 Examples 466
7 Related Commands 467
23.22 copy running-config 467
1 Command Purpose 467
2 Command Syntax 467
3 Command Mode 467
4 Default 467
5 Usage 468
6 Examples 468
7 Related Commands 468
23.23 copy startup-config 468
1 Command Purpose 468
2 Command Syntax 468
3 Command Mode 468
4 Default 468
5 Usage 468
6 Examples 468
7 Related Commands 469
23.24 copy mgmt-if 469
1 Command Purpose 469

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax 469
3 Command Mode 469
4 Default 470
5 Usage 470
6 Examples 470
7 Related Commands 470
23.25 copy 470
1 Command Purpose 470
2 Command Syntax 470
3 Command Mode 470
4 Default 470
5 Usage 470
6 Examples 470
7 Related Commands 470
23.26 more 470
1 Command Purpose 471
2 Command Syntax 471
3 Command Mode 471
4 Default 472
5 Usage 472
6 Examples 472
7 Related Commands 472
23.27 delete 472
1 Command Purpose 472
2 Command Syntax 472
3 Command Mode 472
4 Default 473
5 Usage 473
6 Examples 473
7 Related Commands 473
23.28 rename 473
1 Command Purpose 473

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax 473
3 Command Mode 473
4 Default 473
5 Usage 473
6 Examples 473
7 Related Commands 474
23.29 source 474
1 Command Purpose 474
2 Command Syntax 474
3 Command Mode 474
4 Default 474
5 Usage 475
6 Examples 475
7 Related Commands 475
23.30 system min-frame check 475
1 Command Purpose 475
2 Command Syntax 475
3 Command Mode 476
4 Default 476
5 Usage 476
6 Examples 476
7 Related Commands 476
23.31 banner 476
1 Command Purpose 476
2 Command Syntax 476
3 Command Mode 477
4 Default 477
5 Usage 477
6 Examples 477
7 Related Commands 477
23.32 do 477
1 Command Purpose 477

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax 477
3 Command Mode 478
4 Default 478
5 Usage 478
6 Examples 478
7 Related Commands 478

24 DEVICE Commands 478

24.1 show version 478
1 Command Purpose 478
2 Command Syntax 479
3 Command Mode 479
4 Default 479
5 Usage 479
6 Examples 479
7 Related Commands 480

24.2 show stm prefer 480
1 Command Purpose 480
2 Command Syntax 480
3 Command Mode 480
4 Default 480
5 Usage 480
6 Examples 481
7 Related Commands 481

24.3 show transceiver 481
1 Command Purpose 481
2 Command Syntax 481
3 Command Mode 481
4 Default 481
5 Usage 481
6 Examples 481
7 Related Commands 483

24.4 show system summary 483

Copyright © 2023 Garland Technology, LLC. All rights reserved.

1 Command Purpose 483
2 Command Syntax 483
3 Command Mode 483
4 Default 483
5 Usage 483
6 Examples 483
7 Related Commands 483
24.5 show reboot-info 483
1 Command Purpose 483
2 Command Syntax 483
3 Command Mode 483
4 Default 483
5 Usage 483
6 Examples 483
7 Related Commands 485
24.6 clear reboot-info 485
1 Command Purpose 485
2 Command Syntax 485
3 Command Mode 485
4 Default 485
5 Usage 485
6 Examples 485
7 Related Commands 485
24.7 set device id-led 485
1 Command Purpose 485
2 Command Syntax 487
3 Command Mode 487
4 Default 487
5 Usage 487
6 Examples 487
7 Related Commands 487
24.8 show device id-led 487

Copyright © 2023 Garland Technology, LLC. All rights reserved.

1 Command Purpose 487
2 Command Syntax 487
3 Command Mode 487
4 Default 487
5 Usage 487
6 Examples 487
7 Related Commands 487
24.9 show schedule reboot 487
1 Command Purpose 487
2 Command Syntax 487
3 Command Mode 487
4 Default 487
5 Usage 487
6 Examples 487
7 Related Commands 487
24.10 stm prefer 487
1 Command Purpose 487
2 Command Syntax 487
3 Command Mode 487
4 Default 487
5 Usage 487
6 Examples 487
7 Related Commands 487
24.11 temperature 487
1 Command Purpose 487
2 Command Syntax 487
3 Command Mode 487
4 Default 487
5 Usage 491
6 Examples 491
7 Related Commands 491
24.12 clock set datetime 491

Copyright © 2023 Garland Technology, LLC. All rights reserved.

1 Command Purpose 491
2 Command Syntax 492
3 Command Mode 492
4 Default 492
5 Usage 492
6 Examples 492
7 Related Commands 492
24.13 clock set timezone 493
1 Command Purpose 493
2 Command Syntax 493
3 Command Mode 493
4 Default 493
5 Usage 493
6 Examples 493
7 Related Commands 494
24.14 update bootrom 494
1 Command Purpose 494
2 Command Syntax 494
3 Command Mode 494
4 Default 494
5 Usage 494
6 Examples 494
7 Related Commands 495
24.15 schedule reboot at 495
1 Command Purpose 495
2 Command Syntax 495
3 Command Mode 495
4 Default 496
5 Usage 496
6 Examples 496
7 Related Commands 496
24.16 schedule reboot delay 496

Copyright © 2023 Garland Technology, LLC. All rights reserved.

1 Command Purpose 496
2 Command Syntax 496
3 Command Mode 496
4 Default 496
5 Usage 497
6 Examples 497
7 Related Commands 497
24.17 telnet 497
1 Command Purpose 497
2 Command Syntax 497
3 Command Mode 497
4 Default 497
5 Usage 497
6 Examples 497
7 Related Commands 498
25 Hash load-banlance Commands 498
25.1 hash field 498
1 Command Purpose 499
2 Command Syntax 499
3 Command Mode 499
4 Default 499
5 Usage 499
6 Examples 500
7 Related Commands 500
25.2 l2 500
1 Command Purpose 500
2 Command Syntax 500
3 Command Mode 501
4 Default 501
5 Usage 501
6 Examples 501
7 Related Commands 501

Copyright © 2023 Garland Technology, LLC. All rights reserved.

25.3 ip 501
1 Command Purpose 501
2 Command Syntax 501
3 Command Mode 502
4 Default 502
5 Usage 502
6 Examples 502
7 Related Commands 502
25.4 ipv6 502
1 Command Purpose 502
2 Command Syntax 503
3 Command Mode 503
4 Default 503
5 Usage 503
6 Examples 504
7 Related Commands 504
25.5 vxlan 504
1 Command Purpose 504
2 Command Syntax 504
3 Command Mode 505
4 Default 505
5 Usage 505
6 Examples 506
7 Related Commands 506
25.6 nvgre 506
1 Command Purpose 506
2 Command Syntax 506
3 Command Mode 507
4 Default 507
5 Usage 508
6 Examples 508
7 Related Commands 508

Copyright © 2023 Garland Technology, LLC. All rights reserved.

25.7 mpls 508
1 Command Purpose 508
2 Command Syntax 508
3 Command Mode 509
4 Default 509
5 Usage 509
6 Examples 509
7 Related Commands 509
25.8 udf 509
1 Command Purpose 510
2 Command Syntax 510
3 Command Mode 510
4 Default 510
5 Usage 510
6 Examples 510
7 Related Commands 510
25.9 disable control 511
1 Command Purpose 511
2 Command Syntax 511
3 Command Mode 511
4 Default 511
5 Usage 511
6 Examples 511
7 Related Commands 512
25.10 ipv6 adress compress mode 512
1 Command Purpose 512
2 Command Syntax 512
3 Command Mode 512
4 Default 512
5 Usage 512
6 Examples 513
7 Related Commands 513

Copyright © 2023 Garland Technology, LLC. All rights reserved.

25.11 hash arithmetic 513
1 Command Purpose 513
2 Command Syntax 513
3 Command Mode 513
4 Default 513
5 Usage 513
6 Examples 514
7 Related Commands 514
25.12 hash symmetry 514
1 Command Purpose 514
2 Command Syntax 514
3 Command Mode 514
4 Default 514
5 Usage 514
6 Examples 514
7 Related Commands 515
25.13 description 515
1 Command Purpose 515
2 Command Syntax 515
3 Command Mode 515
4 Default 515
5 Usage 515
6 Examples 515
7 Related Commands 516
25.14 show hash-field 516
1 Command Purpose 516
2 Command Syntax 516
3 Command Mode 517
4 Default 517
5 Usage 517
6 Examples 517
7 Related Commands 517

Copyright © 2023 Garland Technology, LLC. All rights reserved.

25.15 hash value 517
1 Command Purpose 517
2 Command Syntax 518
3 Command Mode 518
4 Default 518
5 Usage 518
6 Examples 518
7 Related Commands 519
25.16 port-channel select 519
1 Command Purpose 519
2 Command Syntax 519
3 Command Mode 519
4 Default 519
5 Usage 519
6 Examples 519
7 Related Commands 520
25.17 description 520
1 Command Purpose 520
2 Command Syntax 520
3 Command Mode 520
4 Default 520
5 Usage 521
6 Examples 521
7 Related Commands 521
25.18 show hash-value 521
1 Command Purpose 521
2 Command Syntax 521
3 Command Mode 521
4 Default 521
5 Usage 521
6 Examples 521
7 Related Commands 521

Copyright © 2023 Garland Technology, LLC. All rights reserved.

25.19 hash-value global 521
1 Command Purpose 521
2 Command Syntax 521
3 Command Mode 521
4 Default 521
5 Usage 521
6 Examples 521
7 Related Commands 521
25.20 port-channel select 521
1 Command Purpose 521
2 Command Syntax 521
3 Command Mode 523
4 Default 523
5 Usage 523
6 Examples 523
7 Related Commands 524
25.21 show hash-value global 524
1 Command Purpose 524
2 Command Syntax 524
3 Command Mode 524
4 Default 524
5 Usage 524
6 Examples 524
7 Related Commands 525
25.22 hash value applied to interface 525
1 Command Purpose 525
2 Command Syntax 525
3 Command Mode 525
4 Default 525
5 Usage 525
6 Examples 526
7 Related Commands 526

Copyright © 2023 Garland Technology, LLC. All rights reserved.

25.23 show hash-value interface-applied 526
1 Command Purpose 526
2 Command Syntax 526
3 Command Mode 526
4 Default 526
5 Usage 526
6 Examples 526
7 Related Commands 527
26 IPFIX Commands 527
26.1 ipfix enable 528
1 Command Purpose 528
2 Command Syntax 528
3 Command Mode 528
4 Default 528
5 Usage 528
6 Examples 528
7 Related Commands 528
26.2 ipfix recorder 528
1 Command Purpose 528
2 Command Syntax 528
3 Command Mode 529
4 Default 529
5 Usage 529
6 Examples 529
7 Related Commands 530
26.3 description 530
1 Command Purpose 530
2 Command Syntax 530
3 Command Mode 530
4 Default 530
5 Usage 530
6 Examples 530

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 531
26.4 match ipv4 531
1 Command Purpose 531
2 Command Syntax 531
3 Command Mode 532
4 Default 532
5 Usage 532
6 Examples 532
7 Related Commands 532
26.5 match ipv6 532
1 Command Purpose 532
2 Command Syntax 533
3 Command Mode 533
4 Default 533
5 Usage 533
6 Examples 533
7 Related Commands 534
26.6 match mac 534
1 Command Purpose 534
2 Command Syntax 534
3 Command Mode 534
4 Default 534
5 Usage 534
6 Examples 534
7 Related Commands 535
26.7 match transport 535
1 Command Purpose 535
2 Command Syntax 535
3 Command Mode 536
4 Default 536
5 Usage 536
6 Examples 536

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 536
26.8 match vlan 536
1 Command Purpose 536
2 Command Syntax 536
3 Command Mode 537
4 Default 537
5 Usage 537
6 Examples 537
7 Related Commands 537
26.9 match cos 537
1 Command Purpose 537
2 Command Syntax 538
3 Command Mode 538
4 Default 538
5 Usage 538
6 Examples 538
7 Related Commands 538
26.10 match interface (input | output) 538
1 Command Purpose 538
2 Command Syntax 539
3 Command Mode 539
4 Default 539
5 Usage 539
6 Examples 539
7 Related Commands 539
26.11 match interface input 540
1 Command Purpose 540
2 Command Syntax 540
3 Command Mode 540
4 Default 540
5 Usage 540
6 Examples 540

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 540
26.12 match vxlan-vni 540
1 Command Purpose 540
2 Command Syntax 541
3 Command Mode 541
4 Default 541
5 Usage 541
6 Examples 541
7 Related Commands 541
26.13 match nvgre-key 541
1 Command Purpose 541
2 Command Syntax 542
3 Command Mode 542
4 Default 542
5 Usage 542
6 Examples 542
7 Related Commands 542
26.14 match transport tcp flags 543
1 Command Purpose 543
2 Command Syntax 543
3 Command Mode 543
4 Default 544
5 Usage 544
6 Examples 544
7 Related Commands 544
26.15 match packet (drop | non-drop) 544
1 Command Purpose 544
2 Command Syntax 544
3 Command Mode 544
4 Default 544
5 Usage 544
6 Examples 544

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 545
26.16 collect counter 545
1 Command Purpose 545
2 Command Syntax 545
3 Command Mode 546
4 Default 546
5 Usage 546
6 Examples 546
7 Related Commands 546
26.17 collect flow 546
1 Command Purpose 546
2 Command Syntax 546
3 Command Mode 547
4 Default 547
5 Usage 547
6 Examples 547
7 Related Commands 547
26.18 collect ttl 547
1 Command Purpose 547
2 Command Syntax 548
3 Command Mode 548
4 Default 548
5 Usage 548
6 Examples 548
7 Related Commands 549
26.19 collect timestamp 549
1 Command Purpose 549
2 Command Syntax 549
3 Command Mode 549
4 Default 549
5 Usage 549
6 Examples 549

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 550
26.20 ipfix exporter 550
1 Command Purpose 550
2 Command Syntax 550
3 Command Mode 550
4 Default 550
5 Usage 550
6 Examples 551
7 Related Commands 551
26.21 description 551
1 Command Purpose 551
2 Command Syntax 551
3 Command Mode 552
4 Default 552
5 Usage 552
6 Examples 552
7 Related Commands 552
26.22 destination 552
1 Command Purpose 552
2 Command Syntax 552
3 Command Mode 553
4 Default 553
5 Usage 553
6 Examples 553
7 Related Commands 553
26.23 dscp 553
1 Command Purpose 553
2 Command Syntax 553
3 Command Mode 553
4 Default 553
5 Usage 553
6 Examples 553

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 554
26.24 domain-id 554
1 Command Purpose 554
2 Command Syntax 554
3 Command Mode 555
4 Default 555
5 Usage 555
6 Examples 555
7 Related Commands 555
26.25 template data timeout 555
1 Command Purpose 555
2 Command Syntax 555
3 Command Mode 556
4 Default 556
5 Usage 556
6 Examples 556
7 Related Commands 556
26.26 flow data timeout 556
1 Command Purpose 556
2 Command Syntax 556
3 Command Mode 557
4 Default 557
5 Usage 557
6 Examples 557
7 Related Commands 557
26.27 transport protocol 557
1 Command Purpose 557
2 Command Syntax 557
3 Command Mode 558
4 Default 558
5 Usage 558
6 Examples 558

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 558
26.28 ttl 558
1 Command Purpose 558
2 Command Syntax 558
3 Command Mode 559
4 Default 559
5 Usage 559
6 Examples 559
7 Related Commands 559
26.29 event flow 559
1 Command Purpose 559
2 Command Syntax 559
3 Command Mode 560
4 Default 560
5 Usage 560
6 Examples 560
7 Related Commands 560
26.30 flow data flush threshold length 560
1 Command Purpose 560
2 Command Syntax 560
3 Command Mode 561
4 Default 561
5 Usage 561
6 Examples 561
7 Related Commands 561
26.31 flow data flush threshold timer 561
1 Command Purpose 561
2 Command Syntax 561
3 Command Mode 562
4 Default 562
5 Usage 562
6 Examples 562

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 562
26.32 flow data flush threshold count 562
1 Command Purpose 562
2 Command Syntax 562
3 Command Mode 563
4 Default 563
5 Usage 563
6 Examples 563
7 Related Commands 563
26.33 ipfix sampler 563
1 Command Purpose 563
2 Command Syntax 563
3 Command Mode 564
4 Default 564
5 Usage 564
6 Examples 564
7 Related Commands 564
26.34 description 564
1 Command Purpose 565
2 Command Syntax 565
3 Command Mode 565
4 Default 565
5 Usage 565
6 Examples 565
7 Related Commands 565
26.35 1 out-of 565
1 Command Purpose 565
2 Command Syntax 566
3 Command Mode 566
4 Default 566
5 Usage 566
6 Examples 566

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 566
26.36 mode 566
1 Command Purpose 567
2 Command Syntax 567
3 Command Mode 567
4 Default 567
5 Usage 567
6 Examples 567
7 Related Commands 567
26.37 mode flow 567
1 Command Purpose 567
2 Command Syntax 568
3 Command Mode 568
4 Default 568
5 Usage 568
6 Examples 568
7 Related Commands 568
26.38 ipfix monitor 569
1 Command Purpose 569
2 Command Syntax 569
3 Command Mode 569
4 Default 569
5 Usage 569
6 Examples 569
7 Related Commands 569
26.39 description 570
1 Command Purpose 570
2 Command Syntax 570
3 Command Mode 570
4 Default 570
5 Usage 570
6 Examples 570

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 571
26.40 recorder 571
1 Command Purpose 571
2 Command Syntax 571
3 Command Mode 571
4 Default 571
5 Usage 571
6 Examples 571
7 Related Commands 572
26.41 exporter 572
1 Command Purpose 572
2 Command Syntax 572
3 Command Mode 572
4 Default 572
5 Usage 572
6 Examples 572
7 Related Commands 572
26.42 ipfix monitor 572
1 Command Purpose 572
2 Command Syntax 572
3 Command Mode 573
4 Default 573
5 Usage 573
6 Examples 573
7 Related Commands 574
26.43 ipfix global 574
1 Command Purpose 574
2 Command Syntax 574
3 Command Mode 574
4 Default 574
5 Usage 574
6 Examples 574

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 574
26.44 flow aging 575
1 Command Purpose 575
2 Command Syntax 575
3 Command Mode 575
4 Default 575
5 Usage 575
6 Examples 575
7 Related Commands 576
26.45 flow export 576
1 Command Purpose 576
2 Command Syntax 576
3 Command Mode 576
4 Default 576
5 Usage 576
6 Examples 576
7 Related Commands 576
26.46 show ipfix global 576
1 Command Purpose 576
2 Command Syntax 577
3 Command Mode 577
4 Default 577
5 Usage 577
6 Examples 577
7 Related Commands 577
26.47 show ipfix recorder 578
1 Command Purpose 578
2 Command Syntax 578
3 Command Mode 578
4 Default 578
5 Usage 578
6 Examples 578

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 579
26.48 show ipfix exporter 579
1 Command Purpose 579
2 Command Syntax 579
3 Command Mode 579
4 Default 579
5 Usage 579
6 Examples 579
7 Related Commands 580
26.49 show ipfix cache 580
1 Command Purpose 580
2 Command Syntax 580
3 Command Mode 580
4 Default 580
5 Usage 580
6 Examples 580
7 Related Commands 581
26.50 show ipfix monitor 581
1 Command Purpose 581
2 Command Syntax 581
3 Command Mode 581
4 Default 582
5 Usage 582
6 Examples 582
7 Related Commands 582
26.51 show ipfix sampler 582
1 Command Purpose 582
2 Command Syntax 582
3 Command Mode 582
4 Default 582
5 Usage 583
6 Examples 583

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands 583
26.52 clear ipfix cache monitor 583
1 Command Purpose 583
2 Command Syntax 583
3 Command Mode 583
4 Default 583
5 Usage 583
6 Examples 584
7 Related Commands 584
26.53 clear ipfix cache observe-point interface 584
1 Command Purpose 584
2 Command Syntax 584
3 Command Mode 584
4 Default 584
5 Usage 584
6 Examples 584
7 Related Commands 584
27 DIAG Commands 584
27.1 show interface queue discard 584
1 Command Purpose 584
2 Command Syntax 586
3 Command Mode 586
4 Default 586
5 Usage 586
6 Examples 586
7 Related Commands 587
27.2 diagnostic-information discard 587
1 Command Purpose 587
2 Command Syntax 587
3 Command Mode 588
4 Default 588
5 Usage 588

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples 588
7 Related Commands 588
27.3 show diagnostic-information 588
1 Command Purpose 588
2 Command Syntax 588
3 Command Mode 589
4 Default 589
5 Usage 589
6 Examples 589
7 Related Commands 589
28 De-duplicate Commands 590
28.1 de-duplicate global 590
1 Command Purpose 590
2 Command Syntax 590
3 Command Mode 590
4 Default 590
5 Usage 590
6 Examples 590
7 Related Commands 590
28.2 de-duplicate enable 591
1 Command Purpose 591
2 Command Syntax 591
3 Command Mode 591
4 Default 591
5 Usage 591
6 Examples 591
7 Related Commands 591
28.3 de-duplicate mode 591
1 Command Purpose 591
2 Command Syntax 591
3 Command Mode 592
4 Default 594

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage 594
6 Examples 594
7 Related Commands 594
28.4 de-duplicate times 595
1 Command Purpose 595
2 Command Syntax 595
3 Command Mode 595
4 Default 595
5 Usage 595
6 Examples 595
7 Related Commands 595
28.5 de-duplicate aging-time 595
1 Command Purpose 595
2 Command Syntax 596
3 Command Mode 596
4 Default 596
5 Usage 596
6 Examples 596
7 Related Commands 596
28.6 de-duplicate ignore 597
1 Command Purpose 597
2 Command Syntax 597
3 Command Mode 597
4 Default 597
5 Usage 597
6 Examples 597
7 Related Commands 598
28.7 show de-duplicate global 598
1 Command Purpose 598
2 Command Syntax 598
3 Command Mode 599
4 Default 599

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage 599
6 Examples 599
7 Related Commands 599
28.8 show de-duplicate stats 599
1 Command Purpose 599
2 Command Syntax 599
3 Command Mode 600
4 Default 600
5 Usage 600
6 Examples 600
7 Related Commands 600
29 DDOS Prevent Commands 600
29.1 ip intercept 600
1 Command Purpose 601
2 Command Syntax 601
3 Command Mode 602
4 Default 602
5 Usage 602
6 Examples 602
7 Related Commands 602
29.2 show ip-intercept config 602
1 Command Purpose 602
2 Command Syntax 602
3 Command Mode 603
4 Default 603
5 Usage 603
6 Examples 603
7 Related Commands 603
29.3 clear ip-intercept statistics 603
1 Command Purpose 603
2 Command Syntax 604
3 Command Mode 604

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default 604
5 Usage 604
6 Examples 604
7 Related Commands 604
29.4 show ip-intercept statistics 604
1 Command Purpose 604
2 Command Syntax 604
3 Command Mode 604
4 Default 604
5 Usage 604
6 Examples 604
7 Related Commands 605
30 LLDP Commands 605
30.1 lldp enable 605
1 Command Purpose 605
2 Command Syntax 605
3 Command Mode 606
4 Default 606
5 Usage 606
6 Examples 606
7 Related Commands 606
30.2 lldp timer tx-interval 606
1 Command Purpose 606
2 Command Syntax 606
3 Command Mode 607
4 Default 607
5 Usage 607
6 Examples 607
7 Related Commands 607
30.3 lldp timer tx-hold 608
1 Command Purpose 608
2 Command Syntax 608

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode 608
4 Default 608
5 Usage 608
6 Examples 608
7 Related Commands 609
30.4 lldp timer tx-delay 609
1 Command Purpose 609
2 Command Syntax 609
3 Command Mode 609
4 Default 609
5 Usage 609
6 Examples 609
7 Related Commands 610
30.5 lldp timer reinit-delay 610
1 Command Purpose 610
2 Command Syntax 610
3 Command Mode 610
4 Default 610
5 Usage 610
6 Examples 610
7 Related Commands 610
30.6 lldp management ip 611
1 Command Purpose 611
2 Command Syntax 611
3 Command Mode 611
4 Default 611
5 Usage 611
6 Examples 611
7 Related Commands 612
30.7 lldp system-name 612
1 Command Purpose 612
2 Command Syntax 612

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode 612
4 Default 612
5 Usage 612
6 Examples 612
7 Related Commands 613
30.8 lldp system-description 613
1 Command Purpose 613
2 Command Syntax 613
3 Command Mode 614
4 Default 614
5 Usage 614
6 Examples 614
7 Related Commands 614
30.9 lldp enable 614
1 Command Purpose 614
2 Command Syntax 614
3 Command Mode 615
4 Default 615
5 Usage 615
6 Examples 615
7 Related Commands 615
30.10 lldp tlv basic 616
1 Command Purpose 616
2 Command Syntax 616
3 Command Mode 616
4 Default 616
5 Usage 616
6 Examples 616
7 Related Commands 617
30.11 lldp tlv med 617
1 Command Purpose 617
2 Command Syntax 617

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode 617
4 Default 618
5 Usage 618
6 Examples 618
7 Related Commands 618
30.12 lldp tlv 8023-org-specific 618
1 Command Purpose 618
2 Command Syntax 618
3 Command Mode 619
4 Default 619
5 Usage 619
6 Examples 619
7 Related Commands 619
30.13 show lldp local config 620
1 Command Purpose 620
2 Command Syntax 620
3 Command Mode 620
4 Default 620
5 Usage 620
6 Examples 620
7 Related Commands 621
30.14 show lldp local tlv-info 621
1 Command Purpose 621
2 Command Syntax 621
3 Command Mode 621
4 Default 621
5 Usage 621
6 Examples 622
7 Related Commands 622
30.15 show lldp neighbor 622
1 Command Purpose 622
2 Command Syntax 622

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode 623
4 Default 623
5 Usage 623
6 Examples 623
7 Related Commands 624
30.16 show lldp statistics 624
1 Command Purpose 624
2 Command Syntax 624
3 Command Mode 624
4 Default 625
5 Usage 625
6 Examples 625
7 Related Commands 625
30.17 clear lldp statistics 625
1 Command Purpose 625
2 Command Syntax 625
3 Command Mode 626
4 Default 626
5 Usage 626
6 Examples 626
7 Related Commands 626

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Revision History

Date	Version	Description
2019-11-12	R1.0	Initial Release
2020-03-09	R1.1	Update document for product upgrade
2020-06-05	R1.2	Update document for product upgrade
2020-08-12	R1.3	Update document for product upgrade
2020-11-12	R1.4	Update document for product upgrade
2021-02-19	R1.5	Update document for product upgrade
2021-09-10	R1.6	Update document for product upgrade
2022-03-24	R1.7	Update document for product upgrade
2022-06-20	R1.8	Update document for product upgrade
2022-10-31	V3.0.15	For product version V3.0.15

Copyright © 2023 Garland Technology, LLC. All rights reserved.

1 Preface

1.1 Declaration

This document updates at irregular intervals because of product upgrade or other reason.

This document is for your reference only.

1.2 Suggestion feedback

If you have any questions when using our product and reading this document, please contact us:

Email: support@centec.com

1.1 Audience

This document is for the following audiences:

- System maintenance engineers
- Debugging and testing engineers
- Network monitoring engineers
- Field maintenance engineers

1.2 Conventions

Table 1-1 Command syntax convention table

Syntax	Description
Italic type with capital letters	Use *italic type* with capital letters for the parameters of the commands. Parameters are the parts which need to replace with the actual value.
(x|y|…)	Select one among the choices.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

(x|y|…|)	Select one or none among the choices.
[x|y|…]	Select one or more among the choices. The choices can be selected repeatedly.
[x|y|…|]	Select one or more or none among the choices. The choices can be selected repeatedly.
{x|y|…}	Select one or more among the choices. The choices can be selected only once.
{x|y|…|}	Select one or more or none among the choices. The choices can be selected only once.
<x-y>	Select a number between x and y.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 INTERFACE Commands

2.1 interface range

1 Command Purpose

Use this command to enter interface range mode, include physical port, linkagg interface.

2 Command Syntax

interface range *KLINE*

Parameter	Parameter Description	Parameter Value
KLINE	Interface range, with "," or "-" to distinguish the interface range set.	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows how to enter interface range eth-0-1 to eth-0-24 and shutdown these 24 interfaces:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch(config)# interface range eth-0-1 - 24
Switch(config-if-range)# shutdown
```

The following example shows how to enter interface eth-0-8 and eth-0-10, and shutdown these 2 interfaces:

```
Switch(config)# interface range eth-0-8,eth-0-10
Switch(config-if-range)# shutdown
```

7 Related Commands

interface

2.2 interface

1 Command Purpose

Use this command to enter interface mode or create iloop interface.

2 Command Syntax

interface *IF_NAME*

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name. e.g.eth-0-1, agg1,iloop1.	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

The interface name can be a physical port name (i.e. eth-0-1), link-agg name (i.e. agg1) or iloop port name(i.e. iloop1).

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

This example shows how to enter physical port eth-0-1:

```
Switch(config)# interface eth-0-1
```

This example shows how to enter aggregation interface agg10:

```
Switch(config)# interface agg10
```

This example shows how to create iloop interface iloop1:

```
Switch(config)# interface iloop1
```

7 Related Commands

interface range

2.3 no interface

1 Command Purpose

Use this command to delete iloop interface.

2 Command Syntax

no interface *IF_ILOOP_NAME*

Parameter	Parameter Description	Parameter Value
IF_ILOOP_NAME	Specify the iloop interface name. e.g.iloop1.	-

3 Command Mode

Global Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

The interface name can only be a iloop port name(i.e. iloop1).

6 Examples

This example shows how to delete iloop interface iloop1:

```
Switch(config)# no interface iloop1
```

7 Related Commands

interface

2.4 shutdown

1 Command Purpose

Use this command to disable the interface manually. Use the no form of this command to enable the interface.

2 Command Syntax

shutdown

no shutdown

3 Command Mode

Interface Configuration

4 Default

No shutdown

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to enter physical port eth-0-1 and disable the interface:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# shutdown
```

The following example shows how to enter physical port eth-0-1 and enable the interface:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no shutdown
```

7 Related Commands

show interface status

2.5 description

1 Command Purpose

Use this command to set the description on the interface.

And use the no form of this command to delete the description.

2 Command Syntax

description *LINE*

no description

Parameter	Parameter Description	Parameter Value
LINE	Interface description	-

3 Command Mode

Interface Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to set the description on the interface eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# description TenGigabitEthernet
```

The following example shows how to remove the description on the interface eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no description
```

7 Related Commands

show interface description

2.6 speed

1 Command Purpose

Use this command to set the interface speed. And use the no form of this command to restore the interface to its default speed value.

2 Command Syntax

speed (auto | 10 | 100 | 1000 | *2.5G* | *5G* | *10G* | *25G* | *40G* | *100G*)

no speed

Parameter	Parameter Description	Parameter Value
auto	Auto negotiation the speed of a port	-
10	Force the port speed to be 10Mb/s	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

100	Force the port speed to be 100Mb/s	-
1000	Force the port speed to be 1000Mb/s	-
2.5G	Force the port speed to be 2.5Gb/s	-
5G	Force the port speed to be 5Gb/s	-
10G	Force the port speed to be 10Gb/s	-
25G	Force the port speed to be 25Gb/s	-
40G	Force the port speed to be 40Gb/s	-
100G	Force the port speed to be 100Gb/s	-

3 Command Mode

Interface Configuration

4 Default

Auto

5 Usage

For different interface, some speed value can't be set.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to set the port speed to 1000Mb/s:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# speed 1000
```

The following example shows how to restore the port speed to default value:

```
Switch(config-if-eth-0-1)# no speed
```

7 Related Commands

show interface status

show interface

2.7 duplex

1 Command Purpose

Use this command to set the mode of operation for a port. And use the no form of this command set the mode of operation to default value.

2 Command Syntax

duplex (auto | full | half)

no duplex

Parameter	Parameter Description	Parameter Value
auto	Auto negotiation mode, the port should be automatically detected in full duplex or half duplex state according to the device it is connected to	-
full	Full duplex mode	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

half	Half duplex mode, can only be configured on ports of 10M or 100M	-

3 Command Mode

Interface Configuration

4 Default

Auto

5 Usage

Half mode is only supported on 10M/100M link.

6 Examples

The following example shows how to set interface eth-0-1 duplex mode to auto:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# duplex auto
```

The following example shows how to set interface eth-0-1 duplex mode to full:

```
Switch(config-if-eth-0-1)# duplex full
```

The following example shows how to set interface eth-0-1 duplex mode to default:

```
Switch(config-if-eth-0-1)# no duplex
```

7 Related Commands

show interface status

show interface

2.8 unidirectional

1 Command Purpose

Use this command to set unidirectional function for a port.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

unidirectional (enable | disable | rx-only)

Parameter	Parameter Description	Parameter Value
enable	Enable unidirectional	-
disable	Disable unidirectional	-
rx-only	Receive only	-

3 Command Mode

Interface Configuration

4 Default

Disable

5 Usage

None

6 Examples

The following example shows how enable unidirectional on interface eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# unidirectional enable
```

The following example shows how disable unidirectional on interface eth-0-1:

```
Switch(config-if-eth-0-1)# unidirectional disable
```

7 Related Commands

show interface status

show interface

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2.9 fec

1 Command Purpose

Use the command to set fec function for a port. And use the no form of this command set fec function to default value.

2 Command Syntax

fec (enable | disable | none | baser | rs)

no fec

Parameter	Parameter Description	Parameter Value
enable	Enable fec	-
disable	Disable fec	-
none	Set fec none	-
baser	Set fec baser	-
rs	Set fec rs	-

3 Command Mode

Interface Configuration

4 Default

None

5 Usage

"enable" and "disable" mode can't be configured in V550 and V530.

6 Examples

The following example shows how to set fec none for a port:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# fec none
```

7 Related Commands

show interface status

2.10 static-channel-group

1 Command Purpose

Use this command to add a port to a static channel group. And use the no form of this command to remove this port from this static channel group.

2 Command Syntax

static-channel-group *AGG_GID*

no static-channel-group

Parameter	Parameter Description	Parameter Value
AGG_GID	Channel group ID	range is <1-55>

3 Command Mode

Interface Configuration

4 Default

None

5 Usage

The valid range of channel group id is limited by hardware and is different for each model.

6 Examples

The following example shows how to add interface eth-0-1 to static channel group 2:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# static-channel-group 2
```

The following example shows how to remove interface eth-0-1 from static channel group 2:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no static-channel-group
```

7 Related Commands

show interface

2.11 media-type

1 Command Purpose

Use this command to set media type of combo port. And use the no form of this command to set media type to default.

2 Command Syntax

media-type (auto | rj45 | sfp)

no media-type

Parameter	Parameter Description	Parameter Value
auto	Automatically select media type of combo port	-
rj45	Set media type as rj45	-
sfp	Set media type as sfp	-

3 Command Mode

Interface Configuration

4 Default

Auto

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

Different media type of the combo port cannot be active at the same time.

6 Examples

The following example shows how to set media type of combo port:

```
Switch(config-if-eth-0-1) media-type auto
```

The following example shows how to set media type of combo port to default:

```
Switch(config-if-eth-0-1)# no media-type
```

7 Related Commands

show interface

2.12 show management interface

1 Command Purpose

Use this command to display the status and configurations of management interface.

2 Command Syntax

show management interface

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to displays the states, configurations and statistics on management interface:

```
Switch# show management interface

Management Interface current state: UP
Description:
Link encap: Ethernet       HWaddr: 00:1E:08:0B:E6:C1
net addr: 10.10.39.104     Mask: 255.255.254.0
Bcast: 10.10.39.255        MTU: 1500
Speed: 1000Mb/s            Duplex: Full
Auto-negotiation: Enable
Received:           1030834 Packets,        79596824 Bytes (75.9 MiB)
Transmitted:         110758 Packets,        16209745 Bytes (15.4 MiB)
```

7 Related Commands

show interface status

2.13 show interface

1 Command Purpose

Use this command to display the configurations and statistics on all interfaces or one interface.

2 Command Syntax

show interface (*IF_NAME* |)

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name to show	-

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

If the parameter “IF_NAME” is not specified, the command indicates that all interfaces on this device should be displayed; otherwise only the specified interface should be displayed.

6 Examples

The following example shows how to display the configurations and statistics of interface eth-0-1:

```
Switch# show interface eth-0-1

Interface eth-0-1
  Interface current state: DOWN
  Hardware is Port, address is 001e.080b.e6c2
  Bandwidth 1000000 kbits
  Index 1 , Metric 1
  Speed - auto ,  Duplex - auto ,  Metadata - Disable ,  Media type is UNKNOWN
  Link type is autonegotiation
  Admin input flow-control is off, output flow-control is off
  Oper input flow-control is off, output flow-control is off
  The Maximum Frame Size is 12800 bytes
    5 minute input rate 0 bits/sec, 0 packets/sec
    5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes
    Received 0 unicast, 0 broadcast, 0 multicast
    0 runts, 0 giants, 0 input errors, 0 CRC
    0 frame, 0 overrun, 0 pause input
    0 packets output, 0 bytes
    Transmitted 0 unicast, 0 broadcast, 0 multicast
    0 underruns, 0 output errors, 0 pause output
```

7 Related Commands

show interface status

2.14 show interface summary

1 Command Purpose

Use this command to display the statistics on all interfaces or one interface.

2 Command Syntax

show interface summary (*IF_NAME* |)

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name to show	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

none

5 Usage

If the parameter “IF_NAME” is not specified, the command indicates that all interfaces on this device should be displayed; otherwise only the specified interface should be displayed.

6 Examples

The following example shows how to display the statistic of interface eth-0-1:

```
Switch# show interface summary eth-0-1

RXBS: rx rate (bits/sec)          RXPS: rx rate (pkts/sec)
TXBS: tx rate (bits/sec)          TXPS: tx rate (pkts/sec)
Interface  Link   RXBS            RXPS            TXBS            TXPS
----------+------+---------------+---------------+---------------+--------------
eth-0-1     DOWN   0               0               0               0
```

7 Related Commands

show interface

2.15 show interface status

1 Command Purpose

Use this command to display the brief information on all physical and link aggregation interfaces.

2 Command Syntax

show interface status

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the brief information on all physical and link aggregation interfaces:

```
Switch# show interface status

Name       Status      Duplex   Speed    Mode    Type          Description
----------+-----------+--------+--------+-------+------------+----------------
eth-0-1     down         auto     auto     trunk   UNKNOWN
eth-0-2     down         auto     auto     trunk   UNKNOWN
eth-0-3     down         auto     auto     trunk   UNKNOWN
eth-0-4     down         auto     auto     trunk   UNKNOWN
eth-0-5     down         auto     auto     trunk   UNKNOWN
eth-0-6     down         auto     auto     trunk   UNKNOWN
eth-0-7     down         auto     auto     trunk   UNKNOWN
eth-0-8     down         auto     auto     trunk   UNKNOWN
eth-0-9     down         auto     auto     trunk   UNKNOWN
eth-0-10    down         auto     auto     trunk   UNKNOWN
eth-0-11    down         auto     auto     trunk   UNKNOWN
eth-0-12    down         auto     auto     trunk   UNKNOWN
eth-0-13    down         auto     auto     trunk   UNKNOWN
eth-0-14    down         auto     auto     trunk   UNKNOWN
eth-0-15    down         auto     auto     trunk   UNKNOWN
eth-0-16    down         auto     auto     trunk   UNKNOWN
eth-0-17    down         auto     auto     trunk   UNKNOWN
eth-0-18    down         auto     auto     trunk   UNKNOWN
eth-0-19    down         auto     auto     trunk   UNKNOWN
eth-0-20    down         auto     auto     trunk   UNKNOWN
eth-0-21    down         auto     auto     trunk   UNKNOWN
eth-0-22    down         auto     auto     trunk   UNKNOWN
eth-0-23    down         auto     auto     trunk   UNKNOWN
eth-0-24    down         auto     auto     trunk   UNKNOWN
eth-0-25    down         auto     auto     trunk   UNKNOWN
eth-0-26    down         auto     auto     trunk   UNKNOWN
eth-0-27    down         auto     auto     trunk   UNKNOWN
eth-0-28    down         auto     auto     trunk   UNKNOWN
eth-0-29    down         auto     auto     trunk   UNKNOWN
eth-0-30    down         auto     auto     trunk   UNKNOWN
eth-0-31    down         auto     auto     trunk   UNKNOWN
eth-0-32    down         auto     auto     trunk   UNKNOWN
FGE0/33     down         full     40000    trunk   UNKNOWN
FGE0/34     down         full     40000    trunk   UNKNOWN
agg5        down         auto     auto     trunk   LAG
```

7 Related Commands

show interface

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2.16 show interface description

1 Command Purpose

Use this command to display the description information on all interfaces.

2 Command Syntax

show interface description

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the description on all physical and link aggregation interfaces:

```
Switch# show interface description

Name       Status      Description
----------+-----------+------------------------------------------------------------
eth-0-1     down        TenGigabitEthernet
eth-0-2     down
eth-0-3     down
eth-0-4     down
eth-0-5     down
eth-0-6     down
eth-0-7     down
eth-0-8     down
eth-0-9     down
eth-0-10    down
eth-0-11    down
eth-0-12    down
eth-0-13    down
eth-0-14    down
eth-0-15    down
eth-0-16    down
eth-0-17    down
eth-0-18    down
eth-0-19    down
eth-0-20    down
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
eth-0-21    down
eth-0-22    down
eth-0-23    down
eth-0-24    down
eth-0-25    down
eth-0-26    down
eth-0-27    down
eth-0-28    down
eth-0-29    down
eth-0-30    down
eth-0-31    down
eth-0-32    down
FGE0/33    down
FGE0/34    down
agg5       down        LinkAgg5
```

7 Related Commands

show interface

2.17 show interface bandwidth-in-use

1 Command Purpose

Use this command to display the physical port bandwidth usage information and the current configured log-threshold.

2 Command Syntax

show interface bandwidth-in-use [*INTERFACE-NAME* [input | output]]

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to display percentage of current bandwidth usage and configuration of current log-threshold:

```
Switch# show interface bandwidth-in-use eth-0-1/1

Name       Direction  Speed    Load-interval Threshold  ResumeRate Usage
---------+----------+--------+-------------+----------+----------+------
eth-0-1/1  input      40Gb/s   150s          90%        70%        60%
eth-0-1/1  output     40Gb/s   150s          80%        60%        85%
```

7 Related Commands

None

2.18 clear counters

1 Command Purpose

Use this command to clear the statistics information on the interfaces.

2 Command Syntax

clear counters (*IF_NAME* |)

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name to clear the statistics counters.	-

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

If the parameter “IF_NAME” is not specified, the command indicates that all interfaces’ statistics counters information on this device should be cleared; otherwise only the specified interface should be cleared.

6 Examples

The following example shows how to clear the statistics information on all interfaces:

```
Switch# clear counters
```

The following example shows how to clear the statistics information on the interface eth-0-1:

```
Switch# clear counters eth-0-1
```

7 Related Commands

show interface

2.19 crc-check

1 Command Purpose

Use this command to set CRC check function for a port.

2 Command Syntax

crc-check enable

no crc-check enable

Parameter	Parameter Description	Parameter Value
enable	crc check function enable	-

3 Command Mode

Interface Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

Disable

5 Usage

None

6 Examples

The following example shows how to enable CRC check function for a port:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# crc-check enable
```

The following example shows how to disable CRC check function for a port:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no crc-check enable
```

7 Related Commands

None

2.20 crc-recalculation

1 Command Purpose

Use this command to set CRC recalculation function for a port.

2 Command Syntax

crc-recalculation enable

no crc-recalculation enable

Parameter	Parameter Description	Parameter Value
enable	crc recalculation function enable	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Interface Configuration

4 Default

enable

5 Usage

None

6 Examples

The following example shows how to enable CRC recalculation function for a port:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# crc-recalculation enable
```

The following example shows how to disable CRC recalculation function for a port:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no crc-recalculation enable
```

7 Related Commands

None

2.21 log-threshold

1 Command Purpose

Use this command to configure physical port Percentage of the bandwidth utilization warning threshold. And use the no form of this command to

stop this function.

2 Command Syntax

log-threshold { input-rate | output-rate } *BANDWIDTH-IN-USE* resume-rate *RESUME-THRESHOLD*

no log-threshold { input-rate | output-rate }

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
BANDWIDTH-IN-USE	Percentage of the bandwidth utilization warning threshold	range is 1-100
RESUME-THRESHOLD	Percentage of bandwidth utilization recovery logs	range is 1-BANDWIDTH-IN-USE

3 Command Mode

Interface Configuration

4 Default

Disable

5 Usage

In order to avoid fluctuation of log and alarm information, values of bandwidth-in-use and resume-threshold should be kept as far as possible.

6 Examples

The following example shows how to set configure physical port input direction Percentage of the bandwidth utilization warning threshold.:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# log-threshold input-rate 80 resume-rate 60
```

The following example shows how to unset the input direction bandwidth utilization of log-threshold on an interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no log-threshold input-rate
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2.22 log-threshold output-discard

1 Command Purpose

Use this command to configure function of of physical port discard packet number warning threshold on output direction.And use the no form of this command to stop this function.

2 Command Syntax

log-threshold output-discard *THRESHOLD_VALUE* interval *INTERVAL-VALUE*

no log-threshold output-discard

Parameter	Parameter Description	Parameter Value
THRESHOLD_VALUE	Exit direction lost count	range is 100-4294967295
INTERVAL-VALUE	Statistical time	range is 1-1440, unit is minutes

3 Command Mode

Interface Configuration

4 Default

Disable

5 Usage

None

6 Examples

The following example shows,how to configure physical port output direction discard packet number warning threshold in five minutes.:

```
Switch(config-if-eth-0-1)# log-threshold output-discard 100000 interval 5
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

The following example shows how to unset the interface output direction discard packet of log-threshold。:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no log-threshold output-discard
```

7 Related Commands

None

2.23 show this

1 Command Purpose

Use this command to show the interface information

2 Command Syntax

show this

3 Command Mode

Interface Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows how to show interface information:

```
Switch(config-if-eth-0-1)# show this

interface eth-0-1
!
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 ErrDisable Commands

3.1 errdisable detect

1 Command Purpose

Use this command to enable link error status detection function for ports. And use the no form of this command to restore to default value.

2 Command Syntax

errdisable detect reason link-flap

no errdisable detect reason link-flap

Parameter	Parameter Description	Parameter Value
link-flap	Link oscillation detection	-

3 Command Mode

Global Configuration

4 Default

Default link-flap is enable

5 Usage

None

6 Examples

The following example shows how to enable link error status detection function for port:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch# configure terminal
Switch(config)# errdisable detect reason link-flap
```

The following example shows how to disable link error status detection function for port:

```
Switch# configure terminal
Switch(config)# no errdisable detect reason link-flap
```

7 Related Commands

show errdisable detect

3.2 errdisable recovery interval

1 Command Purpose

Use this command to set the recovery time of the link from the error state. And use the no form of this command to restore recovery time to default value.

2 Command Syntax

errdisable recovery interval *ERRDIS_RECOVER_TIMER_PARAM*

no errdisable recovery interval

Parameter	Parameter Description	Parameter Value
ERRDIS_RECOVER_TIMER_PARA	Time interval to recover from error state	range is 30-86400, unit is second

3 Command Mode

Global Configuration

4 Default

300

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to set the interval for error status recovery to 100 seconds:

```
Switch# configure terminal
Switch(config)# errdisable recover interval 100
```

The following example shows how to restore the interval to default value:

```
Switch# configure terminal
Switch(config)# no errdisable recover interval
```

7 Related Commands

show errdisable recovery

3.3 errdisable recovery reason

1 Command Purpose

Use this command to enable the error recovery function for the specified reason. And use the no form of this command to disable this function.

2 Command Syntax

errdisable recovery reason link-flap

no errdisable recovery reason link-flap

Parameter	Parameter Description	Parameter Value
link-flap	Enable or disable the error recovery function for link oscillation	-

3 Command Mode

Global Configuration

4 Default

Disable

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

Use this command to enable or disable the error recovery function for the specified reason。

6 Examples

The following example shows how to enable the error recovery function for port:

```
Switch# configure terminal
Switch(config)# errdisable recover reason link-flap
```

The following example shows how to disable the error recovery function for port:

```
Switch# configure terminal
Switch(config)# no errdisable recover reason link-flap
```

7 Related Commands

show errdisable recovery

3.4 errdisable flap

1 Command Purpose

Use this command set link oscillation parameters. And use the no form of this command to restore to default setting.

2 Command Syntax

errdisable flap reason link-flap *ERRDIS_FLAP_COUNT ERRDIS_FLAP_TIME*

no errdisable flap reason link-flap

Parameter	Parameter Description	Parameter Value
ERRDIS_FLAP_COUNT	The maximum number of possible oscillations before setting the port to errdisable	range is 1-100

Copyright © 2023 Garland Technology, LLC. All rights reserved.

ERRDIS_FLAP_TIME	The time of possible oscillations before setting the port to errdisable	range is 1-120

3 Command Mode

Global Configuration

4 Default

10

5 Usage

There are two parameters in link flap error detection, one is flap count, the other is flap time, if the count of flap reach the max flap count in time of flap time specified, the port will enter errdisable state.

6 Examples

The following example shows how to set link oscillation parameters:

```
Switch# configure terminal
Switch(config)# errdisable flap reason link-flap 30 40
```

The following example shows how to restore link oscillation parameters to default value:

```
Switch# configure terminal
Switch(config)# no errdisable flap reason link-flap
```

7 Related Commands

show errdisable flap

3.5 show errdisable detect

1 Command Purpose

Use this command to display whether error detection is enabled.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

show errdisable detect

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display whether error detection is enabled:

```
Switch# show errdisable detect

ErrDisable Reason        Detection status
-------------------------+--------------------
link-flap                Enabled
```

7 Related Commands

errdisable detect reason

3.6 show errdisable recovery

1 Command Purpose

Use this command to display whether error recovery is enabled.

2 Command Syntax

show errdisable recovery

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use this command to get the recovery status of all error reason. If link error is happened, it can get the recovery information.

6 Examples

The following example shows how to display whether error recovery is enabled:

```
Switch# show errdisable recovery

ErrDisable Reason        Timer status
-------------------------+--------------------
link-flap                Enabled
Timer interval: 300 seconds
```

7 Related Commands

errdisable recovery interval

errdisable recovery reason

3.7 show errdisable flap

1 Command Purpose

This command is used to display parameters for link oscillation error detection.

2 Command Syntax

show errdisable flap

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

Use this command to display the link oscillation error detection time, unit is second.

6 Examples

The following example shows how to display the link oscillation error detection time:

```
Switch# show errdisable flap

ErrDisable Reason Flaps      Time (sec)
-----------------+----------+----------
link-flap         10         10
```

7 Related Commands

errdisable flap

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 FLOW Commands

4.1 show interface flow statistics

1 Command Purpose

Use this command to show statistics information which matched the flow on the interface.

2 Command Syntax

show interface flow statistics *IF_NAME* (*FLOW_SEQ_NUM* |)

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify an interface name to show flow statistics. This command supports physical or link aggregation interfaces.	-
FLOW_SEQ_NUM	Specify sequence-number to show flow statistics. If the sequence-number is not specified, this command indicates that all rules on this interface should be shown.	-

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

Interface name must be specified.

6 Examples

The following example shows how to display the flow statistic on interface eth-0-1:

```
Switch# show interface flow statistics eth-0-1

TAP group name: g1
flow name: f1
sequence-num 10 permit any src-ip 10.10.10.0 0.0.0.255 dst-ip any ( bytes 100
packets 1 )
sequence-num 20 deny any src-ip any dst-ip any ( bytes 86 packets 1 )
(total bytes 186 total packets 2 )
```

7 Related Commands

show flow

clear interface flow statistics

4.2 clear interface flow statistics

1 Command Purpose

Use this command to clear statistics information which matched the flow on the interface.

2 Command Syntax

clear interface flow statistics *IF_NAME*

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

IF_NAME	Specify an interface name to clear flow statistics. This command supports physical or link aggregation interfaces.	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Interface name must be specified.

6 Examples

The following example shows how to clear statistics information which matched the flow on the interface:

```
Switch# clear interface flow statistics eth-0-1
```

The following example shows the result after using the command in the example above:

```
Switch# show interface flow statistics eth-0-1

TAP group name: g1
flow name: f1
sequence-num 10 permit any src-ip 10.10.10.0 0.0.0.255 dst-ip any ( bytes 0
packets 0 )
sequence-num 20 deny any src-ip any dst-ip any ( bytes 0 packets 0 )
(total bytes 0 total packets 0 )
```

7 Related Commands

show interface flow statistics

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4.3 show flow

1 Command Purpose

Use this command to show the configuration of flow.

2 Command Syntax

show flow (*NAME_STRING* |)

Parameter	Parameter Description	Parameter Value
NAME_STRING	Flow name, up to 20 characters. If the flow name is not specified, this command indicates that all flows should be shown.	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

This example shows the configuration of flow:

```
Switch# show flow

flow f1
remark flow1ipdeny
sequence-num 10 permit any src-ip 10.10.10.0 0.0.0.255 dst-ip any
sequence-num 20 deny any src-ip any dst-ip any
flow f2
sequence-num 10 permit tcp src-port range 10 200 src-ip any dst-ip any
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

flow

4.4 flow

1 Command Purpose

Use this command to create Flow and then enter Flow configuration mode.

Use the no form of this command to delete the flow.

2 Command Syntax

flow *NAME_STRING* (type decap |)

no flow *NAME_STRING*

Parameter	Parameter Description	Parameter Value
NAME_STRING	Flow name	up to 20 characters
type decap	Set the flow type as tunnel decap. Flow with “type decap” parameter can use “inner-match” fields.	-

3 Command Mode

Global Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

If the system already has a flow with the same name, this command will enter the flow configuration mode.

When the name is not used by any flow, this command is to create the flow and then enter the flow configuration mode. When configured with parameter ”type decap” means this flow match tunnel decap, which flow entries can configure “inner-match” fields.

6 Examples

This example shows how to create a flow named f1 and then enter the flow configuration mode:

```
Switch(config)# flow f1
Switch(config-flow-f1)#
```

The following example shows how to delete the flow:

```
Switch(config)# no flow f1
```

7 Related Commands

show flow

4.5 remark

1 Command Purpose

Use this command to add remarks for the flow.

Use the no form of this command to delete the remarks.

2 Command Syntax

remark *NAME_STRING*

no remark

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

NAME_STRING	Remark string for the flow	Remark string for the flow, which should begin with a-z/A-Z/0-9, valid characters are 0-9A-Za-z.-, and maximum length is 100 characters.

3 Command Mode

Flow Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to add a remark to describe the flow :

```
Switch(config-flow-f1)# remark flow1ipdeny
```

This example shows how to delete the remark of the flow:

```
Switch(config-flow-f1)# no remark
```

7 Related Commands

show flow

4.6 no sequence-num

1 Command Purpose

Use this command to delete a filter from flow.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

no sequence-num *FLOW_SEQ_NUM*

Parameter	Parameter Description	Parameter Value
FLOW_SEQ_NUM	Sequence-number	1 - 65535

3 Command Mode

Flow Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to delete a flow filter with sequence number 10 from flow f1:

```
Switch(config-acl-acl1)# no sequence-num 10
```

7 Related Commands

show flow

sequence-num

4.7 sequence-num

1 Command Purpose

Use this command to add a rule in a flow filter.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

(sequence-num *FLOW_SEQ_NUM* |) (permit | deny) (*PROTOCOL_NUM* | any | mpls (any | label-num (any | *MPLS_LABEL_NUM_WITHOUT_0*) (mpls-label1 (any | *FLOW_LABEL_VALUE*) |) (mpls-label2 (any | *FLOW_LABEL_VALUE*) |) (mpls-label3 (any | *FLOW_LABEL_VALUE*) |)) | pppoe ppp-type (ipv4 | ipv6) | tcp (src-port (range *L4_PORT_NUM L4_PORT_NUM* | eq *L4_PORT_NUM* | gt *L4_PORT_NUM* | lt *L4_PORT_NUM* | any) | dst-port (range *L4_PORT_NUM L4_PORT_NUM* | eq *L4_PORT_NUM* | gt *L4_PORT_NUM* | lt *L4_PORT_NUM* | any) | tcp-code (match-all | match-any) (ack | fin | psh | rst | syn | urg) |) | udp (src-port (range *L4_PORT_NUM1 L4_PORT_NUM2* | eq *L4_PORT_NUM* | gt *L4_PORT_NUM* | lt *L4_PORT_NUM* | any) | dst-port (range *L4_PORT_NUM1 L4_PORT_NUM2* | eq *L4_PORT_NUM* | gt *L4_PORT_NUM* | lt *L4_PORT_NUM* | any) | vxlan-vni (*VNI_VALUE VNI_VALUE_WILD* | any) |) | icmp | igmp | gre (gre-key (*GRE_KEY_VALUE GRE_KEY_WILD* | any) |) | (erspan (*ERSPAN_KEY_VALUE ERSPAN _KEY_WILD* | any) |) | nvgre (nvgre-vsid (*NVGRE_VSID_VALUE NVGRE_ VSID _WILD* | any) |)) (src-ip (*IP_ADDR IP_ADDR_WILD* | any | host *IP_ADDR*) | src-ipv6 (*IPv6_ADDR IPv6_ADDR_WILD* | any | host *IPv6_ADDR*)) (dst-ip (*IP_ADDR IP_ADDR_WILD* | any | host *IP_ADDR*) | dst-ipv6 (*IPv6_ADDR IPv6_ADDR_WILD* | any | host *IPv6_ADDR*)) (flow-label (*FLOW_LABEL LABEL _WILD* | any) |) (dscp *DSCP_VALUE* | ip-precedence *PRECEDENCE_VALUE* |) (first-fragment | non-first-fragment | non-fragment | non-or-first-fragment | small-fragment | any-fragment |) (options |) (truncation |) (vlan (*VLAN_ID VLAN_WILD* | any) |) (inner-vlan (*VLAN_ID VLAN_WILD* | any) |) (cos *COS_ID* |) (inner-cos *COS_ID* |) (ether-type (*ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE* | any) |) (src-mac (*FLOW_MAC_ADDR FLOW_MAC_ADDR_WILD* | any | host *FLOW_MAC_ADDR*) |) (dest-mac (*FLOW_MAC_ADDR FLOW_MAC_ADDR_WILD* | any | host *FLOW_MAC_ADDR*) |) (edit-macda *MAC_ADDRESS* |) (edit-macsa *MAC_ADDRESS* |) (edit-ipsa *IP_ADDRESS* |) (edit-ipda *IP_ADDRESS* |) (edit-ipv6sa *IPv6_ADDRESS* |) (edit-ipv6da *IPv6_ADDRESS* |) (edit-vlan *VLAN_ID* |) (un-tag | un-tag-outer-vlan | un-tag-inner-vlan |) (mark-source *VLAN_ID* |) (strip-header (strip-position (l2 | l3 | l4) |) (strip-offset *OFFSET_VALUE* |) |) (udf udf-id *UDF_ID* (udf0 *UDF_VALUE UDF_VALUE_WILD* | udf1 *UDF_VALUE UDF_VALUE_WILD* | udf2 *UDF_VALUE UDF_VALUE_WILD* | udf3 *UDF_VALUE UDF_VALUE_WILD* |) |) (strip-inner-vxlan-header |) (inner-match *MATCH_NAME* |) (add-l2gre l2gre-sip *L2GRE_SRC_IP* l2gre-dip *L2GRE_DEST_IP* l2gre-dmac *L2GRE_DEST_MAC* l2gre-key *L2GRE_KEY_NUM* l2gre-key-length (16 | 20 | 24 | 32) |) (add-l3gre l3gre-sip

Copyright © 2023 Garland Technology, LLC. All rights reserved.

L3GRE_SRC_IP l3gre-dip *L3GRE_DEST_IP* l3gre-dmac *L3GRE_DEST_MAC* |) (de-duplicate |) (hash-value *VALUE_NAME* |) (edit-l4-src-port *L4_SRC_PORT* |) (edit-l4-dst-port *L4_DST_PORT* |)

Parameter	Parameter Description	Parameter Value
FLOW_SEQ_NUM	Specify a sequence number to create the flow rule. The valid range for sequence number is 1-65535. If the sequence number is not specified, system should automatically assign one number according to the base number and the step length. The base number is the maximum number in the flow (0 for empty flow), the step length is 10.	1-65535
permit	Specify the action of the flow rule. Use the parameter “permit” to indicate packets match this rule is allowed to forward.	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

deny	Specify the action of the flow rule. Use the parameter “deny” to indicate packets match this rule is not allowed to forward.	-
PROTOCOL_NUM | any | tcp | udp | icmp | igmp | gre | nvgre	Specify the IP protocol number of the flow rule.	The valid range for IP protocol number is 0-255. Well known IP protocols can also be specified by name. e.g. IP protocol 1 = icmp, 2 = igmp, 6 = tcp, 17 = udp, 47 = gre/nvgre (gre protocol 0x0800 = gre, 0x6558 = nvgre). Specify the IP protocol number of the flow rule.
mpls (any | label-num (any | MPLS_LABEL_NUM_WITHOUT_0) (mpls-label1 (any|FLOW_LABEL_VALUE) |) (mpls-label2 (any|FLOW_LABEL_VALUE) |) (mpls-label3 (any|FLOW_LABEL_VALUE) |))	Specify the mpls label of the flow rule.	The mpls label number is 0-9.It can match 3 layers of MPLS label values at most.
pppoe ppp-type (ipv4 | ipv6)	Specify the pppoe ppp-type of the flow rule.	The ppp-type is ipv4 or ipv6.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

src-port (range L4_PORT_NUM L4_PORT_NUM | eq L4_PORT_NUM | gt L4_PORT_NUM | lt L4_PORT_NUM | any)	Specify the layer 4 source port of the inner-match rule.	The valid range for L4 source port number is 0 – 65535. This filed is valid only if the IP protocol is TCP or UDP. There are 4 methods to specify the L4 port: 1, eq (equal to) 2, lt (less than) 3, gt (greater than) 4, range Specify the layer 4 source port of the inner-match rule.
dst-port (range L4_PORT_NUM L4_PORT_NUM | eq L4_PORT_NUM | gt L4_PORT_NUM | lt L4_PORT_NUM | any)	Specify the layer 4 destination port of the inner-match rule.	The valid range for L4 destination port number is 0 – 65535. This filed is valid only if the IP protocol is TCP or UDP. There are 4 methods to specify the L4 port: 1, eq (equal to) 2, lt (less than) 3, gt (greater than) 4, range Parameter “any” indicates packets with any L4 port can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

vxlan-vni (VNI_VALUE VNI_VALUE_WILD | any)	Specify the vxlan vni number of the flow rule. This filed is valid only if the IP protocol is UDP and L4 destination port 4789. VNI (VXLAN Network Identifier) is the identifier on the VXLAN network, which is similar to the traditional VLAN. Terminals in different VXLANs cannot connect with each other based on L2 network. One tenant uses one VNI (even if several terminals are in same VNI, they are regarding as one tenant).	The valid range for VNI value is 0-16777215. The valid range for VNI wildcard bits is range 0x0-0xFFFFFF. VNI value and VNI wildcard bits both have 24bits. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any VNI value can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

geneve-vni (GENEVE_VNI_VALUE GENEVE_VNI_VALUE_WILD | any)	Specify the geneve vni number of the flow rule. This filed is valid only if the IP protocol is UDP and L4 destination port 6081. GENEVE_VNI (GENEVE Network Identifier in geneve header) is the identifier on the GENEVE network, which is similar to the traditional VLAN. Terminals in different GENEVEs cannot connect with each other based on L2 network. One tenant uses one GENEVE_VNI (even if several terminals are in same GENEVE_VNI, they are regarding as one tenant).	The valid range for GENEVE_VNI value is 0-16777215. The valid range for GENEVE_VNI wildcard bits is range 0x0-0xFFFFFF. GENEVE_VNI value and GENEVE_VNI wildcard bits both have 24bits. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any GENEVE_VNI value can match this rule.
gre-key (GRE_KEY_VALUE GRE_KEY_WILD | any)	Specify the gre key of the flow rule. This filed is valid only if the IP protocol is gre (Generic Routing Encapsulation).	The valid range for gre key value is 0-4294967295. The valid range for gre key wildcard bits is range 0x0- 0xFFFFFFFF. Gre key value and wildcard bits both have 32bits, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any gre key value can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

erspan (ERSPAN_KEY_VALUE ERSPAN _KEY_WILD | any)	Specify the erspan key value of the flow rule. ERSPAN = Enhanced Remote SPAN.	Valid range for ERSPAM key value is 0-1023 Valid range for ERSPAM key wildcard bits is 0x0-0x3FF ERSPAN key value and wildcard bits both have 10bits, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit.
nvgre-vsid (NVGRE_VSID_VALUE NVGRE_VSID_WILD | any)	Specify the nvgre vsid value of the flow rule. Nvgre = Network Virtualization using Generic Routing Encapsulation.	Valid range for NVGRE VSID value is 0-16777215. Valid range for NVGRE VSID wildcard bits is 0x0-0xFFFFFF VSID is located in the low 24 bit of GRE head. VSID value and wildcard bits both have 24 bits, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any nvgre vsid value can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

src ip (IP_ADDR IP_ADDR_WILD | any | host IP_ADDR)	Specify the source IPv4 address of the flow rule. Use an IPv4 address and an IPv4 address wildcard to specify a network.	Use an IPv4 address and an IPv4 address wildcard to specify a network (e.g. 192.168.1.1 0.0.0.255). If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv4 address to specify an exactly address. Use the parameter “any” to indicate packets with any source IPv4 address value can match this rule.
dst ip (IP_ADDR IP_ADDR_WILD | any | host IP_ADDR)	Specify the destination IPv4 address of the flow rule. Use an IPv4 address and an IPv4 address wildcard to specify a network.	Use an IPv4 address and an IPv4 address wildcard to specify a network (e.g. 192.168.1.1 0.0.0.255). If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv4 address to specify an exactly address. Use the parameter “any” to indicate packets with any destination IPv4 address value can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

src ipv6 (IPv6_ADDR IPv6_ADDR_WILD | any | host IPv6_ADDR)	Specify the source IPv6 address of the flow rule. Use an IPv6 address and an IPv6 address wildcard to specify a network. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.	Use the parameter “host” and an IPv6 address to specify an exactly address. Use the parameter “any” to indicate packets with any destination IPv6 address value can match this rule.
dst ipv6 (IPv6_ADDR IPv6_ADDR_WILD | any | host IPv6_ADDR)	Specify the destination IPv6 address of the flow rule. Use an IPv6 address and an IPv6 address wildcard to specify a network. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.	Use the parameter “host” and an IPv6 address to specify an exactly address. Use the parameter “any” to indicate packets with any destination IPv6 address value can match this rule.
flow-label (FLOW_LABEL LABEL_WILD | any)	Specify the IPv6 Flow label of the flow rule.	Valid range for flow label is 0-1048575. Valid range for flow-label wildcard bits is 0x0-0xFFFFF Flow label value and wildcard bits both have 20bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates ipv6 packets with any flow label value can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

dscp DSCP_VALUE	Specify the DSCP in IPv4 packets value of the inner-match rule. DSCP = Differentiated Services Code Point. Specify the DSCP in IPv4 packets value of the inner-match rule. DSCP = Differentiated Services Code Point. Valid range of DSCP value is 0 – 63.	0-63
ip-precedence PRECEDENCE_VALUE	Specify the IP precedence in IPv4 packets of the inner-match rule. Valid range of IP precedence value is 0 – 7. Specify the IP precedence in IPv4 packets of the inner-match rule. Valid range of IP precedence value is 0 – 7. DSCP & ip precedence configurations are exclusive	0-7
first-fragment	Match packets with first fragment	-
non-first-fragment	Match packets with non first fragment	-
non-fragment	Match packets with non fragment	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

non-or-first-fragment	Match packets with non first fragment	-
small-fragment	Match packets with small fragment	-
any-fragment	Match packets with any fragment	-
options	Match packets with IP options	-
truncation	Use this parameter to truncate the packets matched this rule. Use this parameter to truncate the packets matched this rule. The length of truncation is configured by the “truncation” command in global configuration mode.	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

vlan (VLAN_ID VLAN_WILD | any)	Specify the outer vlan id of the flow rule.	The valid range for vlan id is 0-4095. The valid range for vlan id wildcard bits is 0x0-0xFFF. Vlan id and wildcard bits both have 12bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any outer vlan id can match this rule.
inner-vlan (VLAN_ID VLAN_WILD | any)	Specify the inner vlan id of the flow rule.	The valid range for vlan id is 0-4095. The valid range for vlan id wildcard bits is 0x0-0xFFF. Vlan id and wildcard bits both have 12bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any outer vlan id can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

cos COS_ID	Specify the outer CoS value of the inner-match rule. CoS = Class of Service. Specify the outer CoS value of the inner-match rule. CoS = Class of Service.	0-7
inner-cos COS_ID	Specify the inner CoS value of the inner-match rule. CoS = Class of Service. Specify the inner CoS value of the inner-match rule. CoS = Class of Service.	0-7
ether-type (ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE | any)	Specify the ether-type of the flow rule.	The valid range for ether-type is 0x600-0xFFFF. The valid range for wildcard bits is 0x600-0xFFFF. Ether-type value and wildcard bits both have 16bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any ethertype value can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

src-mac (FLOW_MAC_ADDR FLOW_MAC_ADDR_WILD | any | host FLOW_MAC_ADDR)	Specify the source mac address	Specify the source mac address in HHHH.HHHH.HHHH format. Use a mac address and wildcard bits to specify a batch of mac addresses. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and a mac address to specify an exactly mac address. Use the parameter “any” to indicate packets with any source mac address value can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

dest-mac (FLOW_MAC_ADDR FLOW_MAC_ADDR_WILD | any| host FLOW_MAC_ADDR)	Specify the destination mac address	Specify the destination mac address in HHHH.HHHH.HHHH format. Use a mac address and wildcard bits to specify a batch of mac addresses. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and a mac address to specify an exactly mac address. Use the parameter “any” to indicate packets with any destination mac address value can match this rule.
edit-macda MAC_ADDRESS	Specify the destination mac address of the outgoing packets	Specify the destination mac address of the outgoing packets in HHHH.HHHH.HHHH format.
edit-macsa MAC_ADDRESS	Specify the source mac address of the outgoing packets	Specify the source mac address of the outgoing packets in HHHH.HHHH.HHHH format.。

Copyright © 2023 Garland Technology, LLC. All rights reserved.

edit-ipsa IP_ADDRESS	Specify the source IP address of the outgoing packets	Specify the source IP address of the outgoing packets in A.B.C.D format.。
edit-ipda IP_ADDRESS	Specify the destination IP address of the outgoing packets	Specify the destination IP address of the outgoing packets in A.B.C.D format.。
edit-ipv6sa IPv6_ADDRESS	Specify the source IPv6 address of the outgoing packets.	Specify the source IPv6 address of the outgoing packets.
edit-ipv6da IPv6_ADDRESS	Specify the destination IPv6 address of the outgoing packets.	Specify the destination IPv6 address of the outgoing packets.
edit-vlan VLAN_ID	Specify the vlan id of the outgoing packets.	The valid range for vlan id is 1 – 4094.
un-tag	Remove vlan tags of the packets.	-
un-tag-outer-vlan	Remove outer vlan tag of the packets.	-
un-tag-inner-vlan	Remove inner vlan tag of the packets.	-
mark-source VLAN_ID	Specify the vlan id of the outgoing packets.	The valid range for vlan id is 1 – 4094.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

strip-header (strip-position (l2 | l3 | l4) |) (strip-offset OFFSET_VALUE |)	Remove the outer header of the tunnel packets. The strip-positon and strip-offset can not set and when the packet is gre/nvgre/vxlan/ipip/mpls/ppoe.	The parameter “strip-position” specifies the begging of the outer header. “l2” means begin with the layer 2 tunnel header. “l3” means begin with the layer 3 tunnel header. “l4” means begin with the layer 4 tunnel header. The parameter “strip-offset” specifies the user- defined offset to strip the tunnel outer header. The valid range for strip-offset is 0-30.
strip-inner-vxlan-header	Remove the inner vxlan header in the erspan packets. Remove the inner vxlan header in the erspan packets. This parameter is only valid when the packet is ERSPAN + VXLAN.	-
udf udf-id UDF_ID (udf0 UDF_VALUE UDF_VALUE_WILD | udf1 UDF_VALUE UDF_VALUE_WILD | udf2 UDF_VALUE UDF_VALUE_WILD | udf3 UDF_VALUE UDF_VALUE_WILD |)	Use this command to configure UDF based ACL. UDF entry should be create and configured previously. There are maximum three UDF value corresponding three UDF offset field.	The range of UDF_ID is 0-15, Udf value and wildcard bits both have 32 bits, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

inner-match MATCH_NAME	Specify the inner match profile of the flow rule. Specify the inner match profile of the flow rule. The inner-match profile is created by “inner-match” command in global configuration mode.	-
add-l2gre l2gre-sip L2GRE_SRC_IP l2gre-dip L2GRE_DEST_IP l2gre-dmac L2GRE_DEST_MAC l2gre-key L2GRE_KEY_NUM l2gre-key-length (16 | 20 | 24 | 32)	Use this action to add l2gre header. L2GRE_SRC_IP: L2GRE Source IP L2GRE_DEST_IP: L2GRE Destination IP L2GRE_DEST_MAC: L2GRE Destination MAC L2GRE_KEY_NUM: L2GRE Key Number	-
add-l3gre l3gre-sip L3GRE_SRC_IP l3gre-dip L3GRE_DEST_IP l3gre-dmac L3GRE_DEST_MAC	Use this action to add l3gre header. L3GRE_SRC_IP: L3GRE Source IP L3GRE_DEST_IP: L3GRE Destination IP L3GRE_DEST_MAC: L3GRE Destination MAC	-
de-duplicate	Use this action to config de-duplicate packet of match.The de-duplicate is configured by the “de-duplicate global” command in global configuration mode.	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

hash-value VALUE_NAME	Use this action to configure hash-value for hash load-balance.The hash-value profile if configured by the "hash-value" command in global configuration mode	-
edit-l4-src-port L4_SRC_PORT	Use this action to configure edit l4 source port for TCP or UDP packets	0-65535
edit-l4-dst-port L4_DST_PORT	Use this action to configure edit l4 destination port for TCP or UDP packets	0-65535

3 Command Mode

Flow Configuration

4 Default

None

5 Usage

Wildcard bits in this command are used as reversed. That means value and wildcard bits have same length, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.E.g. IP address 10.10.10.0 wildcard 0.0.0.255 means 256 ip addresses from 10.10.10.0 to 10.10.10.255.Layer 4 information (e.g. tcp/udp port) and fragment information are exclusive. The parameters “erspan” and “edit-vlan, un-tag” after “stripe-head” are not supported

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

This example shows how to add a flow filter with sequence number 10 to flow f1:

```
Switch(config)# flow f1
Switch(config-flow-f1)# sequence-num 10 permit any src-ip 10.10.10.0 0.0.0.255
dst-ip any
```

7 Related Commands

no sequence-num

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 UDF Commands

5.1 show udf

1 Command Purpose

Use this command to show the configuration of UDF entries.

2 Command Syntax

show udf (*UDF_ID* |)

Parameter	Parameter Description	Parameter Value
UDF_ID	Specify a index to show the configuration of a specific UDF entry.	The range is 0-15

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

This example shows the configuration of UDF entries:

```
Switch# show udf
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Udf Global Information:
  Offset Unit : 4 Bytes
Udf Index 0
  Udf Type : l2 header
  Udf Match-Field:
    ether-type 0x8100 0x0
  Offset : n/a|8|n/a|n/a
Udf Index 1
  Udf Type : l3 header
  Udf Match-Field:
    any
  Offset : 4|n/a|n/a|n/a
```

7 Related Commands

udf

5.2 udf

1 Command Purpose

Use this command to create a UDF entry or enter the configuration mode of a specific DUF entry.

2 Command Syntax

udf *UDF_ID* (offset-type *OFFSET_TYPE* |)

Parameter	Parameter Description	Parameter Value
UDF_ID	Specify a index of a UDF entry.	The range is 0-15
OFFSET_TYPE	The offset type should be configured when a UDF entry was first created.	The offset type can be l2-header、l3-header、l4-header.

3 Command Mode

Global Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

The UDF-ID also means the priority of UDF entries, smaller id is a higher priority.

6 Examples

This example shows how to create a UDF entry and enter it's configuration mode:

```
Switch(config)# udf 1 offset-type l3-header
Switch(config-udf-1)#
```

7 Related Commands

show udf

5.3 match

1 Command Purpose

Use this command to configure the match field for an UDF entry.

2 Command Syntax

match (any | ether-type *ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE* | ip-protocol (*PROTOCOL_NUM* | any | tcp | udp | gre | icmp | igmp) | src-port (*L4_PORT_NUM* | any) | dst-port (*L4_PORT_NUM* | any) | vlan-num *VLAN_NUM* | mpls-label-num *MPLS_LABEL_NUM* |)

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

ether-type (ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE | any)	Specify the ether-type of the flow rule.	The valid range for ether-type is 0x600-0xFFFF. The valid range for wildcard bits is 0x600-0xFFFF. Ether-type value and wildcard bits both have 16bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.
PROTOCOL_NUM | any | tcp | udp | icmp | igmp	Specify the IP protocol number of the udf match field.	Specify the IP protocol number of the udf match field. The valid range for IP protocol number is 0-255.
L4_PORT_NUM	Specify the layer 4 source port of the udf match field.	The valid range for L4 source port number is 0 - 65535.
VLAN_NUM	The vlan number of the packets	range is 0-2.
MPLS_LABEL_NUM	The mpls label number of the packets	range is 0-9.

3 Command Mode

UDF Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

This example shows how to configure the match field for an UDF entry:

```
Switch(config-udf-1)# match ether-type 0x8100 0x0 ip-protocol tcp
```

7 Related Commands

show udf

5.4 offset

1 Command Purpose

Use this command to configure the detailed offset value for an UDF entry.

2 Command Syntax

match (offset0 *UDF_OFFSET* | offset1 *UDF_OFFSET* | offset2 *UDF_OFFSET* | offset3 *UDF_OFFSET* |)

Parameter	Parameter Description	Parameter Value
UDF_OFFSET	Specifies the offset in bytes from the beginning.	The valid range of the offset is 0-60 bytes.

3 Command Mode

UDF Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

The offset number must be multiple of 4 bytes because UDF would extract 4 bytes data from a specific offset in packets.

6 Examples

This example shows how to configure the detailed offset value for an UDF entry:

```
Switch(config-udf-1)# offset offset0 4 offset1 20 offset3 36
```

7 Related Commands

show udf

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 PORT-GROUP Commands

6.1 port-group

1 Command Purpose

Use this command to create a port-group and enter the port-group configuration mode.

Use the no form of this command to delete the port-group.

2 Command Syntax

port-group *NAME_STRING* (*PORT_GROUP_ID* |)

no port-group *NAME_STRING*

Parameter	Parameter Description	Parameter Value
NAME_STRING	Port-group Name string	The first character should be a-z or A-Z, character only can be 0-9A-Za-z.-_ and the max len is 31.
PORT_GROUP_ID	Port Group ID, range 1-48	1-48

3 Command Mode

Global Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

This device supports at most 48 port-groups.

6 Examples

The following example shows how to add a port-group:

```
Switch(config)# port-group portgroup1
Switch(config-port-portgroup1)#
```

The following example shows how to delete a port-group:

```
Switch(config)# no port-group portgroup1
```

7 Related Commands

show port-group

6.2 member interface

1 Command Purpose

Use this command to add a member interface in port-group.

Use the no form of this command to delete the member interface.

2 Command Syntax

member interface *IF_NAME_EA*

no member interface *IF_NAME_EA*

Parameter	Parameter Description	Parameter Value
IF_NAME_EA	member interface Name string	Specify the interface name to enter the mode. e.g.eth-0-1, agg1.

3 Command Mode

Port-group Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

This device supports at most 16 member interface.

6 Examples

The following example shows how to add a member interface in port-group:

```
Switch(config-port-portgroup1)# member interface eth-0-1
```

The following example shows how to delete a member interface in port-group:

```
Switch(config-port-portgroup1)# no member interface eth-0-1
```

7 Related Commands

show port-group

6.3 show port-group

1 Command Purpose

Use this command to display the configurations of port-group.

2 Command Syntax

show port-group (*NAME_STRING* |)

Parameter	Parameter Description	Parameter Value
NAME_STRING	Specify the port-group name to show	-

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

If the parameter “NAME_STRING” is not specified, the command indicates that all port-groups on this device should be displayed; otherwise only the specified port-group should be displayed.

6 Examples

The following example shows how to display the configurations port-group portgroup1:

```
Switch# show port-group

port-group portgroup1 1
 member interface eth-0-1
 member interface eth-0-2
```

7 Related Commands

show port-group flow statistics

6.4 show port-group flow statistics

1 Command Purpose

Use this command to display the statistics of port-group.

2 Command Syntax

show port-group flow statistics *NAME_STRING* (*FLOW_SEQ_NUM* |)

Parameter	Parameter Description	Parameter Value
NAME_STRING	Specify the port-group name to show	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

FLOW_SEQ_NUM	Specify sequence-number to show flow statistics. If the sequence-number is not specified, this command indicates that all rules on this interface should be shown.	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

The specified port-group statistics should be displayed.

6 Examples

The following example shows how to display the statistics port-group portgroup1:

```
Switch# show port-group flow statistics

portgroup1
TAP group name: tapgroup1
 flow name: flow1
 sequence-num 10 permit gre src-ip any dst-ip any ( bytes 0 packets 0 )
 sequence-num 20 permit mpls any ( bytes 0 packets 0 )
(total bytes 0 total packets 0 )
```

7 Related Commands

show port-group

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 INNER-MATCH Commands

7.1 show inner-match

1 Command Purpose

Use this command to show the configuration of inner-match.

2 Command Syntax

show inner-match (*INNER_MATCH_NAME* |)

Parameter	Parameter Description	Parameter Value
INNER_MATCH_NAME	Specify an inner-match name to display.	The inner match name should begin with [a-z/A-Z/0-9], valid characters are [0-9A-Za-z.-], and maximum length is 20 characters. If the parameter “ INNER_MATCH_NAME” is not specified, the command indicates that all inner-matches on this device should be displayed; otherwise only the specified one should be displayed

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

This example shows the configuration of all inner-match:

```
Switch# show inner-match

inner-match im1
 sequence-num 1 match icmp src-ip any dst-ip any vlan any
inner-match im2
 sequence-num 1 match udp dst-port eq 4758 src-ip any dst-ip host 2.2.2.2
```

7 Related Commands

inner-match

7.2 inner-match

1 Command Purpose

Use this command to create inner-match and then enter Inner-match configuration mode.

Use the no form of this command to delete the inner-match.

2 Command Syntax

inner-match *INNER_MATCH_NAME*

no inner-match *INNER_MATCH_NAME*

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

INNER_MATCH_NAME	Specify an inner-match name to create and enter the mode.	The inner match name should begin with a-z/A-Z/0-9, valid characters are 0-9A-Za-z.-, and maximum length is 20 characters.

3 Command Mode

Global Configuration

4 Default

None

5 Usage

If the system already has an inner-match with the same name, this command will enter the inner-match configuration mode.

When the name is not used by any inner-match, this command is to create the inner-match firstly and then enter the inner-match configuration mode.

6 Examples

This example shows how to create a inner-match named im1 and then enter the inner-match configuration mode:

```
Switch(config)# inner-match im1
Switch(config-inner-match-im1)#
```

This example shows how to delete a inner-match named im1:

```
Switch(config)# no inner-match im1
```

7 Related Commands

show inner-match

Copyright © 2023 Garland Technology, LLC. All rights reserved.

7.3 remark

1 Command Purpose

Use this command to add remarks for the inner-match.

2 Command Syntax

remark *NAME_STRING*

no remark

Parameter	Parameter Description	Parameter Value
NAME_STRING	Remark string for the inner-match	Begin with a-z/A-Z/0-9, valid characters are 0-9A-Za-z.-, maximum length is 100 characters.

3 Command Mode

Inner-match Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to add a remark to describe the inner-match:

```
Switch(config-inner-match-im1)# remark inner-match-1
```

This example shows how to delete the remark of the inner-match:

```
Switch(config-inner-match-im1)# no remark
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

show inner-match

7.4 no sequence-num

1 Command Purpose

Use this command to delete a filter from inner-match.

2 Command Syntax

no sequence-num *MATCH_SEQ_NUM*

Parameter	Parameter Description	Parameter Value
MATCH_SEQ_NUM	Sequence-number with the valid range 1 - 65535.	1-65535

3 Command Mode

Inner-match Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to delete an inner-match filter with sequence number 10 from im1:

```
Switch(config-inner-match-im1)# no sequence-num 10
```

7 Related Commands

show inner-match

Copyright © 2023 Garland Technology, LLC. All rights reserved.

match

7.5 sequence-num

1 Command Purpose

Use this command to set matching rules for the inner-match filter.

2 Command Syntax

(sequence-num *MATCH_SEQ_NUM* |) match (*PROTOCOL_NUM* | any | mpls (any | label-num (any | *MPLS_LABEL_NUM_WITHOUT_0*) (mpls-label1 (any | *FLOW_LABEL_VALUE*) |) (mpls-label2 (any | *FLOW_LABEL_VALUE*) |) (mpls-label3 (any | *FLOW_LABEL_VALUE*) |)) | pppoe ppp-type (ipv4 | ipv6) | tcp (src-port (range *L4_PORT_NUM L4_PORT_NUM* | eq *L4_PORT_NUM* | gt *L4_PORT_NUM* | lt *L4_PORT_NUM* | any) | dst-port (range *L4_PORT_NUM L4_PORT_NUM* | eq *L4_PORT_NUM* | gt *L4_PORT_NUM* | lt *L4_PORT_NUM* | any) | tcp-code (match-all | match-any) (ack | fin | psh | rst | syn | urg) |) | udp (src-port (range *L4_PORT_NUM1 L4_PORT_NUM2* | eq *L4_PORT_NUM* | gt *L4_PORT_NUM* | lt *L4_PORT_NUM* | any) | dst-port (range *L4_PORT_NUM1 L4_PORT_NUM2* | eq *L4_PORT_NUM* | gt *L4_PORT_NUM* | lt *L4_PORT_NUM* | any) |) | icmp | igmp) (src-ip (*IP_ADDR IP_ADDR_WILD* | any | host *IP_ADDR*) | src-ipv6 (*IPv6_ADDR IPv6_ADDR_WILD* | any | host *IPv6_ADDR*)) (dst-ip (*IP_ADDR IP_ADDR_WILD* | any | host *IP_ADDR*) | dst-ipv6 (*IPv6_ADDR IPv6_ADDR_WILD* | any | host *IPv6_ADDR*)) (flow-label (*FLOW_LABEL LABEL _WILD** | any) |) (dscp *DSCP_VALUE* | ip-precedence *PRECEDENCE_VALUE* |) (first-fragment | non-first-fragment | non-fragment | non-or-first-fragment | small-fragment | any-fragment |) (options |) (vlan (*VLAN_ID VLAN_WILD* | any) |) (inner-vlan (*VLAN_ID VLAN_WILD* | any) |) (cos *COS_ID* |) (inner-cos *COS_ID* |) (ether-type (*ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE* | any) |) (src-mac (*MATCH_MAC_ADDR MATCH_MAC_ADDR_WILD* | any | host *MATCH _MAC_ADDR**) |) (dest-mac (*MATCH_MAC_ADDR MATCH_MAC_ADDR_WILD* | any | host *MATCH_MAC_ADDR*) |)

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

sequence-num MATCH_SEQ_NUM	Specify a sequence number to create the inner-match rule.	The valid range for sequence number is 1-65535. If the sequence number is not specified, system should automatically assign one number according to the base number and the step length. The base number is the maximum number in the inner-match (0 for empty inner-match), the step length is 10.
match	Match the packets according to the rule	-
PROTOCOL_NUM | any | tcp | udp | icmp | igmp	Specify the IP protocol number of the inner-match rule.	The valid range for IP protocol number is 0-255. Well known IP protocols can also be specified by name. e.g. IP protocol 1 = icmp, 2 = igmp, 6 = tcp, 17 = udp. Parameter “any” indicates packets with any IP protocol can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

mpls (any | label-num (any | MPLS_LABEL_NUM_WITHOUT_0) (mpls-label1 (any|FLOW_LABEL_VALUE) |) (mpls-label2 (any|FLOW_LABEL_VALUE) |) (mpls-label3 (any|FLOW_LABEL_VALUE) |))	Specify the mpls label of the flow rule.	The mpls label number is 0-9.It can match 3 layers of MPLS label values at most.
pppoe ppp-type (ipv4 | ipv6)	Specify the pppoe ppp-type of the flow rule.	The ppp-type is ipv4 or ipv6.
src-port (range L4_PORT_NUM L4_PORT_NUM | eq L4_PORT_NUM | gt L4_PORT_NUM | lt L4_PORT_NUM | any)	Specify the layer 4 source port of the inner-match rule.	The valid range for L4 source port number is 0 - 65535. This filed is valid only if the IP protocol is TCP or UDP. There are 4 methods to specify the L4 port: 1, eq (equal to) 2, lt (less than) 3, gt (greater than) 4, range Parameter “any” indicates packets with any L4 port can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

dst-port (range L4_PORT_NUM L4_PORT_NUM | eq L4_PORT_NUM | gt L4_PORT_NUM | lt L4_PORT_NUM | any)	Specify the layer 4 destination port of the inner-match rule.	The valid range for L4 destination port number is 0 – 65535. This filed is valid only if the IP protocol is TCP or UDP. There are 4 methods to specify the L4 port: 1, eq (equal to) 2, lt (less than) 3, gt (greater than) 4, range Parameter “any” indicates packets with any L4 port can match this rule.
src-ip (IP_ADDR IP_ADDR_WILD | any | host IP_ADDR)	Specify the source IPv4 address of the inner-match rule.	Use an IPv4 address and an IPv4 address wildcard to specify a network (e.g. 192.168.1.1 0.0.0.255). If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv4 address to specify an exactly address. Use the parameter “any” to indicate packets with any source IPv4 address value can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

dst-ip (IP_ADDR IP_ADDR_WILD | any | host IP_ADDR)	Specify the destination IPv4 address of the inner-match rule.	Use an IPv4 address and an IPv4 address wildcard to specify a network (e.g. 192.168.1.1 0.0.0.255). If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv4 address to specify an exactly address. Use the parameter “any” to indicate packets with any destination IPv4 address value can match this rule.
src-ipv6 (IPv6_ADDR IPv6_ADDR_WILD | any | host IPv6_ADDR)	Specify the source IPv6 address of the inner-match rule.	Use an IPv6 address and an IPv6 address wildcard to specify a network. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv6 address to specify an exactly address. Use the parameter “any” to indicate packets with any source IPv6 address value can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

dst-ipv6 (IPv6_ADDR IPv6_ADDR_WILD | any | host IPv6_ADDR)	Specify the destination IPv6 address of the inner-match rule.	Use an IPv6 address and an IPv6 address wildcard to specify a network. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv6 address to specify an exactly address. Use the parameter “any” to indicate packets with any destination IPv6 address value can match this rule.
flow-label (FLOW_LABEL LABEL_WILD | any)	Specify the IPv6 Flow label of the inner-match rule.	Valid range for flow label is 0-1048575. Valid range for flow-label wildcard bits is 0x0-0xFFFFF Flow label value and wildcard bits both have 20bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates ipv6 packets with any flow label value can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

dscp DSCP_VALUE	Specify the DSCP in IPv4 packets value of the inner-match rule. DSCP = Differentiated Services Code Point. Specify the DSCP in IPv4 packets value of the inner-match rule. DSCP = Differentiated Services Code Point.	0-63
ip-precedence PRECEDENCE_VALUE	Specify the IP precedence in IPv4 packets of the inner-match rule. DSCP & ip precedence configurations are exclusive.	0-7
first-fragment	Match packets with first fragment	-
non-first-fragment	Match packets with non first fragment	-
non-fragment	Match packets with non fragment	-
non-or-first-fragment	Match packets with non first fragment	-
small-fragment	Match packets with small fragment	-
any-fragment	Match packets with any fragment	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

options	Match packets with IP options	-
vlan (VLAN_ID VLAN_WILD | any)	Specify the outer vlan id of the inner-match rule.	The valid range for vlan id is 0-4095. The valid range for vlan id wildcard bits is 0x0-0xFFF. Vlan id and wildcard bits both have 12bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any outer vlan id can match this rule.
inner-vlan (VLAN_ID VLAN_WILD | any)	Specify the inner vlan id of the inner-match rule.	The valid range for vlan id is 0-4095. The valid range for vlan id wildcard bits is 0x0-0xFFF. Vlan id and wildcard bits both have 12bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any inner vlan id can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

cos COS_ID	Specify the outer CoS value of the inner-match rule. CoS = Class of Service. Specify the outer CoS value of the inner-match rule. CoS = Class of Service.	0-7
inner-cos COS_ID	Specify the inner CoS value of the inner-match rule. CoS = Class of Service. Specify the inner CoS value of the inner-match rule. CoS = Class of Service.	0-7
ether-type (ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE | any)	Specify the ether-type of the inner-match rule.	The valid range for ether-type is 0x600-0xFFFF. The valid range for wildcard bits is 0x600-0xFFFF. Ether-type value and wildcard bits both have 16bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any ethertype value can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

src-mac (MATCH_MAC_ADDR MATCH_MAC_ADDR_WILD | any | host MATCH_MAC_ADDR)	Specify the source mac address in HHHH.HHHH.HHHH format.	Use a mac address and wildcard bits to specify a batch of mac addresses. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and a mac address to specify an exactly mac address. Use the parameter “any” to indicate packets with any source mac address value can match this rule.
dest-mac (MATCH_MAC_ADDR MATCH_MAC_ADDR_WILD | any| host MATCH_MAC_ADDR)	Specify the destination mac address in HHHH.HHHH.HHHH format.	Use a mac address and wildcard bits to specify a batch of mac addresses. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and a mac address to specify an exactly mac address. Use the parameter “any” to indicate packets with any destination mac address value can match this rule.

3 Command Mode

Inner-match Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

Wildcard bits in this command are used as reversed. That means value and wildcard bits have same length, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.

E.g.: ip address 10.10.10.0 wildcard 0.0.0.255 means 256 ip addresses from 10.10.10.0 to 10.10.10.255.

Layer 4 information (e.g. tcp/udp port) and fragment information are exclusive.

6 Examples

This example shows how to add an inner-match filter with sequence number 10 to im1:

```
Switch(config)# inner-match im1
Switch(config-inner-match-im1)# sequence-num 10 match any src-ip 10.10.10.0
0.0.0.255 dst-ip any
```

7 Related Commands

no sequence-num

Copyright © 2023 Garland Technology, LLC. All rights reserved.

8 ACL Commands

8.1 show interface egress ip access-list

1 Command Purpose

Use this command to show egress statistics of ip access-list on an interface.

2 Command Syntax

show interface egress ip access-list statistics *IF_NAME*

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name to show IP ACL statistics. This command supports physical or link aggregation interfaces.	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

The interface name must be specified.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

This example shows the egress ip access-list statistic of interface eth-0-1:

```
Switch# show interface egress ip access-list statistics eth-0-1

egress flow f2
sequence-num 10 permit tcp src-port range 10 200 src-ip any dst-ip any ( bytes 124
packets 1 )
(total bytes 124 total packets 1 )
```

7 Related Commands

clear interface egress ip access-list

8.2 clear interface egress ip access-list

1 Command Purpose

Use this command to clear egress statistics of ip access-list on an interface.

2 Command Syntax

clear interface egress ip access-list statistics *IF_NAME*

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name to clear IP ACL statistics. This command supports physical or link aggregation interfaces.	-

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

The interface name must be specified.

6 Examples

This example shows how to clear the egress ip access-list statistic of interface eth-0-1:

```
Switch# clear interface egress ip access-list statistics eth-0-1
```

This example shows the egress ip access-list statistic of interface eth-0-1:

```
Switch# show interface egress ip access-list statistics eth-0-1

egress flow f2
sequence-num 10 permit tcp src-port range 10 200 src-ip any dst-ip any ( bytes 0
packets 0 )
(total bytes 0 total packets 0 )
```

7 Related Commands

show interface egress ip access-list

8.3 show ip access-list

1 Command Purpose

Use this command to show the configuration of ip access-list.

2 Command Syntax

show ip access-list (*NAME_STRING* |)

Parameter	Parameter Description	Parameter Value
NAME_STRING	Ip access-list name	up to 20 characters

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

This example shows the configuration of ip access-list:

```
Switch# show ip access-list

ip access-list f2
 sequence-num 10 permit tcp src-port range 10 200 src-ip any dst-ip any
```

7 Related Commands

ip access-list

8.4 ip access-list

1 Command Purpose

Use this command to create IP ACL and then enter IP ACL configuration mode.

Use the no form of this command to delete the IP ACL.

2 Command Syntax

ip access-list *NAME_STRING*

no ip access-list *NAME_STRING*

Parameter	Parameter Description	Parameter Value
NAME_STRING	IP access-list name string	Begin with a-z/A-Z/0-9, valid characters are 0-9A-Za-z.-, and maximum length is 20 characters.

3 Command Mode

Global Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

If the system already has an IP ACL with the same name, this command will enter the IP ACL configuration mode

When the name is not used by any ACL, this command is to create the IP ACL firstly and then enter the IP ACL configuration mode.

6 Examples

This example shows how to create an IP ACL named f1 and then enter the IP ACL configuration mode:

```
Switch(config)# ip access-list f1
Switch(config-acl-f1)#
```

7 Related Commands

show ip access-list

8.5 remark

1 Command Purpose

Use this command to add remarks for the flow or ip access-list.

2 Command Syntax

remark *NAME_STRING*

no remark

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

NAME_STRING	Remark string for the IP ACL	Begin with a-z/A-Z/0-9, valid characters are 0-9A-Za-z.-, maximum length is 100 characters.

3 Command Mode

ACL Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to add a remark to describe the IP ACL:

```
Switch(config-acl-acl1)# remark acl1ipdeny
```

This example shows how to remove the remark:

```
Switch(config-acl-acl1)# no remark
```

7 Related Commands

show ip access-list

8.6 no sequence-num

1 Command Purpose

Use this command to delete a filter from ip access-list.

2 Command Syntax

no sequence-num *ACL_SEQ_NUM*

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
ACL_SEQ_NUM	Sequence-number with the valid range 1-65535.	1-65535

3 Command Mode

ACL Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to delete a flow filter with sequence number 10 from ip acl acl1:

```
Switch(config-acl-acl1)# no sequence-num 10
```

7 Related Commands

show ip access-list

sequence-num

8.7 sequence-num

1 Command Purpose

Use this command to permit or deny packets matching the ip access-list filter.

2 Command Syntax

(sequence-num *ACL_SEQ_NUM* |) (permit | deny) (*PROTOCOL_NUM* | any | mpls (any | label-num (any | *MPLS_LABEL_NUM_WITHOUT_0*) (mpls-label1 (any | *FLOW_LABEL_VALUE*) |) (mpls-label2 (any | *FLOW_LABEL_VALUE*) |) (mpls-label3 (any |

Copyright © 2023 Garland Technology, LLC. All rights reserved.

FLOW_LABEL_VALUE) |)) | pppoe ppp-type (ipv4 | ipv6) | tcp (src-port (range *L4_PORT_NUM L4_PORT_NUM* | eq *L4_PORT_NUM* | gt *L4_PORT_NUM* | lt *L4_PORT_NUM* | any) | dst-port (range *L4_PORT_NUM L4_PORT_NUM* | eq *L4_PORT_NUM* | gt *L4_PORT_NUM* | lt *L4_PORT_NUM* | any) | tcp-code (match-all | match-any) (ack | fin | psh | rst | syn | urg) |) | udp (src-port (range *L4_PORT_NUM1 L4_PORT_NUM2* | eq *L4_PORT_NUM* | gt *L4_PORT_NUM* | lt *L4_PORT_NUM* | any) | dst-port (range *L4_PORT_NUM1 L4_PORT_NUM2* | eq *L4_PORT_NUM* | gt *L4_PORT_NUM* | lt *L4_PORT_NUM* | any) |) | icmp | igmp) (src-ip (*IP_ADDR IP_ADDR_WILD* | any | host *IP_ADDR*) | src-ipv6 (*IPv6_ADDR IPv6_ADDR_WILD* | any | host *IPv6_ADDR*)) (dst-ip (*IP_ADDR IP_ADDR_WILD* | any | host *IP_ADDR*) | dst-ipv6 (*IPv6_ADDR IPv6_ADDR_WILD* | any | host *IPv6_ADDR*)) (flow-label (*FLOW_LABEL LABEL _WILD** | any) |) (dscp *DSCP_VALUE* | ip-precedence *PRECEDENCE_VALUE* |) (first-fragment | non-first-fragment | non-fragment | non-or-first-fragment | small-fragment | any-fragment |) (options |) (vlan (*VLAN_ID VLAN_WILD* | any) |) (inner-vlan (*VLAN_ID VLAN_WILD* | any) |) (cos *COS_ID* |) (inner-cos *COS_ID* |) (ether-type (*ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE* | any) |) (src-mac (*ACL_MAC_ADDR ACL_MAC_ADDR_WILD* | any | host *ACL_MAC_ADDR*) |) (dest-mac (*ACL_MAC_ADDR ACL_MAC_ADDR_WILD* | any | host *ACL_MAC_ADDR*) |) ((ipv4-head | l4-head) *UDF_VALUE UDF_VALUE_WILD UDF_OFFSET* |) | truncation (*LENGTH* |)

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

sequence-num ACL_SEQ_NUM	Specify a sequence number to create the acl rule.	The valid range for sequence number is 1-65535. If the sequence number is not specified, system should automatically assign one number according to the base number and the step length. The base number is the maximum number in the flow (0 for empty flow), the step length is 10.
permit	Specify the action of the acl rule. Use the parameter “permit” to indicate packets match this rule is allowed to forward.	-
deny	Specify the action of the acl rule. Use the parameter “deny” to indicate packets match this rule is not allowed to forward.	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

PROTOCOL_NUM | any | tcp | udp | icmp | igmp | gre | nvgre	Specify the IP protocol number of the acl rule.	The valid range for IP protocol number is 0-255. Well known IP protocols can also be specified by name. e.g. IP protocol 1 = icmp, 2 = igmp, 6 = tcp, 17 = udp, 47 = gre/nvgre (gre protocol 0x0800 = gre, 0x6558 = nvgre). Parameter “any” indicates packets with any IP protocol can match this rule.
mpls (any | label-num (any | MPLS_LABEL_NUM_WITHOUT_0) (mpls-label1 (any|FLOW_LABEL_VALUE) |) (mpls-label2 (any|FLOW_LABEL_VALUE) |) (mpls-label3 (any|FLOW_LABEL_VALUE) |))	Specify the mpls label of the flow rule.	The mpls label number is 0-9.It can match 3 layers of MPLS label values at most.
pppoe ppp-type (ipv4 | ipv6)	Specify the pppoe ppp-type of the flow rule.	The ppp-type is ipv4 or ipv6.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

src-port (range L4_PORT_NUM L4_PORT_NUM | eq L4_PORT_NUM | gt L4_PORT_NUM | lt L4_PORT_NUM | any)	Specify the layer 4 source port of the acl rule.	The valid range for L4 source port number is 0 – 65535. This filed is valid only if the IP protocol is TCP or UDP. There are 4 methods to specify the L4 port: 1, eq (equal to) 2, lt (less than) 3, gt (greater than) 4, range Parameter “any” indicates packets with any L4 port can match this rule.
dst-port (range L4_PORT_NUM L4_PORT_NUM | eq L4_PORT_NUM | gt L4_PORT_NUM | lt L4_PORT_NUM | any)	Specify the layer 4 destination port of the acl rule.	The valid range for L4 destination port number is 0 – 65535. This filed is valid only if the IP protocol is TCP or UDP. There are 4 methods to specify the L4 port: 1, eq (equal to) 2, lt (less than) 3, gt (greater than) 4, range Parameter “any” indicates packets with any L4 port can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

src-ip (IP_ADDR IP_ADDR_WILD | any | host IP_ADDR)	Specify the source IPv4 address of the acl rule.	Use an IPv4 address and an IPv4 address wildcard to specify a network (e.g. 192.168.1.1 0.0.0.255). If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv4 address to specify an exactly address. Use the parameter “any” to indicate packets with any source IPv4 address value can match this rule.
dst-ip (IP_ADDR IP_ADDR_WILD | any | host IP_ADDR)	Specify the destination IPv4 address of the acl rule.	Use an IPv4 address and an IPv4 address wildcard to specify a network (e.g. 192.168.1.1 0.0.0.255). If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv4 address to specify an exactly address. Use the parameter “any” to indicate packets with any destination IPv4 address value can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

src-ipv6 (IPv6_ADDR IPv6_ADDR_WILD | any | host IPv6_ADDR)	Specify the source IPv6 address of the acl rule.	Use an IPv6 address and an IPv6 address wildcard to specify a network. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv6 address to specify an exactly address. Use the parameter “any” to indicate packets with any source IPv6 address value can match this rule.
dst-ipv6 (IPv6_ADDR IPv6_ADDR_WILD | any | host IPv6_ADDR)	Specify the destination IPv6 address of the acl rule.	Use an IPv6 address and an IPv6 address wildcard to specify a network. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and an IPv6 address to specify an exactly address. Use the parameter “any” to indicate packets with any destination IPv6 address value can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

flow-label (FLOW_LABEL LABEL_WILD | any)	Specify the IPv6 Flow label of the acl rule.	Valid range for flow label is 0-1048575. Valid range for flow-label wildcard bits is 0x0-0xFFFFF Flow label value and wildcard bits both have 20bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates ipv6 packets with any flow label value can match this rule.
dscp DSCP_VALUE	Specify the DSCP in IPv4 packets value of the acl rule. DSCP = Differentiated Services Code Point. Specify the DSCP in IPv4 packets value of the acl rule. DSCP = Differentiated Services Code Point.	Valid range of DSCP value is 0 – 63.
ip-precedence PRECEDENCE_VALUE	Specify the IP precedence in IPv4 packets of the acl rule. DSCP & ip precedence configurations are exclusive	Valid range of IP precedence value is 0 – 7.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

first-fragment	Match packets with first fragment	-
non-first-fragment	Match packets with non first fragment	-
non-fragment	Match packets with non fragment	-
non-or-first-fragment	Match packets with non first fragment	-
small-fragment	Match packets with small fragment	-
any-fragment	Match packets with any fragment	-
options	Match packets with IP options	-
vlan (VLAN_ID VLAN_WILD | any)	Specify the outer vlan id of the acl rule.	The valid range for vlan id wildcard bits is 0x0-0xFFF. Vlan id and wildcard bits both have 12bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any outer vlan id can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

inner-vlan (VLAN_ID VLAN_WILD | any)	Specify the inner vlan id of the acl rule.	The valid range for vlan id is 0-4095. The valid range for vlan id wildcard bits is 0x0-0xFFF. Vlan id and wildcard bits both have 12bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any inner vlan id can match this rule.
cos COS_ID	Specify the outer CoS value of the acl rule. CoS = Class of Service. Specify the outer CoS value of the acl rule. CoS = Class of Service.	The valid range of Cos is 0 to 7.
inner-cos COS_ID	Specify the inner CoS value of the acl rule. CoS = Class of Service. Specify the inner CoS value of the acl rule. CoS = Class of Service.	The valid range of Cos is 0 to 7.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

ether-type (ETHER_TYPE_VALUE ETHER_TYPE_WILD_VALUE | any)	Specify the ether-type of the acl rule.	The valid range for wildcard bits is 0x600-0xFFFF. Ether-type value and wildcard bits both have 16bits, if a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Parameter “any” indicates packets with any ethertype value can match this rule.
src-mac (ACL_MAC_ADDR ACL_MAC_ADDR_WILD | any | host ACL_MAC_ADDR)	Specify the source mac address in HHHH.HHHH.HHHH format.	Use a mac address and wildcard bits to specify a batch of mac addresses. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and a mac address to specify an exactly mac address. Use the parameter “any” to indicate packets with any source mac address value can match this rule.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

dest-mac (ACL_MAC_ADDR ACL_MAC_ADDR_WILD | any| host ACL_MAC_ADDR)	Specify the destination mac address in HHHH.HHHH.HHHH format.	Use a mac address and wildcard bits to specify a batch of mac addresses. If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. Use the parameter “host” and a mac address to specify an exactly mac address. Use the parameter “any” to indicate packets with any destination mac address value can match this rule.
(ipv4-head | l4-head) UDF_VALUE UDF_VALUE_WILD UDF_OFFSET	UDF = User Define Format. The parameter “ipv4-head” indicates the packet is parsed at the beginning with the IPv4 header. The parameter “l4-head” indicates the packet is parsed at the beginning with the layer4 header.	Udf value and wildcard bits both have 32 bits, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored. The parameter “UDF_OFFSET” specifies the offset bits from the beginning. The valid range of the offset is 0 -60.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

truncation (LENGTH |)	Use this parameter to truncate the packets matched this rule.	set the packets length after truncation, support different truncation length is 14, the value between 64 and 144.The length of truncation is configured by the "truncation" command in global configuration mode , if not config it

3 Command Mode

ACL Configuration

4 Default

None

5 Usage

Wildcard bits in this command are used as reversed. That means value and wildcard bits have same length, If a bit in wildcard is 0 means this bit needs to check, otherwise this bit should be ignored.

E.g.: ip address 10.10.10.0 wildcard 0.0.0.255 means 256 ip addresses from 10.10.10.0 to 10.10.10.255.

Layer 4 information (e.g. tcp/udp port) and fragment information are exclusive.

6 Examples

Create a rule with sequence number 10:

```
Switch(config)# ip access-list acl1
Switch(config-acl-acl1)# sequence-num 10 permit any src-ip 10.10.10.0 0.0.0.255
dst-ip any
```

7 Related Commands

no sequence-num

Copyright © 2023 Garland Technology, LLC. All rights reserved.

show ip access-list

8.8 egress

1 Command Purpose

Use this command to apply IPv4 access list on the outbound direction of an interface

Use the no form of this command to remove the IPv4 access list.

2 Command Syntax

egress *NAME_STRING*

no egress

Parameter	Parameter Description	Parameter Value
NAME_STRING	IP access-list name string	IP access-list name string, which should begin with a-z/A-Z/0-9, valid characters are 0-9A-Za-z.-, maximum length is 20 characters.

3 Command Mode

Interface Configuration

4 Default

None

5 Usage

This command supports physical or link aggregation interfaces.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The example shows how to apply the access list f1 to egress direction eth-0-9:

```
Switch(config)# interface eth-0-19
Switch(config-if-eth-0-19)# egress f1
```

7 Related Commands

ip access-list

Copyright © 2023 Garland Technology, LLC. All rights reserved.

9 TAP Commands

9.1 tap-group

1 Command Purpose

Use this command to create a TAP group and enter the tap configuration mode.

Use the no form of this command to delete the TAP group.

2 Command Syntax

tap-group *TAPNAME* (*NUM* |)

no tap-group *TAPNAME*

Parameter	Parameter Description	Parameter Value
TAPNAME	Tap Group Name string	Begin with a-z/A-Z, valid characters are 0-9A-Za-z.-, maximum length is 20 characters.
NUM	Tap Group ID, range 1-10000	1-10000

3 Command Mode

Global Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

This device supports at most 512 TAP groups.

6 Examples

The following example shows how to add an egress-interface agg1:

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)#
```

The following example shows how to delete a tap-group:

```
Switch(config)# no tap-group tap1
```

7 Related Commands

show tap-group

9.2 description

1 Command Purpose

Use this command to set the description of the TAP group.

Use the no form of this command to delete the description.

2 Command Syntax

description *LINE*

no description

Parameter	Parameter Description	Parameter Value
LINE	TAP group description string	Begin with a-z/A-Z, valid characters are 0-9A-Za-z.-, maximum length is 80 characters

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

tap-group Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows how to config description:

```
Switch(config)# tap-group test001
Switch(config-tap-test001)# description test
Switch(config-tap-test001)#
```

7 Related Commands

tap-group

show tap-group

9.3 ingress

1 Command Purpose

Use this command to add a physical,link aggregation interface, iloop interface or port-group to the ingress direction of the TAP group.

This command can add/delete vlan and edit actions to the packets.

Use the no form of this command to remove the interface.

2 Command Syntax

ingress (*IF_NAME* | range *IF_NAME_LIST*) (un-tag | un-tag-outer-vlan | un-tag-inner-vlan | mark-source *VLAN_ID* |) (truncation |) (edit-macda *MAC_ADDRESS* |) (edit-macsa *MAC_ADDRESS* |) (edit-ipsa *IP_ADDRESS* |) (edit-ipda *IP_ADDRESS* |)

Copyright © 2023 Garland Technology, LLC. All rights reserved.

(edit-ipv6sa *IPv6_ADDRESS* |) (edit-ipv6da *IPv6_ADDRESS* |) (edit-vlan *VLAN_ID* |)

no ingress (*IF_NAME* | range *IF_NAME_LIST*)

ingress (*IF_NAME* | *PORTGROUP_NAME* | range *IF_NAME_LIST*) flow *FLOW_NAME*

no ingress (*IF_NAME* | *PORTGROUP_NAME* | range *IF_NAME_LIST*) flow *FLOW_NAME*

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name. This command supports physical interface,iloop interface or link aggregation interface.	-
PORTGROUP_NAME	Specify the name of port-group.	The first character should be a-z or A-Z, character only can be 0-9A-Za-z.-_ and the max len is 31.
range IF_NAME_LIST	Interface range, with "," or "-" to distinguish the interface range set.supports physical interface,and link aggregation interface.	The '-' is range interface symbol,The ',' is division symbol
un-tag	Remove vlan tags of the packets.	-
un-tag-outer-vlan	Remove outer vlan tag of the packets.	-
un-tag-inner-vlan	Remove inner vlan tag of the packets.	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

mark-source VLAN_ID	Specify additional outer vlan id of the outgoing packets.	Specify additional outer vlan id of the outgoing packets. The valid range for vlan id is 1 – 4094.
truncation	To truncate the packet.	-
edit-macda MAC_ADDRESS	Specify the destination mac address of the outgoing packets.	Specify the destination mac address of the outgoing packets in HHHH.HHHH.HHHH format.
edit-macsa MAC_ADDRESS	Specify the source mac address of the outgoing packets.	Specify the source mac address of the outgoing packets in HHHH.HHHH.HHHH format.。
edit-ipsa IP_ADDRESS	Specify the source IP address of the outgoing packets.	Specify the source IP address of the outgoing packets in A.B.C.D format.。
edit-ipda IP_ADDRESS	Specify the destination IP address of the outgoing packets.	Specify the destination IP address of the outgoing packets in A.B.C.D format.。
edit-vlan VLAN_ID	Specify the vlan id of the outgoing packets.	The valid range for vlan id is 1 – 4094.
edit-ipv6sa IPv6_ADDRESS	Specify the source IPv6 address of the outgoing packets.	::-ffff:ffff:ffff:ffff:ffff:ffff:ffff:ffff。

Copyright © 2023 Garland Technology, LLC. All rights reserved.

edit-ipv6da IPv6_ADDRESS	Specify the destination IPv6 address of the outgoing packets.	::-ffff:ffff:ffff:ffff:ffff:ffff:ffff:ffff。
flow FLOW_NAME	Specify the name of flow to apply to tap group's ingress direction.	-

3 Command Mode

tap-group Configuration

4 Default

None

5 Usage

One interface without configuring a flow can only add to one TAP group.

Same interface with and without configuring a flow cannot exist in one TAP group.

6 Examples

The following example shows how to add an ingress-interface with mark-source 100:

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress eth-0-1 mark-source 100
Switch(config-tap-tap1)#
```

The following example shows how to add an ingress-interface with un-tag:

```
Switch(config)# tap-group tap1
Switch(config-tap-test001)# ingress eth-0-1 un-tag
Switch(config-tap-test001)#
```

The following example shows how to add interface eth-0-1,eth-0-2,eth-0-4 :

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress range eth-0-1-2,eth-0-4
Switch(config-tap-tap1)#
```

The following example shows how to add an ingress-interface with flow flow001:

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress eth-0-1 flow flow001
Switch(config-tap-tap1)#
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

The following example shows how to add an ingress interface agg1:

```
Switch(config)# interface eth-0-2
Switch(config-if-eth-0-2)# static-channel-group 1
Switch(config-if-eth-0-2)# exit
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress agg1
```

The following example shows how to add an ingress interface agg1 with flow flow001:

```
Switch(config)# interface eth-0-2
Switch(config-if-eth-0-2)# static-channel-group 1
Switch(config-if-eth-0-2)# exit
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress agg1 flow flow001
```

The following example shows how to add an ingress interface iloop1:

```
Switch(config)# interface iloop1
Switch(config-if-iloop1)# exit
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress iloop1
```

The following example shows how to add an ingress interface iloop1 with flow flow001:

```
Switch(config)# interface iloop1
Switch(config-if-iloop1)# exit
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress iloop1 flow flow001
```

The following example shows how to add an ingress port-group portgroup1 with flow flow001:

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress portgroup1 flow flow001
```

7 Related Commands

tap-group

egress

9.4 egress

1 Command Purpose

Use this command to add a physical,link aggregation interface, iloop interface to the egress direction of the TAP group.

Use the no form of this command to remove the interface.

2 Command Syntax

egress (*IF_NAME* | range *IF_NAME_LIST*) (timestamp |)

Copyright © 2023 Garland Technology, LLC. All rights reserved.

no egress (*IF_NAME* | range *IF_NAME_LIST*)

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name. This command supports physical interface,link aggregation interface or iloop interface.	-
range IF_NAME_LIST	Interface range, with "," or "-" to distinguish the interface range set.supports physical interface,and link aggregation interface.	The '-' is range interface symbol,The ',' is division symbol
timestamp	Add timestamp for packets on egress interfaces.	-

3 Command Mode

tap-group Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows how to add an egress-interface eth-0-9:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# egress eth-0-9
```

The following example shows how to add interface eth-0-1,eth-0-2,eth-0-4 on egress dicection:

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# egress range eth-0-1-2,eth-0-4
Switch(config-tap-tap1)#
```

The following example shows how to add an egress-interface agg1:

```
Switch(config)# interface eth-0-10
Switch(config-if-eth-0-10)# static-channel-group 1
Switch(config)# interface eth-0-11
Switch(config-if-eth-0-11)# static-channel-group 1
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# egress agg1
```

The following example shows how to add an egress-interface iloop1:

```
Switch(config)# interface iloop1
Switch(config-if-iloop1)# exit
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# egress iloop1
```

7 Related Commands

tap-group

9.5 show tap-group

1 Command Purpose

This command displays the TAP group configurations.

2 Command Syntax

show tap-group (*TAPNAME* |)

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

TAPNAME	Specify a TAP group name to display. If the parameter "TAPNAME" is not specified, the command indicates that all TAP groups on this device should be displayed.	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows the configuration of tap-group:

```
Switch# show tap-group

truncation           : 144
timestamp-over-ether : 0000.0000.0000 0000.0000.0000 0x0000
TAP-group tap1
  ID: 1
  Ingress:
        eth-0-1       flow f1
  Egress:
        eth-0-9
TAP-group tap2
  ID: 2
  Ingress:
        eth-0-21
  Egress:
        eth-0-22
```

7 Related Commands

tap-group

ingress

Copyright © 2023 Garland Technology, LLC. All rights reserved.

10 TIMESTAMP Commands

10.1 timestamp-over-ether

1 Command Purpose

Use this command to configure the TAP timestamp outer header information.

Use the no form of this command to remove the TAP timestamp configuration.

2 Command Syntax

timestamp-over-ether *MAC_ADDR_DA MAC_ADDR_SA ETHTYPE_ID*

no timestamp-over-ether

Parameter	Parameter Description	Parameter Value
MAC_ADDR_DA	Ethernet destination MAC address	MAC address in HHHH.HHHH.HHHH format, valid range is 0.0.0-FFFF.FFFF.FFFF
MAC_ADDR_SA	Ethernet source MAC address	MAC address in HHHH.HHHH.HHHH format, valid range is 0.0.0-FFFF.FFFF.FFFF
ETHTYPE_ID	Ethertype in hexadecimal	range is [0x0-0xffff]

3 Command Mode

Global Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

TAP timestamp is global configuration. TAP timestamp MUST be configured before using the TAP groups.

6 Examples

The following example shows how to configure timestamp-over-ether:

```
Switch# configure terminal
Switch(config)# timestamp-over-ether 1.1.1 2.2.2 0xff12
```

The following example shows how add timestamp for packets going out from tap1/interface eth-0-10:

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress eth-0-1
Switch(config-tap-tap1)# egress eth-0-10 timestamp
Switch(config-tap-tap1)# exit
```

7 Related Commands

tap-group

egress

10.2 show timestamp sync

1 Command Purpose

Use this command configure to display timestamp sync information.

2 Command Syntax

show timestamp sync

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display timestamp information:

```
Switch# show timestamp sync

Sync Type         : Disabled
Sync Count        : 0
Last Sync Time    : Tue Sep 12 07:57:08 2017
```

7 Related Commands

timestamp sync

10.3 timestamp sync

1 Command Purpose

Use this command configure to timestamp sync.

Use the no form of this command to restore the default value.

2 Command Syntax

timestamp sync (systime | none)

no timestamp sync

Parameter	Parameter Description	Parameter Value
systime	Use the system time as time source.	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

none	Use the chip time as time source.	-

3 Command Mode

Global Configuration

4 Default

The default value is "none"

5 Usage

None

6 Examples

The following example shows how to config timestamp sync:

```
Switch(config)# timestamp sync systime
```

7 Related Commands

show timestamp sync

Copyright © 2023 Garland Technology, LLC. All rights reserved.

11 TRUNCATION Commands

11.1 truncation

1 Command Purpose

Use this command to configure the truncation length information.

Use the no form of this command to restore the default value.

2 Command Syntax

truncation *TRUNCATION_LEN*

no truncation

Parameter	Parameter Description	Parameter Value
TRUNCATION_LEN	Truncation length in bytes.	Valid range is 64-144.

3 Command Mode

Global Configuration

4 Default

144

5 Usage

CRC should be re-calculating after packet is truncated. The truncation length include CRC field.

6 Examples

The following example shows how to set truncation length as 64:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch(config)# truncation 64
```

The following example shows how to use truncation in TAP group:

```
Switch(config)# tap-group tap1
Switch(config-tap-tap1)# ingress eth-0-1 truncation
Switch(config-tap-tap1)# egress eth-0-10
```

7 Related Commands

tap-group

ingress

Copyright © 2023 Garland Technology, LLC. All rights reserved.

12 SSH Commands

12.1 ssh

1 Command Purpose

In privileged mode, use this command to log in remote ssh server.

2 Command Syntax

ssh -l *NAME_STRING* (-i *RSAKEYNAME* |) (-p *L4_PORT_NUM* |) (-v (1 | 2) |) (-c (3des | des | 3des-cbc | aes128-cbc | aes192-cbc | aes256-cbc) |) (-m (hmac-md5-128 | hmac-md5-96 | hmac-sha1-160 | hmac-sha1-96) |) (-o number-of-password-prompts *SSHPINPROMPTS* |) (mgmt-if |) (*IP_ADDR* | *STRING*)

Parameter	Parameter Description	Parameter Value
NAME_STRING	Login name	-
RSAKEYNAME	Specify key name	-
L4_PORT_NUM	Remote ssh server port	range is <0-65535>
SSHPINPROMPTS	Number of password prompts	range is <1-7>
IP_ADDR | STRING	Specify IP address of remote system /Specify hostname of remote system	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

Version default is 2

5 Usage

None

6 Examples

The following example shows how to establish connection by ssh:

```
Switch# ssh -l aaa 1.1.1.1
aaa@1.1.1.1's password:

Switch#
```

7 Related Commands

ip ssh server enable

12.2 ip ssh server enable

1 Command Purpose

In global mode, use this command to start ssh server.

2 Command Syntax

ip ssh server enable

3 Command Mode

Global Configuration

4 Default

Enabled

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example enables the SSH server:

```
Switch(config)# ip ssh server enable
```

7 Related Commands

ip ssh server disable

12.3 ip ssh server disable

1 Command Purpose

In global mode, use this command to disable ssh server.

2 Command Syntax

ip ssh server disable

3 Command Mode

Global Configuration

4 Default

Enabled

5 Usage

None

6 Examples

The following example disable the SSH server:

```
Switch(config)# ip ssh server disable
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

ip ssh server enable

12.4 ip ssh server version

1 Command Purpose

In global configuration mode, use this command to configure Secure Shell (SSH) version on your switch. And use the no form of this command to restore the default value.

2 Command Syntax

ip ssh server version (v1 | v2 | all)

no ip ssh server version

Parameter	Parameter Description	Parameter Value
v1	Support SSH version 1	-
v2	Support SSH version 2	-
all	Support SSH version 1 and 2	-

3 Command Mode

Global Configuration

4 Default

V2

5 Usage

SSH server and client will negotiate about the version when connecting. Server and client should select a higher version both supported.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to configure support SSH Version 1:

```
Switch(config)# ip ssh server version v1
```

The following example shows how to restore the default configuration:

```
Switch(config)# no ip ssh server version
```

7 Related Commands

show ip ssh server status

12.5 ip ssh server authentication-retries

1 Command Purpose

Use this command to set retry times when log in remote ssh server failed. Use the command in no format, could rest retry times to default value.

2 Command Syntax

ip ssh server authentication-retries *SSHAUTHRETRIES*

no ip ssh server authentication-retries

Parameter	Parameter Description	Parameter Value
SSHAUTHRETRIES	Retry times	Range is <1-6>

3 Command Mode

Global Configuration

4 Default

6

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following examples configures SSH authentication retry times on your switch:

```
Switch(config)# ip ssh server authentication-retries 3
```

The following examples restore SSH authentication retry times to the default value:

```
Switch(config)# no ip ssh server authentication-retries
```

7 Related Commands

show ip ssh server status

12.6 ip ssh server authentication-timeout

1 Command Purpose

In global configuration mode, use this command to configure Secure Shell (SSH) authentication timeout on your switch.

Use the no form of this command to restore the default value of Secure Shell (SSH) authentication timeout on your switch

2 Command Syntax

ip ssh server authentication-timeout *SSHAUTHTIMEOUT*

no ip ssh server authentication-timeout

Parameter	Parameter Description	Parameter Value
SSHAUTHTIMEOUT	Timeout seconds	Range is <1-120>, unit is seconds

3 Command Mode

Global Configuration

4 Default

120

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following examples configures SSH authentication timeout on your switch:

```
Switch(config)# ip ssh server authentication-timeout 100
```

The following examples restore SSH authentication timeout to default value:

```
Switch(config)# no ip ssh server authentication-timeout
```

7 Related Commands

show ip ssh server status

12.7 ip ssh server authentication-type

1 Command Purpose

In global configuration mode, use this command to configure Secure Shell (SSH) authentication type.

Use the no form of this command to restore the default value of Secure Shell (SSH) authentication type.

2 Command Syntax

ip ssh server authentication-type (all | (password | public-key | rsa))

no ip ssh server authentication-type

Parameter	Parameter Description	Parameter Value
all	Enable all authentication type	-
password	Enable password	-
public-key	Enable public key	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

rsa	Enable rsa	-

3 Command Mode

Global Configuration

4 Default

Public-key and password

5 Usage

When logging in using SSH, the authentication mode will be negotiated at the beginning of establishing connection reply.

6 Examples

The following example configures SSH authentication type to password:

```
Switch(config)# ip ssh server authentication-type password
```

The following example restore SSH authentication type to default value:

```
Switch(config)# no ip ssh server authentication-type
```

7 Related Commands

show ip ssh server status

12.8 ip ssh server rekey-interval

1 Command Purpose

In global configuration mode, use this command to configure Secure Shell (SSH) rekey interval.

Use the no form of this command to restore the default value of Secure Shell (SSH) rekey interval.

2 Command Syntax

ip ssh server rekey-interval *SSHREKEYINTVL*

no ip ssh server rekey-interval

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
SSHREKEYINTVL	Rekey interval in minutes	Range is <1-1440>

3 Command Mode

Global Configuration

4 Default

60

5 Usage

None

6 Examples

The following example configures SSH rekey interval to 30:

```
Switch(config)# ip ssh server rekey-interval 30
```

The following example restore SSH rekey interval to default value:

```
Switch(config)# no ip ssh server rekey-interval
```

7 Related Commands

show ip ssh server status

12.9 ip ssh server host-key

1 Command Purpose

In global configuration mode, use this command to configure Secure Shell (SSH) host-key.

Use the no form of this command to restore the default value of Secure Shell (SSH) host-key.

2 Command Syntax

ip ssh server host-key rsa key *RSAKEYNAME*

Copyright © 2023 Garland Technology, LLC. All rights reserved.

no ip ssh server host-key

Parameter	Parameter Description	Parameter Value
RSAKEYNAME	Key Name	=Y27

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Host-key is used to generate session when establish connection.

6 Examples

The following example shows how to configure SSH host key:

```
Switch(config)# ip ssh server host-key rsa key KEY1
```

The following example shows how to remove SSH host key:

```
Switch(config)# no ip ssh server host-key
```

7 Related Commands

show ip ssh server status

12.10 ip ssh server port

1 Command Purpose

Use this command to configure ssh service port.

2 Command Syntax

ip ssh server port *SERVICE_PORT*

Copyright © 2023 Garland Technology, LLC. All rights reserved.

no ip ssh server port

Parameter	Parameter Description	Parameter Value
SERVICE_PORT	port number	Range is 1025-65535

3 Command Mode

Global Configuration

4 Default

22

5 Usage

When change ssh service port, all users must be forced to disconnect.

6 Examples

The following example configures port number:

```
Switch# configure terminal
Switch(config)# ip ssh server port 2000
```

The following example recovers ssh port to default port:

```
Switch# configure terminal
Switch(config)# no ip ssh server port
```

7 Related Commands

None

12.11 show ip ssh server status

1 Command Purpose

In privileged mode, use this command to show information of SSH.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

show ip ssh server status

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows information of ssh server:

```
Switch# show ip ssh server status

 SSH server enabled
 Version: v2
 Authentication timeout: 33 second(s)
 Authentication retries: 6 time(s)
 Server key lifetime: 60 minute(s)
 Authentication type: password, public-key
```

7 Related Commands

ssh

Copyright © 2023 Garland Technology, LLC. All rights reserved.

13 LACP Commands

13.1 port-channel load-balance-mode

1 Command Purpose

Use this command to set port-channel load balance mode from static to round-robin. Use the no form of this command to set port-channel load balance mode to default static mode.

2 Command Syntax

port-channel *AGG_GID* load-balance-mode round-robin

no port-channel *AGG_GID* load-balance-mode

Parameter	Parameter Description	Parameter Value
AGG_GID	Channel group ID	Range is <1-55>

3 Command Mode

Global Configuration

4 Default

Disabled

5 Usage

None

6 Examples

The following example shows how to set port-channel load balance mode to round-robin:

```
Switch(config)# port-channel 9 load-balance-mode round-robin
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

The following example shows how to set port-channel load balance mode to the default:

```
Switch(config)# no port-channel 9 load-balance-mode
```

7 Related Commands

None

13.2 show channel-group

1 Command Purpose

Use show channel-group summary command to display a summary of all of the channel groups, or a specified channel group. Use show channel-group detail command to display detailed information of all of the channel groups, or a specified channel group. Use show channel-group port command to display port information of all of the channel groups, or a specified channel group.

2 Command Syntax

show channel-group (*AGG_GID* |) (summary | detail | port | backup-ports)

Parameter	Parameter Description	Parameter Value
AGG_GID	Channel group ID	Range is <1-55>

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to display detailed information of the channel group 10:

```
Switch# show channel-group 10 detail

Group: 10
----------------------------
  Mode          : switch
  Ports         : 2          Maxports : 16
  Bundle Ports  : 0
  Protocol      : static

  Port          : eth-0-3
  ----------------------------
    State         : Down Out-Bundle
    Channel group : 10
    Protocol      : static
    Port index    : 3

  Port          : eth-0-4
  ----------------------------
    State         : Down Out-Bundle
    Channel group : 10
    Protocol      : static
    Port index    : 4
```

The following example shows how to display information of all channel groups:

```
Switch# show channel-group summary

Flags:  s - suspend           T - standby
        w - wait              B - in Bundle
        R - Layer3            S - Layer2
        D - down/admin down   U - in use
Mode:  SLB   - static load balance
       DLB   - dynamic load balance
       RR    - round robin load balance
Aggregator Mode Protocol Ports
----------+----+--------+-----------------------------------------------------
agg5(SD)   SLB  Static   eth-0-5(D)
agg10(SD)  SLB  Static   eth-0-3(D)     eth-0-4(D)
```

The following example shows how to display information of the channel group 10:

```
Switch# show channel-group 10 summary

port-channel load-balance hash-arithmetic: xor
port-channel load-balance tunnel-hash-mode: both
Port-channel load-balance hash-field-select:
    src-ip dst-ip src-port-l4 dst-port-l4
Flags:  s - suspend           T - standby
        w - wait              B - in Bundle
        R - Layer3            S - Layer2
        D - down/admin down   U - in use
Mode:  SLB   - static load balance
       DLB   - dynamic load balance
       RR    - round robin load balance
Aggregator Mode Protocol Ports
----------+----+--------+-----------------------------------------------------
agg10(SD)  SLB  Static   eth-0-3(D)     eth-0-4(D)
```

7 Related Commands

static-channel-group

Copyright © 2023 Garland Technology, LLC. All rights reserved.

13.3 show channel-group interface

1 Command Purpose

Use this command to display link aggregation information for the port.

2 Command Syntax

show channel-group interface *IF_NAME*

Parameter	Parameter Description	Parameter Value
IF_NAME	Specify the interface name to show	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display link aggregation information for the specified port:

```
Switch# show channel-group interface eth-0-3

Port          : eth-0-3
----------------------------
  State         : Down Out-Bundle
  Channel group : 10
  Protocol      : static
  Port index    : 3
```

7 Related Commands

static-channel-group

Copyright © 2023 Garland Technology, LLC. All rights reserved.

14 NTP Commands

14.1 ntp minimum-distance

1 Command Purpose

In global configuration mode, use this command to configure the minimum distance between the switch and the NTP server.

Use the no form of this command to restore default ntp minimum distance configures.

2 Command Syntax

ntp minimum-distance *NTP_MIN_DISP*

no ntp minimum-distance

Parameter	Parameter Description	Parameter Value
NTP_MIN_DISP	Distance value time interval in milliseconds	Range is <1-1000>

3 Command Mode

Global Configuration

4 Default

1ms

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to configure minimum distance to 1000ms:

```
Switch(config)# ntp minimum-distance 1000
```

The following example shows how to configure minimum distance to default:

```
Switch(config)# no ntp minimum-distance
```

7 Related Commands

show ntp status

14.2 ntp server

1 Command Purpose

Use this command to allow the software clock to be synchronized by a Network Time Protocol (NTP) time server.

Use the no form of this command to delete the NTP server

2 Command Syntax

ntp server mgmt-if *IP_ADDR* (key *NTP_KEYID* |) (version *NTP_VERSION* |) (prefer |)

no ntp server *IP_ADDR*

Parameter	Parameter Description	Parameter Value
IP_ADDR	IP address of the time server or peer	-
NTP_KEYID	Authentication key to use when sending packets to this peer	Range is <1-64000>
NTP_VERSION	Defines the Network Time Protocol (NTP) version number	Range is <1-3>

Copyright © 2023 Garland Technology, LLC. All rights reserved.

prefer	Makes this peer the preferred peer that provides synchronization	-

3 Command Mode

Global Configuration

4 Default

Not synchronized with any NTP server

5 Usage

None

6 Examples

The following example shows how to configure ntp server ip as 172.16.22.44, the version of NTP as 2:

```
Switch(config)# ntp server mgmt-if 172.16.22.44 version 2
```

The following example shows how to remove ntp server:

```
Switch(config)# no ntp server 172.16.22.44
```

7 Related Commands

show ntp status

14.3 ntp authentication

1 Command Purpose

To enable NTP authentication, use the ntp authentication enable command. To disable the NTP authentication, use the ntp authentication disable command.

2 Command Syntax

ntp authentication (enable | disable)

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Global Configuration

4 Default

Disabled

5 Usage

When NTP authentication is enabled, the switch will synchronize the time with NTP servers with trusted key only.

For more information about trusted key, please see the "ntp trustedkey" command.

6 Examples

The following example shows how to enables NTP authentication:

```
Switch(config)# ntp authentication enable
```

7 Related Commands

show ntp

14.4 ntp key

1 Command Purpose

In global mode, use this command to create a value for a NTP key. And remove the value of the NTP key by the no form of the command

2 Command Syntax

ntp key *NTP_KEYID KEY_STRING*

no ntp key *NTP_KEYID*

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

NTP_KEYID	Authentication key ID	Range is <1-64000>
KEY_STRING	The value of the key	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows how to create a ntp key:

```
Switch(config)# ntp key 123 key123
```

The following example shows how to remove a ntp key:

```
Switch(config)# no ntp key 123
```

7 Related Commands

show ntp key

14.5 ntp trustedkey

1 Command Purpose

Use this command to authenticate the identity of a system to which Network Time Protocol (NTP) will synchronize.

Use the no form of this command to disable authentication of the identity of the system.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

ntp trustedkey *NTP_KEYID*

no ntp trustedkey *NTP_KEYID*

Parameter	Parameter Description	Parameter Value
NTP_KEYID	Authentication key to use when sending packets to this peer	Range is <1-64000>

3 Command Mode

Global Configuration

4 Default

None

5 Usage

If authentication is enabled, use this command to define one or more key numbers (corresponding to the keys defined with the ntp key command) that a peer NTP system must provide in its NTP packets, in order for this system to synchronize to it. This function provides protection against accidentally synchronizing the system to a system that is not trusted, because the other system must know the correct authentication key.

6 Examples

The following example shows how to configure the system to synchronize only to systems providing authentication key 123:

```
Switch(config)# ntp trustedkey 123
```

The following example shows how to disable authentication of the identity of the system:

```
Switch(config)# no ntp trustedkey 123
```

7 Related Commands

ntp key

Copyright © 2023 Garland Technology, LLC. All rights reserved.

14.6 show ntp

1 Command Purpose

In privileged mode, use this command to display NTP configuration.

2 Command Syntax

show ntp

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the NTP configurations :

```
Switch# show ntp

Unicast peer or server:
1.1.1.1 server
10.1.1.23 key 43 version 2 prefer server
10.10.25.8 server
172.16.22.44 version 2 server
192.16.22.44 version 2 server
Authentication: enabled
Local reference clock:
```

7 Related Commands

ntp server

Copyright © 2023 Garland Technology, LLC. All rights reserved.

14.7 show ntp status

1 Command Purpose

In privileged mode, use this command to display current NTP status.

2 Command Syntax

show ntp status

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display ntp status:

```
Switch# show ntp status

system peer          : 10.10.25.8
system peer mode     : client
leap indicator       : 00
stratum              : 5
precision            : -19
root distance        : 0.30511 s
minimum distance     : 0.00099 s
selection threshold  : 1.50000 s
root dispersion      : 0.28767 s
reference ID         : (10.10.25.8|)
reference time       : dd6e331f.6a9c7b92  Thu, Sep 21 2017 20:46:23.416
system flags         : auth monitor ntp kernel stats
jitter               : 0.000000 s
stability            : 18.062 ppm
broadcastdelay       : 3.000000 s
authdelay            : 0.000000 s
```

7 Related Commands

ntp minimum-distance

Copyright © 2023 Garland Technology, LLC. All rights reserved.

14.8 show ntp statistics

1 Command Purpose

In privileged mode, use this command to display ntp statistics.

2 Command Syntax

show ntp statistics

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display ntp statistics:

```
Switch# show ntp statistics

time since reset     :18748
receive buffers      :10
free receive buffers :9
used receive buffers :0
low water refills    :1
dropped packets      :0
ignored packets      :0
received packets     :333
packets sent         :545
packets not sent     :0
interrupts handled   :19081
received by int      :333
```

7 Related Commands

ntp server

clear ntp statistics

Copyright © 2023 Garland Technology, LLC. All rights reserved.

14.9 show ntp associations

1 Command Purpose

In privileged mode, use this command to display neighbor state of NTP.

2 Command Syntax

show ntp associations

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows the status of NTP associations:

```
Switch# show ntp associations

* synced,      + symmetric active mode, - symmetric passive mode,
= client mode, ^ broadcast mode,        ~ broadcast client mode
     remote           local      st poll reach  delay   offset    disp
==============================================================================
=172.16.22.44    169.254.2.1     16 1024    0 0.00000  0.000000 3.99217
=10.1.1.23       169.254.2.1     16 1024    0 0.00000  0.000000 3.99217
=192.16.22.44    169.254.2.1     16 1024    0 0.00000  0.000000 3.99217
*10.10.25.8      169.254.2.1      4  128  377 0.00031  0.067999 0.09810
=1.1.1.1         169.254.2.1     16 1024    0 0.00000  0.000000 3.99217
```

7 Related Commands

ntp server

Copyright © 2023 Garland Technology, LLC. All rights reserved.

14.10 show ntp key

1 Command Purpose

In privileged mode, use this command to display NTP key.

2 Command Syntax

show ntp key

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows the keys of NTP:

```
Switch# show ntp key

Current NTP key configuration:
-+-----+---------+-----------------------------------------
      43       key43
     123      key123
```

7 Related Commands

ntp key

14.11 clear ntp statistics

1 Command Purpose

In privileged mode, use this command to clear NTP statistics.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

clear ntp statistics

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to clear ntp statistics:

```
Switch# clear ntp statistics
```

7 Related Commands

show ntp statistics

Copyright © 2023 Garland Technology, LLC. All rights reserved.

15 NETWORK DIAGNOSIS Commands

15.1 ping

1 Command Purpose

Use this command to check whether a specific IPv4 address is available through management interface.

2 Command Syntax

ping mgmt-if (-b |) *WORD*

Parameter	Parameter Description	Parameter Value
mgmt-if	Send packet from management interface	-
-b	To check a broadcast address	-
WORD	Ping destination address	-

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to check whether 10.10.38.160 is available:

```
Switch# ping mgmt-if 10.10.38.160

PING 10.10.38.160 (10.10.38.160) 56(84) bytes of data.
64 bytes from 10.10.38.160: icmp_seq=1 ttl=64 time=0.513 ms
64 bytes from 10.10.38.160: icmp_seq=2 ttl=64 time=0.229 ms
64 bytes from 10.10.38.160: icmp_seq=3 ttl=64 time=0.261 ms
64 bytes from 10.10.38.160: icmp_seq=4 ttl=64 time=0.265 ms
64 bytes from 10.10.38.160: icmp_seq=5 ttl=64 time=0.387 ms

--- 10.10.38.160 ping statistics ---
5 packets transmitted, 5 received, 0% packet loss, time 3999ms
rtt min/avg/max/mdev = 0.229/0.331/0.513/0.105 ms
```

7 Related Commands

traceroute

15.2 traceroute

1 Command Purpose

Use this command to show the path from the current device to the destination device.

2 Command Syntax

traceroute mgmt-if *WORD*

Parameter	Parameter Description	Parameter Value
mgmt-if	Send packet from management interface	-
WORD	Traceroute destination address	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to show the path from current device to 10.108.1.29:

```
Switch# traceroute mgmt-if 10.108.1.29

traceroute to 10.108.1.29 (10.108.1.29), 30 hops max, 38 byte packets
 1  10.108.1.27 (10.108.1.27)  2998.076 ms !H  3000.361 ms !H  3007.748 ms !H
```

7 Related Commands

ping

Copyright © 2023 Garland Technology, LLC. All rights reserved.

16 MONITOR CAPTURE Commands

16.1 monitor-capture global

1 Command Purpose

Use this command to enter monitor-capture global mode.

2 Command Syntax

monitor-capture global

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows how to enter monitor-capture global:

```
Switch(config)# monitor-capture global
Switch(config-capture)#
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

16.2 monitor-capture packet

1 Command Purpose

Use this command to set monitor-capture attribute.

2 Command Syntax

monitor-capture packet ((length *LEN*) | (number *NUM*) | (time *TIME*))

Parameter	Parameter Description	Parameter Value
length LEN	The Truncation length of packet	64-144
number NUM	The total capture of monitor capture.Auto stop when capture assign packet number	1-1000
time TIME	The time of monitor capture packet,auto stop when time-out	1-120

3 Command Mode

Monitor-capture Configuration

4 Default

no-limit

5 Usage

None

6 Examples

The following example shows how to set monitor capture truncation length:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch(config)# monitor-capture global
Switch(config-capture)# monitor-capture packet length 64
```

The following example shows how to set total number of monitor capture packet :

```
Switch(config)# monitor-capture global
Switch(config-capture)# monitor-capture packet number 10
```

The following example shows how to set time of monitor capture :

```
Switch(config)# monitor-capture global
Switch(config-capture)# monitor-capture packet time 60
```

7 Related Commands

None

16.3 monitor-capture input

1 Command Purpose

Use this command to set capture source node on ingress direction

2 Command Syntax

monitor-capture input *IF_NAME* ((flow *FLOW_NAME*) |)

Parameter	Parameter Description	Parameter Value
IF_NAME	interface name, support phy port,agg port,port group	-
flow FLOW_NAME	flow name	-

3 Command Mode

Monitor-capture Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to set capture packet of input on interface eth-0-1 :

```
Switch(config)# monitor-capture global
Switch(config-capture)# monitor-capture input eth-0-1
```

The following example shows how to set capture packet of input on interface eth-0-1 and match flow1 rules:

```
Switch(config)# flow flow1
Switch(config-flow-flow1)# permit any src-ip host 1.1.1.1 dst-ip any
Switch(config-flow-flow1)# exit
Switch(config)# monitor-capture global
Switch(config-capture)# monitor-capture input eth-0-1 flow flow1
```

7 Related Commands

None

16.4 monitor-capture output

1 Command Purpose

Use this command to set capture source node on egress direction

2 Command Syntax

monitor-capture output *IF_NAME* ((access-list *ACL_NAME*) |)

Parameter	Parameter Description	Parameter Value
IF_NAME	interface name, support phy port,agg port.	-
access-list ACL_NAME	acl name	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Monitor-capture Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows how to set capture packet of output on interface eth-0-1 :

```
Switch(config)# monitor-capture global
Switch(config-capture)# monitor-capture output eth-0-1
```

The following example shows how to set capture packet of ouput on interface eth-0-1 and match acl1 rules:

```
Switch(config)#  ip access-list acl1
Switch(config-acl-acl1)# permit any src-ip host 1.1.1.1 dst-ip any
Switch(config-acl-acl1)# exit
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# egress acl1
Switch(config-if-eth-0-1)# exit
Switch(config)# monitor-capture global
Switch(config-capture)# monitor-capture output eth-0-1  access-list acl1
```

7 Related Commands

None

16.5 monitor-capture packet start

1 Command Purpose

Use this command to start monitor-capture

2 Command Syntax

monitor-capture packet start

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example show how to start monitor-capture:

```
Switch# monitor-capture packet start
```

7 Related Commands

None

16.6 monitor-capture packet stop

1 Command Purpose

Use this command to stop monitor-capture

2 Command Syntax

monitor-capture packet stop

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example show how to stop monitor-capture:

```
Switch# monitor-capture packet stop
```

7 Related Commands

None

16.7 monitor-capture packet restart

1 Command Purpose

Use this command to restart monitor-capture

2 Command Syntax

monitor-capture packet start

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example show how to restart monitor-capture:

```
Switch# monitor-capture packet restart
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

None

16.8 show monitor-capture packet

1 Command Purpose

Use this command to show capture packet

2 Command Syntax

show monitor-capture packet (all | *PACKET-ID*)

Parameter	Parameter Description	Parameter Value
all	show all packets	-
PACKET-ID	show the specified packet	1-1000

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example show all packet of monitor-capture:

```
Switch# show monitor-capture packet all

 ---------------------------------------
Packet     : 1
Source port: eth-0-1
MACDA:0000.0000.0002, MACSA:0000.0000.0001
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
VLAN Tag: 20, priority: 0
IPDA: 30.30.30.3, IPSA: 10.0.0.2
IPv4 Packet, IP Protocol is 0
Data length: 64
Data:
 0000 0000 0002 0000 0000 0001 8100 0014
 0800 4500 0044 0001 0000 4000 3497 0a00
 0002 1e1e 1e03 5858 5858 5858 5858 5858
 5858 5858 5858 5858 5858 5858 5858 5858
----------------------------------------
Packet     : 2
Source port: eth-0-1
MACDA:0000.0000.0002, MACSA:0000.0000.0001
VLAN Tag: 20, priority: 0
IPDA: 30.30.30.3, IPSA: 10.0.0.2
IPv4 Packet, IP Protocol is 0
Data length: 64
Data:
 0000 0000 0002 0000 0000 0001 8100 0014
 0800 4500 0044 0001 0000 4000 3497 0a00
 0002 1e1e 1e03 5858 5858 5858 5858 5858
 5858 5858 5858 5858 5858 5858 5858 5858
----------------------------------------
```

The following example show packet-id of capture packet:

```
Switch# show monitor-capture packet 1

 ----------------------------------------
Packet     : 1
Source port: port1
MACDA:0000.0000.0002, MACSA:0000.0000.0001
VLAN Tag: 20, priority: 0
IPDA: 30.30.30.3, IPSA: 10.0.0.2
IPv4 Packet, IP Protocol is 0
Data length: 64
Data:
 0000 0000 0002 0000 0000 0001 8100 0014
 0800 4500 0044 0001 0000 4000 3497 0a00
 0002 1e1e 1e03 5858 5858 5858 5858 5858
 5858 5858 5858 5858 5858 5858 5858 5858
```

7 Related Commands

None

16.9 clear monitor-capture packet all

1 Command Purpose

Use this command to clear monitor capture buffer.

2 Command Syntax

clear monitor-capture packet all

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to clear monitor-capture buffer:

```
Switch# clear monitor-capture packet all
```

7 Related Commands

None

16.10 show monitor-capture global

1 Command Purpose

Use this command to show monitor-capture global configuration

2 Command Syntax

show monitor-capture global

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows monitor-capture global configuration:

```
Switch# show monitor-capture global

Monitor-capture global information:
    monitor-capture number            : no-limit
    monitor-capture timeout           : no-limit
    monitor-capture length            : 64
    monitor-capture source-nodes:
      Input:
         eth-0-1
         eth-0-1          flow flow1
      Output:
         eth-0-1
         eth-0-1          access-list acl1
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

17 SYSLOG Commands

17.1 logging sync

1 Command Purpose

In privileged mode, use this command to write the log in the memory buffer to the syslog file in flash.

2 Command Syntax

logging sync

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following shows how to enable logging sync function:

```
Switch# logging sync
```

7 Related Commands

show logging buffer

Copyright © 2023 Garland Technology, LLC. All rights reserved.

17.2 logging buffer

1 Command Purpose

In global configuration mode, the command is used to set the number of logs saved by the system temporary buffer, and the default value is restored in the form of no of the command.

2 Command Syntax

logging buffer *CFGLOGLINES*

no logging buffer

Parameter	Parameter Description	Parameter Value
CFGLOGLINES	Log quantity	Range is <10-1000>

3 Command Mode

Global Configuration

4 Default

500

5 Usage

None

6 Examples

The following shows how to set logging buffer line number to 10:

```
Switch(config)# logging buffer 10
```

The following shows how to set logging buffer line number to default value:

```
Switch(config)# no logging buffer
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

show logging buffer

17.3 logging file

1 Command Purpose

In global configuration mode, use this command to set whether to write logs into log files.

2 Command Syntax

logging file (enable | disable)

Parameter	Parameter Description	Parameter Value
enable	Write log information into log files	-
disable	Cancel writing log information to log file	-

3 Command Mode

Global Configuration

4 Default

Enabled

5 Usage

Once enabled, the log writes the currently generated log to the flash:/syslogfile file every 10 minutes.

6 Examples

The following example shows how to enable logging file function:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch(config)# logging file enable
```

7 Related Commands

show logging

17.4 logging level file

1 Command Purpose

In global configuration mode, using this command to set the level of log information, logs above or equal to this level will be counted into log files. And

use the no form of this command to restore the default value.

2 Command Syntax

logging level file (*LOGSEVERITY* | emergency | alert | critical | error | warning | notice | information | debug)

no logging level file

Parameter	Parameter Description	Parameter Value
0 | emergency	System is unusable	-
1 | alert	Immediate action needed	-
2 | critical	Critical conditions	-
3 | error	Error conditions	-
4 | warning	Warning conditions	-
5 | notice	Normal but significant conditions	-
6 | information	Informational messages	-
7 | debug	Debugging messages	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

LOGSEVERITY	Severity level	Range is <0-7>

3 Command Mode

Global Configuration

4 Default

Warning

5 Usage

Use this command to set the level of log information. Log information above or equal to this level will be logged to the log file, while log information below this level will not be logged to the file. If debug is specified, all log messages will be logged to the log file.

6 Examples

The following example shows how to configure the log message level to error:

```
Switch(config)# logging level file error
```

The following example shows how to restore the default value of log message level:

```
Switch(config)# no logging level file
```

7 Related Commands

logging level module

17.5 logging level module

1 Command Purpose

In global configuration mode, use this command to set the level of log information sent to the terminal and entered into the buffer. Logs higher than or equal to this level will be displayed on the terminal. And use the no form of this command to restore the default value.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

logging level module (*LOGSEVERITY* | emergency | alert | critical | error | warning | notice | information | debug)

no logging level module

Parameter	Parameter Description	Parameter Value
0 | emergency	System is unusable	-
1 | alert	Immediate action needed	-
2 | critical	Critical conditions	-
3 | error	Error conditions	-
4 | warning	Warning conditions	-
5 | notice	Normal but significant conditions	-
6 | information	Informational messages	-
7 | debug	Debugging messages	-
LOGSEVERITY	Severity level.	Range is <0-7>

3 Command Mode

Global Configuration

4 Default

Debug

5 Usage

With this, the command sets the level of log information sent to the terminal and recorded to the buffer. Log messages above or equal to this level will be displayed to the terminal

Copyright © 2023 Garland Technology, LLC. All rights reserved.

and written to the log buffer, while those below this level will not be displayed at the terminal, nor will they be written to the log buffer.

6 Examples

The following example shows how to set logging level module to error:

```
Switch(config)# logging level module error
```

The following example shows how to restore the default value of logging level module:

```
Switch(config)# no logging level module
```

7 Related Commands

logging level file

17.6 logging timestamp

1 Command Purpose

In global configuration mode, the command is used to set the timestamp format of log information. And use the no form of this command to restore the default value.

2 Command Syntax

logging timestamp (date | bsd | iso | rfc3164 | rfc3339 | none)

no logging timestamp

Parameter	Parameter Description	Parameter Value
date	The time format displayed when using the date command	-
bsd	BSD style (RFC 3164)	-
iso	ISO style (RFC 3339)	-
rfc3164	RFC 3164 style (bsd)	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

rfc3339	RFC 3339 style (iso)	-
none	No timestamp	-

3 Command Mode

Global Configuration

4 Default

BSD

5 Usage

None

6 Examples

The following example shows how to set the log message timestamp format to RFC3164:

```
Switch(config)# logging timestamp rfc3164
```

The following example shows how to recovery log message timestamp format to default:

```
Switch(config)# no logging timestamp
```

7 Related Commands

show logging

17.7 logging server

1 Command Purpose

In global configuration mode, use this command to set whether to use a remote log server.

2 Command Syntax

logging server (enable | disable)

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
enable	Enable logging server	-
disable	Disable logging server	-

3 Command Mode

Global Configuration

4 Default

Disabled

5 Usage

None

6 Examples

The following example shows how to enable log server:

```
Switch(config)# logging server enable
```

7 Related Commands

show logging

17.8 logging server severity

1 Command Purpose

In global configuration mode, this command is used to set the log level sent to the remote log server. Logs above or equal to this level will be sent to the log server. And use the no form of this command to restore the default value.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

logging server severity (*LOGSEVERITY* | emergency | alert | critical | error | warning | notice | information | debug)

no logging server severity

Parameter	Parameter Description	Parameter Value
0 | emergency	System is unusable	-
1 | alert	Immediate action needed	-
2 | critical	Critical conditions	-
3 | error	Error conditions	-
4 | warning	Warning conditions	-
5 | notice	Normal but significant conditions	-
6 | information	Informational messages	-
7 | debug	Debugging messages	-
LOGSEVERITY	Severity level.	Range is <0-7>

3 Command Mode

Global Configuration

4 Default

Warning

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

This command is used to set the level of log information sent to the remote log server. Logs higher than or equal to this level will be sent to the log server. If the threshold value is debug, all log messages will be sent to the log server.

6 Examples

The following example shows how to set the level of log messages sent to remote log servers to be error, and information above or equal to the level of error will be sent to remote servers:

```
Switch(config)# logging server severity error
```

The following example shows how to recovery the level of log messages sent to remote log servers by default:

```
Switch(config)# no logging server severity
```

7 Related Commands

show logging

17.9 logging server facility

1 Command Purpose

In global configuration mode, use this command to configure the log daemon on the server.

And use the no form of this command to restore the default value.

2 Command Syntax

logging server facility (*LOGFAC* | auth | authpriv | cron | daemon | ftp | kern | local0 | local1 | local2 | local3 | local4 | local5 | local6 | local7 | lpr | mail | news | syslog | user | uucp)

no logging server facility

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

LOGFAC	Log facility-type	Range is <0-11> and <16-23>
4|auth	Authorization system	-
10|authpriv	Authorization private system	-
9|cron	Cron facility	-
3|daemon	System daemon	-
11|ftp	FTP system	-
0|kern	Kernel	-
local0-7	Reserved for locally defined messages	-
6|lpr	Line printer system	-
2|mail	Mail system	-
7|news	USENET news	-
5|syslog	System log	-
1|user	User	-
8|uucp	UNIX-to-UNIX	-

3 Command Mode

Global Configuration

4 Default

Local4

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to set logging server facility to local3:

```
Switch(config)# logging server facility local3
```

The following example shows how to set logging server facility to default:

```
Switch(config)# no logging server facility
```

7 Related Commands

show logging

17.10 logging server address

1 Command Purpose

In the global configuration mode, use this command to set the IP address of the log server. The switch can send the log information to this server. And use the no form of this command to delete the address.

2 Command Syntax

logging server address mgmt-if *IP_ADDR*

no logging server address mgmt-if *IP_ADDR*

Parameter	Parameter Description	Parameter Value
IP_ADDR	Remote server IP address	-

3 Command Mode

Global Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

In order for the switch to send the system log information to the log server correctly, make sure that the server is in its normal functional state.

6 Examples

The following example shows how to set the IP address of log server to 10.10.38.236:

```
Switch(config)# logging server address mgmt-if 10.10.38.236
```

The following example shows how to delete log server:

```
Switch(config)# no logging server address mgmt-if 10.10.38.236
```

7 Related Commands

logging server

17.11 logging merge

1 Command Purpose

When this function is enabled, the switch merges the same logs that appear in a specified period of time into one. During this period, the switch places the received logs in a temporary buffer of a specified size in the background. The size of this period can be specified by using the timeout parameter, and the size of the backstage temporary buffer can be specified by using fifo-size parameter.

2 Command Syntax

logging merge (enable | disable | timeout *MERGETIMEOUT* | fifo-size *MERGEFSIZE*)

no logging merge (timeout | fifo-size)

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

enable	Enable logging merge	-
disable	Disable logging merge	-
MERGEFSIZE	Set the size of the background log merge buffer in terms of entries, default 1024 entries	Range is <100-10240>
MERGETIMEOUT	For a specified period of time, the same logs that appear during that period are merged into one	Range is <1-300>, uint is seconds

3 Command Mode

Global Configuration

4 Default

Logging mergence is enabled. Timeout is 10.

Fifo-size is 1024.

5 Usage

The logging merge command merges all the same logs into one during a specified time range. During this time, the switch buffered these same logs. You can use the timeout keyword to set the time range, and use the fifo-size to set the buffer size.

6 Examples

The following example shows how to enable logging merge:

```
Switch(config)# logging merge enable
```

The following example shows how to set logging merge timeout to default value:

```
Switch(config)# no logging merge timeout
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

show logging

17.12 show logging

1 Command Purpose

In privileged mode, use this command to display the configuration of logging.

2 Command Syntax

show logging

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the configuration of logging:

```
Switch# show logging

Current logging configuration:
============================================================
logging buffer 500
logging timestamp bsd
logging file enable
logging level file warning
logging level module debug
logging server disable
logging server severity warning
logging server facility local4
logging merge disable
logging merge fifo-size 1024
logging merge timeout 10
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

logging buff

logging timestamp

logging file

logging level file

logging level module

logging server

logging server severity

logging server facility

logging merge

17.13 show logging buffer

1 Command Purpose

In privileged mode, use this command to show logging buffer messages.

2 Command Syntax

show logging buffer (*SYSLOGLINES* |)

Parameter	Parameter Description	Parameter Value
SYSLOGLINES	Specify the number of message(s)	(-1000..+1000)

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

By default, syslog lines are sorted in reverse chronological order, which means the newest syslog is on top.

6 Examples

The following example shows how to display logging buffer :

```
Switch# show logging buffer

Sep 14 08:59:16 Switch init-6: starting pid 27391, tty \'/dev/ttyS0\':
\'/usr/sbin/klish\'
Sep 14 08:59:16 Switch init-6: process \'/usr/sbin/klish\' (pid 27327) exited.
Scheduling for restart.
Sep 14 08:49:40 Switch APP-1: logout, vty 1, location 169.254.1.2, by telnet
Sep 14 08:49:16 Switch init-6: starting pid 27327, tty \'/dev/ttyS0\':
\'/usr/sbin/klish\'
Sep 14 08:49:16 Switch init-6: process \'/usr/sbin/klish\' (pid 27259) exited.
Scheduling for restart.
Sep 14 08:39:15 Switch init-6: starting pid 27259, tty \'/dev/ttyS0\':
\'/usr/sbin/klish\'
Sep 14 08:39:15 Switch init-6: process \'/usr/sbin/klish\' (pid 27167) exited.
Scheduling for restart.
Sep 14 08:37:48 Switch APP-6: ready to service
```

7 Related Commands

clear logging buffer

17.14 show logging buffer statistics

1 Command Purpose

In privileged mode, use this command to display the amount of information stored in the log buffer.

2 Command Syntax

show logging buffer statistics

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to display the statistics of logging buffer:

```
Switch# show logging buffer statistics

Logging buffer statistics:
------------------------------------------------------------
Total processed 314 entries
Total dropped 0 entries
Current have 50 entries
```

7 Related Commands

clear logging buffer

17.15 show logging levels

1 Command Purpose

In privileged mode, use this command to show the severity level information of logging.

2 Command Syntax

show logging levels

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to display the severity level information of logging:

```
Switch# show logging levels

Severity  Name         Note
============================================================
0         emergency    system is unusable
1         alert        action must be taken immediately
2         critical     critical conditions
3         error        error conditions
4         warning      warning conditions
5         notice       normal but significant condition
6         information  informational
7         debug        debug-level messages
```

7 Related Commands

logging level file

17.16 show logging facilities

1 Command Purpose

In privileged mode, use this command to display log daemon tool information.

2 Command Syntax

show logging facilities

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the facility information of logging:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch# show logging facilities

Logging facility information:
Facility  Name        Note
============================================================
0         kern        kernel messages
1         user        random user-level messages
2         mail        mail system
3         daemon      system daemons
4         auth        security/authorization messages
5         syslog      messages generated internally by syslogd
6         lpr         line printer subsystem
7         news        network news subsystem
8         uucp        UUCP subsystem
9         cron        clock daemon
10        authpriv    security/authorization messages (private)
11        ftp         ftp daemon
16        local0      reserved for local use 0
17        local1      reserved for local use 1
18        local2      reserved for local use 2
19        local3      reserved for local use 3
20        local4      reserved for local use 4
21        local5      reserved for local use 5
22        local6      reserved for local use 6
23        local7      reserved for local use 7
```

7 Related Commands

logging server facility

17.17 clear logging buffer

1 Command Purpose

In privileged mode, use this command to clear records in the log buffer.

2 Command Syntax

clear logging buffer

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to clear logging buffer:

```
Switch# clear logging buffer
```

7 Related Commands

show logging buffer

Copyright © 2023 Garland Technology, LLC. All rights reserved.

18 SNMP Commands

18.1 show snmp

1 Command Purpose

To display the services information of SNMP, use the show snmp command in privileged EXEC mode.

2 Command Syntax

show snmp

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the information of SNMP:

```
Switch# show snmp

Switch# show snmp
SNMP services: enable
```

7 Related Commands

snmp server enable

Copyright © 2023 Garland Technology, LLC. All rights reserved.

18.2 show snmp-server version

1 Command Purpose

To display the supported version of SNMP, use the show snmp-server version command in privileged EXEC mode.

2 Command Syntax

show snmp-server version

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the information of snmp-server version:

```
Switch# show snmp-server version
SNMP services: SNMPv1/SNMPv2c
```

7 Related Commands

snmp-server version

18.3 show snmp-server community

1 Command Purpose

To display the SNMP community information, use the show snmp-server community command in privileged EXEC mode.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

show snmp-server community

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the information of snmp-server community:

```
Switch # show snmp-server community

Community-Access   Community-String     Security-name
============================================================
read-write         sysname              comm1
```

7 Related Commands

snmp-server community

18.4 show snmp-server engineID

1 Command Purpose

To display the identification of the local Simple Network Management Protocol (SNMP) engine and all remote engines that have been configured on the router, use the show snmp-server engineID command in EXEC mode.

2 Command Syntax

show snmp-server *engineID*

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

An SNMP engine is a copy of SNMP that can reside on a local or remote device.

6 Examples

The following example shows how to display the information of engineID:

```
Switch# show snmp-server engineID

Engine ID   : 000000090200000000c025808
```

7 Related Commands

snmp-server engineID

18.5 show snmp-server sys-info

1 Command Purpose

To display the system information of SNMP, use the show snmp-server sys-info command in privileged EXEC mode.

2 Command Syntax

show snmp-server sys-info

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the information of snmp-server sys-info:

```
Switch# show snmp-server sys-info

Contact: admin@exampledomain.com
Location: Sample Place
```

7 Related Commands

snmp-server system-contact

snmp-server system-location

18.6 show snmp-server trap-receiver

1 Command Purpose

To display the SNMP traps receiver, use the show snmp-server trap-receiver command in privileged EXEC mode.

2 Command Syntax

show snmp-server trap-receiver

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to display the information of snmp-server trap-receiver:

```
Switch# show snmp-server trap-receiver

Target-ipaddress  mgmt-if udpport  version  pdu-type  community
================================================================
10.10.27.232      yes     162      v1       trap      sysname
10.10.27.232      yes     162      v2c      trap      sysname
```

7 Related Commands

snmp-server trap target-address

18.7 show snmp-server inform-receiver

1 Command Purpose

To display the SNMP informs receiver, use the show snmp-server inform-receiver command in privileged EXEC mode.

2 Command Syntax

show snmp-server inform-receiver

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to display the information of snmp-server inform-receiver:

```
Switch# show snmp-server inform-receiver

Target-ipaddress  mgmt-if udpport  version  pdu-type  community
================================================================
10.10.27.233      yes     162      v2c      inform    sysname
```

7 Related Commands

snmp-server inform target-address

18.8 show snmp-server view

1 Command Purpose

To display the family name, storage types, and status of a Simple Network Management Protocol (SNMP) configuration and associated MIB, use the show snmp-server view command in privileged EXEC mode.

2 Command Syntax

show snmp-server view (*USERNAME* |)

Parameter	Parameter Description	Parameter Value
USERNAME	Specify a view name that want to show, WORD	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to display the information of snmp-server view:

```
Switch# show snmp-server view

View-name                       View-type         Subtree
============================================================
a                               excluded          .1
a2                              included          .1.2
abc                             excluded          .1.3.6.2
_all_                           included          .0
_all_                           included          .1
_all_                           included          .2
_none_                          excluded          .0
_none_                          excluded          .1
_none_                          excluded          .2
```

7 Related Commands

snmp-server view

18.9 snmp-server enable

1 Command Purpose

To enable the SNMP function, use the snmp-server enable command in global configuration mode.

Use the no form of this command to disable the SNMP-server.

2 Command Syntax

snmp-server enable

no snmp-server enable

3 Command Mode

Global Configuration

4 Default

Disabled

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to set the snmp-server enable:

```
Switch(config)# snmp-server enable
```

The following example shows how to set the snmp-server disable:

```
Switch(config)# no snmp-server enable
```

7 Related Commands

show snmp

18.10 snmp-server engineID

1 Command Purpose

To specify the Simple Network Management Protocol (SNMP) engine ID on the local device, use the snmp-server engineID command in global configuration mode.

Use the no form of this command to restore the default value

2 Command Syntax

snmp-server *engineID ENGINEID*

no snmp-server *engineID*

Parameter	Parameter Description	Parameter Value
ENGINEID	octet string of hexadecimal characters	10-64 hexadecimal characters

3 Command Mode

Global Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

An SNMP engine ID is generated automatically but is not displayed or stored in the running configuration. Default engine ID is 30383038303830383038. You can display the default or configured engine ID by using the show snmp-server engineID command.

5 Usage

The SNMP engine ID is a unique string used to identify the device for administration purposes. You do not need to specify an engine ID for the device. For further details on the SNMP engine ID, see RFC 2571.

6 Examples

The following example shows how to set the snmp-server engineID:

```
Switch(config)# snmp-server engineID 1234567890
```

The following example shows how to delete the snmp-server engineID:

```
Switch(config)# no snmp-server engineID
```

7 Related Commands

show snmp-server engineID

18.11 snmp-server system-contact

1 Command Purpose

To set the system contact string, use the snmp-server system-contact command in global configuration mode.

Use the no form of this command to delete the contact string.

2 Command Syntax

snmp-server system-contact *KLINE*

no snmp-server system-contact

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
KLINE	Specify SNMP system contact parameter	Up to 255 characters, valid character is among “0-9A-Za-z.-_@*”

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows how to set the system contact string:

```
Switch(config)# snmp-server system-contact admin@example.com
```

The following example shows how to delete the system contact string:

```
Switch(config)# no snmp-server system-contact
```

7 Related Commands

show snmp-server sys-info

18.12 snmp-server system-location

1 Command Purpose

To set the system location string, use the snmp-server system-location command in global configuration mode.

Use the no form of this command to delete the location string.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

snmp-server system-location *KLINE*

no snmp-server system-location

Parameter	Parameter Description	Parameter Value
KLINE	Specify SNMP system location parameter	Up to 255 characters, valid character is among “0-9A-Za-z.-_@*”

3 Command Mode

Global Configuration

4 Default

None

5 Usage

This command is used to set the system location of the SNMP agent so that these descriptions can be accessed through the configuration file.

6 Examples

The following example shows how to set the system location string:

```
Switch(config)# snmp-server system-location Sample_Place
```

The following example shows how to remove the system location string:

```
Switch(config)# no snmp-server system-location
```

7 Related Commands

show snmp-server sys-info

Copyright © 2023 Garland Technology, LLC. All rights reserved.

18.13 snmp-server version

1 Command Purpose

To specify the support of SNMP version, use the snmp-server version command in global configuration mode.

Use the no form of this command to restore the default value.

2 Command Syntax

snmp-server version (all | v1 | v2c)

no snmp-server version

Parameter	Parameter Description	Parameter Value
all	Support all versions (v1, v2c, and v3)	-
v1	Support only v1 version	-
v2c	Support only v2c version	-

3 Command Mode

Global Configuration

4 Default

Support v1 and v2c SNMP versions.

5 Usage

None

6 Examples

The following example shows how to set SNMP -server to support all versions:

```
Switch(config)# snmp-server version all
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

The following example shows how to restore the SNMP -server to support default versions:

```
Switch(config)# no snmp-server version
```

7 Related Commands

show snmp-server version

18.14 snmp-server view

1 Command Purpose

To create or update a view entry, use the snmp-server view command in global configuration mode.

Use the no form of this command to delete the view.

2 Command Syntax

snmp-server view *SNMPNAME* (excluded | included) *SNMPSUBTREE* (mask *SNMPMASK*)

no snmp-server view *SNMPNAME* (excluded | included) *SNMPSUBTREE*

Parameter	Parameter Description	Parameter Value
SNMPNAME	Label for the view record that you are updating or creating. The name is used to reference the record	-
excluded	Configures the OID (and subtree OIDs) specified in sub-tree argument to be included in the SNMP view	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

included	Configures the OID (and subtree OIDs) specified in sub-tree argument to be explicitly excluded from the SNMP view	-
SNMPSUBTREE	Object identifier of the ASN.1 subtree to be included or excluded from the view	-
SNMPMASK	Define the subtree mask	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Other SNMP commands require an SNMP view as an argument. You use this command to create a view to be used as arguments for other commands.

6 Examples

The following example shows how to create a snmp-server view:

```
Switch(config)# snmp-server view abc excluded 1.3.6.2
```

The following example shows how to delete a snmp-server view:

```
Switch(config)# no snmp-server view abc excluded 1.3.6.2
```

7 Related Commands

show snmp-server view

Copyright © 2023 Garland Technology, LLC. All rights reserved.

18.15 snmp-server community

1 Command Purpose

To set up the community access string to permit access to the Simple Network Management Protocol (SNMP), use the snmp-server community command in global configuration mode.

Use the no form of this command to delete the community.

2 Command Syntax

snmp-server community *CONM_NAME* (read-only | read-write) (view *VIEW_NAME* |)

no snmp-server community *CONM_NAME*

Parameter	Parameter Description	Parameter Value
CONM_NAME	Specify a SNMP community name	A string with 1-256 characters. A blank means deny access.
read-only	Specifies read-only access. Authorized management stations can retrieve only MIB objects	-
read-write	Specifies read-write access. Authorized management stations can both retrieve and modify MIB objects	-
view VIEW_NAME	MIB view to which this community has access	-

3 Command Mode

Global Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

None

6 Examples

The following example shows how to create a community named test:

```
Switch(config)# snmp-server community test read-write
```

The following example shows how to delete the community:

```
Switch(config)# no snmp-server community test
```

7 Related Commands

show snmp-server community

18.16 snmp-server trap enable

1 Command Purpose

To enable all Simple Network Management Protocol (SNMP) notification types that are available on your system, use the snmp-server trap enable command in global configuration mode.

Use the no form of this command to disable the trap.

2 Command Syntax

snmp-server trap enable (all | coldstart | warmstart | linkdown | linkup)

no snmp-server trap enable (all | coldstart | warmstart | linkdown | linkup)

Parameter	Parameter Description	Parameter Value
all	Enable all traps	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

coldstart	Cold start traps	-
warmstart	Warm start traps	-
linkdown	Link down traps	-
linkup	Link up traps	-

3 Command Mode

Global Configuration

4 Default

Disabled

5 Usage

The snmp-server trap enable command is used in conjunction with the snmp-server trap target-address command. Use the snmp-server trap target-address command to specify which host or hosts receive SNMP notifications. To send notifications, you must configure at least one snmp-server trap target-address command.

6 Examples

The following example shows how to set all traps enable:

```
Switch(config)# snmp-server trap enable all
```

The following example shows how to set all traps disable:

```
Switch(config)# no snmp-server trap enable all
```

7 Related Commands

snmp-server trap target-address

Copyright © 2023 Garland Technology, LLC. All rights reserved.

18.17 snmp-server trap target-address

1 Command Purpose

To configure a remote trap management IP address, use the snmp-server target-address command in global configuration mode.

Use the no form of this command to delete the target address.

2 Command Syntax

snmp-server trap target-address mgmt-if *IP_ADDR* community *COMNAME* (udpport *UDP_PROT*)

no snmp-server trap target-address *IP_ADDR* community *COMNAME* (udpport *UDP_PROT*)

Parameter	Parameter Description	Parameter Value
IP_ADDR	Specify a SNMP IPV4 address	-
COMNAME	Specify a SNMP community name	-
UDP_PORT	The port number which area is 0 to 65535, the default is 162	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to set the trap target address to 169.254.2.2 and set the udp port to 13:

```
Switch(config)# snmp-server trap target-address mgmt-if 169.254.2.2 community test
udpport 13
```

The following example shows how to delete the trap target address:

```
Switch(config)# no snmp-server trap target-address mgmt-if 169.254.2.2 community
test udp 13
```

7 Related Commands

show snmp-server trap-receiver

18.18 snmp-server trap delay linkup

1 Command Purpose

To configure the trap delay linkup time, use the snmp-server trap delay linkup command in global configuration mode.

Use the no form of this command to restore the default value.

2 Command Syntax

snmp-server trap delay linkup *TRAP_DELAY_TIME*

no snmp-server trap delay linkup

Parameter	Parameter Description	Parameter Value
TRAP_DELAY_TIME	Linkup trap delay time	1-10 seconds

3 Command Mode

Global Configuration

4 Default

0

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to set the delay time to 10 seconds:

```
Switch(config)# snmp-server trap delay linkup 10
```

The following example shows how to restore the delay time to default value:

```
Switch(config)# no snmp-server trap delay linkup
```

7 Related Commands

snmp-server trap enable

18.19 snmp-server trap delay linkdown

1 Command Purpose

To configure the trap delay linkdown time, use the snmp-server trap delay linkdown command in global configuration mode.

Use the no form of this command to restore the default value.

2 Command Syntax

snmp-server trap delay linkdown *TRAP_DELAY_TIME*

no snmp-server trap delay linkdown

Parameter	Parameter Description	Parameter Value
TRAP_DELAY_TIME	Linkdown trap delay time	1-10 seconds

3 Command Mode

Global Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

0

5 Usage

None

6 Examples

The following example shows how to set the delay time to 10 seconds:

```
Switch(config)# snmp-server trap delay linkdown 10
```

The following example shows how to restore the delay time to default value:

```
Switch(config)# no snmp-server trap delay linkdown
```

7 Related Commands

snmp-server trap enable

18.20 snmp-server inform target-address

1 Command Purpose

To specify the recipient of a Simple Network Management Protocol (SNMP) inform message, use the snmp-server inform target-address command in global configuration mode.

Use the no form of this command to delete the configuration.

2 Command Syntax

snmp-server inform target-address mgmt-if *IP_ADDR* community *COMNAME* (udpport *UDP_PROT* |)

no snmp-server inform target-address *IP_ADDR* community *COMNAME* (udpport *UDP_PROT* |)

Parameter	Parameter Description	Parameter Value
IP_ADDR	Specify a SNMP IPV4 address	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

COMNAME	Specify a SNMP community name	-
UDP_PROT	The port number	The port number which area is 0 to 65535, the default is 162

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows how to set the target address for inform messages:

```
Switch(config)# snmp-server inform target-address 169.254.2.2 community test
udpport 100
```

The following example shows how to delete the target address for inform messages:

```
Switch(config)# no snmp-server inform target-address 169.254.2.2 community test
udpport 100
```

7 Related Commands

show snmp-server inform-receiver

18.21 snmp-server access-group

1 Command Purpose

Use this command to apply access list on Simple Network Management Protocol(SNMP).Use the no form of this command to remove access list applied to SNMP.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

snmp-server access-group *NAME_STRING* in

no snmp-server access-group

Parameter	Parameter Description	Parameter Value
NAME_STRING	IP ACL NAME	The initial character name should be a-z, A-Z, 0-9 or ._-, character only can be 0-9A-Za-z.-_ and the max length is 20

3 Command Mode

Global Configuration

4 Default

None

5 Usage

ACL applied on SNMP can only matching of source IP,destination IP, behaviour as WhiteList by default.

6 Examples

The following example shows how to apply acl to SNMP:

```
Switch(config)# ip access-list a5
Switch(config-ip-acl-a5)# exit
Switch(config)# snmp-server access-group a5 in
Notice: ACL applied on SNMP can only matching of source IP,destination IP,
behaviour as WhiteList by default.
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

19 AUTH Commands

19.1 show usernames

1 Command Purpose

Use this command to show local user account names on the switch.

2 Command Syntax

show usernames

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following is sample output from the show usernames command:

```
Switch# show usernames

Number   User name                        Privilege   Password   Rsa Key
--------+--------------------------------+-----------+----------+-------
1        admin                            4           *
2        test                             4           *
Switch#
```

7 Related Commands

username

Copyright © 2023 Garland Technology, LLC. All rights reserved.

19.2 show users

1 Command Purpose

Use this command to display information about terminal lines.

2 Command Syntax

show users

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following is sample output from the show users command:

```
Switch# show users

Line           Host(s)     Idle       Location        User
---------------+-----------+----------+---------------+----------
 130 vty  0     idle        2d20h16m   Local
 131 vty  1     idle        20:42:32   10.10.25.25
*132 vty  2     idle        00:00:00   10.10.25.25
```

7 Related Commands

show usernames

19.3 show web users

1 Command Purpose

Use this command to display information of the web users。

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

show web users

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following is sample to show web users:

```
Switch# show web users

Session Id                        Expire Time         Client IP       User Name
--------------------------------+-------------------+---------------+-----------
320570bf7624e99f9c01912e82c4515b 2017-01-05 00:53:15 10.10.22.236    admin
```

7 Related Commands

username

19.4 show privilege

1 Command Purpose

Use this command to display the current privilege.

2 Command Syntax

show privilege

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display current privilege:

```
Switch# show privilege

Current privilege level is 4
```

7 Related Commands

username

19.5 clear line console 0

1 Command Purpose

Use this command to clear primary console terminal line login.

2 Command Syntax

clear line console 0

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following is sample to clear line console 0:

```
Switch# clear line console 0
[OK]
```

7 Related Commands

line console

19.6 clear line vty

1 Command Purpose

Use this command to clear virtual terminal line login. Line number range is 0 to 7.

2 Command Syntax

clear line vty *VTYID1* (*VTYID2* |)

Parameter	Parameter Description	Parameter Value
VTYID1	First Line number	0-7
VTYID2	Last Line number	0-7

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following is sample to clear virtual terminal line from 4 to 7:

```
Switch# clear line vty 4 7
[OK]
```

7 Related Commands

show users

19.7 clear web session

1 Command Purpose

Use this command to clear web sessions.

2 Command Syntax

clear web session (all | *WEBSESSION*)

Parameter	Parameter Description	Parameter Value
all	Clear all sessions	-
WEBSESSION	Session Name	-

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following is sample to clear all web sessions:

```
Switch# clear web session all

[OK]
```

7 Related Commands

show web users

19.8 show console

1 Command Purpose

Use this command to show the current console configuration.

2 Command Syntax

show console

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following is sample output from the show console command:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch# show console

Current console configuration:
-------------------------------------------------------------
line console 0
 speed 115200
 parity none
 databits 8
 stopbits 1
 exec-timeout 10 0
 privilege level 4
 no line-password
 no login
```

7 Related Commands

line console

19.9 show vty

1 Command Purpose

Use this command to show the current vty configuration.

2 Command Syntax

show vty

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following is sample output from the show vty command:

```
Switch# show vty

line vty maximum 8
line vty 0 7
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
exec-timeout 35791 0
privilege level 4
no line-password
no login
```

7 Related Commands

line vty

19.10 show rsa keys

1 Command Purpose

Use this command to show RSA key information.

2 Command Syntax

show rsa keys

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following is sample to show RSA key:

```
Switch# show rsa keys

Current RSA key configuration:
Name                              Type     Usage   Modulus
--------------------------------+--------+-------+---------
abc                               private  0       1024
importkey                         public   1       1024
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

rsa key

19.11 show rsa key

1 Command Purpose

Use this command to show RSA key information.

2 Command Syntax

show rsa key *RSAKEYNAME* (der | pem (3des *RSAPASSWORD* | aes128 *RSAPASSWORD* | aes192 *RSAPASSWORD* | aes256 *RSAPASSWORD* | des *RSAPASSWORD* |) |)

Parameter	Parameter Description	Parameter Value
RSAKEYNAME	Key name	-
der	Certificate of der	-
pem	Certificate of pem	-
3des	Treble encryption standard	-
des	Data encryption standard	-
Aes128	Advanced encryption standard 128 bit	-
Aes192	Advanced encryption standard 192 bit	-
Aes256	Advanced encryption standard 256 bit	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

RSAPASSWORD	Passphrase used to protect the private key (length should >= 6)	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following is sample to show RSA key:

```
Switch# show rsa key abc

RSA key information:
-------------------------------------------------------------
Name: abc
Type: private
Modulus: 1024 bit
Usage count: 0
Private key DER code:
  30820258
    0201
      00
    028180
      D4E93929 20C1014D D9C64EF3 A8AB905D FDCF2D08 6DEFAC26 691D3168 E4C2F812
      394390A1 A1D648BF 50DE534D 718FF606 69DDC302 F005FBC6 A3A3E616 4A9EEF47
      9093AD9B 42F436A8 71C3C8D2 ECF14DD1 EEEC83AF 9EC5DF87 832A072F 5C02D463
      515753C2 EC610B25 4228B7F0 D9E99DF7 9AD011B5 7BA49B7F 1B838AA9 D92003CB
    0203
      010001
    028180
      2B45DBA0 484FF1FB E8AF2D8C C853565C 4421BF7D 5F1ABF5A 6F32C7C0 11FEAE7C
      C5B6BDC6 9C25F953 291486C9 CEB2FBC6 01EE589C 583C5F17 D85A8F81 28597538
      2F710C05 E9E4CAF9 A1639486 DF19DF70 69246C57 09570697 14C283EE 50786669
      99483E8B A35129CC 61655216 859740C7 7D5E0610 460A265B BB97F546 9C6ED981
    0240
      F06C6D70 F348C0F8 5A6CFB99 215A04FB 9C9E295E 93BE6D9F 5FCBFF93 1EE3C6E8
      B85B2E5C 98F51B66 74B35957 38896051 CCBD6875 A34AF5B7 71BC4FA1 6E448303
    0240
      E2B47BD7 7A5C7D8F 41FB8311 BFE43080 0DF24D7D 0FADCECF 7921975A A7B28623
      1E19AB8D 57F12487 B284D4EA AA2EC370 06DB170F F2E72B96 1DF1F51A 38523D99
    0240
      098D855B B38EF47B E9BBE2D3 56CBE8DE C67E524E 7BB8594A B7D7B733 F54A3FA1
      079237E9 5DFA7F38 36F2D95D E9D52B8A 9484021E 8A7A7400 F1F7F582 088B9859
    0240
      9FD333F7 CE990420 0A1981E6 F28CB230 A5246CC2 BD5A0092 3E489346 E33135E5
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
      EE2394D1 39ED949E 6219C96D 82FB22E7 88BDCEBD 7CB6C300 BB2DC869 6AC97809
    0240
      BEFEFE99 CDBB2AAB BA1EB81B 7B189124 B73700BD 3F40B23A AAE648A4 CF07E99E
      58261516 C58A1468 5603B90B 24CFD0FC 2609C215 E30375CA 0764FF71 1BF434FF
Public key DER code:
  308188
    028180
      D4E93929 20C1014D D9C64EF3 A8AB905D FDCF2D08 6DEFAC26 691D3168 E4C2F812
      394390A1 A1D648BF 50DE534D 718FF606 69DDC302 F005FBC6 A3A3E616 4A9EEF47
      9093AD9B 42F436A8 71C3C8D2 ECF14DD1 EEEC83AF 9EC5DF87 832A072F 5C02D463
      515753C2 EC610B25 4228B7F0 D9E99DF7 9AD011B5 7BA49B7F 1B838AA9 D92003CB
    0203
      010001
```

7 Related Commands

rsa key

19.12 show key config

1 Command Purpose

Use this command to display the details of the current key configuration.

2 Command Syntax

show key config

3 Command Mode

Rsa Key Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the current key configuration:

```
Switch(config-rsa-key)# show key config

Current key configuration:
  key type: private
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
key format: pem
key password: unspecified
```

7 Related Commands

rsa key

19.13 show key string

1 Command Purpose

Use this command to display the details of the current key string.

2 Command Syntax

show key string

3 Command Mode

Rsa Key Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the current key string:

```
Switch(config)# rsa key a

Modify private key a
Switch(config-rsa-key)# show key string
Current key string:
  30820258
    0201
      00
    028180
      AD4F1364 4F46C9F9 25D7BA98 B7F266A4 F3448E83 71D51F84 EF225E90 7D0117F0
      CD81012F 50944BF3 17A5CA56 7A2DC3D2 6A33CD52 6FD2DBE3 442C6546 DC3DD48A
      D8A4020C 2333F039 53FD39DE 01E5038B F1B59E7A 5B355FA2 26148F58 48C16D89
      36828C61 00A518CD F7EEBFBF 68CDB456 DC08BF5F 550A1273 28EF8E7C 0469634F
    0203
      010001
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
    028180
      9321ACDE DE06C4F5 45D14DD2 D5676F08 DE95F73F 546690E9 B472C341 7B3E706A
      B8ACAAAA D687EFAA A30AD72A 6F7366E9 BDCBD8A6 01D54B64 37BE5104 C579A074
      1206CD3C 70BA5E26 D22F0049 EABBCAA3 8AAAA932 C28DF32B 1C75EF5C 0052751C
      A5BA0D06 B0F9E6D2 9FE9281D FE2976C9 6C1A3288 590EB014 311AE5E2 0514AE41
    0240
      D8F10ACD BA5EA745 A5C52F61 19498B76 C181D0A0 F1CA197B C3E5204A 09206E1E
      B5217249 B595CA01 EBF82649 B272511C 8AD5138C 553717CD 4120D026 5D8CAE51
    0240
      CC82FA9D 866C95FA AE967B81 C343F9E0 2D41B59F 45C41197 28F37B3B 0C09D7B6
      4867858D 73876AEF 7692CCC6 A7A51A6C 8A1C62E6 FF75E209 75D02A51 E2346F9F
    0240
      943B3F52 8B0199F1 F0EEE70C C5A686F0 C20FDD69 DB4C6855 34E91E42 F8317C8C
      E6DECFA4 A5BA8FA8 F87F3A4A 28F00B94 2118AE9E B8AB484C 2B302C89 CA6A11C1
    0240
      3F15C828 FF664F7D 5C8D9EDB 90584FA4 0F51CDAC ABE0A76C 717D69ED F4F0B451
      CE53E0A6 9994942F F9EB9EAF 48D76D27 3E13338E FE0E6703 740C1A81 D7BD4511
    0240
      90D784A0 EBF913CE 82A19E91 4A0C5437 120C758F F9C94932 919A36B5 5BB01C76
      7460665E 6A1E8227 1BF592D3 650FCE6A DE22C1CB FCCA9433 A2FA142C D9D75CC9
Switch(config-rsa-key)#
```

7 Related Commands

rsa key

19.14 show tacacs

1 Command Purpose

Use this command to display information about TACACS+ server's configurations.

2 Command Syntax

show tacacs

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following is sample output from the show tacacs command:

```
Switch# show tacacs

============================================================
Host             Port  Timeout Retries Dead Secret
============================================================
2.1.1.1          49    5       3       0    mykey
```

7 Related Commands

tacacs-server host

19.15 show aaa status

1 Command Purpose

Use this command to show authentication, authorization, accounting (AAA) status.

2 Command Syntax

show aaa status

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to show authentication, authorization, accounting status:

```
Switch# show aaa status

AAA status:
     Authentication enable
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

aaa new-model

19.16 show aaa privilege mapping

1 Command Purpose

Use this command to show privilege mapping relationship with server privilege.

2 Command Syntax

show aaa privilege mapping

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to show privilege mapping relationship:

```
Switch# show aaa privilege mapping

    Server     Switch     Server
=======================================
         0          1          0
         1          2          1
      2~10          3         10
     11~15          4         15
```

7 Related Commands

aaa privilege mapping

Copyright © 2023 Garland Technology, LLC. All rights reserved.

19.17 show aaa method-lists

1 Command Purpose

Use this command to show authentication, authorization, accounting (AAA) authentication method lists.

2 Command Syntax

show aaa method-lists authentication (accounting | all | authentication | authorization)

Parameter	Parameter Description	Parameter Value
accounting	Accounting information	-
all	All information	-
authentication	Authentication information	-
authorization	Authorization information	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to show authentication method lists:

```
Switch# show aaa method-lists all

Authen queue = AAA_ML_AUTHEN_LOGIN
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
   Name = default   state = ALIVE: local radius none
Author queue = AAA_ML_AUTHOR_SHELL
   Name = default   state = ALIVE: tacplus none
Account queue = AAA_ML_ACCT_SHELL
   Name = default   state = ALIVE: none
Account queue = AAA_ML_ACCT_COMMAND
   Name = default   state = ALIVE: none
```

7 Related Commands

aaa authentication login

aaa authentication exec

aaa accounting exec

19.18 line console

1 Command Purpose

Use this command to set console configuration.

2 Command Syntax

line console 0

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

6 Examples

The following is an example of configure to line console 0:

```
Switch(config)# line console 0
Switch(config-line)#
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

show console

19.19 line vty

1 Command Purpose

Use line vty command to set virtual terminal line configuration.

2 Command Syntax

line vty *VTYID1* (*VTYID2* |)

Parameter	Parameter Description	Parameter Value
VTYID1	First Line number	0-7
VTYID2	Last Line number	0-7

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

6 Examples

The following is an example of configure to virtual terminal line 4 to 7:

```
Switch(config)# line vty 4 7
Switch(config-line)#
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

show vty

19.20 line vty maximum

1 Command Purpose

Use line vty maximum command to set maximum vty users.

Use the no form of this command to set maximum vty users to it default value.

2 Command Syntax

line vty maximum *VTYMAX*

no line vty maximum

Parameter	Parameter Description	Parameter Value
VTYMAX	Max Line number	0-8. default is 8

3 Command Mode

Global Configuration

4 Default

8

5 Usage

None

6 Examples

The following is an example of configure to three vty users:

```
Switch(config)# line vty maximum 3
```

The following is an example to reset maximum vty users:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch(config)# no line vty maximum
```

7 Related Commands

show line vty

19.21 rsa key generate

1 Command Purpose

Use this command to create a key.

Use the no form of this command to delete the key.

2 Command Syntax

rsa key *RSAKEYNAME* generate (*RSAKEYBITS* |)

no rsa key *RSAKEYNAME*

Parameter	Parameter Description	Parameter Value
RSAKEYNAME	Key name	String begin with [a-zA-Z],valid character is among [0-9A-Za-z.-_], up to 255 characters.
RSAKEYBITS	RSA key bits number	768-4096,default is 1024

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example creates a key named test， length is 768:

```
Switch(config)# rsa key test generate 768

Generating RSA private key, 768 bit long modulus
Please waiting for a moment: done!
Public exponent is 65537 (0x10001)
Generate RSA key successfully
```

The following example deletes the key:

```
Switch(config)# no rsa key test
```

7 Related Commands

show rsa key

rsa key

19.22 rsa key import

1 Command Purpose

Use this command to import a key.

2 Command Syntax

rsa key *RSAKEYNAME* import mgmt-if url *STRING* (private | public) (der | der-hex | pem (*PASSPHRASE* |) | ssh1 (*PASSPHRASE* |) | ssh2 (*PASSPHRASE* |))

Parameter	Parameter Description	Parameter Value
RSAKEYNAME	Key name	-
STRING	The url to save the key file	-
private	Import from private key	-
public	Import from public key	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

der | der-hex | pem | ssh1 | ssh2	The format of the key to import	-
PASSPHRASE	Encrypt the key string	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

6 Examples

The following example imports a key:

```
Switch(config)# rsa key importnewk import mgmt-if url tftp://10.10.38.160/newk.pub
public ssh2

Download from URL to temporary file.
Get file from tftp://10.10.38.160/newk.pub
.
Received 212 bytes in 0.1 seconds
Copy the temporary file to its destination.
.
File system synchronization. Please waiting...
212 bytes in 0.1 seconds, 2 kbytes/second
% Import RSA key successed
```

7 Related Commands

rsa key generate

rsa key export

19.23 rsa key export

1 Command Purpose

Use this command to export a key.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

rsa key *RSAKEYNAME* export mgmt-if url *STRING* (private | public) (der | der-hex | pem ((3des | aes128 | aes192 | aes256 | des) *PASSPHRASE* |) | ssh1 (3des *PASSPHRASE* |) | ssh2 (3des *PASSPHRASE* |))

Parameter	Parameter Description	Parameter Value
RSAKEYNAME	Key name	-
STRING	The url to save the key file	-
private	Export to private key	-
public	Export to public key	-
der | der-hex | pem | ssh1 | ssh2	The format of the key to export	-
3des | aes128 | aes192 | aes256 | des	The encryption transmission algorithm of the exported key file.	-
PASSPHRASE	Encrypt the key string	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example exports a key:

```
Switch(config)# rsa key newk export mgmt-if url tftp://10.10.38.160/newk.pub
public ssh2

Send file to tftp://10.10.38.160/newk.pub
.
Sent 212 bytes in 0.0 seconds
% Export RSA key success
```

7 Related Commands

rsa key generate

rsa key import

19.24 rsa key

1 Command Purpose

Use this command to create a key and enter key configuration mode.

Use the no form of this command to delete the key.

2 Command Syntax

rsa key *RSAKEYNAME*

no rsa key *RSAKEYNAME*

Parameter	Parameter Description	Parameter Value
RSAKEYNAME	Key name	-

3 Command Mode

Global Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example creates a key named test:

```
Switch(config)# rsa key test
Switch(config-rsa-key)#
```

The following example deletes a key named test:

```
Switch(config)# no rsa key test
```

7 Related Commands

rsa key generate

19.25 reset

1 Command Purpose

To clear all key configurations, use the reset command in RSA key configuration mode.

2 Command Syntax

reset

3 Command Mode

Rsa Key Configuration

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows to clear all configurations for the key KEY1:

```
Switch(config)# rsa key KEY1
Switch(config-rsa-key)# reset
```

7 Related Commands

rsa key

19.26 key type

1 Command Purpose

To specify the key type, use the key type command in RSA key configuration mode.

2 Command Syntax

key type (private | public)

Parameter	Parameter Description	Parameter Value
private	Private key	-
public	Public key	-

3 Command Mode

Rsa Key Configuration

4 Default

Public

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example specifies the key type of KEY1 as public key::

```
Switch(config)# rsa key KEY1
Switch(config-rsa-key)# key type public
```

7 Related Commands

rsa key

19.27 key format

1 Command Purpose

To specify the key format, use the key format command in RSA key configuration mode.

2 Command Syntax

key format (der | pem)

Parameter	Parameter Description	Parameter Value
der	Der format	-
pem	Pem format	-

3 Command Mode

Rsa Key Configuration

4 Default

DER

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example specifies the key format of KEY1 as pem:

```
Switch(config)# rsa key KEY1
Switch(config-rsa-key)# key format pem
```

7 Related Commands

rsa key

19.28 key string end

1 Command Purpose

Use this command to exit the rsa key configuration mode and apply all rsa key configurations. After using this command, the current command mode should be global configuration mode.

2 Command Syntax

key string end

3 Command Mode

Rsa Key Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows exit the rsa key configuration mode:

```
Switch(config)# rsa key KEY1
Switch(config-rsa-key)# key string end
Switch(config)#
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

rsa key

19.29 validate

1 Command Purpose

To check the validation of the key strings, use the validate command in RSA key configuration mode.

2 Command Syntax

validate

3 Command Mode

Rsa Key Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows to validate key strings of the key KEY1:

```
Switch(config)# rsa key a

Modify private key a
Switch(config-rsa-key)# 00302017 4A7D385B 1234EF29 335FC973
Switch(config-rsa-key)# 2DD50A37 C4F4B0FD 9DADE748 429618D5
Switch(config-rsa-key)# validate
% Validated Ok
```

7 Related Commands

rsa key

Copyright © 2023 Garland Technology, LLC. All rights reserved.

19.30 KEYLINE

1 Command Purpose

To add key strings from the screen directly, type any strings in RSA key configuration mode except the keywords in this mode.

2 Command Syntax

KEYLINE

3 Command Mode

Rsa Key Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows to type a key string of the key KEY1:

```
Switch(config)# rsa key KEY1
Switch(config-rsa-key)# 00302017 4A7D385B 1234EF29 335FC973
Switch(config-rsa-key)# 2DD50A37 C4F4B0FD 9DADE748
```

7 Related Commands

rsa key

validate

19.31 re-activate radius-server

1 Command Purpose

Use this command to re-activate the specified radius servers.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

re-activate radius-server (all | host *IP_ADDR* (auth-port *AUTHDPORT* |) |)

Parameter	Parameter Description	Parameter Value
all	Re-active all radius-servers	-
host IP_ADDR	Re-active the radius-server by server ip	-
auth-port AUTHDPORT	Re-active the radius-server by server ip and udp port	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use this command to re-activate the radius server. It's unnecessary for users to wait for the radius-server dead time with this command.

6 Examples

This example shows how to re-activate radius-server:

```
Switch# re-activate radius-server all
```

7 Related Commands

radius-server host

Copyright © 2023 Garland Technology, LLC. All rights reserved.

19.32 show radius-server

1 Command Purpose

Use this command to display radius server states of each IEEE 802.1 x sessions.

2 Command Syntax

show radius-server

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use this command to display the current radius-server and dead radius-servers of each IEEE 802.1x sessions.

6 Examples

This example shows how to show radius-server:

```
Switch# show radius-server

====================================
radius servers in dead list:
 server address    : 10.0.0.1:1812
 dead timer        : 4
====================================
```

7 Related Commands

radius-server host

Copyright © 2023 Garland Technology, LLC. All rights reserved.

19.33 radius-server host

1 Command Purpose

Use this command to specify a RADIUS server host.

Use the no form of this command to delete the host.

2 Command Syntax

radius-server host mgmt-if *IP_ADDR* (auth-port *AUTHDPORT* |) (key (8 |) *AUTHDKEY* |) (retransmit *AUTHDRETRIES* |) (timeout *AUTHDTIMEOUT* |)

no radius-server host mgmt-if *IP_ADDR* (auth-port *AUTHDPORT* |)

Parameter	Parameter Description	Parameter Value
mgmt-if	Use management interface	-
IP_ADDR	IP address of radius server	-
auth-port AUTHDPORT	RADIUS server port number (default 1812)	-
8	Specifies a hidden password will follow	-
key (8 |) AUTHDKEY		-
retransmit AUTHDRETRIES	RADIUS server retries (default 3)	-
timeout AUTHDTIMEOUT	RADIUS server timeout in seconds (default 5)	-

3 Command Mode

Global Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

You can use multiple radius-server host commands to specify multiple hosts. The software searches for hosts in the order in which you specify them. If no host-specific timeout, retransmit, or key values are specified, the global values apply to each host.

6 Examples

This example shows how to set the radius-server key::

```
Switch(config)# radius-server host mgmt-if 10.0.0.1
```

This example shows how to delete radius-server key:

```
Switch(config)# no radius-server host mgmt-if  10.0.0.1
```

7 Related Commands

show radius-server

19.34 radius-server deadtime

1 Command Purpose

Use this command to improve RADIUS response times when some servers might be unavailable and cause the unavailable servers to be skipped immediately.

Use the no form of this command to restore the default value.

2 Command Syntax

radius-server deadtime *DEADTIME*

no radius-server deadtime

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

DEAD_TIME	RADIUS server deadtime in minutes	1-20 minutes. default is 5 minute.

3 Command Mode

Global Configuration

4 Default

5

5 Usage

Use this command to cause the switch to mark as "dead" any RADIUS servers that fail to respond to authentication requests, thus avoiding the wait for the request to time out before trying the next configured server. A RADIUS server marked as "dead" is skipped by additional requests for the duration of minutes, unless there are no servers not marked "dead".

6 Examples

This example shows how to set radius-server dead time:

```
Switch(config)# radius-server deadtime 10
```

This example shows how to restore the default radius-server dead time:

```
Switch(config)# no radius-server deadtime
```

7 Related Commands

show radius-server

19.35 radius-server retransmit

1 Command Purpose

Use this command to specify the number of times the switch searches the list of RADIUS server hosts before giving up.

Use the no form of this command to restore the default value.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

radius-server retransmit *RETRANSMIT*

no radius-server retransmit

Parameter	Parameter Description	Parameter Value
RETRANSMIT	RADIUS server retries	1-100, default is 3

3 Command Mode

Global Configuration

4 Default

3

5 Usage

The switch tries all servers, allowing each one to time out before increasing the retransmit count. If the RADIUS server is only a few hops from the switch, we recommend that you configure the RADIUS server retransmit rate to 5.

6 Examples

This example shows how to set radius-server retransmit:

```
Switch(config)# radius-server retransmit 10
```

This example shows how to set default radius-server retransmit:

```
Switch(config)# no radius-server retransmit
```

7 Related Commands

show radius-server

Copyright © 2023 Garland Technology, LLC. All rights reserved.

19.36 radius-server timeout

1 Command Purpose

Use this command to set the interval for which a switch waits for a server host to reply.

Use the no form of this command to restore the default value.

2 Command Syntax

radius-server timeout *TIMEOUT*

no radius-server timeout

Parameter	Parameter Description	Parameter Value
TIMEOUT	RADIUS server timeout in seconds	1-1000 seconds. default is 5 seconds

3 Command Mode

Global Configuration

4 Default

5

5 Usage

Use this command to set the number of seconds a switch waits for a server host to reply before timing out. If the RADIUS server is only a few hops from the switch, we recommend that you configure the RADIUS server timeout to 15 seconds.

6 Examples

This example shows how to set radius-server timeout:

```
Switch(config)# radius-server timeout 10
```

This example shows how to set default radius-server timeout:

```
Switch(config)# no radius-server timeout
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

show radius-server

19.37 radius-server key

1 Command Purpose

Use this command to set the shared encryption key of RADIUS server.

Use the no form of this command to delete the configuration.

2 Command Syntax

radius-server key (8 |) *STRING*

no radius-server timeout

Parameter	Parameter Description	Parameter Value
8	Specifies a hidden password will follow	-
STRING	RADIUS server key-string	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Use this command to set the shared encryption key in a switch. Shared encryption key is the foundation of communicate between switch and server. You need set a same shared encryption string in authentication server and switch.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

This example shows how to set the radius-server key:

```
Switch(config)# radius-server key 123456
```

This example shows how to unset radius-server key:

```
Switch(config)# no radius-server key
```

7 Related Commands

show radius-server

19.38 re-activate tacacs-server

1 Command Purpose

Use this command to re-activate the specified tacacs servers.

2 Command Syntax

re-activate tacacs-server (all | host *IP_ADDR* (auth-port *AUTHDPORT* |) |)

Parameter	Parameter Description	Parameter Value
all	Re-active all tacacs-servers	-
IP_ADDR	Set TACACS server IP address	-
AUTHDPORT	TACACS server port number (default 49)	-

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

Use this command to re-activate the tacacs server. It's unnecessary for users to wait for the tacacs-server dead time with this command.

6 Examples

This example shows how to re-activate tacacs-server:

```
Switch# re-activate tacacs-server host 10.0.0.1 auth-port 49
```

7 Related Commands

tacacs-server host

19.39 tacacs-server host

1 Command Purpose

Use this command to set tacacs-server parameters.

Use the no form of this command to delete the tacacs server.

2 Command Syntax

tacacs-server host mgmt-if *IP_ADDR* (auth-port *AUTHDPORT* |) (key (8 |) *AUTHDKEY* |) (retransmit *AUTHDRETRIES* |) (timeout *AUTHDTIMEOUT* |)

no tacacs-server host mgmt-if *IP_ADDR* (auth-port *AUTHDPORT* |)

Parameter	Parameter Description	Parameter Value
mgmt-if	Use management interface	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

IP_ADDR	IP address of TACACS server	-
auth-port AUTHDPORT		-
8	Specifies a hidden password will follow	-
key (8 |) AUTHDKEY		-
retransmit AUTHDRETRIES	TACACS server retries (default 3)	-
timeout AUTHDTIMEOUT	TACACS server timeout in seconds (default 5)	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Use this command to set tacacs-server parameters.

Use the no form of this command to delete the tacacs server.

6 Examples

The following example set tacacs-server 2.1.1.1:

```
Switch(config)# tacacs-server host 2.1.1.1 key mykey
```

The following example deletes tacacs-server 2.1.1.1:

```
Switch(config)# no tacacs-server host 2.1.1.1
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

show tacacs

19.40 username

1 Command Purpose

Use this command to create a local user account on the switch.

Use the no form of this command to delete the account.

2 Command Syntax

username *NAME_STRING*

no username *NAME_STRING*

Parameter	Parameter Description	Parameter Value
NAME_STRING	User name	String begin with [a-zA-Z],valid character is among [0-9A-Za-z.-_], up to 31 characters.

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Use this command to create a local user account on the switch.

Use the no form of this command to delete the account.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

This is a sample output from this command displaying how to add a user named testName:

```
Switch(config)# username testName
```

This is a sample output from this command displaying how to delete a user named testName:

```
Switch(config)# no username testName
```

7 Related Commands

show usernames

19.41 username password

1 Command Purpose

Use this command to add username and password.

2 Command Syntax

username *NAME_STRING* password (8 |) *PASSWORD* (privilege *PRIVILEGE* |)

Parameter	Parameter Description	Parameter Value
NAME_STRING	User name	-
8	Specifies a hidden password will follow	-
PASSWORD	User password string	-
privilege PRIVILEGE	Set user privilege level	-

3 Command Mode

Global Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

Use this command to add username and password.

6 Examples

This is a sample output from this command displaying how to add a user named testName and with the password of 123456.:

```
Switch(config)# username testName password 123456
```

7 Related Commands

show usernames

19.42 username assign

1 Command Purpose

Use this command to assign a public key to a user.

Use the no form of this command to remove the configuration.

2 Command Syntax

username *NAME_STRING* assign rsa key *RSAKEYNAME*

no username *USERNAME* assign rsa key

Parameter	Parameter Description	Parameter Value
NAME_STRING	User name	String begin with [a-zA-Z],valid character is among [0-9A-Za-z.-_], up to 31 characters.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

RSAKEYNAME	Key Name	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Use this command to assign a public key to a user.

Use the no form of this command to remove the configuration.

6 Examples

This is a sample output from this command displaying how to assign a key:

```
Switch(config)# username abc assign rsa key importkey
```

This is a sample output from this command displaying how to delete the assigned key:

```
Switch(config)# no username abc assign rsa key
```

7 Related Commands

username

rsa key

19.43 username privilege

1 Command Purpose

Use this command to set user privilege level.

2 Command Syntax

username *NAME_STRING* privilege *PRIVILEGE* (password (8 |) *PASSWORD* | secret *PASSWORD* |)

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
NAME_STRING	User name	String begin with [a-zA-Z],valid character is among [0-9A-Za-z.-_], up to 31 characters.
PRIVILEGE	Set user privilege level	-
8	Specifies a hidden password will follow	-
PASSWORD	User password string	-
secret PASSWORD	User secret string	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Use this command to set user privilege level.

6 Examples

This is a sample output from this command displaying how to add a user named testName and with the privilege 3 and password of 12345.:

```
Switch(config)# username u1 privilege 3 secret 12345
```

7 Related Commands

show usernames

Copyright © 2023 Garland Technology, LLC. All rights reserved.

19.44 username secret

1 Command Purpose

Use username command to create a local user account with secret password.

2 Command Syntax

username *NAME_STRING* secret *PASSWORD*

Parameter	Parameter Description	Parameter Value
NAME_STRING	User name	String begin with [a-zA-Z],valid character is among [0-9A-Za-z.-_], up to 31 characters.
secret PASSWORD	User secret string	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Use username command to create a local user account with secret password.

6 Examples

This is a sample output from this command displaying how to add a user named u2 and with the secret 23.:

```
Switch(config)# username u2 secret 23
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

show usernames

19.45 re-username

1 Command Purpose

Use re-username command to modify local user account on the switch.

2 Command Syntax

re-username *OLD_NAME NEW_NAME*

Parameter	Parameter Description	Parameter Value
OLD_NAME	Old user name	String begin with [a-zA-Z],valid character is among [0-9A-Za-z.-_], up to 31 characters.
NEW_NAME	New user name	String begin with [a-zA-Z],valid character is among [0-9A-Za-z.-_], up to 31 characters.

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Use re-username command to modify local user account on the switch.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to change user account's name:

```
Switch(config)# re-username oldUser newUser
```

7 Related Commands

show usernames

19.46 enable password

1 Command Purpose

Use this command to set the password which is needed when user enter Privileged EXEC mode.

2 Command Syntax

enable password (8 |) *PASSWORD*

no enable password

Parameter	Parameter Description	Parameter Value
8	Specifies a hidden password will follow	-
PASSWORD	Enable password string	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

If this command is set, user need to provide the password when enter Privileged EXEC mode.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to set the password:

```
Switch(config)# enable password 654321
Switch(config)# exit
Switch# disable
Switch> enable

Password:
Switch#
```

The following example shows how to unset the password:

```
Switch(config)# no enable password
```

7 Related Commands

enable

disable

19.47 enable password privilege

1 Command Purpose

Use this command to set the password which is needed when user enter Privileged EXEC mode.

Use the no form of this command to unset the password when user enter Privileged EXEC mode.

2 Command Syntax

enable password privilege *PRIVILEGE* (8 |) *PASSWORD*

no enable password privilege *PRIVILEGE*

Parameter	Parameter Description	Parameter Value
PRIVILEGE	Set user privilege level	-
8	Specifies a hidden password will follow	-
PASSWORD	Enable password string	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Global Configuration

4 Default

None

5 Usage

If this command is set, user need to provide the password when enter Privileged EXEC mode.

6 Examples

The following example shows how to set the password:

```
Switch(config)# enable password privilege 2 abc123
Switch(config)# exit
Switch# disable
Switch> enable 2

Password:
Switch#
```

The following example shows how to unset the password:

```
Switch(config)# no enable password privilege 2
```

7 Related Commands

enable

disable

19.48 service password-encryption

1 Command Purpose

Use this command to set up the miscellaneous service encrypt system passwords.

Use the no form of this command to unset service encrypt system passwords.

2 Command Syntax

service password-encryption

Copyright © 2023 Garland Technology, LLC. All rights reserved.

no service password-encryption

3 Command Mode

Global Configuration

4 Default

Not encrypt

5 Usage

After use this command, the password in the display result of “show running-config” should be encrypted.

After use the no form of this command, the newly added password in the display result of “show current-configuration” should be plain text and the existing password should still be encrypted.

6 Examples

The following example shows how to set service password-encryption:

```
Switch(config)# service password-encryption
```

The following example shows how to unset service password-encryption:

```
Switch(config)# no service password-encryption
```

7 Related Commands

show running-config

19.49 aaa new-model

1 Command Purpose

Use this command to enable the authentication, authorization, accounting (AAA) access control model.

Use the no form of this command to disable the authentication, authorization, accounting (AAA) access control model.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

aaa new-model

no aaa new-model

3 Command Mode

Global Configuration

4 Default

Disabled

5 Usage

Use this command to enable the authentication, authorization, accounting (AAA) access control model.

Use the no form of this command to disable the authentication, authorization, accounting (AAA) access control model.

6 Examples

The following example shows how to enable AAA access control model:

```
Switch(config)# aaa new-model
```

The following example shows how to disable AAA access control model:

```
Switch(config)# no aaa new-model
```

7 Related Commands

show aaa status

19.50 aaa authentication login

1 Command Purpose

Use the aaa authentication login configuration command to set authentication, authorization, accounting (AAA) authentication at login.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Use the no form of this command to delete the configuration.

2 Command Syntax

aaa authentication login (default | *AUTHLISTNAME*) (enable |) (line |) (radius |) (tacplus |) (local |) (none |)

no aaa authentication login (default | *AUTHLISTNAME*)

Parameter	Parameter Description	Parameter Value
default	Default method list	-
AUTHLISTNAME	Named authentication list (a-zA-Z0-9._-)	-
enable	Enable password	-
line	Line password	-
radius	RADIUS server	-
tacplus	TACACS+	-
local	Local username	-
none	No authentication	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Use the aaa authentication login configuration command to specify one or more AAA methods.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to set authentication at login:

```
Switch(config)# aaa authentication login default local radius none
```

The following example shows how to delete authentication:

```
Switch(config)# no aaa authentication login default
```

7 Related Commands

show aaa method-lists authentication

19.51 aaa authorization exec

1 Command Purpose

Use the aaa authorization exec configuration command to set authentication, authorization, accounting (AAA) authorization at login.

2 Command Syntax

aaa authorization exec (default | *AUTHLISTNAME*) (none |) (radius |) (local |) (tacplus |)

no aaa authorization exec (default | *AUTHLISTNAME*)

Parameter	Parameter Description	Parameter Value
default	Default method list	-
AUTHLISTNAME	Named authentication list (a-zA-Z0-9._-)	-
none	No authentication	-
radius	RADIUS server	-
local	Local username	-
tacplus	TACACS+	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Use the aaa authorization exec configuration command to Set authentication, authorization, accounting (AAA) authorization at login

6 Examples

The following example shows how to set authorization exec:

```
Switch# configure terminal
Switch(config)# aaa authorization exec default tacplus none
```

7 Related Commands

show aaa method-lists authorization

19.52 aaa accounting exec

1 Command Purpose

Use this command to set authentication, authorization, accounting (AAA) accounting at login.

Use the no form of this command to delete the configuration.

2 Command Syntax

aaa accounting exec (default | *AUTHLISTNAME*) (start-stop (radius | tacplus | none) * | stop-only (radius | tacplus | none) * | none)

no aaa accounting exec (default | *AUTHLISTNAME*)

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

default	Default method list	-
AUTHLISTNAME	Named authentication list (a-zA-Z0-9._-)	-
start-stop	Send accounting request when user login and logout	-
stop-only	Send accounting request when user logout	-
radius	RADIUS server	-
tacplus	TACACS+	-
none	No authentication	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Use this command to set authentication, authorization, accounting (AAA) accounting at login.

6 Examples

The following example shows how to set accounting exec:

```
Switch# configure terminal
Switch(config)# aaa accounting exec default start-stop tacplus
```

The following example shows how to delete accounting:

```
Switch# configure terminal
Switch(config)# no aaa accounting exec default
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

show aaa method-lists accounting

19.53 aaa accounting commands

1 Command Purpose

Use this command to set authentication, authorization, accounting (AAA) accounting for commands.

Use the no form of this command to delete the configuration.

2 Command Syntax

aaa accounting commands (default | *AUTHLISTNAME*) (tacplus | none) *

no aaa accounting commands (default | *AUTHLISTNAME*)

Parameter	Parameter Description	Parameter Value
default	Default method list	-
AUTHLISTNAME	Named authentication list (a-zA-Z0-9._-)	-
tacplus	TACACS+	-
none	No authentication	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Use this command to set authentication, authorization, accounting (AAA) accounting for commands.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to set accounting commands:

```
Switch# configure terminal
Switch(config)# aaa accounting commands default tacplus
```

The following example shows how to delete accounting for commands:

```
Switch# configure terminal
Switch(config)# no aaa accounting commands default
```

7 Related Commands

show aaa method-lists accounting

19.54 aaa privilege mapping

1 Command Purpose

Use this command to set the mapping range in AAA server and switch.

Use the no form of this command to restore the default mapping.

2 Command Syntax

aaa privilege mapping *AAA_PRIVILEGE1 AAA_PRIVILEGE2 AAA_PRIVILEGE3*

no aaa privilege mapping

Parameter	Parameter Description	Parameter Value
AAA_PRIVILEGE1	Max server privilege mapping to switch privilege 1(default is 0)	-
AAA_PRIVILEGE2	Max server privilege mapping to switch privilege 2(default is 1)	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

AAA_PRIVILEGE3	Max server privilege mapping to switch privilege 3(default is 10)	-

3 Command Mode

Global Configuration

4 Default

0, 1, 10

5 Usage

0: The server privilege 0 mapping to switch level 1

1: The server privilege 1 mapping to switch level 2

9: The server privilege 2-9 mapping to switch level 3

Other: The server privilege 10-15 mapping to switch level 4

6 Examples

The following example shows how to set the mapping range:

```
Switch(config)# aaa privilege mapping 0 1 14
```

The following example shows how to set default mapping range:

```
Switch# configure terminal
Switch(config)# no aaa privilege mapping
```

7 Related Commands

show aaa privilege mapping

19.55 debug aaa

1 Command Purpose

Use this command to enable debugging aaa.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Use the no form of this command to disable debugging aaa.

2 Command Syntax

debug aaa (all | packet | event | protocol | timer)

no debug aaa (all | packet | event | protocol | timer)

Parameter	Parameter Description	Parameter Value
all	Enable to report all aaa debug messages	-
packet	Enable to report aaa debug messages for sending and receiving packets	-
event	Enable to report aaa debug messages for events	-
protocol	Enable to report aaa debug messages for protocol states	-
timer	Enable to report aaa debug messages for timer	-

3 Command Mode

Privileged EXEC

4 Default

Disabled

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

In the following example shows how to enable debugging aaa all:

```
Switch# debug aaa all
```

In the following example shows how to disable debugging aaa all:

```
Switch# no debug aaa all
```

7 Related Commands

show debugging

19.56 exec-timeout

1 Command Purpose

Use this command to set console timeout value.

Use the no form of this command to restore the default value.

2 Command Syntax

exec-timeout *ETIMEOUTMIN* (*ETIMEOUTSEC* |)

no exec-timeout

Parameter	Parameter Description	Parameter Value
ETIMEOUTMIN	Timeout value in minute.	0-35791
ETIMEOUTSEC	Timeout value in second	0- 2147483

3 Command Mode

Line Configuration

4 Default

10

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to set console exec-timeout to 2 minutes 30 seconds:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# exec-timeout 2 30
```

The following example shows how to set console exec-timeout to default value:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# no exec-timeout
```

7 Related Commands

show console

19.57 login

1 Command Purpose

Use this command to enable console password checking, you can choose local password checking.

Use the no form of this command to disable console password checking.

2 Command Syntax

login (local |)

no login (local |)

Parameter	Parameter Description	Parameter Value
local	Local username	-

3 Command Mode

Line Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

no password checking

5 Usage

Use this command to enable console password checking, you can choose local password checking.

Use the no form of this command to disable console password checking.

6 Examples

The following example shows how to set console local password checking enable:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# login local
```

The following example shows how to set console local password checking disable:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# no login local
```

7 Related Commands

show console

19.58 privilege level

1 Command Purpose

Use this command to set console privilege level for line.

Use the no form of this command to restore the default value.

2 Command Syntax

privilege level *PRIVILEGE*

no privilege level

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

PRIVILEGE	Default privilege level for line	-

3 Command Mode

Line Configuration

4 Default

1

5 Usage

Use this command to set console privilege level for line.

Use the no form of this command to restore the default value.

6 Examples

The following example shows how to set console privilege level for line to 2:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# privilege level 2
```

The following example shows how to set console privilege level for line to default value:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# no privilege level
```

7 Related Commands

show console

19.59 line-password

1 Command Purpose

Use this command to set console line-password specifies a hidden password will follow or user password string.

Use the no form of this command to unset console line-password.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

line-password (8 |) *NAME_STRING*

no line-password

Parameter	Parameter Description	Parameter Value
8	Specifies a hidden password will follow	-
NAME_STRING	User password string	-

3 Command Mode

Line Configuration

4 Default

No console line-password

5 Usage

Use this command to set console line-password specifies a hidden password will follow or user password string.

Use the no form of this command to unset console line-password.

6 Examples

The following example shows how to set console line-password specifies a hidden password will follow:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# line-password 8 test
```

The following example shows how to unset console line-password:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# no line-password
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

show console

19.60 stopbits

1 Command Purpose

Use this command to set console sync line stop bits.

Use no form of this command to set console sync line stop bits to default value.

2 Command Syntax

stopbits (1 | 2)

no stopbits

Parameter	Parameter Description	Parameter Value
1	Set 1 bit stop bit	-
2	Set 2 bits stop bits	-

3 Command Mode

Line Configuration

4 Default

One-bit stop

5 Usage

None

6 Examples

The following example shows how to set console sync line stop bits one-bit stop:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# stopbits 1
```

The following example shows how to set console sync line stop bits to default value:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# no stopbits
```

7 Related Commands

show console

19.61 databits

1 Command Purpose

Use this command to set console number of data bits.

Use the no form of this command to set console number of data bits per character to default value.

2 Command Syntax

databits (7 | 8)

no databits

Parameter	Parameter Description	Parameter Value
7	7-bit databits.	-
8	8-bit databits.	-

3 Command Mode

Line Configuration

4 Default

8-bit databits

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

Use this command to set console number of data bits.

Use the no form of this command to set console number of data bits per character to default value.

6 Examples

The following example shows how to set console number of data bits per character to 7-bit databits:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# databits 7
```

7 Related Commands

show console

19.62 parity

1 Command Purpose

Use this command to set console terminal parity.

Use the no form of this command to restore the default value.

2 Command Syntax

parity (even | odd | none)

no parity

Parameter	Parameter Description	Parameter Value
even	Parity mode even	-
odd	Parity mode odd	-
none	No parity	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Line Configuration

4 Default

No parity

5 Usage

Use this command to set console terminal parity.

Use the no form of this command to restore the default value

6 Examples

The following example shows how to set console terminal parity type odd:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# parity odd
```

The following example shows how to set console terminal parity type to default value:

```
Switch# configure terminal
Switch(config)# line console 0
Switch(config-line)# no parity
```

7 Related Commands

line console

show console

19.63 speed

1 Command Purpose

Use this command to set the transmit and receive speeds of console terminal.

Use the no form of this command to restore the default value.

2 Command Syntax

speed (115200 | 57600 | 38400 | 19200 | 9600 | 4800 | 2400 | 1200 | 600)

Copyright © 2023 Garland Technology, LLC. All rights reserved.

no speed

3 Command Mode

Line Configuration

4 Default

115200

5 Usage

None

6 Examples

The following is an example of set console terminal speed to 115200:

```
Switch(config)# line console 0
Switch(config-line)# speed 115200
```

The following is an example of set console terminal speed to default value:

```
Switch(config)# line console 0
Switch(config-line)# no speed
```

7 Related Commands

show console

19.64 authorization exec

1 Command Purpose

Use this command to enable authentication, authorization, accounting (AAA) authorization for logins.

Use the no form of this command to restore the default value.

2 Command Syntax

authorization exec (default | *LISTNAME*)

no authorization exec

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
default	Default authorization list	-
LISTNAME	An authorization list with this name (a-zA-Z0-9._-)	-

3 Command Mode

Line Configuration

4 Default

None

5 Usage

Use this command to enable authentication, authorization, accounting (AAA) authorization for logins.

Use the no form of this command to restore the default value.

6 Examples

The following example shows how to enable authorization for logins:

```
Switch# configure terminal
Switch(config)# line vty 0 7
Switch(config-line)# authorization exec default
```

The following example shows how to set authorization to default method list:

```
Switch# configure terminal
Switch(config)# line vty 0 7
Switch(config-line)# no authorization exec
```

7 Related Commands

show vty

Copyright © 2023 Garland Technology, LLC. All rights reserved.

19.65 accounting exec

1 Command Purpose

Use this command to enable authentication, authorization, accounting (AAA) accounting for logins.

Use the no form of this command to restore the default value.

2 Command Syntax

accounting exec (default | *LISTNAME*)

no accounting exec

Parameter	Parameter Description	Parameter Value
default	Default accounting list	-
LISTNAME	An accounting list with this name (a-zA-Z0-9._-)	-

3 Command Mode

Line Configuration

4 Default

None

5 Usage

Use this command to enable authentication, authorization, accounting (AAA) accounting for logins.

Use the no form of this command to restore the default value.

6 Examples

The following example shows how to enable accounting for logins:

```
Switch# configure terminal
Switch(config)# line vty 0 7
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch(config-line)# accounting exec default
```

The following example shows how to set accounting exec to default method list:

```
Switch# configure terminal
Switch(config)# line vty 0 7
Switch(config-line)# no accounting exec
```

7 Related Commands

show vty

19.66 accounting commands

1 Command Purpose

Use this command to enable accounting for commands.

2 Command Syntax

accounting commands (default | *LISTNAME*)

no accounting commands

Parameter	Parameter Description	Parameter Value
default	Default accounting list	-
LISTNAME	An accounting list with this name (a-zA-Z0-9._-)	-

3 Command Mode

Line Configuration

4 Default

None

5 Usage

Use this command to enable accounting for commands.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to enable accounting for commands:

```
Switch# configure terminal
Switch(config)# line vty 0 7
Switch(config-line)# accounting commands default
```

7 Related Commands

show vty

19.67 end

1 Command Purpose

To end the current configuration session and return to Privileged EXEC mode, use the end command in global configuration mode.

2 Command Syntax

end

3 Command Mode

All Configuration Mode

4 Default

None

5 Usage

This command will bring you back to Privileged EXEC mode regardless of what configuration mode or configuration sub-mode you are in.

This global configuration command can be used in any configuration mode.

Use this command when you are done configuring the system and you want to return to EXEC mode to perform verification steps.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

In the following example, the end command is used to exit from interface configuration mode and return to Privileged EXEC mode:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# end
Switch#
```

7 Related Commands

None

19.68 ip access-class

1 Command Purpose

Use this command to set vty IPv4 ACL.Use the no form of this command to remove ACL from vty.

2 Command Syntax

ip access-class *NAME_STRING* in

no ip access-class in

Parameter	Parameter Description	Parameter Value
NAME_STRING	IP ACL NAME	The initial character name should be a-z, A-Z, 0-9 or ._-, character only can be 0-9A-Za-z.-_ and the max length is 20

3 Command Mode

Line Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to configure IPv4 ACL on vty:

```
Switch# configure terminal
Switch(config)# line vty 1
Switch(config-line)# ip access-class a4 in
```

7 Related Commands

ip access-list

Copyright © 2023 Garland Technology, LLC. All rights reserved.

20 SFLOW Commands

20.1 sflow enable

1 Command Purpose

Use this command to enable sFlow globally.

Use the no form of this command to disable sFlow.

2 Command Syntax

sflow enable

no sflow enable

3 Command Mode

Global Configuration

4 Default

Disabled

5 Usage

Before any other sFlow command can be configured, sFlow services must be enabled globally. Use the no parameter with this command to remove all sFlow configurations and disable sFlow globally.

6 Examples

This example shows how to enable sFlow services globally:

```
Switch(config)# sflow enable
```

This example shows how to disable sFlow services globally:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch(config)# no sflow enable
```

7 Related Commands

show sflow

20.2 sflow agent

1 Command Purpose

Use this command to configure sFlow agent.

Use the no form of this command to delete the sFlow agent.

2 Command Syntax

sflow agent ip *IP_ADDR*

no sflow agent ip

Parameter	Parameter Description	Parameter Value
IP_ADDR	IPv4 address	-

3 Command Mode

Global Configuration

4 Default

0.0.0.0

5 Usage

Use this command to configure IP address for sflow agent. If not configured, sflow agent IP address will be 0.0.0.0.

6 Examples

This example shows how to configure agent with IP address 10.0.0.254:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch(config)# sflow agent ip 10.0.0.254
```

This example shows how to configure agent with IP address 0.0.0.0:

```
Switch(config)# no sflow agent ip
```

7 Related Commands

show sflow

20.3 sflow collector

1 Command Purpose

Use this command to configure sFlow collector.

Use the no form of this command to delete the sFlow collector.

2 Command Syntax

sflow collector mgmt-if *IP_ADDR* (*UDP_PORT* |)

no sflow collector *IP_ADDR*

Parameter	Parameter Description	Parameter Value
IP_ADDR	Collector IPv4 address	-
UDP_PORT	Collector UDP port number	1-65535, default is 6343

3 Command Mode

Global Configuration

4 Default

Default source ip is the ip address of interface which is connected with sflow collector

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

Use this command to add a collector by specifying the combination of IP address and UDP port and source IP address. Only up to two unique combinations can be allowed to add.

6 Examples

This example shows how to add a collector:

```
Switch(config)# sflow collector mgmt-if 10.0.0.254 3000
```

This example shows how to remove a collector:

```
Switch# configure terminal
Switch(config)# no sflow collector 10.0.0.254 3000
```

7 Related Commands

show sflow

20.4 sflow counter interval

1 Command Purpose

Use this command to configure sFlow polling-interval for counter sample.

Use the no form of this command to restore the default value.

2 Command Syntax

sflow counter interval *INTERVAL_VAL*

no sflow counter interval

Parameter	Parameter Description	Parameter Value
INTERVAL_VAL	Interval value in second	1-2000 seconds, default is 20 seconds.

3 Command Mode

Global Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

20

5 Usage

Use this command to set sFlow polling-interval for counter sample. Use the no parameter with this command to restore to the default value. Default interval value is 20 seconds.

6 Examples

This example shows how to set sFlow polling-interval to 10 second:

```
Switch(config)# sflow counter interval 10
```

This example shows how to set sFlow polling-interval to default value:

```
Switch(config)# no sflow counter interval
```

7 Related Commands

show sflow

20.5 sflow counter-sampling enable

1 Command Purpose

Use this command to enable counter sampling on specified port.

Use the no form of this command to disable counter sampling.

2 Command Syntax

sflow counter-sampling enable

no sflow counter-sampling enable

3 Command Mode

Interface Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

Disabled

5 Usage

Use this command to enable counter sampling on specified port. This command can only be configured on a port which is not a link-agg group member. The port can be either a physical port or a link-agg port.

6 Examples

This example shows how to set sFlow polling-interval to 10 second::

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# sflow counter-sampling enable
```

This example shows how to disable sFlow counter sampling on interface eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no sflow counter-sampling enable
```

7 Related Commands

show sflow

20.6 sflow flow-sampling rate

1 Command Purpose

Use this command to configure flow sampling rate.

Use the no form of this command to restore the default value.

2 Command Syntax

sflow flow-sampling rate *RATE*

no sflow flow-sampling rate

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

RATE	Sample rate value,	must be a power of 2. Range is 1-32768, default is 32768.

3 Command Mode

Interface Configuration

4 Default

32768

5 Usage

Use this command to set sFlow packet sampling rate. The rate value is packet number. When the value is 32768, one packet will be sampled when 32768 packets are passed, sFlow uses CPU resources to collect samples and send samples to the collector. If a low sampling rate is set, CPU utilization can become high. To protect CPU from overwhelming, exceeded flow samples would be dropped. If a sampling rate less than default value is configured, a prompt will be given to info the potential of involving a high CPU utilization. This command can only be configured on a port which is not a link-agg group member. The port can be either a physical port or a link-agg port.

6 Examples

This example shows how to enable sFlow counter sampling on interface eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# sflow flow-sampling rate 2048
% Warning: sFlow sampling requires high CPU usage, especially with a low rate.
  Suggested rate not less than 32768.
```

This example shows how to disable sFlow counter sampling on interface eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no sflow flow-sampling rate
```

7 Related Commands

show sflow

Copyright © 2023 Garland Technology, LLC. All rights reserved.

20.7 sflow flow-sampling enable

1 Command Purpose

Use this command to enable packet sampling on individual port.

Use the no form of this command to disable packet sampling.

2 Command Syntax

sflow flow-sampling enable (input | output | both)

no sflow flow-sampling enable (input | output | both)

Parameter	Parameter Description	Parameter Value
input	Sampling for input packets	-
output	Sampling for output packets	-
both	Sampling for packets on both direction	-

3 Command Mode

Interface Configuration

4 Default

Disabled

5 Usage

Use this command to enable packet sampling on individual port. This command can only be configured on a port which is not a link-agg group member. The port can be either a physical port or a link-agg port.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

This example shows how to enable input packet sampling on route port eth-0-1:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# sflow flow-sampling enable input
```

7 Related Commands

show sflow

20.8 debug sflow

1 Command Purpose

Use this command to turn on the debug switches of sflow module.

Use the no form of this command to turn off the debug switches of sflow module.

2 Command Syntax

debug sflow (all | packet | counter | sample)

no debug sflow (all | packet | counter | sample)

Parameter	Parameter Description	Parameter Value
all	Enable to report all debug messages	-
counter	Enable to report sflow debug messages for counters	-
packet	Enable to report sflow debug messages for sending and receiving packets	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

sample	Enable to report sflow debug messages for sampling	-

3 Command Mode

Privileged EXEC

4 Default

Disabled

5 Usage

Use this command to turn on the debug switches of sflow module.

6 Examples

In the following example shows how to enable debugging sflow all:

```
Switch# Switch# debug sflow all
```

7 Related Commands

show debugging

20.9 show sflow

1 Command Purpose

Use this command to show the running information of sflow.

2 Command Syntax

show sflow

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

Use this command to show the running information of sflow.

6 Examples

This example shows how to show the sflow running information:

```
Switch# show sflow

sFlow Version: 4
sFlow Global Information:
 Agent IPv4 address            : 10.0.0.254
 Counter Sampling Interval     : 10 seconds
 Collector 1:
  IPv4 Address: 10.0.0.254
  Port: 3000
sFlow Port Information:
                                 Flow-Sample   Flow-Sample
 Port        Counter   Flow      Direction     Rate
 ---------------------------------------------------------
 eth-0-7     Enable    Enable    Input         2048
```

7 Related Commands

sflow enable

sflow agent

Copyright © 2023 Garland Technology, LLC. All rights reserved.

21 GLOBAL Commands

21.1 show debugging

1 Command Purpose

To display the debugging status, use the show debugging command in EXEC mode.

2 Command Syntax

show debugging (aaa | sflow |) (detail |)

Parameter	Parameter Description	Parameter Value
aaa	Display the states of aaa debugging	-
sflow	Display the states of sflow debugging	-
detail	Display the detailed information of debugging	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use this command to display the debugging status.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following is sample output from the show debugging aaa command:

```
Switch# show debugging aaa detail

Module       Feature          Type                Status
-----------+----------------+-------------------+------
auth         aaa              event               on
             aaa              packet              on
             aaa              protocol            off
             aaa              timer               on
```

7 Related Commands

debug aaa

debug sflow

21.2 no debug all

1 Command Purpose

Use this command to turn off all debugging switches.

2 Command Syntax

no debug all

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use this command to turn off all debugging switches.

6 Examples

In the following example shows how to disable all debugging:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch# no debug all
```

7 Related Commands

show debugging

21.3 show history

1 Command Purpose

To display the history command lines, use the show history command in EXEC mode.

2 Command Syntax

show history

3 Command Mode

Privileged EXEC

4 Default

none

5 Usage

Use this command to display the history command lines.

6 Examples

This example shows how to display history commands information of device:

```
Switch# show history

    1  show version
    2  debug sflow all
    3  no debug sflow all
    4  show history 1  show history
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

21.4 show running-config

1 Command Purpose

To display the current operating configuration, use the show running-config command in EXEC mode.Default configuration don't dispaly.

2 Command Syntax

show running-config

3 Command Mode

Privileged EXEC

4 Default

none

5 Usage

Use this command to display the current operating configuration.Default configuration don't display

6 Examples

This example shows how to display current operating configuration of device:

```
Switch# show running-config

hostname Switch
timestamp sync systime
username admin privilege 4 password admin
username test privilege 4 password test
!
!
logging server enable
logging merge disable
logging merge timeout 23
!
ntp authentication enable
!
ntp server mgmt-if 1.1.1.1
ntp server mgmt-if 10.10.25.8
ntp server mgmt-if 192.16.22.44 version 2
!
snmp-server enable
snmp-server system-contact admin@example.com
!
snmp-server view view1 included .1.2.3.4 mask f
!
snmp-server community sysname read-write
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
!
snmp-server trap target-address mgmt-if 10.10.27.232 community sysname
!
management ip address 10.10.39.104/23
management route add gateway 10.10.39.254
!
port-channel load-balance hash-arithmetic crc
port-channel load-balance set vxlan-vni
port-channel load-balance set inner-dst-mac
!
flow f1
!
flow f2
!
sflow enable
sflow agent ip 10.0.0.254
sflow counter interval 10
!
interface eth-0-1
 description TenGigabitEthernet
 speed 1000
 shutdown
!
interface eth-0-2
 shutdown
!
interface eth-0-3
 shutdown
 static-channel-group 10
!
interface eth-0-4
 shutdown
 static-channel-group 10
!
interface eth-0-5
 shutdown
 static-channel-group 5
!
interface eth-0-6
 shutdown
!
interface eth-0-7
 shutdown
 sflow counter-sampling enable
 sflow flow-sampling enable input
 sflow flow-sampling rate 2048
!
interface eth-0-8
 shutdown
!
interface eth-0-9
 shutdown
!
interface eth-0-10
 shutdown
!
interface eth-0-11
!
interface eth-0-12
!
interface eth-0-13
!
interface eth-0-14
!
interface eth-0-15
!
interface eth-0-16
!
interface eth-0-17
!
interface eth-0-18
!
interface eth-0-19
!
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
interface eth-0-20
!
interface eth-0-21
!
interface eth-0-22
!
interface eth-0-23
!
interface eth-0-24
!
interface eth-0-25
!
interface eth-0-26
!
interface eth-0-27
!
interface eth-0-28
!
interface eth-0-29
!
interface eth-0-30
!
interface eth-0-31
!
interface eth-0-32
!
interface eth-0-33
!
interface eth-0-34
!
interface agg5
 description LinkAgg5
!
interface agg10
!
tap-group tap1 1
 ingress eth-0-1 flow f1
 egress eth-0-9
!
tap-group tap2 2
 ingress eth-0-21
 egress eth-0-22
!
tap-group g1 3
 ingress eth-0-33
!
line console 0
 privilege level 4
 no line-password
 no login
line vty 0 7
 exec-timeout 35791 0
 privilege level 4
 no line-password
 no login
```

7 Related Commands

None

21.5 md5sum

1 Command Purpose

To calculate the md5sum of the file.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

md5sum *FILENAME*

Parameter	Parameter Description	Parameter Value
FILENAME	Specify the file name	-

3 Command Mode

Privileged EXEC

4 Default

none

5 Usage

Use this command to calculate the md5sum of the file.

6 Examples

This example shows how to calculate the md5sum of the file:

```
Switch# md5sum flash:/boot/SwitchOS-vXXX-tap-v3.0.8.bin

8771a9cb344cebb70f8baa4715f3f97d flash:/boot/SwitchOS-vXXX-tap-v3.0.8.bin
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

22 MANAGEMENT Commands

22.1 show diagnostic-information

1 Command Purpose

Use this command to display the diagnostic information of the system.

2 Command Syntax

show diagnostic-information

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Diagnostic information includes “show version” information, “show clock” information, etc.

The result is usually very long and user can print the result into a file on the flash.

6 Examples

The following example shows how to display the diagnostic information:

```
Switch# show diagnostic-information
```

7 Related Commands

show version

show clock

Copyright © 2023 Garland Technology, LLC. All rights reserved.

22.2 show services

1 Command Purpose

To display the networking services, use the show services command in privileged EXEC mode.

2 Command Syntax

show services

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

This command is used to display networking services of the switch.

6 Examples

In the following example shows how to display networking services of the switch:

```
Switch# show services

Networking services configuration:
Service Name Status Port Protocol
---------------+-------------+----------+----------
http enable 80 TCP
telnet enable 23 TCP
ssh enable 22 TCP
snmp disable 161 UDP
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

22.3 show services rpc-api

1 Command Purpose

2 Command Syntax

show services rpc-api

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

```
Switch# show services rpc-api

RPC-API service configuration:
 Server State        : disable
 Port                : 80
 Authentication Mode : none
 SSL State           : disable
```

7 Related Commands

service rpc-api

22.4 hostname

1 Command Purpose

To specify or modify the host name for the network server, use the hostname command in global configuration mode.

Use the no form of this command to reset the default value.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

hostname *NAME_STRING*

no hostname

Parameter	Parameter Description	Parameter Value
NAME_STRING	This system's network name	Up to 63 characters.

3 Command Mode

Global Configuration

4 Default

Switch

5 Usage

The host name is used in prompts and default configuration filenames.

The name must also follow the rules for ARPANET host names. They must start with a letter, and have as interior characters only letters, digits, hyphens, and underline. Names must be 63 characters or fewer.

6 Examples

The following example changes the host name to DUT1:

```
Switch(config)# hostname DUT1
```

The following example changes the host name to default:

```
DUT1(config)# no hostname
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

22.5 format

1 Command Purpose

To format file system.

2 Command Syntax

format (system | boot | *udisk:*)

Parameter	Parameter Description	Parameter Value
system	The system partition	-
boot	The boot partition	-
udisk:	The USB mass storage device (MSDOS file system)	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Format the USB mass storage device (MSDOS file system)

6 Examples

The following shows an example to format USB mass storage device:

```
Switch(config)# format udisk:

WARNING: All data on udisk: will be lost!!!
And format operation may take a while. Are you sure to process with format?
[yes/no]: yes
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

umount udisk:

22.6 umount udisk:

1 Command Purpose

To uninstall the USB mass storage device before plug out it from the switch.

2 Command Syntax

umount *udisk:*

3 Command Mode

Global Configuration

4 Default

None

5 Usage

USB mass storage device must exist in the system. You can use the “umount” command to uninstall the USB mass storage device.

6 Examples

The following example umount USB mass storage device:

```
Switch(config)# umount udisk:
```

7 Related Commands

format udisk:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

22.7 reset factory-config

1 Command Purpose

To reset factory configuration

2 Command Syntax

reset factory-config

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

The flash/boot/.factory-config.conf needs to exist for resetting factory configuration.

6 Examples

The following shows an example to reset factory configuration:

```
Switch# reset factory-config

Startup-config will be overwritten with factory-config. Continue? [yes/no]:y
```

7 Related Commands

None

22.8 management ip address dhcp

1 Command Purpose

Use this command to set the management IP address on the Switch from the dhcp protocol.

To remove the management IP address from the dhcp protocol, use the no form of this command.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

management ip address dhcp

no management ip address dhcp

3 Command Mode

Global Configuration

4 Default

None

5 Usage

User cannot connect to the device via telnet and only console port is available for management after removing the IP address.

6 Examples

The following example sets the management ipv4 address from dhcp protocol:

```
Switch(config)# management ip address dhcp
```

The following example unsets the management ipv4 address from dhcp protocol:

```
Switch(config)# no management ip address dhcp
```

7 Related Commands

management ip address

22.9 management ip address

1 Command Purpose

Use this command to set the management IP address on the Switch.

To remove the management IP address, use the no form of this command.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

management ip address *IP_ADDR_MASK*

no management ip address

Parameter	Parameter Description	Parameter Value
IP_ADDR_MASK	IP address with mask length	In A.B.C.D/M format

3 Command Mode

Global Configuration

4 Default

None

5 Usage

User cannot connect to the device via telnet and only console port is available for management after removing the IP address.

6 Examples

The following example sets the management ipv4 address:

```
Switch(config)# management ip address 10.10.39.104/23
```

The following example unsets the management ipv4 address:

```
Switch(config)# no management ip address
```

7 Related Commands

management route gateway

Copyright © 2023 Garland Technology, LLC. All rights reserved.

22.10 management ipv6 address

1 Command Purpose

Use this command to set the management IPv6 address on the Switch.

To remove the management IPv6 address, use the no form of this command.

2 Command Syntax

management ipv6 address *IPV6_ADDR_MASK*

no management ipv6 address

Parameter	Parameter Description	Parameter Value
IPV6_ADDR_MASK	IPv6 address with mask length	In X:X::X:X/M format

3 Command Mode

Global Configuration

4 Default

None

5 Usage

User cannot connect to the device via telnet and only console port is available for management after removing the IP address.

6 Examples

The following example sets the management ipv6 address:

```
Switch(config)# management ipv6 address 2000::1/64
```

The following example unsets the management ipv6 address:

```
Switch(config)# no management ipv6 address
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

management ipv6 route gateway

22.11 management route gateway

1 Command Purpose

Use this command to set the gateway on the Switch for management ip.

Use no form of this command to delete the gateway on the Switch for management ip.

2 Command Syntax

management route (add |) gateway *IP_ADDR*

no management route gateway

Parameter	Parameter Description	Parameter Value
add	Add a gateway address	-
IP_ADDR	IP address	-

3 Command Mode

Global Configuration

4 Default

None

5 Usage

Use this command to set the gateway on the Switch for management ip.

Use no form of this command to delete the gateway on the Switch for management ip.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example sets the gateway of 192.168.100.254 for the switch:

```
Switch(config)# management route add gateway 192.168.100.254
```

The following example unsets the gateway of 192.168.100.254 for the switch:

```
Switch(config)# no management route gateway
```

7 Related Commands

management ip address

22.12 management ipv6 route gateway

1 Command Purpose

Use this command to set the gateway on the Switch for management ipv6 address.

2 Command Syntax

management ipv6 route (add | del) gateway *IPV6_ADDR*

Parameter	Parameter Description	Parameter Value
add	Add a gateway ipv6 address	-
del	Delete a gateway ipv6 address	-
IPV6_ADDR	IPv6 address	-

3 Command Mode

Global Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

Use this command to set the gateway on the Switch for management ipv6 address.

6 Examples

The following example sets the gateway of 2000::64 for the switch:

```
Switch(config)# management ipv6 route add gateway 2000::64
```

7 Related Commands

management ipv6 address

22.13 service telnet enable

1 Command Purpose

Use this command to set service telnet enable.

Use the no form of this command to set service telnet disable.

2 Command Syntax

service telnet enable

no service telnet enable

3 Command Mode

Global Configuration

4 Default

Enabled

5 Usage

Uses this command to enable the telnet service.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example set telnet service enable for the switch:

```
Switch# configure terminal
Switch(config)# service telnet enable
```

The following example set telnet service disable for the switch:

```
Switch(config)# no service telnet enable

Connection closed by foreign host.
```

7 Related Commands

telnet

22.14 service http

1 Command Purpose

Use this command to set service http enable or disable or restart or timeout.

2 Command Syntax

service http (enable | disable | restart | timeout *TIMEOUT_VALUE*)

Parameter	Parameter Description	Parameter Value
enable	Enable the http service	-
disable	Disable the http service	-
restart	Restart the http service	-
timeout TIMEOUT_VALUE	Set http timeout value, unit is minute	1-60

3 Command Mode

Global Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

Enabled

Timeout default value is 10 minutes

5 Usage

Uses this command to enable or disable or restart http service or set timeout value.

6 Examples

The following example set http service enable for the switch:

```
Switch(config)# service http enable
```

The following example set http service disable for the switch:

```
Switch(config)# service http disable
```

The following example set http service restart for the switch:

```
Switch(config)# service http restart
```

7 Related Commands

show web users

22.15 service http port

1 Command Purpose

Use this command to set set http service L4 port number; use the no command to set the default http service L4 port number.

2 Command Syntax

service http port *L4_NUM_PORT*

no service http port

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

L4_NUM_PORT	Http service L4 port number	The range is 1025-65535

3 Command Mode

Global Configuration

4 Default

80

5 Usage

None

6 Examples

The following example set http service L4 port number for the switch:

```
Switch(config)# service http port 2000
```

The following example set the default http service L4 port number for the switch:

```
Switch(config)# no service http port
```

7 Related Commands

show web users

22.16 service https

1 Command Purpose

Use this command to set service https enable or disable or restart or set timeout.

2 Command Syntax

service https (enable | disable | restart | timeout *TIMEOUT_VALUE*)

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

enable	Enable the https service	-
disable	Disable the https service	-
restart	Restart the https service	-
timeout TIMEOUT_VALUE	Set https timeout value, unit is minute	1-60

3 Command Mode

Global Configuration

4 Default

Enabled

5 Usage

Uses this command to enable or disable or restart https service.

6 Examples

The following example set https service enable for the switch:

```
Switch(config)# service https enable
```

The following example set https service disable for the switch:

```
Switch(config)# service https disable
```

The following example set https service restart for the switch:

```
Switch(config)# service https restart
```

7 Related Commands

show web users

Copyright © 2023 Garland Technology, LLC. All rights reserved.

22.17 service https port

1 Command Purpose

Use this command to set set https service L4 port number; use the no command to set the default https service L4 port number.

2 Command Syntax

service https port *L4_NUM_PORT*

no service https port

Parameter	Parameter Description	Parameter Value
L4_NUM_PORT	Https service L4 port number	The range is 1025-65535

3 Command Mode

Global Configuration

4 Default

443

5 Usage

None

6 Examples

The following example set https service L4 port number for the switch:

```
Switch(config)# service https port 2000
```

The following example set the default https service L4 port number for the switch:

```
Switch(config)# no service https port
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

show web users

22.18 service rpc-api enable

1 Command Purpose

Use the command to enable rpc-api service. And use disable command to disable rpc-api service.

2 Command Syntax

service rpc-api enable (port *PORT_NUM* |) (ssl (ssl-port *SSL_PORT_NUM* |) |)

service rpc-api disable

Parameter	Parameter Description	Parameter Value
PORT_NUM	port number of https service	Default port number is 80
SSL_PORT_NUM	port number of SSL service	Default port number is 443

3 Command Mode

Global Configuration

4 Default

Disabled

5 Usage

Use this command to enable RPC-API service. If parameters need to be modified, RPC-API service need to be disable. RPC-API service can not be enable when http has been enable.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example enables encrypted RPC-API service:

```
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# service rpc-api enable ssl
Switch(config)#
```

The following example disables encrypted RPC-API service:

```
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# service rpc-api disable
Switch(config)#
```

7 Related Commands

service rpc-api auth-mode

22.19 service rpc-api auth-mode

1 Command Purpose

Use the command to configure the auth mode of RPC-API.

2 Command Syntax

service rpc-api auth-mode (basic)

no service rpc-api auth-mode

3 Command Mode

Global Configuration

4 Default

Configure the auth mode of RPC-API

5 Usage

Use this command to enable or disable the auth mode of RPC-API.If the the the auth mode has been enabled.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example enables the auth mode of RPC-API:

```
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# service rpc-api auth-mode basic
```

The following example disables the auth mode of RPC-API:

```
Switch(config)# no service rpc-api auth-mode basic
```

7 Related Commands

services rpc-api enable

22.20 certificate load pem-cert

1 Command Purpose

Use the command to import the new certificate file. Use the no command to restore the default certificate file.

2 Command Syntax

certificate load pem-cert (*FILENAME* | *GFLASHFILE*)

no certificate load pem-cert

Parameter	Parameter Description	Parameter Value
FILENAME	certificate file name, no path but suffix	-
GFLASHFILE	certificate file name with path	-

3 Command Mode

Global Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

Default certificate file

5 Usage

The private key and certificate need to be placed in the same file as the new certificate file. You need to upload the new certificate file to the any directory under the flash/ directory on the device before using this command. Ensure that the HTTPS service is turned on at the time of command execution and restart the HTTPS service after execution to take effect.

6 Examples

The following example import new certificate file cert.pem:

```
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# certificate load pem-cert flash:/boot/cert.pem
Switch(config)#
```

The following example restore the default certificate file:

```
Switch# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# no certificate load pem-cert
Switch(config)#
```

7 Related Commands

None

22.21 statistics unit

1 Command Purpose

Use the command to change the unit of traffic statistics.

2 Command Syntax

statistics unit (1 | *K* | *M* | *G*)

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

1	statistics/1	-
K	statistics/1,000	-
M	statistics/1,000,000	-
G	statistics/1,000,000,000	-

3 Command Mode

Global Configuration

4 Default

default unit is 1

5 Usage

change the unit of statistics

6 Examples

The following example change the unit:

```
Switch(config)#statistics unit K
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

23 SYSTEM CONFIGURATION Commands

23.1 disable

1 Command Purpose

To exit Privileged EXEC mode and return to user EXEC mode, enter the disable command in EXEC mode.

2 Command Syntax

disable

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

To exit Privileged EXEC mode and return to user EXEC mode, enter the disable command in EXEC mode.

The prompt for Privileged EXEC mode is “#”, for EXEC mode is “>”.

6 Examples

In the following example, the user enters Privileged EXEC mode using the enable command, then exits back to user EXEC mode using the disable command:

```
Switch# disable
Switch>
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

enable

23.2 enable

1 Command Purpose

To enter Privileged EXEC mod, use the enable command in user EXEC or Privileged EXEC mode.

2 Command Syntax

enable

3 Command Mode

User EXEC

4 Default

None

5 Usage

To enter Privileged EXEC mod, use the enable command in user EXEC or Privileged EXEC mode.

The prompt for Privileged EXEC mode is “#”, for EXEC mode is “>”.

6 Examples

In the following example, the user enters Privileged EXEC mode using the enable command. The system prompts the user for a password before allowing access to the Privileged EXEC mode. The password is not printed to the screen. The user then exits back to user EXEC mode using the disable command:

```
Switch# disable
Switch> enable
Password:
Switch#

Password:
Switch#
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

disable

enable password

23.3 logout

1 Command Purpose

To logout of the current CLI session, enter the logout command in EXEC mode.

2 Command Syntax

logout

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

To logout of the current CLI session, enter the logout command in EXEC mode.

6 Examples

In the following example, the user logout of the current CLI session using the logout command:

```
Switch# logout

Connection closed by foreign host.
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

23.4 reboot

1 Command Purpose

To reload the operating system, use the reboot command in Privileged EXEC mode.

2 Command Syntax

reboot

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

The reboot command halts the system. Use the reboot command after configuration information is entered into a file and saved to the startup configuration.

6 Examples

The following example is sample dialog from the reboot command:

```
Switch# reboot

Building configuration...
Reboot system? [confirm]y
Waiting ...
% Connection is closed by administrator!
```

7 Related Commands

write

23.5 show file system

1 Command Purpose

Use this command to show file system information.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

show file system

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use this command to show file system information.

6 Examples

The following example is to show file system information:

```
Switch# show file system

Type         Size         Used         Free         Use%
=============================================================================
flash:/      887M         56M          827M         7%
flash:/boot  776M         360M         412M         47%
udisk:       0B           0B           0B           100%
```

7 Related Commands

None

23.6 show management ip address

1 Command Purpose

Use this command to show management interface ip address.

2 Command Syntax

show management ip address

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use this command to show management interface ip address.

6 Examples

The following example is to show management interface ip address:

```
Switch# show management ip address

Management IP address:  10.10.39.131/23
Gateway:  0.0.0.0
```

7 Related Commands

management ip address

management route gateway

23.7 show startup-config

1 Command Purpose

Use this command to show contents of startup configuration.Default configuration don't dispaly.

2 Command Syntax

show startup-config

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

Use this command to show contents of startup configuration.Default configuration don't display.

6 Examples

The following example is to show contents of startup configuration:

```
Switch# show startup-config

hostname Switch
timestamp sync systime
enable password abc
!
username admin privilege 4 password admin
username test privilege 4 password test
!
!
logging server enable
!
radius-server host mgmt-if 1.1.1.1
!
tacacs-server host mgmt-if 1.1.1.2
!
tacacs-server host mgmt-if 2.1.1.1 key mykey
!
!
ntp authentication enable
!
ntp key 43 aNickKey
ntp trustedkey 43
ntp key 123 ntpkty123
!
ntp server mgmt-if 1.1.1.1
ntp server mgmt-if 10.10.25.8
ntp server mgmt-if 192.16.22.44 version 2
!
snmp-server enable
snmp-server system-contact admin@example.com
!
snmp-server view view1 included .1.2.3.4 mask f
!
snmp-server trap target-address mgmt-if 10.10.27.232 community sysname
!
snmp-server inform target-address mgmt-if 10.10.27.233 community sysname
!
management ip address 10.10.39.104/23
management route add gateway 10.10.39.254
!
port-channel load-balance hash-arithmetic crc
port-channel load-balance set vxlan-vni
port-channel load-balance set inner-dst-mac
!
ip access-list a
!
ip access-list e1
!
ip access-list aaaa
!
flow f1
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
!
flow f2
!
sflow enable
sflow agent ip 10.0.0.254
sflow counter interval 10
!
interface eth-0-1
 description TenGigabitEthernet
 speed 1000
 shutdown
!
interface eth-0-2
 shutdown
!
interface eth-0-3
 shutdown
 static-channel-group 10
!
interface eth-0-4
 shutdown
 static-channel-group 10
!
interface eth-0-5
 shutdown
 static-channel-group 5
!
interface eth-0-6
 shutdown
!
interface eth-0-7
 shutdown
 sflow counter-sampling enable
 sflow flow-sampling enable input
 sflow flow-sampling rate 2048
!
interface eth-0-8
 shutdown
!
interface eth-0-9
 shutdown
!
interface eth-0-10
 shutdown
!
interface eth-0-11
!
interface eth-0-12
!
interface eth-0-13
!
interface eth-0-14
!
interface eth-0-15
!
interface eth-0-16
!
interface eth-0-17
!
interface eth-0-18
!
interface eth-0-19
!
interface eth-0-20
!
interface eth-0-21
!
interface eth-0-22
!
interface eth-0-23
!
interface eth-0-24
!
interface eth-0-25
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
!
interface eth-0-26
!
interface eth-0-27
!
interface eth-0-28
!
interface eth-0-29
!
interface eth-0-30
!
interface eth-0-31
!
interface eth-0-32
!
interface eth-0-33
!
interface eth-0-34
!
interface agg5
 description LinkAgg5
!
interface agg10
!
tap-group tap1 1
 ingress eth-0-1 flow f1
 egress eth-0-9
!
tap-group tap2 2
 ingress eth-0-21
 egress eth-0-22
!
tap-group g1 3
 ingress eth-0-33
!
line console 0
 privilege level 4
 no line-password
 no login
line vty 0 7
 exec-timeout 35791 0
 privilege level 4
 no line-password
 no login
```

7 Related Commands

write

23.8 write

1 Command Purpose

Use this command to write startup configuration.

2 Command Syntax

write

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use this command to write startup configuration.

6 Examples

The following example is to write startup configuration:

```
Switch# write
[OK]
```

7 Related Commands

show startup-config

23.9 boot system flash

1 Command Purpose

To specify the system image that the switch loads at startup in flash, use the following boot system commands in Privileged EXEC mode.

2 Command Syntax

boot system flash *STRING*

Parameter	Parameter Description	Parameter Value
STRING	System image file for next booting	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use this command to specify an image to boot system.

This command will take effect after reboot.

6 Examples

The following example is sample dialog from the boot system command:

```
Switch# boot system flash:/boot/SecPathTAP2000A-IMW110-E6601.BIN.01

Are you sure to use flash:/boot/SecPathTAP2000A-IMW110-E6601.BIN.01 as the next
boot image? [confirm]y
Waiting ........ success
```

7 Related Commands

reboot

23.10 boot system tftp:

1 Command Purpose

To specify the system image that the switch loads at startup in tftp, use the following boot system commands in Privileged EXEC mode.

2 Command Syntax

boot system *tftp:* mgmt-if *IP_ADDR STRING*

Parameter	Parameter Description	Parameter Value
IP_ADDR	Server IP	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

STRING	Image file name	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Management IP address in startup-config file will be used as source address when system boot via TFTP.

This command will take effect after reboot.

6 Examples

The following example is sample dialog from the boot system via tftp command:

```
Switch# boot system tftp: mgmt-if 10.10.38.160 SecPathTAP2000A-IMW110-E6601.BIN.01
Waiting . success
```

7 Related Commands

reboot

23.11 show boot

1 Command Purpose

To display the current image and the image the next startup will load, use the show boot command in Privileged EXEC mode.

2 Command Syntax

show boot (image |)

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
image	Show the detailed information about the boot image.	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use this command to display the current image and the image the next startup will load.

6 Examples

The following is sample output from the show boot command:

```
Switch# show boot

The current boot image version is: 1.10, ESS 6601
The current running image is: flash:/boot/SecPathTAP2000A-IMW110-E6601.BIN.01
The next running image is: tftp://10.10.38.160/SecPathTAP2000A-IMW110-E6601.BIN.01
```

The following is sample output from the show boot image command:

```
Switch# show boot image

Current boot image version: E580-1.10, ESS 6601
System image files list:
  Create Time           Version               File name
----------------------+---------------------+---------------------------------
  2017-08-02 13:32:31   v5.1.4                CNOS-e580-hybrid-v5.1.4.bin
* 2017-09-21 15:43:52   v1.10, ESS 6601       SecPathTAP2000A-IMW110-E6601.BIN.01
```

7 Related Commands

boot system flash

boot system tftp:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

23.12 show memory

1 Command Purpose

Use this command to show memory with keyword.

2 Command Syntax

show memory (ccs | cds | switch | chsm | appcfg | fea | authd | all)

Parameter	Parameter Description	Parameter Value
ccs	Configure center service	-
cds	Data center service	-
switch	Switch process	-
chsm	Chassis manage process	-
appcfg	Application configure process	-
fea	Forwarding process	-
authd	Authentication daemon process	-
all	All processes	-

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following is sample output from the show memory appcfg command:

```
Switch# show memory appcfg

AppCfg Memory Information:
Type   Description                          Alloc Count  Alloc Size
-------------------------------------------------------------------
0      MEM_TEMP                           : 1            8188
2      MEM_LIB_HASH                       : 16           320
3      MEM_LIB_HASH_BACKET_LIST           : 16           131008
4      MEM_LIB_HASH_BACKET                : 37           444
9      MEM_LIB_SOCK_MASTER                : 1            192
10     MEM_LIB_SOCK                       : 5            1280
11     MEM_LIB_SOCK_SESSION               : 7            229348
12     MEM_LIB_SOCK_DATA                  : 1            16
16     MEM_LIB_SLIST                      : 113          2260
17     MEM_LIB_SLISTNODE                  : 57           684
22     MEM_TBL_MASTER                     : 44           9788
23     MEM_TBL_INTERFACE                  : 37           28416
67     MEM_TBL_SYS_GLOBAL                 : 1            384
68     MEM_TBL_VERSION                    : 1            768
72     MEM_TBL_CHASSIS                    : 1            64
77     MEM_TBL_SYS_SPEC                   : 8            3072
84     MEM_TBL_MEM_SUMMARY                : 1            28
112    MEM_TBL_SSH_CFG                    : 1            48
113    MEM_TBL_SNMP_CFG                   : 1            768
114    MEM_TBL_SNMP_VIEW                  : 1            256
116    MEM_TBL_SNMP_TRAP                  : 1            384
117    MEM_TBL_SNMP_INFORM                : 1            384
118    MEM_TBL_SYSLOG_CFG                 : 1            384
119    MEM_TBL_NTP_SERVER                 : 3            288
121    MEM_TBL_NTP_KEY                    : 2            80
122    MEM_TBL_NTP_CFG                    : 1            64
123    MEM_TBL_NTP_IF                     : 1            8
124    MEM_TBL_NTP_IF                     : 1            256
125    MEM_TBL_USER                       : 2            1536
126    MEM_TBL_VTY                        : 8            32736
127    MEM_TBL_CONSOLE                    : 1            768
128    MEM_TBL_AUTHEN                     : 1            192
129    MEM_TBL_LOGIN                      : 3            1152
161    MEM_TBL_LOG_GLOBAL                 : 1            12
163    MEM_TBL_SYS_LOAD                   : 1            32
165    MEM_TBL_CLOCK                      : 1            40
177    MEM_TBL_OPM_GLOBAL                 : 1            4
180    MEM_TBL_OPM_DEBUG                  : 1            4
194    MEM_TBL_DOT1X_GLOBAL               : 1            768
198    MEM_TBL_ENABLE                     : 4            3072
199    MEM_TBL_CHIP                       : 1            4
201    MEM_TBL_AUTHOR                     : 1            192
202    MEM_TBL_ACCOUNT                    : 1            192
203    MEM_TBL_ACCOUNTCMD                 : 1            192
229    MEM_TBL_SFLOW_GLOBAL               : 1            48
234    MEM_DS_BRGIF                       : 36           27648
235    MEM_DS_LAG                         : 5            80
245    MEM_DS_ACLQOS_IF                   : 3            3072
247    MEM_DS_DHCLIENT_IF                 : 36           9216
262    MEM_PM_TEMP                        : 1            4092
263    MEM_PM_LIB_MASTER                  : 1            1024
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

show memory summary

23.13 show memory summary

1 Command Purpose

Use this command to show the summary of memory states.

2 Command Syntax

show memory summary total

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following is sample output from the show memory summary command:

```
Switch# show memory summary total

Total memory      : 940428 KB
Used memory       : 259228 KB
Freed memory      : 681200 KB
Buffer memory     : 0 KB
Cached memory     : 125848 KB
Memory utilization: 27.56%
```

7 Related Commands

show memory

Copyright © 2023 Garland Technology, LLC. All rights reserved.

23.14 show cpu utilization

1 Command Purpose

Use this command to show utilizations of cpu.

2 Command Syntax

show cpu utilization

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use this command to show utilizations of cpu.

6 Examples

The following is sample output from the show cpu utilization command:

```
Switch# show cpu utilization

Process              Usage(%)
--------------------+----------
python               3.42
fea                  2.62
switch               0.20
appcfg               0.10
cds                  0.10
snmpd                0.10
ccs                  0.10
kworker              0.10
Others               5.55
------------------------------
Total                12.29
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

23.15 terminal length

1 Command Purpose

Use this command to set number of terminal lines on a screen. Range is 0 to 512.

Use the no form of this command to restore the default value.

2 Command Syntax

terminal length *TERM_LINES*

terminal no length

Parameter	Parameter Description	Parameter Value
TERM_LINES	Number of lines on screen (0 for no pausing)	-

3 Command Mode

Privileged EXEC

4 Default

0 (no pausing)

5 Usage

None

6 Examples

The following is sample to set terminal length lines:

```
Switch# terminal length 100
```

The following is sample to unset terminal length lines:

```
Switch# terminal no length
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

None

23.16 terminal monitor

1 Command Purpose

To copy debug output to the current terminal line, use the terminal monitor command in Privileged EXEC mode.

To close the debug output to the current terminal line, use the no form of this command.

2 Command Syntax

terminal monitor

terminal no monitor

3 Command Mode

Privileged EXEC

4 Default

Debug output to the current terminal line is closed

5 Usage

To copy debug output to the current terminal line, use the terminal monitor command in Privileged EXEC mode.

To close the debug output to the current terminal line, use the no form of this command.

6 Examples

The following is sample output from the terminal monitor command:

```
Switch# terminal monitor
```

The following is sample close the debug output to the current terminal line:

```
Switch# terminal no monitor
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

debug aaa

debug sflow

23.17 cd

1 Command Purpose

Change the current directory to dir, use the cd command in EXEC mode.

2 Command Syntax

cd (*STRING* |)

Parameter	Parameter Description	Parameter Value
STRING	Directory name	-

3 Command Mode

Privileged EXEC

4 Default

The initial default file system is flash:. If you do not specify a directory on a file system, the default is the root directory on that file system.

5 Usage

Change the current directory to dir, use the cd command in EXEC mode.

6 Examples

In the following example, the cd command is set the flash:/boot file system to the Flash memory:

```
Switch# cd flash:/boot
Switch# pwd

flash:/boot
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

pwd

23.18 mkdir

1 Command Purpose

To create a new directory in a Flash file system, use the mkdir command in EXEC mode.

2 Command Syntax

mkdir *STRING*

Parameter	Parameter Description	Parameter Value
STRING	Directory name or file name	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

This command is valid only for local file systems.

6 Examples

The following example creates a directory named newdir in Flash:

```
Switch# mkdir flash:/newdir
```

7 Related Commands

rmdir

Copyright © 2023 Garland Technology, LLC. All rights reserved.

dir

23.19 rmdir

1 Command Purpose

To remove an existing directory in a Flash file system or udisk device, use the rmdir command in Privileged EXEC mode.

2 Command Syntax

rmdir *STRING*

Parameter	Parameter Description	Parameter Value
STRING	Directory name or file name	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

This command is valid only for local file systems.

6 Examples

The following example deletes a directory named newdir:

```
Switch# rmdir flash:/newdir

Are you sure to delete flash:/newdir ? [no]y
```

7 Related Commands

mkdir

Copyright © 2023 Garland Technology, LLC. All rights reserved.

23.20 pwd

1 Command Purpose

Use this command to print working directory.

2 Command Syntax

pwd

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use this command to print working directory.

6 Examples

The following example print current working directory:

```
Switch# pwd
flash:/
```

7 Related Commands

cd

23.21 ls

1 Command Purpose

To display a list of files on a file system, use the ls command in EXEC mode.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

ls (*flash:* | *flash:/boot* | *udisk:* |) (*STRING* |)

Parameter	Parameter Description	Parameter Value
flash:	File system on the flash	-
flash:/boot	File path “flash:/boot”	-
udisk:	USB storage devices	-
STRING	Directory name or file name	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use the ls (Flash file system) command to display flash information.

6 Examples

The following is sample output from the ls command:

```
Switch# ls

Directory of flash:/

total 3196
-rw-r--r-- 1    1371 May 31 22:32 001E080BE6C2.1.lic
-rwxr-xr-x 1  295938 Aug 15 10:26 AQR-G2_v3.2.5_ID19866_VER537.cld
-rw-r--r-- 1   39861 Jul  5 15:07 E580_48X2Q4Z_EPLD-4.1_0410_POWERDOWN.tar.gz
drwxr-xr-x 2    2464 Sep 22 14:41 boot
drwxr-xr-x 7     760 Aug 15 10:26 cold
drwxr-xr-x 3    1016 Sep 22 14:42 conf
-rw-r--r-- 1     147 Aug 15 10:31 dhcpsnooping
-rw------- 1     151 Aug 15 10:31 dhcpv6snooping
drwxr-xr-x 2     728 Sep  4 20:53 info
-rw-r--r-- 1     909 Jul 18 13:30 init_flow
-rw-r--r-- 1    3181 Aug 15 10:09 jinl_astp
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
drwxr-xr-x 3     224 Aug 10 11:25 lib
-rw-r--r-- 1    2180 Jul 13 16:09 liujy_lab.conf
drwxr-xr-x 2     288 Jul  1  2016 log
drwxr-xr-x 7     488 Aug 23  2016 monitor
drwxr-xr-x 2     232 May  2 19:03 reboot-info
-rw-r--r-- 1   11963 Mar 30 18:21 route.txt
-rw-r--r-- 1    2624 Sep 22 14:41 startup-config.conf
-rw------- 1   13686 Apr 10 18:57 startup-config.conf.2017-4-10
-rw-r--r-- 1    1314 May  4 18:48 startup-config.conf.empty
-rw-r--r-- 1    1694 Apr 21 17:40 startup-config.conf_0421
-rwxr-xr-x 1 1015068 Mar 18  2017 stressapptest
-rw-r--r-- 1 1155521 Sep 22 15:56 syslog
drwxr-xr-x 2    4192 Sep 12 06:09 syslogfile

Total 887.00M bytes (875.00M bytes free)
```

7 Related Commands

dir

23.22 copy running-config

1 Command Purpose

To copy current device configuration to other files, use this command in EXEC mode.

2 Command Syntax

copy running-config (mgmt-if |) (*STRING* |)

Parameter	Parameter Description	Parameter Value
mgmt-if	Need to connect to the URL via management interface	-
STRING	Copy to URL and local file name	-

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

Use this command to copy current running-config to destination file.

6 Examples

The following example copies the current configuration to the file named current-config.conf:

```
Switch# copy running-config flash:/current-config.conf
flash:/current-config.conf
[OK]
```

7 Related Commands

delete

23.23 copy startup-config

1 Command Purpose

Use this command to copy startup-config to tftp server or dest file.

2 Command Syntax

copy startup-config (mgmt-if |) (*STRING* |)

Parameter	Parameter Description	Parameter Value
mgmt-if	Need to connect to the URL via management interface	-
STRING	Copy to URL and local file name	-

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

None

6 Examples

This is a sample output from the command displaying how to copy startup-config to tftp server:

```
Switch# copy startup-config mgmt-if tftp://10.10.38.160/

TFTP server [10.10.38.160]
Name of the TFTP file to access [] startup-config
Send file to tftp://10.10.38.160/startup-config
.
Sent 2337 bytes in 0.0 seconds
```

7 Related Commands

delete

23.24 copy mgmt-if

1 Command Purpose

Use this command to copy file from tftp server to local.

2 Command Syntax

copy mgmt-if *SRC_STRING DST_STRING*

Parameter	Parameter Description	Parameter Value
SRC_STRING	Copy from URL	-
DST_STRING	Copy to local file	-

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

Use this command to copy file from tftp server to local.

6 Examples

This is a sample output from the command displaying how to copy file from tftp server to local:

```
Switch# copy mgmt-if tftp://10.10.38.160 flash:/boot


TFTP server [10.10.38.160]
Name of the TFTP file to access [] collections.py
Download from URL to temporary file.
Get file from tftp://10.10.38.160/collections.py
.
Received 25403 bytes in 0.2 seconds
Copy the temporary file to its destination.
.
File system synchronization. Please waiting...
25403 bytes in 0.1 seconds, 248 kbytes/second
```

7 Related Commands

delete

23.25 copy

1 Command Purpose

Use this command to copy file from local file to tftp server or local.

2 Command Syntax

copy *SRC_STRING* mgmt-if *DST_STRING*

Parameter	Parameter Description	Parameter Value
SRC_STRING	Copy from URL	-
DST_STRING	Copy to local file	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

This is a sample output from the command displaying how to copy file from local file to tftp server:

```
Switch# copy flash:/startup-config.conf mgmt-if tftp://10.10.38.160

TFTP server [10.10.38.160]
Name of the TFTP file to access [] startup-config.conf
Send file to tftp://10.10.38.160/startup-config.conf
.
Sent 2177 bytes in 0.1 seconds
```

7 Related Commands

delete

23.26 more

1 Command Purpose

To display the contents of a file, use the more command in EXEC mode.

2 Command Syntax

more *STRING*、

Parameter	Parameter Description	Parameter Value
STRING	Text file name	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

The system can only display a file in ASCII format.

6 Examples

The following partial sample output displays the configuration file named startup-config in flash:

```
Switch# more flash:/startup-config.conf
```

7 Related Commands

dir

23.27 delete

1 Command Purpose

To delete a file on the flash, use the delete command in Privileged EXEC mode.

2 Command Syntax

delete *STRING*、

Parameter	Parameter Description	Parameter Value
STRING	File name for delete	-

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

If you attempt to delete the configuration file or image, the system prompts you to confirm the deletion.

6 Examples

The following example deletes the file named test from the flash:

```
Switch# delete flash:/test

Are you sure to delete flash:/test? [no]y
```

7 Related Commands

copy

23.28 rename

1 Command Purpose

To rename a file in a Class C Flash file system or udisk device, use the rename command in EXEC mode.

2 Command Syntax

rename *OLD_STRING NEW_STRING*

Parameter	Parameter Description	Parameter Value
OLD_STRING		-
NEW_STRING		-

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

This command is valid only for local file systems.

6 Examples

In the following example, the file named startup-config.conf-bak is renamed startup-config.conf-bak1:

```
Switch# rename flash:/startup-config.conf-bak flash:/startup-config.conf-bak1
Are you sure to rename flash:/startup-config.conf-bak ? [confirm]y
.
File system synchronization. Please waiting...
1061 bytes in 0.1 seconds, 10 kbytes/second
```

7 Related Commands

ls

23.29 source

1 Command Purpose

Read and execute commands from filename in the shell environment.

2 Command Syntax

source *STRING*

Parameter	Parameter Description	Parameter Value
STRING	Configuration file	-

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

None

6 Examples

The following is show how to source commands from a file:

```
Switch# source flash:/bash_shutdown.txt
Switch# configure terminal

Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# interface range eth-0-5 - 7
Switch(config-if-range)# shutdown
Switch(config-if-range)# end
Switch#
```

7 Related Commands

None

23.30 system min-frame check

1 Command Purpose

Use this command enable system min frame check, system min frame size is 64bytes.

2 Command Syntax

system min-frame check enable

no system min-frame check enable

Parameter	Parameter Description	Parameter Value
enable	enable system min frame check	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Global Configuration

4 Default

enable

5 Usage

None

6 Examples

The following example shows how to enable system min frame check:

```
Switch(config)# system min-frame check enable
```

The following example shows how to disable system min frame check:

```
Switch(config)# no system min-frame check enable
```

7 Related Commands

None

23.31 banner

1 Command Purpose

Use this command to define a banner

2 Command Syntax

banner (exec | login) *STRING*

no banner (exec | login)

Parameter	Parameter Description	Parameter Value
exec	exec banner	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

login	login banner	-
STRING	banner text information	c banner-text c, where 'c' is a delimiting character, only allow '0-9A-Za-z,@._-'

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

6 Examples

The following example shows how to define a exec banner:

```
Switch(config)# banner exec @no_delete_configuration@
```

7 Related Commands

None

23.32 do

1 Command Purpose

Use this command to execute the commands in EXEC mode

2 Command Syntax

do *COMMAND_STRING*

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
COMMAND_STRING	The string of the command	-

3 Command Mode

All Configuration Mode

4 Default

None

5 Usage

None

6 Examples

The following example shows how to execute the do command:

```
Switch# configure terminal
Switch(config)# do show interface eth-0-1

Interface eth-0-1
  Interface current state: DOWN
  Hardware is Port, address is 001e.080b.e6c2
  Bandwidth 1000000 kbits
  Index 1 , Metric 1
  Speed - auto ,  Duplex - auto ,  Metadata - Disable ,  Media type is UNKNOWN
  Link type is autonegotiation
  Admin input flow-control is off, output flow-control is off
  Oper input flow-control is off, output flow-control is off
  The Maximum Frame Size is 12800 bytes
    5 minute input rate 0 bits/sec, 0 packets/sec
    5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes
    Received 0 unicast, 0 broadcast, 0 multicast
    0 runts, 0 giants, 0 input errors, 0 CRC
    0 frame, 0 overrun, 0 pause input
    0 packets output, 0 bytes
    Transmitted 0 unicast, 0 broadcast, 0 multicast
    0 underruns, 0 output errors, 0 pause output
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

24 DEVICE Commands

24.1 show version

1 Command Purpose

To display the version information of the hardware and firmware, use the show version command in EXEC mode.

2 Command Syntax

show version

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

This command can display the version information of the hardware and firmware.

6 Examples

This example shows how to display version information of the hardware and firmware:

```
Switch# show version

i-Ware Software, Version 1.10, ESS 6601 01
Vendor Information
SecPath FW uptime is 0 weeks, 1 day, 1 hours, 16 minutes
Boot image: flash:/boot/SecPathTAP2000S-IMW110-E6601.BIN
Boot image version: 1.10, ESS 6601 01
Next running image : flash:/boot/SecPathTAP2000S-IMW110-E6601.BIN
SLOT 1
Hardware Type        : switch
SDRAM size           : 2048M
Flash size           : 2048M
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Hardware Version     : 1.2
EPLD Version         : 2.1
BootRom Version      : 6.1.1
System serial number : E101ZB142025
```

7 Related Commands

None

24.2 show stm prefer

1 Command Purpose

Use the show stm prefer privileged EXEC command to display information about the profiles that can be used to maximize system resources for a particular feature.

2 Command Syntax

show stm prefer (current | next | default)

Parameter	Parameter Description	Parameter Value
current	Current profile information	-
next	Next profile information	-
default	Balance on all kinds of tables size	-

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

The numbers displayed for each profile represent an approximate maximum number for each feature resource. Use this command to show the default balance on all kinds of tables size.

6 Examples

This is an example of output from the show stm prefer current command:

```
Switch# show stm prefer current

number of tap group                       : 1/512
number of tap ingress truncation          : 0/4
number of link aggregation(static)        : 0/31
number of Flow features:
    Flow entry ingress entries            : 0/1024
    Flow entry egress entries             : 0/255
    System Flow configure                 : 2/4096
    System Flow entry configure           : 0/8192
    System L4 Port Range entries          : 0/7
```

7 Related Commands

stm prefer

24.3 show transceiver

1 Command Purpose

Use this command to show the transceiver information.

2 Command Syntax

show transceiver (*IF_NAME_E* |) (detail |)

Parameter	Parameter Description	Parameter Value
IF_NAME_E	Ethernet interface name	-
detail	Show detailed information	-

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

Use this command to show the interface transceiver information, or the transceiver detail information.

6 Examples

This example shows how to display transceiver information:

```
Switch# show transceiver detail

Port eth-0-17 transceiver info:
Transceiver Type: 1000BASE-T_SFP
 Transceiver Vendor Name : INNOLIGHT
 Transceiver PN          : TC-SORJZ-N00
 Transceiver S/N         : IN0912SZ01025C
Transceiver Output Wavelength: N/A
Supported Link Type and Length:
      Link Length for copper: 100 m
Digital diagnostic is not implemented.
Port eth-0-21 transceiver info:
Transceiver Type: 1000BASE-SX
 Transceiver Vendor Name : FINISAR CORP.
 Transceiver PN          : FTLF8519P3BTL
 Transceiver S/N         : PPB2DL1
Transceiver Output Wavelength: 850 nm
Supported Link Type and Length:
      Link Length for 50/125um multi-mode fiber: 300 m
      Link Length for 62.5/125um multi-mode fiber: 150 m
--------------------------------------------------------------------------------
Transceiver is internally calibrated.
mA: milliamperes, dBm: decibels (milliwatts), NA or N/A: not applicable.
++ : high alarm, +  : high warning, -  : low warning, -- : low alarm.
The threshold values are calibrated.
--------------------------------------------------------------------------------
                                  High Alarm  High Warn   Low Warn    Low Alarm
                Temperature       Threshold   Threshold   Threshold   Threshold
Port            (Celsius)         (Celsius)   (Celsius)   (Celsius)   (Celsius)
--------------+-----------------+-----------+-----------+-----------+----------
eth-0-21     32.92              110.00      93.00       -30.00      -40.00
--------------------------------------------------------------------------------
                                  High Alarm  High Warn   Low Warn    Low Alarm
                Voltage           Threshold   Threshold   Threshold   Threshold
Port            (Volts)            (Volts)     (Volts)     (Volts)     (Volts)
--------------+-----------------+-----------+-----------+-----------+----------
eth-0-21     3.29               3.60        3.50        3.10        3.00
--------------------------------------------------------------------------------
                                  High Alarm  High Warn   Low Warn    Low Alarm
                Current           Threshold   Threshold   Threshold   Threshold
Port            (milliamperes)      (mA)        (mA)        (mA)        (mA)
--------------+-----------------+-----------+-----------+-----------+----------
eth-0-21     6.53               13.00       12.50       2.00        1.00
--------------------------------------------------------------------------------
                Optical           High Alarm  High Warn   Low Warn    Low Alarm
                Transmit Power    Threshold   Threshold   Threshold   Threshold
Port             (dBm)              (dBm)       (dBm)       (dBm)       (dBm)
--------------+-----------------+-----------+-----------+-----------+----------
eth-0-21     -5.08              0.00        -3.00       -9.50       -13.50
--------------------------------------------------------------------------------
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
                Optical           High Alarm  High Warn   Low Warn    Low Alarm
                Receive Power     Threshold   Threshold   Threshold   Threshold
Port             (dBm)              (dBm)       (dBm)       (dBm)       (dBm)
---------------+-----------------+-----------+-----------+-----------+----------
eth-0-21     -6.68              0.50        -1.00       -16.99      -21.02
```

7 Related Commands

None

24.4 show system summary

1 Command Purpose

Use this command to show the summary of system information.

2 Command Syntax

show system summary

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

This command to show the summary of system information.

6 Examples

This example shows how to display the summary of system information:

```
Switch# show system summary

########## Version Table ##########
i-Ware Software, Version 1.10, ESS 6601 01
Vendor Information
SecPath FW uptime is 0 weeks, 0 day, 0 hours, 52 minutes
Boot image: flash:/boot/SecPathTAP2000A-IMW110-E6601.BIN.03
Boot image version: 1.10, ESS 6601 01
Next running image : flash:/boot/SecPathTAP2000A-IMW110-E6601.BIN.03
SLOT 1
Hardware Type        : switch
SDRAM size           : 1024M
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Flash size           : 2048M
Hardware Version     : 2.0
EPLD Version         : 1.2
BootRom Version      : 8.1.3
System serial number : E142GD16107A
########## Management IP Table ##########
Management IP address:  10.10.39.104/23
Gateway:  10.10.39.254
########## Route Mac Table ##########
  Route MAC is: 001e.080b.e6c2
########## Users Table ##########
 Line            Host(s)     Idle       Location        User
---------------+----------+----------+---------------+----------
 130 vty  0      idle        00:51:05   Local
 131 vty  1      idle        00:50:30   10.10.25.25
*132 vty  2      idle        00:00:00   10.10.25.25
########## Memory Summary Table ##########
Total memory       : 940428 KB
Used memory        : 260220 KB
Freed memory       : 680208 KB
Buffer memory      : 0 KB
Cached memory      : 125840 KB
Memory utilization: 27.67%
```

7 Related Commands

None

24.5 show reboot-info

1 Command Purpose

Use this command to show reboot information.

2 Command Syntax

show reboot-info

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use this command to show reboot information.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to display reboot information:

```
Switch# show reboot-info

Times      Reboot Type     Reboot Time
----------+---------------+--------------------
1          MANUAL          2017-06-27 06:46:19
2          MANUAL          2017-06-28 02:12:28
3          MANUAL          2017-06-30 08:34:57
4          MANUAL          2017-07-05 09:45:01
5          MANUAL          2017-07-13 08:12:08
6          POWER           2017-07-23 09:47:32
7          POWER           2017-07-30 05:47:48
8          POWER           2017-07-30 08:37:03
9          POWER           2017-08-03 02:14:48
10         MANUAL          2017-08-03 12:07:06
11         MANUAL          2017-08-05 03:41:58
12         MANUAL          2017-08-05 06:30:18
13         BHMDOG          2017-08-05 16:48:30
14         POWER           2017-08-10 03:19:47
15         MANUAL          2017-08-10 03:27:31
16         MANUAL          2017-08-10 03:34:27
17         UNKNOWN         2017-08-11 06:48:21
18         MANUAL          2017/08/15 02:13:55
19         POWER           2017/08/15 02:22:21
20         MANUAL          2017/08/15 02:26:27
21         MANUAL          2017/08/15 02:29:39
22         MANUAL          2017/08/15 02:32:37
23         MANUAL          2017/08/15 02:35:11
24         POWER           2017-08-15 07:51:14
25         MANUAL          2017-08-15 08:19:48
26         UNKNOWN         2017-08-15 08:40:01
27         MANUAL          2017-08-15 08:44:19
28         MANUAL          2017-08-16 03:43:38
29         MANUAL          2017-08-17 07:00:46
30         MANUAL          2017-08-18 07:23:43
31         POWER           2017-09-12 02:34:24
32         UNKNOWN         2017-09-12 05:56:16
33         POWER           2017-09-12 07:17:19
34         POWER           2017-09-12 07:22:47
35         ABNORMAL        2017-09-12 07:31:32
36         MANUAL          2017-09-12 07:44:43
37         MANUAL          2017-09-12 07:50:12
38         MANUAL          2017-09-12 07:57:50
39         MANUAL          2017-09-19 13:07:38
40         POWER           2017-09-20 10:07:18
41         MANUAL          2017-09-20 10:26:10
42         ABNORMAL        2017-09-21 06:38:38
43         MANUAL          2017-09-21 06:50:39
44         MANUAL          2017-09-21 07:13:14
45         MANUAL          2017-09-21 07:36:41
46         MANUAL          2017-09-21 07:47:01
47         MANUAL          2017-09-21 13:05:42
48         MANUAL          2017-09-22 06:42:49
49         MANUAL          2017-09-26 11:48:08
50         MANUAL          2017-09-26 13:03:57
```

7 Related Commands

clear reboot-info

Copyright © 2023 Garland Technology, LLC. All rights reserved.

24.6 clear reboot-info

1 Command Purpose

Use this command to clear reboot information.

2 Command Syntax

clear reboot-info

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

The clear reboot-info command can clear reboot information.

6 Examples

The following example shows how to clear reboot information:

```
Switch# clear reboot-info
```

7 Related Commands

show reboot-info

24.7 set device id-led

1 Command Purpose

Use this command to set the device indicate led force on or force off.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

set device id-led (on | off)

Parameter	Parameter Description	Parameter Value
on	Turn on the led	-
off	Turn off the led	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

The command can set device indicate led force on or force off.

6 Examples

The following example shows how to set device indicate led force on:

```
Switch# set device id-led on
```

7 Related Commands

show device id-led

24.8 show device id-led

1 Command Purpose

Use this command to show device indicate led information.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

show device id-led

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

Use this command to show device indicate led information.

6 Examples

The following example shows the device indicates led information:

```
Switch# show device id-led

Indicate led is forced on
```

7 Related Commands

set device id-led

24.9 show schedule reboot

1 Command Purpose

Use this command to show schedule reboot information.

2 Command Syntax

show schedule reboot

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

Use this command to show schedule reboot information.

6 Examples

The following example shows schedule reboot information:

```
Switch# show schedule reboot

Current time is : 2017-09-26 22:14:49
Will reboot at  : 2017-09-26 23:48:44
```

7 Related Commands

schedule reboot delay

schedule reboot at

24.10 stm prefer

1 Command Purpose

Use the stm prefer Global Configuration command to configure the profile used in Switch Table Management (STM) resource allocation. You can use profile to allocate system memory to best support the features being used in your application. Use profile to approximate the maximum number of unicast MAC addresses, quality of service (QoS) access control entries (ACEs) and unicast routes.

2 Command Syntax

stm prefer default

3 Command Mode

Global Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

System use the default profile when first boot up, this profile balance all the features.

5 Usage

Users must reload the switch for the configuration to take effect.

6 Examples

This example shows how to configure the default profile on the switch:

```
Switch(config)# stm prefer default

% Changes to STM profile have been stored, but cannot take effect until the next
reload. Use 'show stm prefer current' to see what STM profile is currently active.
```

7 Related Commands

show stm prefer current

show stm prefer next

24.11 temperature

1 Command Purpose

Use this command to specify the system temperature monitor threshold.

Use the no form of this command to restore the default value.

2 Command Syntax

temperature *TEMP_LOW TEMP_HIGH TEMP_CRIT*

no temperature

Parameter	Parameter Description	Parameter Value
TEMP_LOW	Low alarm temperature degree Celsius	range -15 to 50

Copyright © 2023 Garland Technology, LLC. All rights reserved.

TEMP_HIGH	High alarm temperature degree Celsius	range 50 to 85
TEMP_CRIT	Critical temperature degree Celsius	range 55 to 90

3 Command Mode

Global Configuration

4 Default

The default threshold is low temperature 5, high temperature 65, and critical temperature 80.

5 Usage

The unit for temperature is centigrade. The critical temperature must higher than high temperature 5 Celsius degrees. The high temperature must higher than low temperature 5 Celsius degrees.

6 Examples

This example shows how to specify the temperature thresholds:

```
Switch(config)# temperature 5 70 80
```

This example shows how to specify the temperature thresholds to default value:

```
Switch(config)# no temperature
```

7 Related Commands

show environment

24.12 clock set datetime

1 Command Purpose

Use this command to set system current date and time on the Switch.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

clock set datetime *ABS_TIME CLOCK_MONTH ABS_DAY ABS_YEAR*

Parameter	Parameter Description	Parameter Value
ABS_TIME	Current time	-
CLOCK_MONTH	Month of the year	1-12
ABS_DAY	Day of the month	1-31
ABS_YEAR	Year	2000-2037

3 Command Mode

Global Configuration

4 Default

The default time is based from UTC.

5 Usage

If no other source of time is available, you can manually configure the time and date after the system is restarted. The time remains accurate until the next system restart. We recommend that you use manual configuration only as a last resort. If you have an outside source to which the switch can synchronize, you do not need to manually set the system clock.

6 Examples

This example shows how to manually set the system clock:

```
Switch(config)# clock set datetime 22:43:23 9 26 2017
```

7 Related Commands

show clock

Copyright © 2023 Garland Technology, LLC. All rights reserved.

24.13 clock set timezone

1 Command Purpose

Use this command to set timezone.

Use the no form of this command to restore the default value.

2 Command Syntax

clock set timezone *Z_NAME* (add | minus) *TZ_HOURS* (*TZ_MIN* (*TZ_SEC* |) |)

no clock set timezone

Parameter	Parameter Description	Parameter Value
Z_NAME	Zone name,	Valid characters are among "A-Za-z_", must be less than 32 characters
add	Specify the time offset is positive from UTC	-
minus	Specify the time offset is negative from UTC	-
TZ_HOURS	Hours offset from UTC	0-23
TZ_MIN	Minutes offset from UTC	0-59
TZ_SEC	Seconds offset from UTC	0-59

3 Command Mode

Global Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

This example shows how to set the clock timezone :

```
Switch(config)# clock set timezone Beijing add 8
```

This example shows how to recover the clock timezone:

```
Switch(config)# no clock set timezone
```

7 Related Commands

show clock

24.14 update bootrom

1 Command Purpose

Use this command to upgrade bootrom image.

2 Command Syntax

update bootrom *STRING*

Parameter	Parameter Description	Parameter Value
STRING	Source file direction	-

3 Command Mode

Global Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

This command can upgrade bootrom image.

6 Examples

This example shows how to update bootrom image:

```
Switch(config)# update bootrom flash:/boot/bootrom.bin
```

7 Related Commands

reboot

24.15 schedule reboot at

1 Command Purpose

Use this command to set schedule reboot at a time.

Use the no form of this command to cancel the schedule.

2 Command Syntax

schedule reboot at *HOUR_MIN* (*YEAR_MON_DAY* |)

no schedule reboot

Parameter	Parameter Description	Parameter Value
HOUR_MIN	Specify the hour and minute	-
YEAR_MON_DAY	Specify the date for current year, year range is [2000, 2037]	-

3 Command Mode

Global Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

The reboot time could select time with format HH:MM, and optional date with format YYYY/MM/DD or MM/DD/YYYY or MM/DD.

6 Examples

The following example shows how to set schedule reboot at a time:

```
Switch(config)# schedule reboot at 10:20 2016/10/2
```

7 Related Commands

show schedule reboot

24.16 schedule reboot delay

1 Command Purpose

Use this command to set schedule reboot after a time.

2 Command Syntax

schedule reboot delay *DELAY_TIME*

no schedule reboot

Parameter	Parameter Description	Parameter Value
DELAY_TIME	Specify the delay time	-

3 Command Mode

Global Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

The reboot delay time could select be format HH:MM, or minutes in range of [1,720].

6 Examples

The following example shows how to set schedule reboot after a time:

```
Switch(config)# schedule reboot delay 100
```

7 Related Commands

show schedule reboot

24.17 telnet

1 Command Purpose

Use this command to remote access to other devices

2 Command Syntax

telnet mgmt-if *NAME_STRING* (*TCP_PORT* |)

Parameter	Parameter Description	Parameter Value
mgmt-if	Establish a remote connection through the management port	-
NAME_STRING	IP address or hostname of a remote system	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

TCP_PORT	Specify the tcp port number, the default number is 23	1-65535

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

The command is used to establish a connection to other devices through the management port.The default tcp port is 23.

6 Examples

The following example shows how to remote access to other devices:

```
Switch# telnet mgmt-if 10.10.39.101
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

25 Hash load-banlance Commands

25.1 hash field

1 Command Purpose

Use this command to set hash field or create a new hash field, and enter hash field configure view;use the no command to delete user-defined hash field.

2 Command Syntax

hash field (port-channel | *NAME*)

no hash-field *NAME*

Parameter	Parameter Description	Parameter Value
port-channel	Port-channel of system default hash field	-
NAME	Hash field name string	The initial character of name should be a-z, A-Z, or 0-9, character only can be 0-9A-Za-z.-_ and the max length is 64

3 Command Mode

Global Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

The system support the max number of hash field is 4, including 1 system default hash fields named port-channel and 3 user-defined hash fields.when applied to the hash value,it can't be deleted.

6 Examples

The following example shows how to create a new hash field named user:

```
Switch(config)# hash-field user
Switch(config-hash-field-user)#
```

7 Related Commands

show hash-field

25.2 l2

1 Command Purpose

Use this command to set l2 packet hash field; use the no command to set the l2 packet field to default.

2 Command Syntax

l2 (macda | macsa | vlan | eth-type | src-interface)

no l2

Parameter	Parameter Description	Parameter Value
macda	MAC Destination Address	-
macsa	MAC Source Address	-
vlan	Vlan	-
eth-type	Ethernet Type	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

src-interface	Source Interface	-

3 Command Mode

Config-hash-field

4 Default

l2 macsa macda

5 Usage

None

6 Examples

The following example shows how to select macsa for l2 packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# l2 macsa
```

The following example shows how to select default l2 packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no l2
```

7 Related Commands

show hash-field port-channel

25.3 ip

1 Command Purpose

Use this command to set ip packet hash field; use the no command to set the ip packet field to default.

2 Command Syntax

ip (ipda | ipsa | ip-protocol | sourceport | destport | src-interface)

no ip

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
ipda	IP Destination Address	-
ipsa	IP Source Address	-
ip-protocol	IP Header protocol	-
sourceport	Layer4 Source Port	-
destport	Layer4 Destination Port	-
src-interface	Source Interface	-

3 Command Mode

Config-hash-field

4 Default

ip ipsa ipda sourceport destport ip-protocol

5 Usage

None

6 Examples

The following example shows how to select ipsa for ip packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# ip ipsa
```

The following example shows how to select default ip packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no ip
```

7 Related Commands

show hash-field port-channel

Copyright © 2023 Garland Technology, LLC. All rights reserved.

25.4 ipv6

1 Command Purpose

Use this command to set ipv6 packet hash field; use the no command to set the ipv6 field to default.

2 Command Syntax

ipv6 (ipda | ipsa | ip-protocol | sourceport | destport | src-interface)

no ipv6

Parameter	Parameter Description	Parameter Value
ipda	IP Destination Address	-
ipsa	IP Source Address	-
ip-protocol	IP Header protocol	-
sourceport	Layer4 Source Port	-
destport	Layer4 Destination Port	-
src-interface	Source Interface	-

3 Command Mode

Config-hash-field

4 Default

ipv6 ipsa ipda sourceport destport ip-protocol

5 Usage

Only when the system is in ipv6 mode, the ipv6 packet hash field can work normally.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to select ipsa for ipv6 packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# ipv6 ipsa
```

The following example shows how to select default ipv6 packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no ipv6
```

7 Related Commands

show hash-field port-channel

25.5 vxlan

1 Command Purpose

Use this command to set vxlan packet hash field.

To return the configuration to default value use the no form of this command.

2 Command Syntax

vxlan { vni | src-interface }

vxlan ({ vni | src-interface } |) outer { ipsa | ipda | sourceport | destport | vlan }

vxlan ({ vni | src-interface } |) inner-layer2 { macsa | macda | eth-type }

vxlan ({ vni | src-interface } |) inner-layer3 { ipsa | ipda | sourceport | destport | ip-protocol }

no vxlan

Parameter	Parameter Description	Parameter Value
vni	VXLAN VNI	-
src-interface	Source Interface	-
outer ipsa	Outer header's IP Source Address	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

outer ipda	Outer header's IP Destination Address	-
outer sourceport	Outer header's Layer4 Source Port	-
outer destport	Outer header's Layer4 Destination Port	-
outer vlan	Outer header's Vlan ID	-
inner macsa	Inner header's MAC Source Address	-
inner macda	Inner header's MAC Destination Address	-
inner eth-type	Inner header's Ethernet Type	-
inner ipsa	Inner header's IP Source Address	-
inner ipda	Inner header's IP Destination Address	-
inner sourceport	Inner header's Layer4 Source Port	-
inner destport	Inner header's Layer4 Destination Port	-
inner ip-protocol	Inner header's IP Header protocol	-

3 Command Mode

Config-hash-field

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

vxlan vni outer ipsa ipda sourceport

5 Usage

Outer configuration and inner configuration cannot take effect at the same time.

6 Examples

The following example shows how to select outer ipsa and vni for vxlan packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# vxlan vni outer ipda
```

The following example shows how to select default vxlan packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no vxlan
```

7 Related Commands

show hash-field port-channel

25.6 nvgre

1 Command Purpose

Use this command to set nvgre packet hash field.

To return the configuration to default value use the no form of this command.

2 Command Syntax

nvgre { vsid | src-interface }

nvgre ({ vsid | src-interface } |) outer { ipsa | ipda | gre-protocol }

nvgre ({ vsid | src-interface } |) inner-layer2 { macsa | macda | eth-type }

nvgre ({ vsid | src-interface } |) inner-layer3 { ipsa | ipda | sourceport | destport | ip-protocol }

no nvgre

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
vsid	NVGRE VSID	-
src-interface	Source Interface	-
outer ipsa	Outer header's IP Source Address	-
outer ipda	Outer header's IP Destination Address	-
outer gre-protocol	Outer header's GRE Protocol	-
inner macsa	Inner header's MAC Source Address	-
inner macda	Inner header's MAC Destination Address	-
inner eth-type	Inner header's Ethernet Type	-
inner ipsa	Inner header's IP Source Address	-
inner ipda	Inner header's IP Destination Address	-
inner sourceport	Inner header's Layer4 Source Port	-
inner destport	Inner header's Layer4 Destination Port	-
inner ip-protocol	Inner header's IP Header protocol	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Config-hash-field

4 Default

nvgre vsid outer ipsa ipda

5 Usage

Outer configuration and inner configuration cannot take effect at the same time.

6 Examples

The following example shows how to select outer ipsa and vsid for nvgre packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# nvgre vsid outer ipda
```

The following example shows how to select default nvgre packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no nvgre
```

7 Related Commands

show hash-field port-channel

25.7 mpls

1 Command Purpose

Use this command to set mpls packet hash field.

To return the configuration to default value use the no form of this command.

2 Command Syntax

mpls { top-label | 2nd-label | 3rd-label | src-interface }

no mpls

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
top-label	Mpls Top Lable	-
2nd-label	Mpls Second Lable	-
3rd-label	Mpls Third Lable	-
src-interface	Source Interface	-

3 Command Mode

Config-hash-field

4 Default

mpls top-label 2nd-label

5 Usage

None

6 Examples

The following example shows how to select top-label for mpls packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# mpls top-label
```

The following example shows how to select default mpls packet load balance in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no mpls
```

7 Related Commands

show hash-field port-channel

Copyright © 2023 Garland Technology, LLC. All rights reserved.

25.8 udf

1 Command Purpose

Use this command to set udf hash field; use the no command to delete the udf hash field.

2 Command Syntax

udf *UDF_ID*

no udf *UDF_ID*

Parameter	Parameter Description	Parameter Value
UDF_ID	UDF ID	0-15

3 Command Mode

Config-hash-field

4 Default

use the value which is truncated by udf to calculate hash value

5 Usage

only used for openflow select group

6 Examples

The following example shows how to configure udf hash field:

```
Switch(config)# hash-field aaa
Switch(config-hash-field-aaa)# udf 0

如下示例，显示了如何删除UDF的hash值

Switch(config)# hash-field aaa
Switch(config-hash-field-aaa)# no udf 0
```

7 Related Commands

show hash-field

Copyright © 2023 Garland Technology, LLC. All rights reserved.

25.9 disable control

1 Command Purpose

Use this command to force ip packet ,ipv6 packet or mpls packet to follow l2 hash configuration.

To return the configuration to default value use the no form of this command.

2 Command Syntax

ip disable

no ip disable

ipv6 disable

no ipv6 disable

mpls disable

no mpls disable

3 Command Mode

Config-hash-field

4 Default

no ip disable

no ipv6 disable

no mpls disable

5 Usage

None

6 Examples

The following example shows how to not select ipv6 packet field to hash in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# ipv6 disable
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

The following example shows how to select ipv6 packet field to hash in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no ipv6 disable
```

7 Related Commands

show hash-field port-channel

25.10 ipv6 adress compress mode

1 Command Purpose

Use this command to set compress arithmetic for ipv6 address.

To return the configuration to default value use the no form of this command.

2 Command Syntax

ipv6 address compres mode (lsb | xor)

no ipv6 address compress mode

Parameter	Parameter Description	Parameter Value
lsb	Least Significant bit arithmetic	-
xor	Exclusive or arithmetic	-

3 Command Mode

Config-hash-field

4 Default

lsb

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to set ipv6 address compress arithmetic in port-channel:

```
Switch(config-hash-field-port-channel)# ipv6 address compress mode lsb
```

The following example shows how set default compress arithmetic of ipv6 address in port-channel:

```
Switch(config-hash-field-port-channel)# no ipv6 address compress mode
```

7 Related Commands

show hash-field

25.11 hash arithmetic

1 Command Purpose

Use this command to set hash arithmetic.

To return the configuration to default value use the no form of this command.

2 Command Syntax

hash-arithmetic (crc | xor)

no hash-arithmetic

Parameter	Parameter Description	Parameter Value
crc	Cyclical redundancy check arithmetic	-
xor	Exclusive or arithmetic	-

3 Command Mode

Config-hash-field

4 Default

xor

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to set hash arithmetic in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# hash-arithmetic crc
```

The following example shows how set default hash arithmetic in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no hash-arithmetic
```

7 Related Commands

show hash-field

25.12 hash symmetry

1 Command Purpose

Use this command to enable hash symmetry function.

To return the configuration to default value use the no form of this command.

2 Command Syntax

mode symmetry

no mode symmetry

3 Command Mode

Config-hash-field

4 Default

no mode symmetry

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to set hash symmetry in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# mode symmetry
```

The following example shows how to set hash symmetry to default in port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no mode symmetry
```

7 Related Commands

show hash-field port-channel

25.13 description

1 Command Purpose

Use this command to configure the description for hash field; use the no command to delete the description.

2 Command Syntax

descrition *NAME*

no description

Parameter	Parameter Description	Parameter Value
NAME	Hash field descrition	The initial character of name should be a-z, A-Z, or 0-9, character only can be 0-9A-Za-z.-_ and the max length is 64

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Config-hash-field

4 Default

None

5 Usage

None

6 Examples

The following example shows how to set descrition for port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# description linkagg
```

The following example shows how to delete descrition for port-channel:

```
Switch(config)# hash-field port-channel
Switch(config-hash-field-port-channel)# no description
```

7 Related Commands

show hash-field port-channel

25.14 show hash-field

1 Command Purpose

Use this command to display the configurations and statistics on all hash fields or a hash field.

2 Command Syntax

show hash-field (port-channel | *NAME* |)

Parameter	Parameter Description	Parameter Value
port-channel	Port-channel of system default hash field	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the configurations and statistics on the port-channel:

```
Switch# show hash-field port-channel

hash-field name: port-channel
 Option                              Control type
-------------------------------------------------------------------------
 hash-arithmetic                     xor
 hash symmetry                       disable
 ip                                  enable
 ipv6                                enable
 mpls                                enable
-------------------------------------------------------------------------
 hash field select
 Packet                HashField
-------------------------------------------------------------------------
 l2:                   macsa                 macda

 ip:                   ipsa                  ipda
                       l4-sourceport         l4-destport
                       ip-protocol

 ipv6:                 ipsa                  ipda
                       l4-sourceport         l4-destport
                       ip-protocol

 gre:                  ipsa                  ipda
                       gre-key

 vxlan:                vni                   outer-l4-sourceport
                       outer-ipda            outer-ipsa

 nvgre:                vsid                  outer-ipda
                       outer-ipsa

 mpls:                 top-label             2nd-label
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

25.15 hash value

1 Command Purpose

Use this command to create a hash value and enter hash value configure view; use the no command to delete the hash value.

2 Command Syntax

hash-value *NAME*

no hash-value *NAME*

Parameter	Parameter Description	Parameter Value
NAME	Hash value name string	The initial character of name should be a-z, A-Z, or 0-9, character only can be 0-9A-Za-z.-_ and the max length is 64

3 Command Mode

Global Configuration

4 Default

None

5 Usage

The system support the max number of hash value is 63.when applied to the interface,it can't be deleted.

6 Examples

The following example shows how to creat hash value aaa:

```
Switch(config)# hash-value aaa
Switch(config-hash-value-aaa)#
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

The following example shows how to delete hash value aaa:

```
Switch(config)# no hash-value aaa
Switch(config)#
```

7 Related Commands

show hash-value

25.16 port-channel select

1 Command Purpose

Use this command to select hash field for all mode linkagg; use the no command to delete the configuration.

2 Command Syntax

port-channel select *NAME*

no port-channel select

Parameter	Parameter Description	Parameter Value
NAME	Hash field name string	-

3 Command Mode

Config-hash-value

4 Default

None

5 Usage

the hash value can apply on the agg ipput or the port input.

6 Examples

The following example shows how to select hash field for in hash value user:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch(config)# hash-value aaa
Switch(config-hash-value-aaa)# port-channel  select user
```

The following example shows how to delete hash field and hash arithmetic for linkagg in hash value aaa:

```
Switch(config)# hash-value aaa
Switch(config-hash-value-aaa)# no port-channel select
```

7 Related Commands

show hash-value

25.17 description

1 Command Purpose

Use this command to configure the description for hash value; use the no command to delete the description.

2 Command Syntax

descrition *NAME*

no description

Parameter	Parameter Description	Parameter Value
NAME	Hash value descrition	The initial character of name should be a-z, A-Z, or 0-9, character only can be 0-9A-Za-z.-_ and the max length is 64

3 Command Mode

Config-hash-value

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how set description for hash value aaa:

```
Switch(config)# hash-value aaa
Switch(config-hash-value-aaa)# description valueaaa
```

The following example shows how delete description for hash value aaa:

```
Switch(config)# hash-value aaa
Switch(config-hash-value-aaa)# no description
```

7 Related Commands

show hash-value

25.18 show hash-value

1 Command Purpose

Use this command to display the configurations of a hash value or all hash value.

2 Command Syntax

show hash-value (*NAME* |)

Parameter	Parameter Description	Parameter Value
NAME	Hash value name string	-

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to display the configurations of hash value:

```
Switch# show hash-value

LBT:load balance type         LBM:load balance mode
PT :packet type               HF :hash field name
HA :hash arithmetic
hash-value name: aaa
 LBT            LBM             PT             HF             HA
-------------------------------------------------------------------------
 port-channel   -               all            NOCFG          NOCFG
```

7 Related Commands

None

25.19 hash-value global

1 Command Purpose

Use this command to enter hash value global configure view.

2 Command Syntax

hash-value global

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to enter hash value global view:

```
Switch(config)# hash-value global
Switch(config-hash-value-global)#
```

7 Related Commands

show hash-value global

25.20 port-channel select

1 Command Purpose

Use this command to select hash field for linkagg; use the no command to set the default configuration.

2 Command Syntax

port-channel select *NAME*

no port-channel select

Parameter	Parameter Description	Parameter Value
NAME	Hash field name string	-

3 Command Mode

Config-hash-value-global

4 Default

port-channel

5 Usage

Compared with hash value configuration, this command has lower priority

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to select hash field for linkagg in hash value global :

```
Switch(config)# hash-value global
Switch(config-hash-value-global)# port-channel select user
```

The following example shows how to set default hash field for linkagg in hash value global :

```
Switch(config)# hash-value global
Switch(config-hash-value-global)# no port-channel select
```

7 Related Commands

show hash-value global

25.21 show hash-value global

1 Command Purpose

Use this command to display the configurations of hash value global.

2 Command Syntax

show hash-value global

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the configurations of hash value global:

```
Switch# show hash-value global
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
LBT:load balance type          LBM :load balance mode
PT :packet type                HF  :hash field name
HA :hash arithmetic
hash-value global
 LBT             LBM             PT              HF              HA
-------------------------------------------------------------------------
 port-channel    -               all             port-channel    xor
```

7 Related Commands

None

25.22 hash value applied to interface

1 Command Purpose

Use this command to apply a hash value to interface; use the no command to remove the hash-value from interface.

2 Command Syntax

load-balance hash-value *NAME* input

no load-balance hash-value input

Parameter	Parameter Description	Parameter Value
NAME	Hash value name	-

3 Command Mode

Interface Configuration

4 Default

None

5 Usage

Physical port and linkagg port can select input direction .linkagg port of output direction only support hash-value global.Agg member port can't configure the command.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to apply a hash value to eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if)# load-balance hash-value aaa input
```

The following example shows how to remove a hash value from eth-0-1:

```
Switch(config)# interface eth-0-1
Switch(config-if)# no load-balance hash-value input
```

7 Related Commands

show hash-value interface-applied

25.23 show hash-value interface-applied

1 Command Purpose

Use this command to display the relationship between hash value and interface.

2 Command Syntax

show hash-value interface-applied

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the relationship between hash value paorfile and interface:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch# show hash-value interface-applied

eth-0-1
 hash-value aaa input
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

26 IPFIX Commands

26.1 ipfix enable

1 Command Purpose

Use this command to enable ipfix globally.

2 Command Syntax

ipfix enable

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to enable ipfix globally:

```
Switch# configure terminal
Switch(config)# ipfix enable
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

26.2 ipfix recorder

1 Command Purpose

Use this command to create a ipfix recorder and enter recorder configure mode. To remove the ipfix recorder, use the no form of this command.

2 Command Syntax

ipfix recorder *NAME*

no ipfix recorder *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix recorder name	Up to 32 characters

3 Command Mode

Global Configuration

4 Default

None

5 Usage

If ipfix recorder has existed, it will enter IPFIX recorder Configuration; if ipfix recorder is new, it will create a recorder and enter IPFIX recorder Configuration; this command should work with the commands of match and collect.

6 Examples

This example shows how to create ipfix recorder recorder1in global configuration and enter IPFIX recorder Configuration:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)#

Switch# configure terminal
Switch(config)# no ipfix recorder recorder1
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

decription

match ipv4

match ipv6

match transport

collect ttl

collect flow

collect counter

26.3 description

1 Command Purpose

This command used to describe ipfix recorder, use the no form of this command to delete this description.

2 Command Syntax

description *DESCRIPTION*

Parameter	Parameter Description	Parameter Value
DESCRIPTION	ipfix monitor description	The length of ipfix monitor description should not exceed 64 characters

3 Command Mode

IPFIX recorder Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

This example shows how to describe recorder in IPFIX recorder Configuration:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# descrption this is a ipfix recorder
```

This example shows how to delete the description of the recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# no description
```

7 Related Commands

None

26.4 match ipv4

1 Command Purpose

This command configures the fields of ipv4 in ipfix recorder, use the no form of this command to delete this configure.

2 Command Syntax

match ipv4 (source | destination) address (mask *IP_MASK_LEN* |)

match ipv4 (dscp | ecn | ttl)

no match ipv4 (source | destination) address

no match ipv4 (dscp | ecn | ttl)

Parameter	Parameter Description	Parameter Value
source	ipv4 source ipaddress	-
destination	ipv4 destination ipaddress	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

dscp	ipv4 dscp value	-
ecn	ipv4 ecn value	-
ttl	ipv4 ttl value	-
IP_MASK_LEN	mask length for ipv4 address	1-32

3 Command Mode

IPFIX recorder Configuration

4 Default

Default value is 32

5 Usage

None

6 Examples

This example shows how to configure to use ipv4 source address and ipv4 destination address in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match ipv4 source address

Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)#  match ipv4 destination address
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

26.5 match ipv6

1 Command Purpose

This command configures the fields of ipv6 in ipfix recorder, use the no form of this command to delete this configure.

2 Command Syntax

match ipv6 (source | destination) address (mask *IPV6_MASK_LEN* |)

no match ipv6 (source | destination) address

match ipv6 (flowlabel | dscp)

no match ipv6 (flowlabel | dscp)

Parameter	Parameter Description	Parameter Value
source	ipv6 source ipaddress	-
destination	ipv4 destination ipaddress	-
dscp	ipv6 dscp value	-
flowlabel	ipv6 flowlabel value	-
IPV6_MASK_LEN	mask length for ipv6 address	range is 1-128 and must be the multiple of 4

3 Command Mode

IPFIX recorder Configuration

4 Default

Default value is 128

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

This example shows how to configure to use ipv6 source address and ipv6 destination address in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match ipv6 source address

Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match ipv6 destination address
```

7 Related Commands

None

26.6 match mac

1 Command Purpose

this command configures the fields of mac in ipfix recorder, use the no form of this command to delete this configure.

2 Command Syntax

match mac （destination | source） address

no match mac （destination | source） address

Parameter	Parameter Description	Parameter Value
source	Source mac address	-
destination	Destination mac address	-

3 Command Mode

IPFIX recorder Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure to use source mac address in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match mac source address
```

7 Related Commands

None

26.7 match transport

1 Command Purpose

This command configures the fields of transport in ipfix recorder, use the no form of this command to delete this configure.

2 Command Syntax

match transport (destination-port | source-port | type)

no match transport (destination-port | source-port | type)

match transport icmp (opcode | type)

no match transport icmp (opcode | type)

Parameter	Parameter Description	Parameter Value
destination-port	Destination port	-
source-port	Source port	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

type	Transport layer type	-
opcode	Icmp operated code	-

3 Command Mode

IPFIX recorder Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure to use source port and destination port of transport in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match transport source-port

Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match transport destination-port
```

7 Related Commands

None

26.8 match vlan

1 Command Purpose

This command configures the fields of vlan in ipfix recorder, use the no form of this command to delete this configure.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

match vlan (inner |)

no match vlan (inner |)

Parameter	Parameter Description	Parameter Value
inner	Inner VLAN	-

3 Command Mode

IPFIX recorder Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure to use inner vlan in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match vlan inner
```

7 Related Commands

None

26.9 match cos

1 Command Purpose

This command configures the fields of cos in ipfix recorder, use the no form of this command to delete this configure.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

match cos（inner | ）

no match cos（inner | ）

Parameter	Parameter Description	Parameter Value
inner	Inner COS	-

3 Command Mode

IPFIX recorder Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure to use inner cos in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match cos inner
```

7 Related Commands

None

26.10 match interface (input | output)

1 Command Purpose

This command configures the fields of interface in ipfix recorder, use the no form of this command to delete this configure.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

match interface (input | output)

no match interface (input | output)

Parameter	Parameter Description	Parameter Value
input	input direction	-
output	output direction	-

3 Command Mode

IPFIX recorder Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure input direction in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match interface input
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

26.11 match interface input

1 Command Purpose

This command configures the fields of interface in ipfix recorder, use the no form of this command to delete this configure.

2 Command Syntax

match interface input

no match interface input

Parameter	Parameter Description	Parameter Value
input	input direction	-

3 Command Mode

IPFIX recorder Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure input direction in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match interface input
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

26.12 match vxlan-vni

1 Command Purpose

This command configures the fields of vxlan-vni in ipfix recorder, use the no form of this command to delete this configure.

2 Command Syntax

match vxlan-vni

no match vxlan-vni

3 Command Mode

IPFIX recorder Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure to use vxlan-vni in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match vxlan-vni
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

26.13 match nvgre-key

1 Command Purpose

This command configures the fields of nvgre-key in ipfix recorder, use the no form of this command to delete this configure.

2 Command Syntax

match nvgre-key

no match nvgre-key

3 Command Mode

IPFIX recorder Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure to use nvgre-key in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match nvgre-key
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

26.14 match transport tcp flags

1 Command Purpose

This command configures the tcp flags fields of packet in ipfix recorder, use the no form of this command to delete this configure.

2 Command Syntax

match transport tcp flags ({ ack | cwr | ece | fin | psh | rst | syn | urg } |)

no match transport tcp flags ({ ack | cwr | ece | fin | psh | rst | syn | urg } |)

Parameter	Parameter Description	Parameter Value
ack	TCP acknowledgement	-
cwr	TCP congestion window reduced	-
ece	TCP Explicit Notification Congestion echo	-
fin	TCP finish	-
psh	TCP push	-
rst	TCP reset	-
syn	TCP synchronize	-
urg	TCP urgent	-

3 Command Mode

IPFIX recorder Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure to use tcp flags:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match transport tcp flags ack
```

7 Related Commands

None

26.15 match packet (drop | non-drop)

1 Command Purpose

This command configures the fields of packet in ipfix recorder, use the no form of this command to delete this configure.

2 Command Syntax

match packet (drop | non-drop)

no match packet (drop | non-drop)

Parameter	Parameter Description	Parameter Value
drop	Drop packet	-
non-drop	Non-drop packet	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

IPFIX recorder Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure to use drop packet:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# match packet drop
```

7 Related Commands

None

26.16 collect counter

1 Command Purpose

this command configures byte number and packet number that needed to be collected in ipfix recorder, use the no form of this command to delete this configure.

2 Command Syntax

collect counter (delta |) (bytes | packets)

no collect counter (delta |) (bytes | packets)

Parameter	Parameter Description	Parameter Value
delta	delta counter	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

bytes	Collect flow with byte number	-
packets	Collect flow with packet number	-

3 Command Mode

IPFIX recorder Configuration

4 Default

Without collecting any information

5 Usage

None

6 Examples

This example shows how to configure to collect the number of flow's byte in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# collect counter bytes
```

7 Related Commands

None

26.17 collect flow

1 Command Purpose

This command configures to collect ipfix flow information in ipfix recorder, use the no form of this command to delete this configure.

2 Command Syntax

collect flow (drop | destination | fragmentation)

Copyright © 2023 Garland Technology, LLC. All rights reserved.

no collect flow (drop | destination | fragmentation)

Parameter	Parameter Description	Parameter Value
drop	Only collect the droped flows	-
destination	Collect destination address of flows	-
fragmentation	Only collect the fragmented flows	-

3 Command Mode

IPFIX recorder Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure to collect the destination address of flows in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# collect flow destination
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

26.18 collect ttl

1 Command Purpose

This command configures to collect ipfix flow information about ttl in ipfix recorder, use the no form of this command to delete this configure.

2 Command Syntax

collect ttl (maximum | minimum | changed |)

no collect ttl (maximum | minimum | changed |)

Parameter	Parameter Description	Parameter Value
maximum	Collect flow max ttl value	-
minimum	Collect flow min ttl value	-
changed	Collect flow ttl changed history	-

3 Command Mode

IPFIX recorder Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure to collect the maximum ttl and minimum ttl of the flows in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch(Config-ipfix-reocrder)# collect ttl maximum
Switch(Config-ipfix-reocrder)# collect ttl minimum
```

7 Related Commands

None

26.19 collect timestamp

1 Command Purpose

This command configures to collect ipfix flow information about timestamp in ipfix recorder, use the no form of this command to delete this configure.

2 Command Syntax

collect timestamp (first | last)

no collect timestamp (first | last)

Parameter	Parameter Description	Parameter Value
first	Collect flow start timestamp	-
last	Collect flow end timestamp	-

3 Command Mode

IPFIX recorder Configuration

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

This example shows how to configure to collect the timestamp of the flows in ipfix recorder:

```
Switch# configure terminal
Switch(config)# ipfix recorder recorder1
Switch(Config-ipfix-reocrder)# collect timestamp  first
```

7 Related Commands

None

26.20 ipfix exporter

1 Command Purpose

Use this command to create a ipfix exporter and enter exporter configure mode.

To remove the ipfix exporter, use the no form of this command.

2 Command Syntax

ipfix exporter *NAME*

no ipfix exporter *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix exporter name	Up to 32 characters

3 Command Mode

Global Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

If ipfix exporter has existed, it will enter IPFIX exporter Configuration; if ipfix exporter is new, it will create exporter and enter IPFIX exporter Configuration; this command should work with the other commands .

6 Examples

This example shows how to create ipfix exporter exporter1in global configuration and enter IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)#
```

This example shows how to delete ipfix exporter exporter1:

```
Switch# configure terminal
Switch(config)# no ipfix exporter exporter1
```

7 Related Commands

template data timeout

flow data timeout

event flow start

event flow end (tcp-end|timeout)

transport protocol udp

26.21 description

1 Command Purpose

This command used to describe ipfix exporter, use the no form of this command to delete this description.

2 Command Syntax

description *DESCRIPTION*

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

DESCRIPTION	Ipfix exporter description	Up to 64 characters

3 Command Mode

IPFIX exporter Configuration

4 Default

None

5 Usage

None

6 Examples

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# descrption this is a ipfix exporter

Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# no description
```

7 Related Commands

None

26.22 destination

1 Command Purpose

This command used to configure collecter host name that need to receive flow records in ipfix exporter, use the no form of this command to delete this description.

2 Command Syntax

destination mgmt-if ipv4 *IPV4_ADDR*

no destination

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

IPV4_ADDR	IP address of collector	-

3 Command Mode

IPFIX exporter Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to create a host named host1 in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# destination mgmt-if ipv4 9.0.0.2
```

7 Related Commands

None

26.23 dscp

1 Command Purpose

this command used to configure the dscp value of the message that need to be sended in ipfix exporter, use the no form of this command to delete this description.

2 Command Syntax

dscp *DSCP*

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

DSCP	dscp value	0-63

3 Command Mode

IPFIX exporter Configuration

4 Default

63

5 Usage

None

6 Examples

This example shows how to configure dscp to be 20 in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# dscp 20
```

7 Related Commands

None

26.24 domain-id

1 Command Purpose

This command used to configure the ipfix domain value of the message that needs to be sent in ipfix exporter, use the no form of this command to delete this description.

2 Command Syntax

domain-id *ID*

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

ID	domain id	1-65535

3 Command Mode

IPFIX exporter Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure domain-id to be 1000 in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# domain-id 1000
```

7 Related Commands

None

26.25 template data timeout

1 Command Purpose

This command used to configure time interval of sending template data in ipfix exporter, use the no form of this command to delete this description.

2 Command Syntax

template data timeout *TIMEOUT*

no template data timeout

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

TIMEOUT	template data timeout	1-86400

3 Command Mode

IPFIX exporter Configuration

4 Default

600

5 Usage

None

6 Examples

This example shows how to configure time interval of sending template data to be 200 seconds in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# template data timeout 200
```

7 Related Commands

None

26.26 flow data timeout

1 Command Purpose

This command used to configure time interval of sending flow data in ipfix exporter, use the no form of this command to delete this description.

2 Command Syntax

flow data timeout *TIMEOUT*

no flow data timeout

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
TIMEOUT	flow data timeout	1-86400

3 Command Mode

IPFIX exporter Configuration

4 Default

600

5 Usage

None

6 Examples

This example shows how to configure time interval of sending flow data to be 200 seconds in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# flow data timeout 200
```

7 Related Commands

None

26.27 transport protocol

1 Command Purpose

This command used to configure to use which transport when send message in ipfix exporter, use the no form of this command to delete this description.

2 Command Syntax

transport protocol udp port *UDP_PORT*

no transport protocol

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
UDP_PORT	transport protocol number	Range is 2000 to 65535, Default is 2055

3 Command Mode

IPFIX exporter Configuration

4 Default

2055

5 Usage

None

6 Examples

This example shows how to configure transport protocol of flow data sended to be udp and its port is 3500 in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# transport protocol udp 3500
```

7 Related Commands

None

26.28 ttl

1 Command Purpose

This command used to configure the ttl of the sended message in ipfix exporter, use the no form of this command to delete this description.

2 Command Syntax

ttl *TTL*

Copyright © 2023 Garland Technology, LLC. All rights reserved.

no ttl

Parameter	Parameter Description	Parameter Value
TTL	TTL value	1-255

3 Command Mode

IPFIX exporter Configuration

4 Default

255

5 Usage

None

6 Examples

This example shows how to configure ttl value of flow data to be 255 in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# ttl 255
```

7 Related Commands

None

26.29 event flow

1 Command Purpose

This command used to configure which event should triggle to send flow information at once in ipfix exporter, use the no form of this command to delete this description.

2 Command Syntax

event flow start

Copyright © 2023 Garland Technology, LLC. All rights reserved.

no event flow start

event flow end (tcp-end | timeout)

no event flow end (tcp-end | timeout)

3 Command Mode

IPFIX exporter Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure the event about ending tcp transmission of flow data will triggle to send flow information in IPFIX exporter Configuration:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# event flow tcp-end
```

7 Related Commands

None

26.30 flow data flush threshold length

1 Command Purpose

This command used to configure the threshold.When the threshold is reached,flow information should be sent at once in ipfix exporter

2 Command Syntax

flow data flush threshold length *LENGTH*

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
LENGTH	length threshold value	1000-60000

3 Command Mode

IPFIX exporter Configuration

4 Default

1416

5 Usage

None

6 Examples

This example shows how to configure the length threshold value about flow data in IPFIX exporter Configuration.When the threshod is reached,flow data information will be sent at once.:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# flow data flush threshold length 2000
```

7 Related Commands

None

26.31 flow data flush threshold timer

1 Command Purpose

This command used to configure the threshold.When the threshold is reached,flow information should be sent at once in ipfix exporter

2 Command Syntax

flow data flush threshold timer *TIMER*

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
TIMER	timer threshold value	100-60000

3 Command Mode

IPFIX exporter Configuration

4 Default

500

5 Usage

None

6 Examples

This example shows how to configure the timer threshold value in IPFIX exporter Configuration.When the threshod is reached,flow data information will be sent at once.:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# flow data flush threshold timer 1000
```

7 Related Commands

None

26.32 flow data flush threshold count

1 Command Purpose

This command used to configure the threshold.When the threshold is reached,flow information should be sent at once in ipfix exporter

2 Command Syntax

flow data flush threshold count *COUNT*

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
COUNT	count threshold value	1-100

3 Command Mode

IPFIX exporter Configuration

4 Default

10

5 Usage

None

6 Examples

This example shows how to configure the count threshold value about flow data in IPFIX exporter Configuration.When the threshod is reached,flow data information will be sent at once.:

```
Switch# configure terminal
Switch(config)# ipfix exporter exporter1
Switch(Config-ipfix-exporter)# flow data flush threshold count 20
```

7 Related Commands

None

26.33 ipfix sampler

1 Command Purpose

Use this command to create a ipfix sampler and enter sampler configure mode. To remove the ipfix sampler, use the no form of this command.

2 Command Syntax

ipfix sampler *NAME*

Copyright © 2023 Garland Technology, LLC. All rights reserved.

no ipfix sampler *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix sampler name	Up to 32 characters

3 Command Mode

Global Configuration

4 Default

None

5 Usage

If ipfix sampler has existed, it will enter IPFIX sampler Configuration; if ipfix sampler is new, it will create sampler and enter IPFIX sampler Configuration; this command should work with the command of match and collect.

6 Examples

This example shows how to create ipfix sampler sampler1 in global configuration and enter IPFIX sampler Configuration:

```
Switch# configure terminal
Switch(config)# ipfix sampler sampler 1
Switch(Config-ipfix-sampler)#
```

This example shows how to delete ipfix sampler sampler1:

```
Switch# configure terminal
Switch(config)# no ipfix sampler sampler1
```

7 Related Commands

1 out-of

Copyright © 2023 Garland Technology, LLC. All rights reserved.

26.34 description

1 Command Purpose

2 Command Syntax

description *DESCRIPTION*

Parameter	Parameter Description	Parameter Value
DESCRIPTION	ipfix sampler description	Up to 64 characters

3 Command Mode

IPFIX sampler Configuration

4 Default

None

5 Usage

None

6 Examples

```
Switch# configure terminal
Switch(config)# ipfix sampler sampler 1
Switch(Config-ipfix-sampler)# descrption this is a ipfix sampler

Switch# configure terminal
Switch(config)# ipfix sampler sampler 1
Switch(Config-ipfix-sampler)# no description
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

26.35 1 out-of

1 Command Purpose

This command used to configure the rate of ipfix sampler, use the no form of this command to delete this configure.

2 Command Syntax

1 out of *CLI_IPFIX_SAMPLER_RATE_RNG*

Parameter	Parameter Description	Parameter Value
CLI_IPFIX_SAMPLER_RATE_RNG	How many packets will sample one packet	2-8191

3 Command Mode

IPFIX sampler Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure the rate of sampling is 1/100 in IPFIX sampler Configuration:

```
Switch# configure terminal
Switch(config)# ipfix sampler sampler 1
Switch(Config-ipfix-sampler)# 1 out of 100
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

26.36 mode

1 Command Purpose

This command used to configure the mode of ipfix sampler.

2 Command Syntax

mode (random | determinate)

Parameter	Parameter Description	Parameter Value
random	random sample mode	-
determinate	determinate sample mode	-

3 Command Mode

IPFIX sampler Configuration

4 Default

determinate

5 Usage

None

6 Examples

This example shows how to configure the determinate sampl mode in IPFIX sampler Configuration:

```
Switch# configure terminal
Switch(config)# ipfix sampler sampler 1
Switch(Config-ipfix-sampler)# mode determinate
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

26.37 mode flow

1 Command Purpose

This command used to configure the mode flow of ipfix sampler.

2 Command Syntax

mode flow (new | all)

Parameter	Parameter Description	Parameter Value
new	only sample new flow	-
all	sample all flow	-

3 Command Mode

IPFIX sampler Configuration

4 Default

all

5 Usage

None

6 Examples

This example shows how to configure the ipfix sampler to sample all flow in IPFIX sampler Configuration:

```
Switch# configure terminal
Switch(config)# ipfix sampler sampler 1
Switch(Config-ipfix-sampler)# mode flow all
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

26.38 ipfix monitor

1 Command Purpose

Use this command to create a ipfix monitor and enter monitor configure mode. To remove the ipfix monitor, use the no form of this command.

2 Command Syntax

ipfix monitor *NAME*

no ipfix monitor *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix monitor name	Up to 32 characters

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to create ipfix monitor monitor1 in global configuration and enter IPFIX monitor Configuration:

```
Switch# configure terminal
Switch(config)# ipfix monitor monitor1
Switch(Config-ipfix-monitor)#
```

This example shows how to delete ipfix monitor monitor1:

```
Switch# configure terminal
Switch(config)# no ipfix monitor monitor1
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

recorder

exporter

26.39 description

1 Command Purpose

2 Command Syntax

description *DESCRIPTION*

Parameter	Parameter Description	Parameter Value
DESCRIPTION	The length of ipfix monitor description should not exceed 64 characters	Up to 64 characters

3 Command Mode

IPFIX monitor Configuration

4 Default

None

5 Usage

None

6 Examples

Add descriptoin for IPFIX monitor:

```
Switch# configure terminal
Switch(config)# ipfix monitor monitor1
Switch(Config-ipfix-monitor)# descrption this is a ipfix monitor
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

Remove description:

```
Switch# configure terminal
Switch(config)# ipfix monitor monitor1
Switch(Config-ipfix-monitor)# no description
```

7 Related Commands

None

26.40 recorder

1 Command Purpose

Use this command to create a ipfix recorder of the ipfix monitor. To remove the ipfix monitor, use the no form of this command.

2 Command Syntax

recorder *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix recorder name	Up to 32 characters

3 Command Mode

IPFIX monitor Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to create a recorder of the ipfix monitor configure mode:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch# configure terminal
Switch(config)# ipfix monitor monitor1
Switch(Config-ipfix-monitor)# recorder recorder1
```

7 Related Commands

None

26.41 exporter

1 Command Purpose

Use this command to create a ipfix exporter of the ipfix monitor. To remove the ipfix monitor, use the no form of this command.

2 Command Syntax

exporter *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix exporter name	Up to 32 characters

3 Command Mode

IPFIX monitor Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to create a exporter of the ipfix monitor configure mode:

```
Switch# configure terminal
Switch(config)# ipfix monitor monitor1
Switch(Config-ipfix-monitor)# exporter exporter1
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

None

26.42 ipfix monitor

1 Command Purpose

This command used to enable ipfix.

2 Command Syntax

ipfix monitor (input | output) *NAME* (sampler *NAME* |)

no ipfix monitor (input | output)

Parameter	Parameter Description	Parameter Value
input	do ipfix for the inputed packets	-
output	do ipfix for the outputed packets	-
NAME	IPFIX monitor name	Up to 32 characters
sampler NAME	IPFIX sampler name	Up to 32 characters

3 Command Mode

Interface Configuration

4 Default

None

5 Usage

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

This example shows how to enable ipfix:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if)# ipfix monitor input monitor sampler test-sample
```

7 Related Commands

None

26.43 ipfix global

1 Command Purpose

Use this command to enter ipfix global configure mode.

2 Command Syntax

ipfix global

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to enter ipfix global configure mode:

```
Switch# configure terminal
Switch(config)# ipfix global
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

None

26.44 flow aging

1 Command Purpose

Use this command to configure ipfix global flow aging interval.

2 Command Syntax

flow aging *INTERVAL*

Parameter	Parameter Description	Parameter Value
INTERVAL	The aging time of the flow	Range is 15 to 65535, the default is 1800 seconds

3 Command Mode

IPFIX Global Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure the aging time to be 200 seconds in global configure mode:

```
Switch# configure terminal
Switch(config)# ipfix global
Switch(config-ipfix-global)# flow aging 200
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

None

26.45 flow export

1 Command Purpose

Use this command to configure ipfix global flow export interval.

2 Command Syntax

flow export *INTERVAL*

Parameter	Parameter Description	Parameter Value
INTERVAL	The export time of the flow	Range is 0 to 1000, the default is 5 seconds

3 Command Mode

IPFIX Global Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to configure the export time to be 200 seconds in global configure mode:

```
Switch# configure terminal
Switch(config)# ipfix global
Switch(config-ipfix-global)# flow export 200
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

None

26.46 show ipfix global

1 Command Purpose

Use the show ipfix global privileged EXEC command to display the configure information of ipfix global.

2 Command Syntax

show ipfix global

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

This example shows how to display configuration about ipfix global in privileged EXEC mode:

```
Switch# show ipfix global
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

26.47 show ipfix recorder

1 Command Purpose

Use the show ipfix recorde privileged EXEC command to display the configure information of one ipfix recorder.

2 Command Syntax

show ipfix recorder *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix recorder name	Up to 32 characters

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

This example shows how to show ipfix recorder command:

```
Switch# show ipfix recorder recorder1

IPFIX recorder information:
    Name           : recorder1
    Description    :
    Match info     :
        match Source Mac Address
        match IPv4 Source Address
        match IPv4 Destination Address
        match Vxlanvni
    Collect info    :
        collect Flow Byte Number
        collect Flow Packet Number
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

None

26.48 show ipfix exporter

1 Command Purpose

Use the show ipfix exporter privileged EXEC command to display the configure information of one ipfix exporter.

2 Command Syntax

show ipfix exporter *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix exporter name	Up to 32 characters

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

This example shows how to display configuration about exporter1 in privileged EXEC mode:

```
Switch# show ipfix exporter exporter1

IPFIX exporter information:
    Name                            : exporter1
    Description                     :
    Domain ID                       : 0
    Collector Name                  : 9.0.0.2
    IPFIX message protocol           : UDP
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
    IPFIX message destination Port   : 2055
    IPFIX message TTL value          : 255
    IPFIX message DSCP value         : 63
    IPFIX data interval              : 200
    IPFIX template interval          : 1800
    IPFIX exporter events            :
        Flow aging event
```

7 Related Commands

None

26.49 show ipfix cache

1 Command Purpose

This command used to show the state information of the ipfix on the interface.

2 Command Syntax

show ipfix cache observe-point interface *IFNAME* (input | output)

show ipfix cache monitor *NAME*

show ipfix cache counter observe-point interface *IFNAME*

show ipfix cache counter monitor *NAME*

Parameter	Parameter Description	Parameter Value
IFNAME	Interface name	Support physical/aggregation
NAME	ipfix monitor name	Up to 32 characters

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

This example shows how to show the state information of the ipfix on the interface eth-0-1in privileged EXEC mode:

```
Switch# show ipfix cache observe-point interface eth-0-1 input

  Cache dir              : input
  Cache flow profile     : 0
  Cache key profile      : 0
  Cache key info    :
      Source mac          : 0000.0002.0001
      ipsa                : 10.10.10.3/32
      ipda                : 10.10.10.1/32
  Cache collect info:
      Byte number of ingress               : 64
      Packet number of ingress             : 1
```

7 Related Commands

None

26.50 show ipfix monitor

1 Command Purpose

This command used to describe the configration of the ipfix monitor.

2 Command Syntax

show ipfix monitor *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix monitor name	Up to 32 characters

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

None

6 Examples

This example shows how to display configuration of monitor 1 in privileged EXEC mode:

```
Switch# show ipfix monitor monitor1

IPFIX monitor information:
    Name                            : monitor1
    Description                     :
    Recorder                        : recorder1
    exporter                        : exporter1
```

7 Related Commands

None

26.51 show ipfix sampler

1 Command Purpose

This command used to describe the configration of the ipfix sampler.

2 Command Syntax

show ipfix sampler *NAME*

Parameter	Parameter Description	Parameter Value
NAME	ipfix sampler name	Up to 32 characters

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

None

6 Examples

This example shows how to display configuration of sampler1 in privileged EXEC mode:

```
Switch# show ipfix sampler sampler1

IPFIX sampler information:
    Name                            : sampler1
    Description                     :
    Rate                            : 100
    Sample mode                     : determinate
    Flow mode                       : all
```

7 Related Commands

None

26.52 clear ipfix cache monitor

1 Command Purpose

This command used to clear cache with ipfix monitor name.

2 Command Syntax

clear ipfix cache monitor *NAME*

Parameter	Parameter Description	Parameter Value
NAME	IPFIX monitor name	Up to 32 characters

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

None

6 Examples

This example shows how to clear ipfix cache with name test in privileged EXEC mode:

```
Switch# clear ipfix cache monitor test
```

7 Related Commands

None

26.53 clear ipfix cache observe-point interface

1 Command Purpose

This command used to clear cache on interface.

2 Command Syntax

clear ipfix cache observe-point interface (*IFNAME*) (input | output)

Parameter	Parameter Description	Parameter Value
IFPHYSICAL	Name of interface	Support physical/aggregation
input	the inputed packets	-
output	the outputed packets	-

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

None

6 Examples

This example shows how to clear ipfix cache on interface eth-0-1 in privileged EXEC mode:

```
Switch# clear ipfix cache observe-point interface eth-0-1 input
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

27 DIAG Commands

27.1 show interface queue discard

1 Command Purpose

Use this command to display the situation of interface queue discard.

2 Command Syntax

show interface queue discard (*IF_NAME_E* |)

clear interface queue discard (*IF_NAME_E* |)

Parameter	Parameter Description	Parameter Value
IF_NAME_E	interface Name string	Specify the interface name to enter the mode. e.g.eth-0-1.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

If the parameter “IF_NAME_E” is not specified, the command indicates that all interfaces on this device should be displayed; otherwise only the specified interface should be displayed.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to display the situation of interface queue discard:

```
Switch# show interface queue discard

Interface Queue Drop-Packets Stats:
Interface            Drop-Packets         Drop-Bytes
--------------------+--------------------+--------------------
eth-0-1              0                    0
eth-0-2              0                    0
eth-0-3              0                    0
eth-0-4              0                    0
eth-0-5              0                    0
eth-0-6              0                    0
eth-0-7              0                    0
eth-0-8              0                    0
eth-0-9              0                    0
eth-0-10             0                    0
eth-0-11             0                    0
eth-0-12             0                    0
eth-0-13             0                    0
eth-0-14             0                    0
eth-0-15             0                    0
eth-0-16             0                    0
eth-0-17             0                    0
eth-0-18             0                    0
eth-0-19             0                    0
eth-0-20             0                    0
eth-0-21             0                    0
eth-0-22             0                    0
eth-0-23             0                    0
eth-0-24             0                    0
```

The following example shows how to clear interface queue discard:

```
Switch# clear interface queue discard
```

7 Related Commands

N/A

27.2 diagnostic-information discard

1 Command Purpose

Use this command to enable the function of diagnostic-information discard.

2 Command Syntax

diagnostic-information discard enable

no diagnostic-information discard enable

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
enable	enable	The string of enable.

3 Command Mode

Global Configuration

4 Default

no diagnostic-information discard enable

5 Usage

The command uses to enable the function of diagnostic-information discard.

6 Examples

The following example shows how to enable the function of diagnostic-information discard:

```
Switch(config)# diagnostic-information discard enable
```

The following example shows how to disable the function of diagnostic-information discard:

```
Switch(config)# no diagnostic-information discard enable
```

7 Related Commands

N/A

27.3 show diagnostic-information

1 Command Purpose

Use this command to display the situation of packet discard.

2 Command Syntax

show diagnostic-information discard

clear diagnostic-information discard

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
discard	discard	The string of discard.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

The command uses to dispaly the situation of packet discard.

6 Examples

The following example shows how to display the situation of packet discard:

```
Switch# show diagnostic-information discard

Diagnostic-Information Discard:
Drop-Reason                    Description
-------------------------------+-----------------------------------
CTC_DROP_TTL_CHK               TTL check fail
CTC_DROP_ACL_DENY              Acl deny
CTC_DROP_PKT_ERR               Packet check error
CTC_DROP_ISOLATE_CHK           Port isolate check fail
CTC_DROP_TRANSIT_DISABLE       Transit disable
CTC_DROP_IP_CHK                Ip address or packet check fail
CTC_DROP_VLAN_FILTER           Vlan filtering
CTC_DROP_STP_CHK               Stp check fail
CTC_DROP_CHKSUM_ERR            Checksum error
CTC_DROP_PARSER_ERR            Parser error
CTC_DROP_TRAFFIC_MANAGER       Trafic manager check fail
CTC_DROP_NET_RX                Netrx check fail
CTC_DROP_NET_TX                Nettx check fail
Others                         Other drop reasons
```

The following example shows how to clear packet discard:

```
Switch# clear diagnostic-information discard
```

7 Related Commands

N/A

Copyright © 2023 Garland Technology, LLC. All rights reserved.

28 De-duplicate Commands

28.1 de-duplicate global

1 Command Purpose

Use this command to enter de-duplicate global configure mode.

2 Command Syntax

de-duplicate global

3 Command Mode

Global Configuration

4 Default

None

5 Usage

None

6 Examples

This example shows how to enter de-duplicate global configure mode:

```
Switch(config)# de-duplicate global
Switch(config-duplicate)#
```

7 Related Commands

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

28.2 de-duplicate enable

1 Command Purpose

Use this command to enable de-duplicate function.

2 Command Syntax

de-duplicate enable

no de-duplicate enable

3 Command Mode

De-duplicate Configuration

4 Default

disbale

5 Usage

None

6 Examples

This example shows how to enable de-duplicate function:

```
Switch(config-duplicate)# de-duplicate enable
```

This example shows how to disable de-duplicate function:

```
Switch(config-duplicate)# no de-duplicate enable
```

7 Related Commands

show de-duplicate global

Copyright © 2023 Garland Technology, LLC. All rights reserved.

28.3 de-duplicate mode

1 Command Purpose

Use this command to configure de-duplicate mode.

2 Command Syntax

de-duplicate mode { 0 | 1 | 2 | 3 | 4 }

Parameter	Parameter Description	Parameter Value
0	Mode0:it is considered to be the duplicate packet if the five-tuple, tcpflag, TCP/UDP checksum, IP identification, TCP sequence number and TCP acknowledgement number is the same.	-
1	Mode1:it is considered to be the duplicate packet if the five-tuple, tcpflag, TCP/UDP checksum, IP identification, TCP sequence number, TCP acknowledgement number and payload is the same.	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2	Mode2:it is considered to be the duplicate packet if the five-tuple, tcpflag, TCP/UDP checksum, IP identification, TCP sequence number, TCP acknowledgement number, ipv4 header(except TTL, IP checksum and IPV4 extend header) and payload is the same.	-
3	Mode3:it is considered to be the duplicate packet if the five-tuple, tcpflag, TCP/UDP checksum, IP identification, TCP sequence number, TCP acknowledgement number, vlan(include SP-VLAN and CE-VLAN), ipv4 header(except TTL, IP checksum and IPV4 extend header) and payload is the same.	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4	Mode4:it is considered to be the duplicate packet if the five-tuple, tcpflag, TCP/UDP checksum, IP identification, TCP sequence number, TCP acknowledgement number, destination mac address, source mac address, vlan(include SP-VLAN and CE-VLAN), ipv4 header(except TTL, IP checksum and IPV4 extend header) and payload is the same.	-

3 Command Mode

De-duplicate Configuration

4 Default

mode 1

5 Usage

None

6 Examples

This example shows how to configure de-duplicate mode 3:

```
Switch(config-duplicate)# de-duplicate mode 3
```

7 Related Commands

show de-duplicate global

Copyright © 2023 Garland Technology, LLC. All rights reserved.

28.4 de-duplicate times

1 Command Purpose

Use this command to configure de-duplicate times.

2 Command Syntax

de-duplicate times { *NUM* | no-limit }

Parameter	Parameter Description	Parameter Value
NUM	de-duplicate times	1-10
no-limit	no-limit de-duplicate times	-

3 Command Mode

De-duplicate Configuration

4 Default

no-limit

5 Usage

None

6 Examples

This example shows how to configure de-duplicate times 5:

```
Switch(config-duplicate)# de-duplicate times 5
```

7 Related Commands

show de-duplicate global

Copyright © 2023 Garland Technology, LLC. All rights reserved.

28.5 de-duplicate aging-time

1 Command Purpose

Use this command to configure de-duplicate aging-time.

2 Command Syntax

de-duplicate aging-time *TIME*

Parameter	Parameter Description	Parameter Value
TIME	de-duplicate entry age time	100-1000ms

3 Command Mode

De-duplicate Configuration

4 Default

100ms

5 Usage

None

6 Examples

This example shows how to configure de-duplicate aging-time 500ms:

```
Switch(config-duplicate)# de-duplicate aging-time 500
```

7 Related Commands

show de-duplicate global

Copyright © 2023 Garland Technology, LLC. All rights reserved.

28.6 de-duplicate ignore

1 Command Purpose

Use this command to configure de-duplicate ignore field.

2 Command Syntax

de-duplicate { ignore-tcpflag | ignore-checksum | ignore-ip-id | ignore-seqnum | ignore-acknum | ignore-interface } enable

no de-duplicate { ignore-tcpflag | ignore-checksum | ignore-ip-id | ignore-seqnum | ignore-acknum | ignore-interface } enable

Parameter	Parameter Description	Parameter Value
ignore-tcpflag	ignore tcpflag field	-
ignore-checksum	ignore TCP/UDP checksum field	-
ignore-ip-id	ignore IP identificationfield	-
ignore-seqnum	ignore TCP sequence number field	-
ignore-acknum	ignore TCP acknowledgement number field	-
ignore-interface	ignore interface of packet coming in	-

3 Command Mode

De-duplicate Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

de-duplicate ignore-tcpflag enable

de-duplicate ignore-checksum enable

de-duplicate ignore-ip-id enable

de-duplicate ignore-seqnum enable

de-duplicate ignore-acknum enable

no de-duplicate ignore-interface enable

5 Usage

None

6 Examples

This example shows how to enable de-duplicate ignore-interface field:

```
Switch(config-duplicate)# de-duplicate ignore-interface enable
```

This example shows how to disable de-duplicate ignore-interface field:

```
Switch(config-duplicate)# no de-duplicate ignore-interface enable
```

7 Related Commands

show de-duplicate global

28.7 show de-duplicate global

1 Command Purpose

Use this command to dispaly de-duplicate global configuration.

2 Command Syntax

show de-duplicate global

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

This example shows how to display de-duplicate global configuration:

```
Switch# show de-duplicate global

De-duplicate global information:
     de-duplicate enable            : disable
     de-duplicate mode              : 1
     de-duplicate times             : 5
     de-duplicate aging-time        : 500 ms
De-duplicate ignore-field information:
     de-duplicate ignore-tcpflag    : disable
     de-duplicate ignore-checksum   : disable
     de-duplicate ignore-ip-id      : disable
     de-duplicate ignore-seqnum     : disable
     de-duplicate ignore-acknum     : disable
     de-duplicate ignore-interface  : enable
```

7 Related Commands

de-duplicate global

28.8 show de-duplicate stats

1 Command Purpose

Use this command to dispaly de-duplicate stats.

2 Command Syntax

show de-duplicate stats

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

This example shows how to dispaly de-duplicate stats:

```
Switch# show de-duplicate stats

tap-group tap2,ingress eth-0-1_2:
 pkt_in:0 pkt_out:0 pkt_delta:0
 byte_in:0 byte_out:0 byte_delta:0
tap-group tap1,ingress eth-0-1_1,flow flow1,sequence-num 10:
 pkt_in:0 pkt_out:0 pkt_delta:0
 byte_in:0 byte_out:0 byte_delta:0
```

7 Related Commands

de-duplicate global

Copyright © 2023 Garland Technology, LLC. All rights reserved.

29 DDOS Prevent Commands

29.1 ip intercept

1 Command Purpose

Using the IP intercept ICMP command to configure the system to defend against ICMP flooding attacks.

Configuring switches to defend against Smurf attacks using the IP intercept Smurf command.

Configuring switches to defend against Fraggle attacks using the IP intercept Fraggle command.

Using the IP intercept UDP command to configure the system to defend against UDP flooding attacks.

Using the IP intercept TCP command to configure the system to defend against SYN flooding attacks.

Using the IP intercept maceq command, configure the system to filter ports whose source MAC address is equal to the destination MAC address.

Using IP intercept ipeq command, configure the system to filter ports whose source IP address is equal to the destination IP address.

2 Command Syntax

ip intercept (smurf | fraggle | maceq | ipeq | icmp (maxcount *IPT_MAXCOUNT* |) tcp (maxcount *IPT_MAXCOUNT* |) udp (maxcount *IPT_MAXCOUNT* |))

no ip intercept (smurf | fraggle | maceq | ipeq | icmp | tcp | udp)

Parameter	Parameter Description	Parameter Value
IPT_MAXCOUNT	Set the maximum rate of receiving packets	Range is 0-1000

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Global Configuration

4 Default

Againsting SYN attacks is enabled by default; Againsting other attacks are disabled by default.

The default number of packets to defend against ICMP flooding attacks is 500 per second.

The default number of packets to defend against UDP flooding attacks is 500 per second.

The default number of packets to defend against SYN flooding attacks is 500 per second.

5 Usage

None

6 Examples

The following example shows how to configures the ip intercept:

```
Switch# configure terminal
Switch(config)# ip intercept icmp maxcount 100
Switch(config)# ip intercept fraggle
Switch(config)# ip intercept maceq
Switch(config)# ip intercept tcp maxcount 200
```

The following example shows how to convert the ip intercept icmp:

```
Switch# configure terminal
Switch(config)# no ip intercept icmp
```

7 Related Commands

show ip-intercept statistics

show ip-intercept config

29.2 show ip-intercept config

1 Command Purpose

In privileged mode, use this command to display the current DDos defense configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

show ip-intercept config

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows to the current ddos defense config:

```
Switch# show ip-intercept config

Current DDoS Prevent configuration:
--------------------------------+--------+--------+---------
Fraggle Attack Intercept         :Enable
ICMP Flood Intercept             :Enable  Maxcount:500
IP Equal Intercept               :Disable
MAC Equal Intercept              :Disable
Smurf Attack Intercept           :Enable
SYN Flood Intercept              :Enable  Maxcount:200
UDP Flood Intercept              :Disable
```

7 Related Commands

ip intercept

29.3 clear ip-intercept statistics

1 Command Purpose

In privileged mode, clear ip-intercept statistics command is used to clear current attack detection packet loss statistics.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

clear ip-intercept statistics

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to clear statistic of the intercept packets:

```
Switch# clear ip-intercept statistics
```

7 Related Commands

show ip-intercept statistics

29.4 show ip-intercept statistics

1 Command Purpose

In privileged mode, display current attack detection packet loss statistics using show ip-intercept statistics command.

2 Command Syntax

show ip-intercept statistics

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

None

6 Examples

The following example shows how to the statistics of the intercept packets:

```
Switch# show ip-intercept statistics

Current DDoS Prevent statistics:
-------------------------------------------------+----------------
mgmt-if Resist Fraggle Attack packets number      :  0
mgmt-if Resist ICMP Flood packets number          :  0
mgmt-if Resist Smurf Attack packets number        :  0
mgmt-if Resist SYN Flood packets number           :  0
mgmt-if Resist UDP Flood packets number           :  0
```

7 Related Commands

clear ip-intercept statistics

Copyright © 2023 Garland Technology, LLC. All rights reserved.

30 LLDP Commands

30.1 lldp enable

1 Command Purpose

Use the lldp enable command to make lldp work globally. Use the no lldp enable command to make lldp disable globally.

2 Command Syntax

lldp enable

no lldp enable

3 Command Mode

Global Configuration

4 Default

Disabled

5 Usage

None

6 Examples

The following example shows how to enable and disable lldp function globally:

```
Switch# configure terminal
Switch(config)# lldp enable
Switch(config)# no lldp enable
```

7 Related Commands

show lldp local config

Copyright © 2023 Garland Technology, LLC. All rights reserved.

30.2 lldp timer tx-interval

1 Command Purpose

Use the command to set the lldp timer tx interval. And recover to default interval by using the no form of this command.

2 Command Syntax

lldp timer tx-interval *INTERVAL_VALUE*

no lldp timer tx-interval

Parameter	Parameter Description	Parameter Value
INTERVAL_VALUE	INTERVAL VALUE	5-32768

3 Command Mode

Global Configuration

4 Default

30s

5 Usage

The range of INTERVAL_VALUE is 5s-32768s, Its value must be greater than or equal to four times tx-delay, default value is 30s.

6 Examples

The following example shows how to set lldp tx hold time value:

```
Switch# configure terminal
Switch(config)# lldp timer tx-interval 20
```

The following example shows how to recover lldp tx hold time to default value:

```
Switch# configure terminal
Switch(config)# no lldp timer tx-interval
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

7 Related Commands

show lldp local config

30.3 lldp timer tx-hold

1 Command Purpose

Use the command to set lldp tx hold time value(tx-hold*tx-interval). And recover to default value by using the no form of this command.

2 Command Syntax

lldp timer tx-hold *HOLD_VALUE*

no lldp timer tx-hold

Parameter	Parameter Description	Parameter Value
HOLD_VALUE	Multiplier	2-10

3 Command Mode

Global Configuration

4 Default

4

5 Usage

The range of HOLD_VALUE is 2-10, default value is 4.

6 Examples

The following example shows how to set lldp tx hold time value:

```
Switch# configure terminal
Switch(config)# lldp timer tx-hold 3
```

The following example shows how to recover lldp reinit delay time to default value:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch# configure terminal
Switch(config)# no lldp timer tx-hold
```

7 Related Commands

show lldp local config

30.4 lldp timer tx-delay

1 Command Purpose

Use the command to set lldp tx delay time value. And recover to default value by using the no form of this command.

2 Command Syntax

lldp timer tx-delay *DELAY_VALUE*

no lldp timer tx-delay

Parameter	Parameter Description	Parameter Value
DELAY_VALUE	DELAY VALUE	1-8192

3 Command Mode

Global Configuration

4 Default

2s

5 Usage

The range of DELAY_VALUE is 1s-8192s, It must be less than or equal to a quarter of its value tx-interval, default value is 2s.

6 Examples

The following example shows how to set lldp tx delay time value:

Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
Switch# configure terminal
Switch(config)# lldp timer tx-delay 1
```

The following example shows how to recover lldp tx delay time to default value:

```
Switch# configure terminal
Switch(config)# no lldp timer tx-delay
```

7 Related Commands

show lldp local config

30.5 lldp timer reinit-delay

1 Command Purpose

Use the command to set lldp reinit delay time value. And recover to default value by using the no form of this command.

2 Command Syntax

lldp timer reinit-delay *RE_DELAY_VALUE*

no lldp timer reinit-delay

Parameter	Parameter Description	Parameter Value
RE_DELAY_VALUE	RE_DELAY VALUE	1-10

3 Command Mode

Global Configuration

4 Default

2s

5 Usage

The range of RE_DELAY_VALUE is 1s-8192s, default value is 2s.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

6 Examples

The following example shows how to set lldp reinit delay time value:

```
Switch# configure terminal
Switch(config)# lldp timer reinit-delay 1
```

The following example shows how to recover lldp reinit delay time to default value:

```
Switch# configure terminal
Switch(config)# no lldp timer reinit-delay
```

7 Related Commands

show lldp local config

30.6 lldp management ip

1 Command Purpose

Use the command to set the lldp management ip address. And recover to default value by using the no form of this command.

2 Command Syntax

lldp management ip *IP_ADDRESS*

no lldp management ip

Parameter	Parameter Description	Parameter Value
IP_ADDRESS	IP ADDRESS	-

3 Command Mode

Global Configuration

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to set the lldp management ip address:

```
Switch# configure terminal
Switch(config)# lldp management ip 1.2.3.4
```

The following example shows how to recoverlldp management ip address to default value:

```
Switch# configure terminal
Switch(config)# no lldp management ip
```

7 Related Commands

show lldp local tlv-info

30.7 lldp system-name

1 Command Purpose

Use the command to set the lldp system name. And recover to default value by using the no form of this command.

2 Command Syntax

lldp system-name *SYSTEM_NAME*

no lldp system-name

Parameter	Parameter Description	Parameter Value
SYSTEM_NAME	SYSTEM NAME	The first character should be a-z or A-Z or 0-9, character only can be 0-9A-Za-z.-_ and the max len is 64

Copyright © 2023 Garland Technology, LLC. All rights reserved.

3 Command Mode

Global Configuration

4 Default

Defaul value is the value of hostname

5 Usage

None

6 Examples

The following example shows how to set the lldp system name:

```
Switch# configure terminal
Switch(config)# lldp system-name lldpname
```

The following example shows how to recover the lldp system name to default value:

```
Switch# configure terminal
Switch(config)# no lldp system-name
```

7 Related Commands

show lldp local tlv-info

30.8 lldp system-description

1 Command Purpose

Use the command to set the lldp system description. And recover to default value by using the no form of this command.

2 Command Syntax

lldp system-description *SYSTEM_DESCRIPTION*

no lldp system-description

Parameter	Parameter Description	Parameter Value

Copyright © 2023 Garland Technology, LLC. All rights reserved.

SYSTEM_DESCRIPTION	SYSTEM DESCRIPTION	Length range is 1-255

3 Command Mode

Global Configuration

4 Default

Default value is the system description of “show version” command

5 Usage

None

6 Examples

The following example set the lldp system description:

```
Switch# configure terminal
Switch(config)# lldp system-description string
```

The following example shows how to reset the lldp system description:

```
Switch# configure terminal
Switch(config)# no lldp system-description
```

7 Related Commands

show lldp local tlv-info

30.9 lldp enable

1 Command Purpose

Use the command to set the lldp admin status on interface, txonly, rxonly, txrx. And turn off LLDP on interface by using the no form of this command.

2 Command Syntax

lldp enable (txonly | rxonly | txrx)

no lldp enable

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
txonly	enable packet send	-
txrx	enable packet send and receive	-
rxonly	enable packet receive	-

3 Command Mode

Interface Configuration

4 Default

enable txrx

5 Usage

None

6 Examples

The following example shows how to turn on LLDP on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# lldp enable txrx
```

The following example shows how to turn off LLDP on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no lldp enable
```

7 Related Commands

show lldp local config

Copyright © 2023 Garland Technology, LLC. All rights reserved.

30.10 lldp tlv basic

1 Command Purpose

Use the command to set the lldp basic tlv on interface, management-address, port-description, system-capabilities, system-capabilities, system-description, system-name and all of them. And cancel selection by using the no form of this command.

2 Command Syntax

lldp tlv basic (all | management-address | port-description | system-capabilities | system-description | system-name)

no lldp tlv basic (all | management-address | port-description | system-capabilities | system-description | system-name)

Parameter	Parameter Description	Parameter Value
all	all basic TLV	-
management-address	management-address TLV	-
port-description	port-description TLV	-
system-capabilities	system-capabilities TLV	-
system-description	system-description TLV	-
system-name	system-name TLV	-

3 Command Mode

Interface Configuration

4 Default

All basic tlv have been enabled

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to set the lldp basic tlv on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# lldp tlv basic port-description
Switch(config-if-eth-0-1)# lldp tlv basic all
```

The following example shows how to unset the lldp basic tlv on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no lldp tlv basic port-description
Switch(config-if-eth-0-1)# no lldp tlv basic all
```

7 Related Commands

show lldp local config

30.11 lldp tlv med

1 Command Purpose

Use the command to set the lldp med tlv inventory on interface. And cancel selection by using the no form of this command.

2 Command Syntax

lldp tlv med (inventory)

Parameter	Parameter Description	Parameter Value
inventory	select Inventory TLV	-

3 Command Mode

Interface Configuration

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

Inventory MED TLV have been enabled

5 Usage

None

6 Examples

The following example shows how to set the lldp med tlv on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# lldp tlv med inventory
```

The following example shows how to unset the lldp med tlv on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no lldp tlv med inventory
```

7 Related Commands

show lldp local config

30.12 lldp tlv 8023-org-specific

1 Command Purpose

Use the command to set the lldp 8023-org-specific tlv on interface, mac-phy-cfg, max-frame-size, link-aggregation and all of them. And cancel selection by using the no form of this command.

2 Command Syntax

lldp tlv 8023-org-specific (all | mac-phy-cfg | max-frame-size | link-aggregation)

no lldp tlv 8023-org-specific (all | mac-phy-cfg | max-frame-size | link-aggregation)

Parameter	Parameter Description	Parameter Value
all	select all IEEE 802.3 TLV	-

Copyright © 2023 Garland Technology, LLC. All rights reserved.

mac-phy-cfg	select MAC/PHY Configuration/Status TLV	-
max-frame-size	select Maximum Frame Size TLV	-
link-aggregation	select Link Aggregation TLV	-

3 Command Mode

Interface Configuration

4 Default

All IEEE 802.3 tlv have been enabled

5 Usage

None

6 Examples

The following example shows how to set the lldp 8023-org-specific tlv on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# lldp tlv 8023-org-specific mac-phy-cfg
Switch(config-if-eth-0-1)# lldp tlv 8023-org-specific all
```

The following example shows how to unset the lldp 8023-org-specific tlv on interface:

```
Switch# configure terminal
Switch(config)# interface eth-0-1
Switch(config-if-eth-0-1)# no lldp tlv 8023-org-specific mac-phy-cfg
Switch(config-if-eth-0-1)# no lldp tlv 8023-org-specific all
```

7 Related Commands

show lldp local config

Copyright © 2023 Garland Technology, LLC. All rights reserved.

30.13 show lldp local config

1 Command Purpose

Use the show lldp local config privileged EXEC command to display the global time information and lldp enable or not.

Use the show lldp local config interface ethx privileged EXEC command to display the interface LLDP admin status and TVL information.

2 Command Syntax

show lldp local config (interface *IFNAME*)

Parameter	Parameter Description	Parameter Value
IFNAME	Interface name	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display the global time information and lldp enable or disable:

```
Switch# show lldp local config

LLDP global configuration:
-------------------------+--------------------
LLDP function global enabled: YES
LLDP TxHold              : 4
LLDP TxInterval          : 10s
LLDP ReinitDelay         : 2s
LLDP TxDelay             : 2s

switch# show lldp local config interface eth-0-1
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
LLDP configuration on interface eth-0-1:
------------------------+-------------------
LLDP admin status        : TXRX
Basic optional TLV Enabled:
    Port Description TLV
    System Name TLV
    System Description TLV
    System Capabilities TLV
    Management Address TLV

IEEE 802.3 TLV Enabled:
    MAC/PHY Configuration/Status TLV
    Link Aggregation TLV
    Maximum Frame Size TLV

LLDP-MED TLV Enabled:
    Med Capabilities TLV
    Inventory TLV
```

7 Related Commands

None

30.14 show lldp local tlv-info

1 Command Purpose

Use the show lldp local tlv-info privileged EXEC command to display the global tvl information.

Use the show lldp local tlv-info interface ethx privileged EXEC command to display the port tvl information.

2 Command Syntax

show lldp local tlv-info (interface *IFNAMEE*)

Parameter	Parameter Description	Parameter Value
IFNAME	Interface name	-

3 Command Mode

Privileged EXEC

4 Default

None

Copyright © 2023 Garland Technology, LLC. All rights reserved.

5 Usage

None

6 Examples

The following example shows how to display the global tvl information:

```
Switch# show lldp local tlv-info

LLDP global TLV information:
-------------------------+-------------------
System Name               : switch

System Description        : XXXXX , XXXXX, XXXXX, Vendor information

System Capabilities       :
    Other     :  Enabled

Configured Management IP Address:

LLDP MED Inventory Information:
  Hardware Rivision       : XXXXX
  Firmware Rivision       : 1.0
  Software Rivision       : 3.0.13.4
  Serial Number           : XXXXX
  Manufacturer Name       : Vendor information
  Model Name              : XXXXX

switch# show lldp local tlv-info interface eth-0-1
LLDP TLV information on interface eth-0-1:
-------------------------+-------------------
Link Aggregation status   : Supported

MAC/PHY Configuration/Status:
AutoNego Support          : Supported, Enabled
AutoNego Capability       : 0
Operational MAU Type      : 0

Maximum Frame Size        : 16127
```

7 Related Commands

None

30.15 show lldp neighbor

1 Command Purpose

Use the show lldp neighbor privileged EXEC command to display all the information of remote device.

Use the show lldp neighbor brief privileged EXEC command to display the brief information of remote device.

Copyright © 2023 Garland Technology, LLC. All rights reserved.

2 Command Syntax

show lldp neighbor (brief |) (interface *IFNAMEE*)

Parameter	Parameter Description	Parameter Value
IFNAMEE	Interface name	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to lldp neighbor information:

```
Switch# show lldp neighbor

Remote LLDP Information of port eth-0-1
==========================================================================
Neighbor Index : 1
Basic Information
    Chassis Info:
        Chassis ID type      : Mac address
        Chassis ID           : 001E.0820.6665

    Port Info:
        Port ID type         : Interface Name
        Port ID              : eth-0-1

    Time To Live:
        TTL                  : 40
        ExpireTime           : 33

    Port Description         : eth-0-1
    System Name              : bianzh
    System Description       : XXXXX, XXXXX, XXXXX, Vendor information
    System Capabilities:
        Other                : Enabled

    Management info:
        Management Address Type  : IPv4
        Management Address       : 10.10.39.157

IEEE 802.3
```


Copyright © 2023 Garland Technology, LLC. All rights reserved.

```
    Link Aggregation:
        Link Aggregation Capability : Support
        Link Aggregation Status     : Disabled
        Link Aggregation Port ID    : Unknown

    MAC/PHY Configuration/Status:
        AutoNego Support     : Support, Enabled
        AutoNego Capability  : Unknown
        Operational MAU Type : Unknown - Unknown

    Maximum Frame Size       : 16127

LLDP MED Information
    Med capabilities:
        LLDP-MED Capabiliies
        Inventory

    Inventory Information:
        Hardware Rivision        : XXXXX
        Firmware Rivision        : 1.0
        Software Rivision        : 3.0.13.4
        Serial Number            : XXXXX
        Manufacturer Name        : Vendor information
        Model Name               : XXXXX

switch# show lldp neighbor brief
Local Port               : eth-0-1
ChassisID                : 001E.0820.6665
Remote Port              : eth-0-1
HoldTime                 : 40
ExpireTime               : 27
System Name              : switch
```

7 Related Commands

None

30.16 show lldp statistics

1 Command Purpose

Use the show lldp statistics privileged EXEC command to display the frames.

2 Command Syntax

show lldp statistics (interface *IFNAMEE*)

Parameter	Parameter Description	Parameter Value
IFNAME	Interface Name	-

3 Command Mode

Privileged EXEC

Copyright © 2023 Garland Technology, LLC. All rights reserved.

4 Default

None

5 Usage

None

6 Examples

The following example shows how to display lldp statistics:

```
Switch# show lldp statistics


-------------------------+-------------------
LLDP Port statistics for : eth-0-1
Frames Transmitted       : 10
Frames Aged              : 0
Frames Discarded         : 0
Frames with Error        : 0
Frames received          : 0
TLVs Discarded           : 0
TLVs Unrecognized        : 0
Switch# show lldp statistics interface eth-0-1
LLDP statistics information:
-------------------------+-------------------
LLDP Port statistics for : eth-0-1
Frames Transmitted       : 10
Frames Aged              : 0
Frames Discarded         : 0
Frames with Error        : 0
Frames received          : 0
TLVs Discarded           : 0
TLVs Unrecognized        : 0
```

7 Related Commands

None

30.17 clear lldp statistics

1 Command Purpose

Use the clear lldp statistics privileged EXEC command to remove all the frames transmitted or received.

2 Command Syntax

clear lldp statistics (interface *IFNAMEE*)

Copyright © 2023 Garland Technology, LLC. All rights reserved.

Parameter	Parameter Description	Parameter Value
IFNAME	Interface Name	-

3 Command Mode

Privileged EXEC

4 Default

None

5 Usage

None

6 Examples

The following example shows how to clear lldp statistics:

```
Switch# clear lldp statistics
Switch# clear lldp statistics interface eth-0-1
```

7 Related Commands

None