

## PB100G24AC Ver 2.0.11 Quick Start Guide

1. Connect serial port to unit with the included serial cable. Serial parameters are as follows:
  - baud rate: 115200
  - parity: N
  - data bits: 8
  - stop bits: 1
2. After the PB100G24AC is finished booting, set the management IP address:  
Switch> enable
3. Setting up the Ethernet management port: (the default management ip is 10.10.10.1)
  - Switch# configure terminal
  - Switch(config)# management ip address 192.168.1.31/24
4. Go to Firefox or Chrome and type in the ip address and see the following screen:



Login to the system using **admin/gtadmin1**

**For questions, please contact Garland Technical Support at:**  
8 AM – 9 PM (CST) Monday – Friday (except for observed US Holidays)  
+1.716.242.8500 support@garlandtechnology.com