



See every bit, byte, and packet<sup>®</sup>

**EdgeLens Inline Security**

**Packet Broker**

**INT40G2XX44 | 1.19.5**

# User Manual

<b>Introduction</b>	<b>4</b>
Part Numbers	4
Additional Specifications	4
<b>1 Dashboard</b>	<b>5</b>
1.1 System	5
1.2 Bypass Taps	5
1.3 Packet Broker	5
<b>2 System</b>	<b>6</b>
2.1 System Info	7
2.2 General	7
2.3 Admin	7
2.3.1 Groups	8
2.3.2 Users	8
2.3.3 Authentication	9
2.4 Network Settings	10
2.5 Date & Time	11
2.6 Syslog	11
2.7 SNMP	12
2.8 Export Configuration	12
2.9 Import Configuration	13
2.10 Software Upgrade	13
2.11 Reboot	14
<b>3 Bypass Taps</b>	<b>15</b>
3.1 Primary-Secondary Tap	16
3.1.1 Bypass Tap Name	16
3.1.2 Heartbeat Settings	16
3.1.3 Taps Settings	17
<b>4 Packet Broker</b>	<b>20</b>
4.1 Filter Template	21
4.2 Load Balancing Policy	22
4.2.1 Load Balancing Group	22
4.3 Config Maps	23
4.3.1 Config Maps	24
4.3.2 Ingress	24
4.3.3 Filter	25

4.3.4 Egress	25
4.3.5 Config Map Save	26
4.3.6 Modify a Config Map	26
4.3.7 Config Map Statistics	27
4.3.8 Delete Config Map	27
4.3.9 Config Map Priority	28
4.3.9.1 Method 1	28
4.3.9.2 Method 2	28
4.3.10 Enable and Disable Config Map	29
4.3.10.1 Disable Config Map	29
4.3.10.2 Enable Config Map	29
<b>5 Port Info</b>	<b>30</b>
5.1 Port Configuration	31
5.1.1 Port Description	31
5.1.2 Set Speed	31
5.1.3 Mode	31
5.2 Port Statistics	31

Copyright © 2022 Garland Technology, LLC. All rights reserved.

No part of this document may be reproduced in any form or by any means without prior written permission of GarlandTechnology, LLC.

The Garland Technology trademarks, service marks ("Marks") and other Garland Technology trademarks are the property of Garland Technology, LLC. PacketMAX Series products of marks are trademarks or registered trademarks of Garland Technology, LLC. You are not permitted to use these Marks without the prior written consent of Garland Technology.

All other trademarks and trade names mentioned in this document are the property of their respective holders.

#### Notice

The purchased products, services and features are stipulated by the contract made between Garland Technology and the customer. All or part of the products, services, and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees, or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

## Introduction

Garland's innovative EdgeLens® is a bypass TAP, network packet broker hybrid, purpose-built to give you the power of a bypass TAP to manage the availability of inline tools, instrument high availability (HA) deployments, and tool chaining. As well as network TAP packet visibility for out-of-band monitoring tools like threat detection, storage, and performance monitoring with packet broker functionality like traffic aggregation, filtering, and load balancing.

Inline Security Packet Brokers like the EdgeLens "Inline lifecycle management" allows you to sandbox new tool deployments, manage updates, install patches, perform maintenance or troubleshooting and validate out-of-band, without impacting the network.

## Part Numbers

INT40G2SR44

INT40G2LR44

## Additional Specifications

Max. system throughput:

Support for: SFP( SX, LX and TX) and SFP+ (SR, LR, ER)

Operating Temp: 0 to 40° C or 32 to 104° F

Operating Humidity: 5 to 95%

Dimensions: 21.09" L x 1.719" H x 17.32" W

(535.686mm L x 43.6626 mm H x 439.928mm W)

Airflow: 100 IF/m

(2) AC Power Supplies Included




## 1 Dashboard

The Dashboard of the INT40G2XX44 is divided into 3 sections: System, Bypass Taps, and Packet Broker

### 1.1 System


The System section consists of the following. These indications are consistent regardless of the tap mode and packet broker configuration.



- |                    |                    |
|--------------------|--------------------|
| PS2                | Power Supply 2 LED |
| PS1                | Power Supply 1 LED |
| SYS                | System LED         |
| Ethernet Interface | Upper Left LED     |
| Serial Interface   | Lower Left LED     |

### 1.2 Bypass Taps

The Bypass Taps of the Dashboard consists of the following.



#### Tap 1

- Port 1 (Network)
- Port 2 (Network)
- Port 37 (Primary Inline Appliance)
- Port 38 (Primary Inline Appliance)
- Port 39 (Secondary Inline Appliance)
- Port 40 (Secondary Inline Appliance)
- L/A1 – L/A2
- BP
- L/A3 – L/A4
- BP


#### Tap 2

- Port 3 (Network)
- Port 4 (Network)
- Port 41 (Primary Inline Appliance)
- Port 42 (Primary Inline Appliance)
- Port 43 (Secondary Inline Appliance)
- Port 44 (Secondary Inline Appliance)

- |                                      |
|--------------------------------------|
| Tap 1 Network Port Link/Activity LED |
| Tap 1 Bypass LED                     |
| Tap 2 Network Port Link/Activity LED |
| Tap 2 Bypass LED                     |

### 1.3 Packet Broker

The Packet Broker of the Dashboard consists of the following.




- |                                   |                   |
|-----------------------------------|-------------------|
| Port 5 thru 35 (odd) Up Arrows    | Link/Activity LED |
| Port 6 thru 36 (even) Down Arrows | Link/Activity LED |

## 2 System

The following configuration options may be displayed, modified, enabled, or disabled under the System panel.

- |                  |                      |
|------------------|----------------------|
| System Info      | SNMP                 |
| General          | Export Configuration |
| Admin            | Import Configuration |
| Network Settings | Software Upgrade     |
| Date & Time      | Reboot               |
| Syslog           |                      |



1. Select System on the Dashboard Menu bar.



The System panel will be displayed. The system configuration options will be displayed on the left side of the panel.

## 2.1 System Info

The System Information panel displays the following.

- Chassis Name
- Chassis Model
- Chassis Serial Number
- MAC Address
- Software Version

## 2.2 General

The following configuration options may be displayed or modified.

- Chassis Name
- Key Press Timeout

1. Select General.

The panel will display the current configuration.

2. Select Edit Configuration.
3. Enable, disable or modify the desired options.
4. Select Save to save updates.
5. Select Cancel to return to the General System Settings panel.

## 2.3 Admin

The following configuration options may be displayed, modified, enabled, or disabled.

- Groups
- Users
- Local Authentication
- TACACS Authentication

1. Select Admin.

The panel will display the current configuration.

The default user is “admin/gtadmin1”. The “admin” user privileges are defined by the default group “admin”. Changes to the default user “admin” and group “admin” are allowed. However, the “admin” user or group “admin” may not be deleted.



## 2.3.1 Groups

The group defines the authorization for a user or group of users. A group may be used for local or TACACS authorization. In Use “true” means that there is at least one local user assigned to the group. If a group is used by TACACS, the In Use will indicate “false”.

1. Select Groups + to create a new group.

The Create New Group panel will be displayed.

2. Enter the Group Name.
3. Select the privileges for the new group.
4. Select Save to save updates.
5. Select Cancel to return to the Admin Settings panel.

The new group will be displayed on the Admin Settings panel.

6. Edit the group privileges by selecting the pencil.
7. Deleted the group by selecting the Red X. If a group has at least one local user assigned it cannot be deleted.

## 2.3.2 Users

Users displayed on the Admin Settings panel are for local authentication only.

1. Select Users + to create a new user.

The Create New User panel will be displayed.

2. Enter the Username.
3. Enter the Password.
4. Select the group the user will be assigned.
5. Select Save to save updates.
6. Select Cancel to return to the Admin Settings panel.

The new local user will be displayed on the Admin Settings panel.

7. Edit the username, password, or assigned group by selecting the pencil.
8. Delete the local user by selecting the Red X.

## 2.3.3 Authentication

Authentication allows for two options, Local or TACACS. Local or TACACS Authentication may be enabled or disabled independently and at least one option must be enabled.

### 1. Select Authentication Settings.

The Authentication Settings panel will be displayed. Local Authentication is enabled by default.

### 2. Select TACACS Authentication to enable.

### 3. Enter the TACACS Server IP Address.

### 4. Enter the TACACS Server Secret Word, optional.

### 5. Select Save to save updates.

### 6. Select Cancel to return the Admin Settings panel.

### 7. TACACS Test

This option may be used to verify the authentication of a TACACS user and password. The TACACS Test option will be active only if TACACS Authentication has been enabled.

The TACACS Test panel will appear.

#### 7.1 Enter the Username.

#### 7.2 Enter the Password.

#### 7.3 Select Test.

The GUI will display the results of the authentication of the user and the password entered.

### 8. TACACS Ping

This option may be used to verify the network connectivity from the unit to the TACACS server. The TACACS Ping option will be active only if TACACS authentication has been enabled.

The GUI will display the results of the ping test.

## 2.4 Network Settings

The following configuration options may be displayed, modified, enabled, or disabled. Any change made to any network, setting option could cause network connectivity disruption for about 60 seconds.

DHCP	DNS 1
IP Address	DNS 2
Mask	SSL Certificate Loaded
Gateway	Using Uploaded SSL Certificate

1. Select Network Settings. The Network Settings panel will be displayed with the current configuration.
2. Select Edit Settings. The Network Settings panel will appear.
3. Enable, disable or modify the desired options.
4. Enable or disable Using Uploaded SSL Certificate.

This option may be enabled if an SSL cert.pem and key.pem files have been uploaded to the unit using the Add SSL Certificate option on the Network Settings panel.

5. Select Save to save updates.
6. Select Cancel to return the Network Settings panel.
7. Add SSL Certificate.

Uploading a custom SSL certificate involves two files. The cert.pem file and key.pem file. The unit will consider these files during the upload. If the files do not match or one of the files are corrupted, the unit will abort the upload. The Result Messages will be displayed in the GUI. Adding an SSL certificate will cause the GUI to restart. This could take up to 90 seconds. It may be required to refresh or restart the web browser.

8. Select Add SSL Certificate.

The Select Certificate and Select Key File panel will appear.

9. Select Choose File for Select Certificate.
10. Select the desired cert.pem file.
11. Select Open.
12. Select the Choose File for Select Key File.
13. Select the desired key.pem file.
14. Select Open.
15. Select Upload.
16. Select Restart Import to select a different cert.pem or key.pem file.
17. Select Cancel to return to the Network Settings panel

## 2.5 Date & Time

The following configuration options may be displayed, modified, enabled, or disabled.

Timezone	Time
UTC	Date
NTP IP Address	
NTP Pool	

1. Select Date & Time.

The Date & Time Settings panel will be displayed with the current configuration.

2. Select Edit Settings.

The Date & Time Settings panel will be displayed.

3. Enable, disable or modify the desired options.
4. Select Save to save updates.
5. Select Cancel to return the Date & Time Settings panel.

## 2.6 Syslog

The following configuration options may be displayed, modified, enabled, or disabled.

Unit ID	Syslog Server IP Address
Protocol	Protocol Port Number

1. Select Syslog.

The Syslog Configuration panel will be displayed with the current configuration.

2. Select Edit Settings.
3. Enable Syslog Config.
4. Enable, disable or modify the desired options.
5. Select Save to save updates.
6. Select Cancel to return the Syslog Configuration panel.
7. Sys Log Test may be selected to send a test message to the server.

## 2.7 SNMP

The following configuration options may be displayed, modified, enabled, or disabled.

V2 Read/Write	V2 read Only	V3 MD5/DES	V3 SHA/AES
Access Port	Access Port	Access Port	Access Port
Trap Port	Trap Port	Trap Port	Trap Port
Trap IP Address	Trap IP Address	Trap IP Address	
Community Password	Community Password	User	User
		Auth Password	Auth Password
		Priv Password	Priv Password

### 1. Select SNMP.

The SNMP Configuration panel will be displayed with the current configuration.

### 2. Select Edit Configuration.

The SNMP Configuration panel will be displayed.

### 3. Select Enable SNMP Config.

### 4. Enable, disable or modify the desired options.

### 5. Select Save to save updates.

### 6. Select Cancel to return the Syslog Configuration panel.

### 7. SNMP Test may be selected to send a test trap to the server.

## 2.8 Export Configuration

This option creates a configuration file (exportCfg.json) that may be used to recover a unit. The exportCfg.json file may be renamed if desired. The exportCfg.json file does not contain Usernames, Passwords, Groups, or Network Settings.

### 1. Select Export Configuration.

The Export Configuration panel will be displayed.

### 2. Select Export.

The exportCfg.json file will be downloaded to the default download destination of the browser.

## 2.9 Import Configuration

This option allows a previously created configuration file (exportCfg.json) to be uploaded to the unit. The Chassis Model is the only option that is considered and must match, otherwise, the unit will reject the exportCfg.json file.

1. Select Import Configuration.

The Import Configuration panel will be displayed.

2. Select Choose File.
3. Select the desired exportCfg.json file.
4. Select Open.
5. Select Upload.

The unit will automatically verify the selected exportCfg.json file.

6. Select Configure.

The unit will import and load the exportCfg.json. An “import done” message will be displayed when complete. A reboot is not required.

## 2.10 Software Upgrade

This option allows the unit’s firmware to be upgraded. The existing unit configuration will not be affected and maintained during the upgrade. It may be required to refresh or restart the web browser after the firmware upgrade is complete.

1. Select Software Upgrade.

The Update Firmware panel will be displayed.

2. Select Choose File.
3. Select the desired firmware file.
4. Select Open.

The new firmware file will be displayed.

5. Select Upload.

The unit will validate the firmware file.

The unit will install the firmware file.

The unit will reboot.

6. After the upgrade is complete. The GUI will refresh to the Login panel.

## 2.11 Reboot

This option allows the unit to be rebooted. The traffic will be affected for up to 3 minutes.

### 1. Select Reboot.

The Reboot Device panel will be displayed.

### 2. Select Reboot.

The unit will present an “Are you sure?” message.

### 3. Select OK.

A “rebooting” message will be displayed.

A “Session timed out. Go to Login screen” message will be displayed.

### 4. Select Go.

The Login panel will be displayed.






## 3.1 Primary-Secondary Tap

The network, primary inline appliance and secondary inline appliance ports are defined by the system for each tap. The network ports are typically connected to network devices such as a server or router. The primary inline appliance ports are typically connected to a primary inline appliance or tool to monitor the network traffic. The secondary inline appliance ports are typically connected to a secondary inline appliance or tool to monitor the network traffic. The network traffic is sent to the primary inline appliance or the secondary inline appliance. Heartbeat packets are transmitted bidirectionally from the primary inline appliance ports on the tap through the primary inline appliance or tool to monitor the health of the device. Likewise, heartbeat packets are transmitted bidirectionally from the secondary inline appliance ports on the tap through the secondary inline appliance or tool to monitor the health of the device.

Figure 1 Primary-Secondary Tap



### 3.1.1 Bypass Tap Name

1. Select the Pencil icon for the desired tap.

The Tap Name panel will be displayed.

2. Enter the name.
3. Remove the name by placing the cursor in the name panel, backspace or delete the current name.
4. Select the Check to save updates.
5. Select Cancel to return the Bypass Taps panel.

### 3.1.2 Heartbeat Settings

The following configuration options may be displayed or modified.

No. Of Lost HB Packets  
Heartbeats per Second

1. Select Settings on the Bypass Taps panel.

The Configure Heartbeat Settings panel will be displayed with the current configuration.

2. Enter the No. Of Lost HB Packets. Default is 10.

This is the number of heartbeats that must be lost on the inline appliance ports before any tap will switch to bypass.

3. Enter the Heartbeats per Second. Default is 10.

This is the number of heartbeats per second applied to the inline appliance ports for all taps.

4. Select Save to save updates.

5. Select Cancel to return the Bypass Taps panel.

### 3.1.3 Taps Settings

The following configuration options may be displayed, modified, enabled, or disabled.

Tap Mode	Reverse Bypass
Fail Mode	Revertive
LFP	Coupled

1. Edit the Tap Settings, by placing the cursor on any tap and double-press the left mouse button.

The Tap panel will be displayed.

2. Select Edit Tap Settings.

The Configure Inline Appliance panel will be displayed.

3. Select the Tap Mode.

**Active** Allows the tap to automatically switch from inline to bypass if an issue occurs with the primary inline appliance port(s) and secondary inline appliance port(s), loss of link or heartbeats. The default switching action from inline to bypass is defined by the system as, from the primary inline appliance, to the secondary inline appliance, to bypass. The default switching action from bypass to inline is defined by the system as, from bypass, to the secondary inline appliance. Switching from the secondary inline appliance to the primary inline appliance may be accomplished via two methods. Select the Switch to Primary option or enable Revertive. If revertive is enabled, then the system will switch from bypass to the primary inline appliance if it is recovered first.

Figure 2 Primary-Secondary Tap (Primary Inline)





Figure 3 Primary-Secondary Tap (Secondary Inline)



**Force Bypass** If selected, the tap will switch the traffic between the network ports with no regard for the primary inline appliance or the secondary inline appliance port(s), link or heartbeats. Typically used during maintenance activities.

Figure 4 Primary-Secondary Tap (Bypass)





Figure 5 Primary-Secondary Tap (Force Bypass)



#### 4. Select the Fail Mode.

- Open** If selected and power is lost to the unit. The traffic will switch between the network ports.
- Closed** If selected and power is lost to the unit. The traffic will go down.

**5. LFP** If enabled and link is lost on one of the network ports. The TX will be disabled on the other network port. The RX for both network ports remain on.


Figure 6 Primary-Secondary Tap (LFP)



## 6. Reverse Bypass

If enabled and the primary inline appliance and the secondary inline appliance port(s) fail, loss of link or heartbeats. The TX will be disabled on both of the network ports. The RX for both network ports remain on.

Figure 7 Primary-Secondary Tap (Reverse Bypass)



## 7. Revertive

If enabled and the primary inline appliance port(s) fail, loss of link or heartbeats, the system will switch to the secondary inline appliance. When the issue with the primary inline appliance is resolved, has link and heartbeats. The traffic will automatically revert back to the primary inline appliance. This option also affects the switching from bypass to inline. If disabled, the system is designed to switch from bypass to the secondary inline appliance. If the primary inline appliance restores first, has link and heartbeats, a manual switch to the primary inline appliance is required. If enabled and the primary inline appliance restores first, the system will switch from bypass to the primary inline appliance.

## 8. Taps Coupled

If enabled all switching functionality supported by Tap 1 and Tap 2 are coupled together. Taps coupled will couple the revertive option for both Taps. If taps coupled is enabled or disabled the other tap options can not be selected until the accept and save are selected. Then the other tap options will become active.

9. Select Accept to save updates. Save must additionally be selected on the Tap panel.

10. Select Cancel to return the Tap panel.

11. Select Back to Primary to manually switch the traffic from the secondary inline appliance to the primary inline appliance. This function is independent for each tap unless they are coupled. Then selecting Back to Primary on either tap, will cause both taps to switch.

12. Select Save to save updates.

13. Select Cancel to return the Bypass Taps panel.

## 4 Packet Broker


The following configuration options may be displayed, modified, enabled or disabled under the Packet Broker panel.

Configuration Maps  
Filter Templates

Load Balance Policy  
Load Balance Groups



1. Select Packet Broker on the Dashboard menu bar.



The Packet Broker Configurations panel will be displayed.

## 4.1 Filter Template

Filter templates may be created as a pass-all, pass-by, or deny-by. Pass by or deny by templates may include multiple matching options to filter traffic. The options are considered by the system as (and) options. Thus, for traffic to pass it must match all defined options. Once a template is created it will appear on the Create Config Map panel and may be used to create an ingress filter. Template options may be modified when applied to a config map. Any option modification made will not change the original template. It is advisable to rename a filter applied to a config map if the original template options were modified.

1. Select Filter Templates on the Packet Broker Configurations panel. The Filter Templates panel will be displayed.
2. Select Create Template. The Create New Filter Template panel will be displayed.
3. Enter the template name. If no name is entered the system will automatically apply a name as follows, tmplt, tmplt(2), tmplt(3), etc.
4. Enter the description, optional.
5. Select the Template Type, Pass All, Pass By or Deny By.
6. If pass by or deny by was selected in Step 5, the options will be displayed as follows.

- Source MAC Address / Source MAC Mask
- Destination MAC Address / Destination MAC Mask
- Ether Type
- Source IP Address / Source IP Mask
- Destination IP Address / Destination IP Mask
- Inner VLAN ID
- Outer VLAN ID
- DSCP
- IP Protocol
- L4 Source Port or Range
- L4 Destination Port or Range

7. Select Save Template once all desired option modifications have been completed.
8. The new filter template will appear on the Filter Templates panel.
9. The filter template may be modified by selecting the template name.
10. The filter template may be deleted by selecting the red X.

## 4.2 Load Balancing Policy

The load balancing policy determines the hashing applied to all load balancing groups, taps in the load balance mode and the ATLB2 Chained mode. The load balancing policy options are as follows and may be applied as L3 and/or L4 or L2.

Ipv4 Source	MAC Source
Ipv4 Destination	MAC Destination
L4 Source Port	L4 Destination Port

1. Select Load Balancing Policy on the Packet Broker Configurations panel.

The Load Balancing Policy panel will be displayed.

2. Select the desired load balancing policy options.
3. Select Save to save updates.
4. Select Cancel to disregard changes.

### 4.2.1 Load Balancing Group

Load balancing groups are used as an egress option on config maps. The traffic applied to the ports assigned to a load balancing group will follow the hashing per the load balancing policy. Ports may be added or removed from load balancing groups as desired. However, if ports are added or removed from a load balancing group that is used in a config map, the config map load balancing group will be also modified, the reverse is also applied. Previously created load balancing groups will appear on the Create Config Map panel.

1. Select Load Balancing Groups on the Packet Broker Configurations panel.

The Load Balancing Groups panel will be displayed.

2. Select Create Group.

The Create New Load Balance Group panel will be displayed.

3. Enter the name. If no name is entered the system will automatically apply a name as follows, lbg, lbg(2), lbg(3), etc.
4. Enter the description, optional.
5. Add ports by placing the cursor on the desired port. Select with the left mouse button. Drag the port to the New L.B. Group panel and release. Repeat for all desired ports. Ports may be added in any combination.
6. Remove a port by placing the cursor on the port in the New L.B. Group panel and double press the left mouse button.
7. Select Save to save updates.
8. Select Cancel to return to the Load Balancing Groups panel.


The load balancing group will be displayed on the Load Balancing Groups panel. The assigned ports will also be displayed.

9. Edit the load balancing group by selecting the Edit for the desired group.
10. Deleted the load balancing group group by selecting the red X. Load balancing groups may not be deleted if used on a config map.

## 4.3 Config Maps

Config maps are unidirectional connections between an ingress port to an egress port(s).

1. Select Create Config Map on the Packet Broker Configurations panel.



The Create Config Map panel will be displayed. Any previously created filter templates will be displayed along with the new options. Any port shaded gray can be used for a config map, any port shaded black may not be used.


2. Select the Name pencil icon to apply a name, optional. If no name is entered the system will automatically apply a name to the config maps as follows, map, map(1), map(2), etc.
3. Place the cursor in the Name panel and enter the name.
4. Select the Check to apply.
5. Select the Description pencil to apply a description, optional.
6. Place the cursor in the Description panel and enter the description, optional.
7. Select the Check to apply updates.



## 4.3.1 Config Maps

Config maps are unidirectional connections between an ingress port to an egress port(s).

1. Select Create Config Map on the Packet Broker Configurations panel.



The Create Config Map panel will be displayed. Any previously created filter templates will be displayed along with the new options. Any port shaded gray can be used for a config map, any port shaded black may not be used.

2. Select the Name pencil icon to apply a name, optional. If no name is entered the system will automatically apply a name to the config maps as follows, map, map(1), map(2), etc.

3. Place the cursor in the Name panel and enter the name.

4. Select the Check to apply.

5. Select the Description pencil to apply a description, optional.


6. Place the cursor in the Description panel and enter the description, optional.

7. Select the Check to apply updates.

## 4.3.2 Ingress

1. Add an ingress port(s) 1 and/or 2 by placing the cursor on the desired port. Select with the left mouse button. Drag the port to the Ingress panel and release. Ports may be added in any combination. If ports 1 and 2 are added, then the traffic from the ports will be aggregated.

Figure 2 Ingress



2. Remove a port by selecting the red X.

### 4.3.3 Filter

1. Add filters by placing the cursor on the desired filter template. A previously created filter template or the new filter template option may be selected. Select with the left mouse button. Drag the filter template to the Filter panel and release it. The filter template will become an actual filter once the config map is saved. Filters may be added in any combination. If multiple filters are added, then the top filter is the highest priority. The filters are considered from top to bottom. A filter may be selected and moved up or down depending on priority preference.

Figure 3 Filter





Figure 4 Filter System Considerations



2. Filter templates may be modified by selecting the green filter icon for the desired template.

The Edit Filter panel will be displayed.

Any option modification made will not change the original template. It is advisable to rename a filter if the original filter template options were modified.

3. Enter the filter name, optional. If no name is entered the system will automatically apply a name to the filter as follows, iFlt, iFlt(2), iFlt(3), etc.


4. Select Accept once all desired options have been modified.

5. Remove a Filter Template by selecting the red X.

### 4.3.4 Egress

1. Add an egress port(s) by placing the cursor on the desired port. Select with the left mouse button. Drag the port to the Egress panel and release. Ports may be added in any combination. If multiple ports are added, then 100% of the traffic will be sent to each port.

Figure 5 Egress Port(s)



2. Remove a port by selecting the red X.


## 4.3.5 Config Map Save

1. Select Save to save the current configuration.

The “Save this configuration? (May take a few seconds.)” panel will be displayed.


2. Select OK to save the Config Map.

3. Select Cancel to disregard.



## 4.3.6 Modify a Config Map


1. Modify a config map by selecting the Edit icon. Modifications may be made using the create sections previously discussed.



## 4.3.7 Config Map Statistics

Config map statistics are displayed in the filter match column for each config map. The number displayed represents all packets that have passed through the config map.


1. Select Refresh to refresh the config map statistics.
2. Select Clear Counters to clear and refresh the config map statistics.
3. Select the View Counts icon to display individual statistics.



4. Select Refresh Counts to refresh the statistics.
5. Select Clear Counts to clear and refresh the statistics.
9. Select Close to return to the Packet Broker Configurations panel.

## 4.3.8 Delete Config Map

1. Select the Delete in the Delete column for the desired config map(s).



2. The Select All option may be selected to delete all config maps.
3. Select Delete Selected.

## 4.3.9 Config Map Priority

The config map priority needs to be considered when the same ingress port(s) is used in multiple config maps to send traffic to multiple egress ports. In this case, the config map with the highest priority will be considered first. In the following example, there are three config maps with ingress port 1. The Traffic\_A config map is the highest priority 1, the Traffic\_B config map is the next priority 2 and finally, the Traffic\_C is the next priority 3.





Figure 7 Config Map System Considerations



The Priority of a config map may be changed to a higher or lower value using two methods.

### 4.3.9.1 Method 1

1. Select the up or down arrow for the config map.
2. Select Save to save updates.

### 4.3.9.2 Method 2

1. Select Set.

The Set Priority panel will be displayed.

2. Enter the priority in the Set New Priority panel.
3. Select Set to accept the priority value.
4. Select Cancel to disregard.
5. Select Save to save updates.

## 4.3.10 Enable and Disable Config Map

Config maps may be enabled or disabled as desired. If a config map is enabled, it is in the database and available for traffic. If a config map is disabled, it is in the database and not available for traffic. If the config map has a green check, then it is enabled. If the config map has a red dash, then it is disabled.

The screenshot shows the 'Packet Broker Configurations' page. At the top, there's a 'System Filters Resource' table:

	Max	Used	Available
Filters	500	3	497
Egress Filters	0	0	0

Below this are buttons: Save, Refresh, Clear Counters, Create Config Map, Filter Templates, and Delete Selected.

The main table is as follows:

Enable	Priority	Name	Ingress Ports	Filter Match	Egress Ports	View Counts	Set Priority	Edit	Delete (select all)
<input checked="" type="checkbox"/>	1	Traffic_A	01	0	03 04	↑	^ v Set	✎	<input type="checkbox"/>
<input type="checkbox"/>	2	Traffic_B	01	0	03	↑	^ v Set	✎	<input type="checkbox"/>
<input checked="" type="checkbox"/>	3	Traffic_C	01	0	04	↑	^ v Set	✎	<input type="checkbox"/>

### 4.3.10.1 Disable Config Map

1. Select the green check for the config map in the Enable column.

The green check will change to a red dash.

2. Select Save.

### 4.3.10.2 Enable Config Map

1. Select the red dash for the config map in the Enable column.


The red dash will change to a green check.

2. Select Save.


## 5 Port Info

The following configuration options may be displayed or modified under the Port Info panel.

- |                  |                 |
|------------------|-----------------|
| Port Number      | Mode            |
| Port Description | SFP Data        |
| Link             | Split           |
| Set Speed        | Port Statistics |
| Speed            |                 |



1. Select Port Info on the Dashboard menu bar.



The Port Configuration panel will be displayed.

## 5.1 Port Configuration

The port configuration is displayed by default. The Description, Set Speed and Mode may be modified. All other options are display only. However, they may be updated by selecting Refresh.

### 5.1.1 Port Description

1. Modify the port description by placing the cursor on Port Description for the desired port and press the left mouse button.

The Edit Description panel will be displayed.

2. Place the cursor in the description field and enter the new description.
3. Select Set to save updates.
4. Select Cancel to return to the Port Configuration panel.

### 5.1.2 Set Speed

1. Modify the port speed by selecting the pull down panel for the desired port.
2. Select the desired speed.
3. Select Save to save updates.

### 5.1.3 Mode

1. Modify the port mode by selecting the pull down panel for the desired port.
2. Select the desired mode. The available port modes are Normal, Loopback, Listen Only and Force Link.
3. Select Save to save updates.

## 5.2 Port Statistics

The following statistics may be displayed on the Port Statistics panel.

Port number	Receive Errors	Transmit Errors
Receive Packets	Transmit Packets	
Receive Discards	Transmit Discards	

1. Select Port Statistics on the Port Configuration panel.

The Port Statistics panel will be displayed.

2. Update the statistics by selecting Refresh.
3. Clear and refresh the statistics by selecting Clear.